

OWNER'S MANUAL 2016



TC 125
TC 250

Art. no. 3402058en

DEAR HUSQVARNA MOTORCYCLES CUSTOMER

1

Congratulations on your decision to purchase a Husqvarna motorcycle. You are now the owner of a state-of-the-art sports motorcycle that will give you enormous pleasure if you service and maintain it properly.

We hope you enjoy your new vehicle!

Enter the serial numbers of your vehicle below.

Chassis number (☞ p. 11)	Dealer's stamp
Engine number (☞ p. 11)	

The Owner's Manual contained the latest information for this model series at the time of going to print. Minor differences due to developments in design cannot be ruled out completely.

All specifications are non-binding. Husqvarna Motorcycles GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. Husqvarna Motorcycles accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2015 Husqvarna Motorcycles GmbH, Mattighofen Austria

All rights reserved

Reprinting, including excerpts, and duplication of any kind only with the written consent of the publisher.



ISO 9001(12 100 6061)

Husqvarna Motorcycles applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.

Issued by: TÜV Management Service

REG.NO. 12 100 6061

Husqvarna Motorcycles GmbH
5230 Mattighofen, Austria

This document is valid for the following models:

TC 125 (F2101P0)

TC 250 (F2301P1)



3402058en

07/2015

TABLE OF CONTENTS

2

1	MEANS OF REPRESENTATION.....	5	8.3	Starting off.....	23
1.1	Symbols used.....	5	8.4	Shifting, riding.....	23
1.2	Formats used.....	5	8.5	Braking.....	23
2	SAFETY ADVICE.....	6	8.6	Stopping, parking.....	24
2.1	Use definition - intended use.....	6	8.7	Transport.....	24
2.2	Safety advice.....	6	8.8	Refueling.....	25
2.3	Degrees of risk and symbols.....	6	9	SERVICE SCHEDULE.....	26
2.4	Tampering warning.....	6	9.1	Service schedule.....	26
2.5	Safe operation.....	6	9.2	Service work (as additional order).....	27
2.6	Protective clothing.....	7	10	TUNING THE CHASSIS.....	28
2.7	Work rules.....	7	10.1	Checking the basic chassis setting with the rider's weight.....	28
2.8	Environment.....	7	10.2	Compression damping of the shock absorber ...	28
2.9	Owner's Manual.....	7	10.3	Adjusting the low-speed compression damping of the shock absorber.....	28
3	IMPORTANT NOTES.....	8	10.4	Adjusting the high-speed compression damping of the shock absorber.....	29
3.1	Manufacturer and implied warranty.....	8	10.5	Adjusting the rebound damping of the shock absorber.....	30
3.2	Operating and auxiliary substances.....	8	10.6	Measuring the rear wheel sag unloaded.....	31
3.3	Spare parts, accessories.....	8	10.7	Checking the static sag of the shock absorber.....	31
3.4	Service.....	8	10.8	Checking the riding sag of the shock absorber.....	32
3.5	Figures.....	8	10.9	Adjusting the spring preload of the shock absorber 🏍.....	33
3.6	Customer service.....	8	10.10	Adjusting the riding sag 🏍.....	34
4	VIEW OF VEHICLE.....	9	10.11	Checking the basic setting of the fork.....	34
4.1	View of vehicle, front left (example).....	9	10.12	Adjusting the compression damping of the fork.....	35
4.2	View of vehicle, rear right (example).....	10	10.13	Adjusting the rebound damping of the fork.....	35
5	SERIAL NUMBERS.....	11	10.14	Handlebar position.....	36
5.1	Chassis number.....	11	10.15	Adjusting the handlebar position 🏍.....	36
5.2	Type label.....	11	11	SERVICE WORK ON THE CHASSIS.....	37
5.3	Engine number.....	11	11.1	Raising the motorcycle with a lift stand.....	37
5.4	Fork part number.....	11	11.2	Removing the motorcycle from the lift stand.....	37
5.5	Shock absorber article number.....	11	11.3	Bleeding the fork legs.....	37
6	CONTROLS.....	12	11.4	Cleaning the dust boots of the fork legs.....	37
6.1	Clutch lever.....	12	11.5	Removing the fork protector.....	38
6.2	Hand brake lever.....	12	11.6	Installing the fork protector.....	38
6.3	Throttle grip.....	12	11.7	Removing the fork legs 🏍.....	38
6.4	Kill switch.....	12	11.8	Installing the fork legs 🏍.....	39
6.5	Map-Select switch (TC 250).....	13	11.9	Removing the lower triple clamp 🏍.....	39
6.6	Opening the filler cap.....	13	11.10	Installing the lower triple clamp 🏍.....	40
6.7	Closing the filler cap.....	13	11.11	Checking the play of the steering head bearing.....	42
6.8	Fuel tap.....	14	11.12	Adjusting the play of the steering head bearing 🏍.....	42
6.9	Choke.....	14	11.13	Greasing the steering head bearing 🏍.....	43
6.10	Shift lever.....	14	11.14	Removing the start number plate.....	43
6.11	Kick starter.....	15	11.15	Installing the start number plate.....	43
6.12	Foot brake lever.....	15	11.16	Removing the front fender.....	44
6.13	Plug-in stand.....	15	11.17	Installing the front fender.....	44
7	PREPARING FOR USE.....	16	11.18	Removing the shock absorber 🏍.....	44
7.1	Advice on first use.....	16	11.19	Installing the shock absorber 🏍.....	46
7.2	Running in the engine.....	17	11.20	Removing the seat.....	48
7.3	Preparing the vehicle for difficult riding conditions.....	17	11.21	Mounting the seat.....	49
7.4	Preparing for rides on dry sand.....	17	11.22	Removing the air filter box cover.....	49
7.5	Preparing for rides on wet sand.....	19	11.23	Installing the air filter box cover.....	50
7.6	Preparing for rides on wet and muddy surfaces.....	20	11.24	Removing the air filter 🏍.....	50
7.7	Preparations for riding at high temperatures and low speeds.....	20	11.25	Cleaning the air filter and air filter box 🏍.....	51
7.8	Preparing for rides at low temperature or in snow.....	21			
8	RIDING INSTRUCTIONS.....	22			
8.1	Checks and maintenance work when preparing for use.....	22			
8.2	Starting.....	22			

11.26	Installing the air filter 	51	15	TUNING THE ENGINE	89
11.27	Sealing the air filter box  (TC 250)	52	15.1	Checking the play in the throttle cable	89
11.28	Removing the main silencer	52	15.2	Adjusting the play in the throttle cable 	89
11.29	Installing the main silencer	53	15.3	Carburetor – idle	90
11.30	Changing the glass fiber yarn filling in the main silencer 	53	15.4	Carburetor – adjusting the idle speed 	90
11.31	Removing the right side cover	54	15.5	Emptying the carburetor float chamber 	91
11.32	Installing the right side cover	55	15.6	Ignition curve plug-in connector (TC 125)	92
11.33	Removing the fuel tank 	55	15.7	Changing the ignition timing map	92
11.34	Installing the fuel tank 	57	15.8	Checking the basic position of the shift lever	92
11.35	Checking the chain for dirt	58	15.9	Adjusting the basic position of the shift lever 	93
11.36	Cleaning the chain	58	15.10	Engine characteristic – auxiliary spring (TC 250)	93
11.37	Checking the chain tension	59	15.11	Engine characteristic – setting the auxiliary spring  (TC 250)	93
11.38	Adjusting the chain tension	59	16	SERVICE WORK ON THE ENGINE	95
11.39	Checking the chain, rear sprocket, engine sprocket, and chain guide	60	16.1	Checking the gear oil level	95
11.40	Checking the frame 	63	16.2	Changing the gear oil 	95
11.41	Checking the swingarm 	64	16.3	Draining the gear oil 	96
11.42	Checking the routing of the throttle cable	64	16.4	Refilling with gear oil 	97
11.43	Checking the rubber grip	65	16.5	Adding gear oil 	97
11.44	Additionally securing the rubber grip	65	17	CLEANING, CARE	99
11.45	Adjusting the basic position of the clutch lever	66	17.1	Cleaning the motorcycle	99
11.46	Checking/correcting the fluid level of the hydraulic clutch	66	18	STORAGE	100
11.47	Changing the hydraulic clutch fluid 	67	18.1	Storage	100
12	BRAKE SYSTEM	69	18.2	Preparing for use after storage	100
12.1	Checking the free travel of the hand brake lever	69	19	TROUBLESHOOTING	101
12.2	Adjusting the basic position of the hand brake lever	69	20	TECHNICAL DATA	103
12.3	Checking the brake discs	69	20.1	Engine	103
12.4	Checking the front brake fluid level	70	20.1.1	TC 125	103
12.5	Adding front brake fluid 	70	20.1.2	TC 250	103
12.6	Checking the front brake linings	71	20.2	Engine tightening torques	104
12.7	Changing the front brake linings 	71	20.2.1	TC 125	104
12.8	Checking the free travel of foot brake lever	73	20.2.2	TC 250	105
12.9	Adjusting the basic position of the foot brake lever 	73	20.3	Carburetor	106
12.10	Checking the rear brake fluid level	74	20.3.1	TC 125	106
12.11	Adding rear brake fluid 	75	20.3.2	Carburetor - basic setting for sandy surfaces (TC 125)	106
12.12	Checking the rear brake linings	76	20.3.3	Carburetor tuning (TC 125)	107
12.13	Changing the rear brake linings 	76	20.3.4	TC 250	108
13	WHEELS, TIRES	79	20.3.5	Carburetor - basic setting for sandy surfaces (TC 250)	108
13.1	Removing the front wheel 	79	20.3.6	Carburetor tuning (TC 250)	109
13.2	Installing the front wheel 	79	20.3.7	General carburetor tuning 	110
13.3	Removing the rear wheel 	80	20.4	Capacities	110
13.4	Installing the rear wheel 	81	20.4.1	Gear oil	110
13.5	Checking the tire condition	82	20.4.2	Coolant	110
13.6	Checking the tire air pressure	83	20.4.3	Fuel	110
13.7	Checking the spoke tension	83	20.5	Chassis	110
14	COOLING SYSTEM	84	20.6	Tires	111
14.1	Cooling system	84	20.7	Fork	111
14.2	Radiator cover (TC 125)	84	20.7.1	TC 125	111
14.3	Installing the radiator cover (TC 125)	84	20.7.2	TC 250	111
14.4	Removing the radiator cover (TC 125)	85	20.8	Shock absorber	112
14.5	Checking the antifreeze and coolant level	85	20.8.1	TC 125	112
14.6	Checking the coolant level	86	20.8.2	TC 250	112
14.7	Draining the coolant 	86	20.9	Chassis tightening torques	113
14.8	Refilling with coolant 	87	21	SUBSTANCES	115
			22	AUXILIARY SUBSTANCES	117
			23	STANDARDS	118

TABLE OF CONTENTS

24 LIST OF ABBREVIATIONS 119

INDEX..... 120

1.1 Symbols used

The meaning of specific symbols is described below.

	Indicates an expected reaction (e.g. of a work step or a function).
	Indicates an unexpected reaction (e.g. of a work step or a function).
	All work marked with this symbol requires specialist knowledge and technical understanding. In the interests of your own safety, have these jobs performed by an authorized Husqvarna Motorcycles workshop. There, your motorcycle will be optimally cared for by specially trained experts using the specialist tools required.
	Indicates a page reference (more information is provided on the specified page).
	Indicates information with more details or tips.
	Indicates the result of a testing step.

1.2 Formats used

The typographical formats used in this document are explained below.

Proprietary name	Indicates a proprietary name.
Name[®]	Indicates a protected name.
Brand[™]	Indicates a brand available on the open market.
<u>Underlined terms</u>	Refer to technical details of the vehicle or indicate technical terms, which are explained in the glossary.

2.1 Use definition - intended use

Husqvarna sport motorcycles are designed and built to withstand the normal stresses and strains of competitive use. The motorcycles comply with currently valid regulations and categories of the top international motorsport organizations.



Info

The motorcycle may only be used in closed off areas remote from public road traffic.

2.2 Safety advice

A number of safety instructions need to be followed to operate the vehicle safely. Therefore, read this manual carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.



Info

The vehicle has various information and warning labels at prominent locations. Do not remove information/warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.3 Degrees of risk and symbols



Danger

Indicates a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Indicates a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Indicates a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Indicates a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



Warning

Indicates a danger that will lead to environmental damage if the appropriate measures are not taken.

2.4 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

- 1 The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- 1 Removal or puncturing of the main silencer, baffles, header pipes or any other components which conduct exhaust gases.
- 2 Removal or puncturing of parts of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing moving part of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

2.5 Safe operation



Danger

Danger of accidents Danger arising from the rider's judgement being impaired.

- Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.

The vehicle should only be used by trained persons.

Have malfunctions that impair safety promptly eliminated by an authorized Husqvarna Motorcycles workshop.

Adhere to the information and warning labels on the vehicle.

2.6 Protective clothing



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.

In the interest of your own safety, Husqvarna Motorcycles recommends that you only operate the vehicle while wearing protective clothing.

2.7 Work rules

Special tools are necessary for certain tasks. The tools are not contained in the vehicle but can be ordered under the number in parentheses. E.g.: bearing puller (15112017000)

During assembly, non-reusable parts (e.g. self-locking screws and nuts, seals and seal rings, O-rings, pins, lock washers) must be replaced by new parts.

In some instances, a thread locker (e.g. **Loctite**®) is required. The manufacturer instructions for use must be followed.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.

After you complete the repair or service work, check the operating safety of the vehicle.

2.8 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and regulations of the respective country.

Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

2.9 Owner's Manual

It is important that you read this Owner's Manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and maintain your motorcycle. Only then will you find out how to customize the vehicle ideally for your own use and how you can protect yourself from injury.

Keep the Owner's Manual in an accessible place to enable you to refer to it as needed.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized Husqvarna Motorcycles dealer.

The Owner's Manual is an important component of the vehicle and must be handed over to the new owner if the vehicle is sold.

3.1 Manufacturer and implied warranty

The work prescribed in the service schedule must be carried out by an authorized Husqvarna Motorcycles workshop only and confirmed both in the customer's Service & Warranty Booklet and in the **Husqvarna Motorcycles Dealer.net**; otherwise, all warranty claims will be void. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the warranty.

Additional information on the manufacturer or implied warranty and the procedures involved can be found in the Service & Warranty Booklet.

3.2 Operating and auxiliary substances



Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.

Use operating and auxiliary substances (such as fuel and lubricants) as specified in the Owner's Manual.

3.3 Spare parts, accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by Husqvarna Motorcycles and have them installed by an authorized Husqvarna Motorcycles workshop. Husqvarna Motorcycles accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessory products are specified in parentheses in the descriptions. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

The current Husqvarna Motorcycles accessories for your vehicle can be found on the Husqvarna Motorcycles website.
International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. Incorrect adjustment and tuning of the engine and chassis can lead to damage and breakage of components.

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

3.5 Figures

The figures contained in the manual may depict special equipment.


In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.

3.6 Customer service

Your authorized Husqvarna Motorcycles dealer will be happy to answer any questions you may have regarding your vehicle and Husqvarna Motorcycles.

A list of authorized Husqvarna Motorcycles dealers can be found on the Husqvarna Motorcycles website.
International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com


4.1 View of vehicle, front left (example)



M01257-10


1	Filler cap
2	Air filter box lid
3	Plug-in stand (🔗 p. 15)
4	Shift lever (🔗 p. 14)
5	Engine number (🔗 p. 11)
6	Choke (🔗 p. 14)
7	Fuel tap (🔗 p. 14)

4.2 View of vehicle, rear right (example)




1	Clutch lever (☞ p. 12)
2	Kill switch (☞ p. 12)
3	Fork compression adjustment
4	Fork rebound adjustment
5	Throttle grip (☞ p. 12)
6	Hand brake lever (☞ p. 12)
7	Kick starter (☞ p. 15)
8	Foot brake lever (☞ p. 15)
9	Shock absorber compression adjustment
10	Shock absorber rebound adjustment
11	Level viewer for brake fluid, rear

5.1 Chassis number




The chassis number ❶ is stamped on the right side of the steering head.

5.2 Type label




The type label ❶ is fixed to the front of the steering head.

5.3 Engine number




The engine number ❶ is stamped on the left side of the engine under the engine sprocket.

5.4 Fork part number




The fork part number ❶ is stamped on the inner side of the fork stub.

5.5 Shock absorber article number




The shock absorber article number ❶ is stamped on the top of the shock absorber above the adjusting ring towards the engine side.

6.1 Clutch lever



(TC 125)

The clutch lever ① is fitted on the left side of the handlebar.
The clutch is hydraulically operated and self-adjusting.



(TC 250)

The clutch lever ① is fitted on the left side of the handlebar.
The clutch is hydraulically operated and self-adjusting.

6.2 Hand brake lever




Hand brake lever ① is fitted on the right side of the handlebar.
The front brake is engaged using the hand brake lever.

6.3 Throttle grip



Throttle grip ① is fitted on the right side of the handlebar.

6.4 Kill switch




The kill switch ① is fitted on the left side of the handlebar.

Possible states

- Kill switch ☒ in basic position – In this position, the ignition circuit is closed, and the engine can be started.
- Kill switch ☒ pressed – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

6.5 Map-Select switch (TC 250)



The **Map-Select** switch ❶ is fitted on the right side of the handlebar.

Possible states

I	PERFORMANCE – This position is used for higher performance.
II	SOFT – This position is used for better rideability.

The engine characteristic can be changed on the handlebar using the **Map-Select** switch.

6.6 Opening the filler cap

**Danger**

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

**Warning**


Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that has been contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.

**Warning**


Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.




- Turn filler cap ❶ counterclockwise and lift it off.

6.7 Closing the filler cap



- Mount filler cap ❶ and turn it clockwise until the fuel tank is tightly closed.

**Info**

Run the fuel tank breather hose ❷ without kinks.

6.8 Fuel tap




The fuel tap is on the left side of the fuel tank.


Open or close the supply of fuel to the carburetor using tap handle **1** on the fuel tap.

Possible states

- Fuel supply closed **OFF** – Fuel cannot flow from the fuel tank to the carburetor.
- Fuel supply open **ON** – Fuel can flow from the fuel tank to the carburetor. The fuel tank empties completely.



6.9 Choke



Choke **1** is fitted on the left side of the carburetor.

Activating the choke function frees a drill hole in the carburetor through which the engine can draw extra fuel. This results in a richer fuel-air mixture, which is needed for a cold start.


Info

If the engine is warm, the choke function must be deactivated.


Possible states

- Choke function activated – The choke lever is pulled out to the stop.
- Choke function deactivated – The choke lever is pushed in to the stop.

6.10 Shift lever




Shift lever **1** is mounted on the left side of the engine.



(TC 125)

The gear positions can be seen in the photograph.


The neutral or idle position is between the first and second gears.



(TC 250)

The gear positions can be seen in the photograph.
The neutral or idle position is between the first and second gears.

6.11 Kick starter




Kick starter **1** is fitted on the right side of the engine.
The top part of the kick starter pivots.

i Info


Before riding, swing the top part of the kick starter inward toward the engine.

6.12 Foot brake lever



Foot brake lever **1** is located in front of the right footrest.
The foot brake lever is used to activate the rear brake.

6.13 Plug-in stand



The holder for plug-in stand **1** is on the left side of the wheel spindle.
The plug-in stand is used to park the motorcycle.

i Info

Remove the plug-in stand before riding.

7.1 Advice on first use

-  **Danger**
Danger of accidents Danger arising from the rider's judgement being impaired.
- Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.
-  **Warning**
Risk of injury Missing or poor protective clothing presents an increased safety risk.
- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.
-  **Warning**
Danger of crashing Poor vehicle handling due to different tire tread patterns on front and rear wheels.
- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.
-  **Warning**
Danger of accidents Critical riding behavior due to inappropriate riding.
- Adapt your riding speed to the road conditions and your riding ability.
-  **Warning**
Danger of accidents Accident risk caused by presence of a passenger.
- Your vehicle is not designed to carry passengers. Do not ride with a passenger.
-  **Warning**
Danger of accidents Failure of brake system.
- If the foot brake lever is not released, the brake linings drag continuously. The rear brake may fail due to overheating. Take your foot off the foot brake lever when you are not braking.
-  **Warning**
Danger of accidents Unstable riding behavior.
- Do not exceed the maximum permissible weight and axle loads.
-  **Warning**
Risk of misappropriation Usage by unauthorized persons.
- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.

 **Info**
When using your motorcycle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-delivery inspection work has been carried out by an authorized Husqvarna Motorcycles workshop.
✓ You receive a delivery certificate and the Service and Warranty Booklet at vehicle handover.
- Before your first trip, read the entire Owner's Manual carefully.
- Get to know the controls.
- Adjust the basic position of the clutch lever. (🔧 p. 66)
- Adjust the basic position of the hand brake lever. (🔧 p. 69)
- Adjust the basic position of the foot brake lever. 🦶 (🔧 p. 73)
- Adjust the basic position of the shift lever. 🦶 (🔧 p. 93)
- Become accustomed to the handling of the motorcycle on suitable terrain.

 **Info**
Your motorcycle is not authorized for riding on public roads.
When offroad, being accompanied by another person on another vehicle so that you can help each other is recommended.

- Try also to ride as slowly as possible and in a standing position to get a better feeling for the motorcycle.
- Do not make any off-road trips that exceed your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.

- Do not take luggage along.
- Do not exceed the maximum permissible weight and the maximum permissible axle loads.

Guideline

Maximum permissible overall weight	335 kg (739 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)

- Check the spoke tension. (🔧 p. 83)



Info

The spoke tension must be checked after half an hour of operation.

- Run in the engine. (🔧 p. 17)

7.2 Running in the engine

- During the running-in phase, do not exceed the specified engine performance.

Guideline

Maximum engine performance	
During the first 3 operating hours	< 70 %
During the first 5 operating hours	< 100 %

- Avoid fully opening the throttle!

7.3 Preparing the vehicle for difficult riding conditions



Info

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

(TC 250)

- Seal the air filter box. 🛠️ (🔧 p. 52)
- Clean the air filter and air filter box. 🛠️ (🔧 p. 51)



Info

Check the air filter approx. every 30 minutes.

- Additionally secure the rubber grip. (🔧 p. 65)
- Check the electrical connector for humidity and corrosion and to ensure it is firmly seated.
 - » If humidity, corrosion, or damage is found:
 - Clean and dry the connector, or change it if necessary.

Difficult riding conditions are:

- Rides on dry sand. (🔧 p. 17)
- Rides on wet sand. (🔧 p. 19)
- Rides on wet and muddy surfaces. (🔧 p. 20)
- Riding at high temperatures and low speeds. (🔧 p. 20)
- Rides at low temperature or in snow. (🔧 p. 21)

7.4 Preparing for rides on dry sand



600872-10

- Check the radiator cap.

Value on the radiator cap	1.8 bar (26 psi)
---------------------------	------------------


- » If the indicated value does not correspond to the required value:



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.



- Change the radiator cap.

(TC 125)

- Fit a dust cover on the air filter.

Dust cover for air filter (79006920000)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.

- Fit a sand cover on the air filter.

Sand cover for air filter (79006922000)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.

(TC 250)

- Fit a dust cover on the air filter.

Dust cover for air filter (77206920100)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.

- Fit a sand cover on the air filter.

Sand cover for air filter (59006922000)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.

- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized Husqvarna Motorcycles workshop.

- Clean the chain.
- Fit the steel sprocket.



Tip

Do not grease the chain.


- Clean the radiator fins.
- Straighten bent radiator fins carefully.

Condition

Regular use in sand

- Change the piston every 10 operating hours.

7.5 Preparing for rides on wet sand



- Check the radiator cap.

Value on the radiator cap	1.8 bar (26 psi)
---------------------------	------------------

- » If the indicated value does not correspond to the required value:



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

- Change the radiator cap.

(TC 125)

- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (79006921000)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.



(TC 250)


- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (77206921100)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.



- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized Husqvarna Motorcycles workshop.



- Clean the chain.
- Fit the steel sprocket.



Tip

Do not grease the chain.

- Clean the radiator fins.
- Straighten bent radiator fins carefully.

Condition

Regular use in sand

- Change the piston every 10 operating hours.

7.6 Preparing for rides on wet and muddy surfaces



M01274-01

(TC 125)

- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (79006921000)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.



M01267-01

(TC 250)


- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (77206921100)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.



M01107-01

- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized Husqvarna Motorcycles workshop.



600868-01

- Fit the steel sprocket.
- Clean the motorcycle. (☛ p. 99)
- Straighten bent radiator fins carefully.

7.7 Preparations for riding at high temperatures and low speeds



600872-10

- Check the radiator cap.

Value on the radiator cap	1.8 bar (26 psi)
---------------------------	------------------

- » If the displayed value does not equal the setpoint value:



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

- Change the radiator cap.



- Adjust the secondary ratio to the terrain.



Info

The engine oil heats up quickly when the clutch is operated frequently due to an excessively high secondary drive.

- Clean the chain.
- Clean the radiator fins.
- Carefully align bent radiator fins.
- Check the coolant level. (🔧 p. 86)

7.8 Preparing for rides at low temperature or in snow



(TC 125)

- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (79006921000)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.



(TC 250)


- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (77206921100)



Info

Observe the fitting instructions for Husqvarna Motorcycles accessories.



- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized Husqvarna Motorcycles workshop.

8.1 Checks and maintenance work when preparing for use



Info

Before riding the vehicle, always check its condition and operating safety.
The vehicle must be in perfect technical condition when used.

- Check the gear oil level. (🔧 p. 95)
- Check the front brake fluid level. (🔧 p. 70)
- Check the rear brake fluid level. (🔧 p. 74)
- Check the front brake linings. (🔧 p. 71)
- Check the rear brake linings. (🔧 p. 76)
- Check that the brake system is functioning properly.
- Check the coolant level. (🔧 p. 86)
- Check the chain for dirt. (🔧 p. 58)
- Check the chain, rear sprocket, engine sprocket, and chain guide. (🔧 p. 60)
- Check the chain tension. (🔧 p. 59)
- Check the tire condition. (🔧 p. 82)
- Check the tire air pressure. (🔧 p. 83)
- Check the spoke tension. (🔧 p. 83)
- Clean the dust boots of the fork legs. (🔧 p. 37)
- Bleed the fork legs. (🔧 p. 37)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts and hose clamps regularly for tightness.
- Check the fuel supply.

8.2 Starting



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

Note

Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.



Info

If the motorcycle is unwilling to start, the cause can be old fuel in the float chamber. The flammable elements of the fuel evaporate after a long time of standing.

If the float chamber is filled with fresh fuel, the engine starts immediately.

Engine has been out of use for more than 1 week

- Empty the carburetor float chamber. 🛠️ (🔧 p. 91)
- Turn handle ❶ of the fuel tap to the **ON** position. (Figure L01808-10 🛠️ p. 14)
- ✓ Fuel can flow from the fuel tank to the carburetor.
- Remove the motorcycle from the stand.
- Shift gear to neutral.

The engine is cold

- Pull the choke lever out as far as possible.
- Press the kick starter forcefully through its full range.



Info

Do not open the throttle.

8.3 Starting off



Info

The plug-in stand must be removed before riding.

- Pull the clutch lever, shift into first gear, release the clutch lever slowly and at the same time open the throttle gently.

8.4 Shifting, riding



Warning

Danger of accidents If you change down at high engine speed, the rear wheel can lock up.

- Do not change into a low gear at high engine speed. The engine races and the rear wheel can lock up.



Info

If you hear unusual noises while riding, stop immediately, switch off the engine and contact an authorized Husqvarna Motorcycles workshop.

First gear is used for starting off or for steep inclines.

- Shift into a higher gear when conditions allow (incline, road situation, etc.). To do so, release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the throttle.
- If the choke function was activated, deactivate it after the engine has warmed up.
- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is $\frac{3}{4}$ open. This will barely reduce the speed but fuel consumption will be considerably lower.
- Always open the throttle only as much as the engine can handle – abrupt throttle opening increases fuel consumption.
- Apply the brakes and close the throttle at the same time to switch down.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and either open the throttle or shift again.
- Switch off the engine if you expect to be standing for a long time.

Guideline

≥ 2 min

- Avoid frequent and longer slipping of the clutch. This heats the engine oil, the engine, and the cooling system.
- Ride with a lower engine speed instead of with a high engine speed and a slipping clutch.

8.5 Braking



Warning

Danger of accidents If you brake too hard, the wheels can lock.

- Adapt your braking to the traffic situation and the road conditions.



Warning

Danger of accidents Reduced braking efficiency caused by spongy pressure point of front or rear brake.

- Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

- Clean or dry a dirty or wet brake system by riding and braking gently.

- On sandy, wet or slippery surfaces, use the rear brake.
- Braking should always be completed before you go into a bend. Change down to a lower gear appropriate to your road speed.
- Make use of the braking effect of the engine when driving down long downhill stretches. To do so, shift back one or two gears, but do not overrev the engine. You will need to apply the brakes far less often and the brake system will not overheat.

8.6 Stopping, parking



Warning

Risk of misappropriation Usage by unauthorized persons.

- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.
- Apply the brakes on the motorcycle.
- Shift gear to neutral.
- Press and hold the kill switch  while the engine is idling until the engine stops.
- Turn handle **1** of the fuel tap to the **OFF** position. (Figure L01808-10  p. 14)
- Rest the vehicle on the plug-in stand.

8.7 Transport

Note


Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.




- Switch off the engine.
- Use tension belts or other suitable devices to secure the motorcycle against accidents or falling over.

8.8 Refueling

- **Danger**
Fire hazard Fuel is highly flammable.
- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
 - The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

- **Warning**
Danger of poisoning Fuel is poisonous and a health hazard.
- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.

- **Warning**
Environmental hazard Improper handling of fuel is a danger to the environment.
- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Switch off the engine.
- Open the filler cap. (🔧 p. 13)
- Fill the fuel tank with fuel up to level **A**.

Guideline

Level A		35 mm (1.38 in)
Total fuel tank capacity, approx. (TC 125)	7 l (1.8 US gal)	Super unleaded (98 octane) mixed with 2-stroke engine oil (1:40) (🔧 p. 116)
Total fuel tank capacity, approx. (TC 250)	7.5 l (1.98 US gal)	Super unleaded (95 octane) mixed with 2-stroke engine oil (1:60) (🔧 p. 116)
Engine oil, 2-stroke (🔧 p. 115)		

- Close the filler cap. (🔧 p. 13)

9.1 Service schedule

	Every 20 operating hours	
	Every 10 operating hours/after every race	
Change the gear oil.  (TC 125)	•	•
Change the gear oil.  (TC 250)		•
Check the front brake linings. ( p. 71)	•	•
Check the rear brake linings. ( p. 76)	•	•
Check the brake discs. ( p. 69)	•	•
Check the brake lines for damage and leakage.	•	•
Check the rear brake fluid level. ( p. 74)	•	•
Check the free travel of the foot brake lever. ( p. 73)	•	•
Check the frame and swingarm. 	•	•
Check the swingarm bearing. 		•
Check the heim joints at the top of the shock absorber. 	•	•
Check the shock absorber linkage. 	•	•
Check the tire condition. ( p. 82)	•	•
Check the tire air pressure. ( p. 83)	•	•
Check the wheel bearing for play. 	•	•
Check the wheel hubs. 	•	•
Check the rim run-out. 	•	•
Check the spoke tension. ( p. 83)	•	•
Check the chain, rear sprocket, engine sprocket, and chain guide. ( p. 60)	•	•
Check the chain tension. ( p. 59)	•	•
Grease all moving parts (e.g., hand lever, chain, ...) and check for smooth operation. 	•	•
Check/rectify the fluid level of the hydraulic clutch. ( p. 66)	•	•
Check the front brake fluid level. ( p. 70)	•	•
Check the free travel of the hand brake lever. ( p. 69)	•	•
Check the play of the steering head bearing. ( p. 42)	•	•
Change the piston and check the cylinder and Z dimension.  (TC 125)		•
Change the piston and check the cylinder.  (TC 250)		•
Change the piston and check the cylinder and Z dimension. (under difficult operating conditions)  (TC 125)	•	•
Change the piston and check the cylinder. (under difficult operating conditions)  (TC 250)	•	•
Change the spark plug and spark plug connector.  (TC 125)	•	•
Change the spark plug and spark plug connector.  (TC 250)		•
Check the inlet membrane. 	•	•
Check the exhaust control for functioning and smooth operation. 		•
Check the clutch. 	•	•
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and sleeves for cracking, leaks, and incorrect routing. 	•	•
Check the antifreeze and coolant level. ( p. 85)	•	•
Check the cables for damage and routing without sharp bends. 	•	•
Check that the throttle cables are undamaged, routed without sharp bends, and set correctly.	•	•
Clean the air filter and air filter box.  ( p. 51)	•	•
Change glass fiber yarn filling in the main silencer.  ( p. 53)		•
Check the screws and nuts for tightness. 	•	•
Check idle. 	•	•
Final check: Check the vehicle for safe operation and take a test ride.	•	•
Make the service entry in the Husqvarna Motorcycles Dealer.net and in the Service and Warranty Booklet. 	•	•

- Periodic interval

9.2 Service work (as additional order)


	Annually		
	Every 40 operating hours		
	Once after 20 operating hours		
	Once after 10 operating hours		
Change the front brake fluid. 			•
Change the rear brake fluid. 			•
Change the hydraulic clutch fluid.  (p. 67)			•
Grease the steering head bearing.  (p. 43)			•
Check/adjust the carburetor components. 			•
Perform a fork service. 	○		•
Service the shock absorber. 		○	•
Change the connecting rod, conrod bearing, and crank pin. 			•
Check the transmission and shift mechanism. 			•
Change all engine bearings. 			•

○ One-time interval

• Periodic interval

10.1 Checking the basic chassis setting with the rider's weight

i Info
When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, swingarm and frame, the basic settings of the suspension components must match the rider's weight.
 - As delivered, Husqvarna offroad motorcycles are adjusted for an average rider's weight (with full protective clothing).
- Guideline
- | | |
|-----------------------|------------------------------|
| Standard rider weight | 75... 85 kg (165... 187 lb.) |
|-----------------------|------------------------------|
- If the rider's weight is above or below the standard range, the basic setting of the suspension components must be adjusted accordingly.
 - Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.

10.2 Compression damping of the shock absorber


The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed. High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed. The high-speed setting, for example, has an effect on the landing after a jump: the rear wheel suspension compresses quickly. The low-speed setting, for example, has an effect when riding over long ground swells: the rear wheel suspension compresses slowly. These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

10.3 Adjusting the low-speed compression damping of the shock absorber

! Caution
Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

i Info
The effect of the low-speed setting can be seen in slow to normal compression of the shock absorber.




- (TC 125)
- Turn adjusting screw ❶ clockwise with a screwdriver up to the last perceptible click.

i Info
Do not loosen fitting ❷!

- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



i

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

- (TC 250)
- Turn adjusting screw ❶ clockwise with a screwdriver up to the last perceptible click.

i

Info
Do not loosen fitting ❷!

- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

i

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.4 Adjusting the high-speed compression damping of the shock absorber


!

Caution
Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

i

Info
The effect of the high-speed setting can be seen in fast compression of the shock absorber.



- (TC 125)
- Using an open end wrench, turn adjusting screw ❶ clockwise all the way.

i

Info
Do not loosen fitting ❷!


- Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns

i

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.



(TC 250)

- Turn adjusting screw **1** all the way clockwise with a socket wrench.



Info

Do not loosen fitting **2**!

- Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.


10.5 Adjusting the rebound damping of the shock absorber



Caution

Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



(TC 125)

- Turn adjusting screw **1** clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.


Guideline

Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.



(TC 250)

- Turn adjusting screw **1** clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.6 Measuring the rear wheel sag unloaded

Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 37)

Main work


(TC 125)

- Position the sag gauge in the rear axle and measure the distance to marking **SAG** on the rear fender.


Sag gauge (00029090500)

Pin for sag gauge (00029990010)

- Note down the value as dimension **A**.



402415-10



400988-10

(TC 250)

- Measure the distance – as vertical as possible – between the rear axle and a fixed point, for example, a mark on the rear fairing.
- Note down the value as dimension **A**.

Finishing work

- Remove the motorcycle from the lift stand. (☞ p. 37)

10.7 Checking the static sag of the shock absorber

(TC 125)

- Measure distance **A** of rear wheel unloaded. (☞ p. 31)
- Hold the motorcycle upright with the aid of an assistant.
- Again measure the distance between the rear axle and marking **SAG** on the rear fender using the sag gauge.
- Note down the value as dimension **B**.

Info


The static sag is the difference between measurements **A** and **B**.

- Check the static sag.


Static sag	40 mm (1.57 in)
------------	-----------------

- » If the static sag is less or more than the specified value:

- Adjust the spring preload of the shock absorber. (☞ p. 33)



402416-10



(TC 250)

- Measure distance **A** of rear wheel unloaded. (☞ p. 31)
- Hold the motorcycle upright with the aid of an assistant.
- Measure the distance between the rear axle and the fixed point again.
- Note down the value as dimension **B**.



Info


The static sag is the difference between measurements **A** and **B**.

- Check the static sag.

Static sag	30 mm (1.18 in)
------------	-----------------

- » If the static sag is less or more than the specified value:
 - Adjust the spring preload of the shock absorber. ☞ (☞ p. 33)

10.8 Checking the riding sag of the shock absorber



(TC 125)

- Measure distance **A** of rear wheel unloaded. (☞ p. 31)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
- ✓ The rear wheel suspension levels out.
- Another person again measures the distance between the rear axle and marking **SAG** on the rear fender using the sag gauge.
- Note down the value as dimension **C**.



Info

The riding sag is the difference between measurements **A** and **C**.

- Check the riding sag.

Guideline

Riding sag	110 mm (4.33 in)
------------	------------------

- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. ☞ (☞ p. 34)

(TC 250)

- Measure distance **A** of rear wheel unloaded. (☞ p. 31)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
- ✓ The rear wheel suspension levels out.
- Another person now measures the distance between the rear axle and the fixed point.
- Note down the value as dimension **C**.




Info

The riding sag is the difference between measurements **A** and **C**.

- Check the riding sag.

Guideline

Riding sag	100 mm (3.94 in)
------------	------------------



- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. 🛠️ (📖 p. 34)

10.9 Adjusting the spring preload of the shock absorber 🛠️



Caution
Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info
Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.

- Preparatory work**
- Raise the motorcycle with a lift stand. (📖 p. 37)
 - Remove the right side cover. (📖 p. 54)
 - Remove the main silencer. (📖 p. 52)
 - Remove the shock absorber. 🛠️ (📖 p. 44)
 - After removing the shock absorber, clean it thoroughly.

Main work
(TC 125)

- Loosen screw ❶.
 - Turn adjusting ring ❷ until the spring is no longer under tension.
- Hook wrench (T106S)
- Measure the overall spring length while the spring is not under tension.
 - Tighten the spring by turning adjusting ring ❷ to measurement A.

Guideline

Spring preload	7 mm (0.28 in)
----------------	----------------




Info
Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten screw ❶.

Guideline

Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)
--------------------------------------	----	-------------------



(TC 250)

- Loosen screw ❶.
 - Turn adjusting ring ❷ until the spring is no longer under tension.
- Hook wrench (T106S)
- Measure the overall spring length while the spring is not under tension.
 - Tighten the spring by turning adjusting ring ❷ to measurement A.

Guideline

Spring preload	8 mm (0.31 in)
----------------	----------------




Info
Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten screw ❶.

Guideline

Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)
--------------------------------------	----	-------------------



Finishing work

- Install the shock absorber. (🔧 p. 46)
- Install the main silencer. (🔧 p. 53)
- Install the right side cover. (🔧 p. 55)
- Remove the motorcycle from the lift stand. (🔧 p. 37)

10.10 Adjusting the riding sag 🛠


Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 37)
- Remove the right side cover. (🔧 p. 54)
- Remove the main silencer. (🔧 p. 52)
- Remove the shock absorber. 🛠 (🔧 p. 44)
- After removing the shock absorber, clean it thoroughly.

Main work

- Choose and mount a suitable spring.

Guideline



Spring rate (TC 125)	
Weight of rider: 65... 75 kg (143... 165 lb.)	39 N/mm (223 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	42 N/mm (240 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	45 N/mm (257 lb/in)
Spring rate (TC 250)	
Weight of rider: 65... 75 kg (143... 165 lb.)	51 N/mm (291 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	54 N/mm (308 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	57 N/mm (325 lb/in)



Info

The spring rate is shown on the outside of the spring.

Finishing work


- Install the shock absorber. 🛠 (🔧 p. 46)
- Install the main silencer. (🔧 p. 53)
- Install the right side cover. (🔧 p. 55)
- Remove the motorcycle from the lift stand. (🔧 p. 37)
- Check the static sag of the shock absorber. (🔧 p. 31)
- Check the riding sag of the shock absorber. (🔧 p. 32)
- Adjust the rebound damping of the shock absorber. (🔧 p. 30)

10.11 Checking the basic setting of the fork



Info


For various reasons, no exact riding sag can be determined for the forks.



- As with the shock absorber, smaller differences in the rider's weight can be compensated by the spring preload.
- However, if the fork is often overloaded (hard end stop on compression), harder springs must be fit to avoid damage to the fork and frame.

10.12 Adjusting the compression damping of the fork

i Info
The hydraulic compression damping determines the fork suspension behavior.



- Turn white adjusting screw ❶ all the way clockwise.

i Info
Adjusting screw ❶ is located at the upper end of the left fork leg. The compression damping is located in the left fork leg (white adjusting screw). The rebound damping is located in the right fork leg (red adjusting screw).


- Turn counterclockwise by the number of clicks corresponding to the fork type.
Guideline

Compression damping (TC 125)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Compression damping (TC 250)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

i Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.13 Adjusting the rebound damping of the fork

i Info
The hydraulic rebound damping determines the fork suspension behavior.



- Turn red adjusting screw ❶ all the way clockwise.


i Info
Adjusting screw ❶ is located at the upper end of the right fork leg. The rebound damping is located in the right fork leg (red adjusting screw). The compression damping is located in the left fork leg (white adjusting screw).

- Turn counterclockwise by the number of clicks corresponding to the fork type.
Guideline

Rebound damping (TC 125)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Rebound damping (TC 250)	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

i Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.14 Handlebar position



The holes on the handlebar support are placed at a distance of **A** from the center.


Hole distance A	3.5 mm (0.138 in)
-----------------	-------------------

The handlebar can be mounted in 2 different positions. In this way, the handlebar can be mounted in the most comfortable position for the rider.

10.15 Adjusting the handlebar position

Warning
Danger of accidents Handlebar breakage.

- If the handlebar is bent or straightened it will cause material fatigue, and the handlebar can break. Always replace handlebar.



- Remove screws **1**. Take off the handlebar clamps. Remove the handlebar and lay it to one side.

Info
Cover the components to protect them against damage.
Do not kink the cables and lines.

- Remove screws **2**. Remove handlebar support **3**.
- Position rubber bushings **4** and push through nuts **5** from below.
- Place the handlebar support in the required position. Mount and tighten screws **2**.

Guideline

Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	Loctite® 243™
--------------------------	-----	------------------------	---------------

- Position the handlebar.


Info
Make sure the cables and wiring are positioned correctly.

- Position the handlebar clamps.
- Mount screws **1**, but do not tighten yet.
- Screw the handlebar clamps so that both parts touch at the front and tighten all of the screws.

Guideline

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
------------------------	----	---------------------

11.1 Raising the motorcycle with a lift stand



Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Raise the motorcycle at the frame underneath the engine.

Lift stand (81329955000)


- ✓ Neither wheel is in contact with the ground.
- Secure the motorcycle against falling over.

11.2 Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.




- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, insert plug-in stand ① into the left side of the wheel spindle.



Info

Remove the plug-in stand before riding.

11.3 Bleeding the fork legs



Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 37)


Main work

- Release bleeder screws ①.
- ✓ Any excess pressure escapes from the interior of the fork.
- Tighten the bleeder screws.

Finishing work

- Remove the motorcycle from the lift stand. (☞ p. 37)

11.4 Cleaning the dust boots of the fork legs



Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 37)
- Remove the fork protector. (☞ p. 38)

Main work

- Push dust boots ① of both fork legs downward.



Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean and oil the dust boots and inner fork tubes of both fork legs.


Universal oil spray (🔧 p. 117)

- Press the dust boots back into their normal position.
- Remove excess oil.

Finishing work


- Install the fork protector. (🔧 p. 38)
- Remove the motorcycle from the lift stand. (🔧 p. 37)

11.5 Removing the fork protector



- Remove screws ❶. Take off the clamp.
- Remove screws ❷. Take off the left fork protector.
- Remove screws ❸. Take off the right fork protector.

11.6 Installing the fork protector



- Position the left fork protector. Mount and tighten screws ❶.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Position the brake line and clamp. Mount and tighten screws ❷.
- Position the right fork protector. Mount and tighten screws ❸.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

11.7 Removing the fork legs 🛠



Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 37)
- Remove the front wheel. 🛠 (🔧 p. 79)


Main work

- Remove screws ❶ and take off the clamp.
- Remove screws ❷ and take off the brake caliper.
- Allow the brake caliper and brake line to hang tension-free to the side.




Info

Do not activate the hand brake lever while the front wheel is removed.



- Unscrew screws ③. Take out the left fork leg.
- Unscrew screws ④. Take out the right fork leg.

11.8 Installing the fork legs




Main work

- Position the fork legs.
- ✓ Bleeder screws ① are positioned toward the front.

Info

The rebound damping is located in the right fork leg (red adjusting screw). The compression damping is located in the left fork leg (white adjusting screw).

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.



- Tighten screws ②.


Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------

- Tighten screws ③.

Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
----------------------------	----	--------------------



- Position the brake caliper. Mount and tighten screws ④.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
----------------------------	----	---------------------	---------------

- Position the brake line and clamp. Mount and tighten screws ⑤.


Finishing work

- Install the front wheel. (p. 79)

11.9 Removing the lower triple clamp

Preparatory work

- Raise the motorcycle with a lift stand. (p. 37)
- Remove the front wheel. (p. 79)
- Remove the fork legs. (p. 38)
- Remove the start number plate. (p. 43)
- Remove the front fender. (p. 44)
- Remove the handlebar cushion.




Main work

- Take off cable holder **1** in front of the left radiator.
- Remove screw **2**.
- Remove screw **3**.
- Take off the upper triple clamp with the handlebar and set it aside.


Info

Protect the components against damage by covering them.
Do not bend the cables and lines.



- Remove O-ring **4**. Remove protective ring **5**.
- Take off the lower triple clamp with the steering stem.
- Remove the upper steering head bearing.

11.10 Installing the lower triple clamp




Main work


- Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease (☛ p. 117)

- Insert the lower triple clamp with the steering stem. Mount the upper steering head bearing.
- Check whether upper steering head seal **1** is correctly positioned.
- Slide on protective ring **2** and O-ring **3**.




- Position the upper triple clamp with the handlebar.
- Mount screw **4** but do not tighten yet.



- Position the fork legs.
- ✓ Bleeder screws **5** are positioned toward the front.

Info


Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.



- Tighten screws ⑥.

Guideline


Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
----------------------------	----	--------------------



- Tighten screw ④.

Guideline


Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
--------------------------	---------	--------------------



- Mount and tighten screw ⑦.

Guideline

Screw, top steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
--------------------------	----	---------------------	---------------




- Tighten screws ⑧.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------

- Secure wiring harness and clutch line with cable holder ⑨.



- Position the brake caliper. Mount and tighten screws ⑩.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
----------------------------	----	---------------------	---------------

- Position the brake line and clamp. Mount and tighten screws ⑪.

Finishing work

- Install the front fender. (☞ p. 44)
- Install the start number plate. (☞ p. 43)
- Install the front wheel. ☞ (☞ p. 79)
- Check that the wiring harness, throttle cables, and brake and clutch lines can move freely and are routed correctly.
- Check the play of the steering head bearing. (☞ p. 42)
- Remove the motorcycle from the lift stand. (☞ p. 37)
- Mount the handlebar cushion.

11.11 Checking the play of the steering head bearing



Warning


Danger of accidents Unstable vehicle handling from incorrect steering head bearing play.

- Adjust the steering head bearing play without delay. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

If the bike is ridden with play in the steering head bearing, the bearing and the bearing seats in the frame can become damaged over time.



Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 37)

Main work

- Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

No play should be noticeable in the steering head bearing.

- » If there is noticeable play present:
 - Adjust the play of the steering head bearing. ☞ (☞ p. 42)
- Move the handlebar to and fro over the entire steering range.


The handlebar must be able to move easily over the entire steering range. There should be no perceptible detent positions.

- » If detent positions are noticeable:
 - Adjust the play of the steering head bearing. ☞ (☞ p. 42)
 - Check the steering head bearing and replace if required.

Finishing work

- Remove the motorcycle from the lift stand. (☞ p. 37)

11.12 Adjusting the play of the steering head bearing ☞



Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 37)
- Remove the handlebar cushion.

Main work

- Loosen screws ❶. Remove screw ❷.
- Loosen and retighten screw ❸.

Guideline

Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
--------------------------	---------	--------------------

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
- Tighten screws ❶.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------

- Mount and tighten screw ❷.


Guideline

Screw, top steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
--------------------------	----	---------------------	---------------

Finishing work


- Check the play of the steering head bearing. (☞ p. 42)
- Remove the motorcycle from the lift stand. (☞ p. 37)
- Mount the handlebar cushion.

11.13 Greasing the steering head bearing




- Remove the lower triple clamp. (p. 39)
- Install the lower triple clamp. (p. 40)

11.14 Removing the start number plate




- (TC 125)
- Remove screw 1.
 - Remove screw 2 and take off the brake line guide and start number plate.




- (TC 250)
- Detach brake line 1 from the brake line guide.
 - Remove screw 2. Take off the start number plate.

11.15 Installing the start number plate



- (TC 125)
- Position the brake line and brake line guide on the start number plate.
 - Mount and tighten screw 1.
 - Position the start number plate.
 - ✓ The holding lugs engage in the fender.
 - Mount and tighten screw 2.

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)



- (TC 250)
- Position the start number plate.
 - ✓ The holding lugs engage in the fender.
 - Mount and tighten screw 1.
- Guideline
- | | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|
- Position brake line 2 in the brake line guide.


11.16 Removing the front fender

Preparatory work

- Remove the start number plate. (🔧 p. 43)

Main work

- Remove screws ❶ and ❷. Remove the front fender.




11.17 Installing the front fender

Main work

- Position the front fender. Mount and tighten screws ❶ and ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------




Finishing work

- Install the start number plate. (🔧 p. 43)

11.18 Removing the shock absorber 🛠


Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 37)
- Remove the right side cover. (🔧 p. 54)
- Remove the main silencer. (🔧 p. 52)



Main work (TC 125)

- Remove the cable tie(s).
- Remove screws ①.
- Remove screws ② with the washers.
- Remove the frame protector on the left and right.




- Remove screw ③.
- Remove screw cap ④.




Info


Raise the wheel slightly to be able to remove the screws more easily.




- Press angle lever ⑤ toward the rear.
- Press linkage lever ⑥ downward.




- Remove screws ⑦.
- Pull off foot brake cylinder from the push rod.




- Remove the connecting link of the chain.
- Take off the chain.




- Remove nut ⑧ and pull out the swingarm pivot.
- Push the swingarm back and secure it against falling over.



- Hold the shock absorber and remove screw 9.



- Remove the shock absorber from below carefully.




(TC 250)


- Remove screw 1.
- Remove screw cap 2.

Info

Raise the wheel slightly to be able to remove the screws more easily.




- Press angle lever 3 toward the rear.
- Press linkage lever 4 downward.



- Hold the shock absorber and remove screw 5.
- Raise the swingarm slightly and remove the shock absorber carefully in upward direction.






11.19 Installing the shock absorber



Main work
(TC 125)

- Carefully position the shock absorber from the bottom.
- Mount and tighten screw 1.

Guideline			
Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™



- Position the swingarm and mount the swingarm pivot.

i Info
Pay attention to flat area **A**.

- Mount and tighten nut **2**.

Guideline

Nut, swingarm pivot	M16x1.5	100 Nm (73.8 lbf ft)
---------------------	---------	-------------------------

- Mount the chain.
- Connect the chain with the connecting link.

Guideline

The closed side of the chain joint lock must face in the direction of travel.

- Position the foot brake cylinder.
- ✓ Push rod **3** engages in the foot brake cylinder.

i Info
Ensure that the dust boot is correctly seated.

- Mount and tighten screws **4**.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Position the angle lever and linkage lever.
- Mount and tighten screw cap **5**.

Guideline

Nut, linkage lever to angle lever	M14x1.5	80 Nm (59 lbf ft)
-----------------------------------	---------	-------------------

i Info
Pay attention to flat area **B**.

- Mount and tighten screw **6**.

Guideline

Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
------------------------------	-----	------------------------	----------------

i Info
Raise the wheel slightly to be able to mount the screw more easily.

- Position the frame protector on the left and right.
- Mount and tighten screws **7**.

Guideline


Screw, frame protector	M5	3 Nm (2.2 lbf ft)
------------------------	----	-------------------

- Mount and tighten screws **8** with the washers.

Guideline

Screw, frame protector	M5	3 Nm (2.2 lbf ft)
------------------------	----	-------------------

- Mount the cable tie(s).
- Check the free travel of the foot brake lever. (☛ p. 73)




(TC 250)

- Raise the swingarm slightly, and carefully position the shock absorber from the top.
- Mount and tighten screw ❶.

Guideline

Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
---------------------------	-----	---------------------	----------------



- Position the angle lever and linkage lever.
- Mount and tighten screw cap ❷.

Guideline

Nut, linkage lever to angle lever	M14x1.5	80 Nm (59 lbf ft)	
-----------------------------------	---------	-------------------	--

- Mount and tighten screw ❸.

Guideline

Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
------------------------------	-----	---------------------	----------------



Info

Raise the wheel slightly to be able to mount the screw more easily.

Finishing work


- Install the main silencer. (🔧 p. 53)
- Install the right side cover. (🔧 p. 55)
- Remove the motorcycle from the lift stand. (🔧 p. 37)

11.20 Removing the seat



(TC 125)


- Remove the air filter box cover. (🔧 p. 49)
- Remove screw ❶.
- Pull seat back and lift it off.




(TC 250)

- Remove screws ❶ in the recessed grips on the left and right.
- Raise the rear of the seat, pull the seat back, and lift it off.

11.21 Mounting the seat




- (TC 125)
- Mount the front of the seat on the collar bushing and the rear in the bracket.
 - Push the seat forward.
 - Make sure that the seat is correctly engaged in at the front and the rear.
 - Mount and tighten screw 1.
- Guideline
- | | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|
- Install the air filter box cover. (👉 p. 50)




- (TC 250)
- Mount the front of the seat on the collar bushing of the fuel tank, lower the seat at the rear, and simultaneously push the seat forward.
 - Make sure that the seat is correctly locked in.
 - Mount and tighten screws 1.
- Guideline
- | | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

11.22 Removing the air filter box cover




- (TC 125)
- Pull off the air filter box cover sideways in areas A, B and C, and remove toward the front.



(TC 250)


- Release catch 1.
- Pull off the air filter box cover sideways in areas A and B, and remove toward the rear.

11.23 Installing the air filter box cover



(TC 125)

- Position air filter box cover on collar bushings 1 and 2 and push toward the rear.
- Engage the air filter box cover in areas A, B and C.



(TC 250)

- Position the air filter box cover and catch 1.
- Engage the air filter box cover in areas A and B.
- Engage catch 1.

11.24 Removing the air filter

Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never operate the vehicle without an air filter as dust and dirt will enter the engine and lead to increased wear.




Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.


Preparatory work

- Remove the air filter box cover. (p. 49)



Main work (TC 125)

- Detach ❶ retaining tab. Remove air filter with air filter support.
- Take off air filter from air filter support.



(TC 250)

- Push air filter holding bracket ❶ toward the air filter at position A, and detach it at end B.
- Swivel the air filter holding bracket to one side and remove the air filter with the air filter support.
- Take off air filter from air filter support.

11.25 Cleaning the air filter and air filter box



Warning


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.



Preparatory work

- Remove the air filter box cover. (☞ p. 49)
- Remove the air filter. ☞ (☞ p. 50)

Main work

- Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaning agent (☞ p. 117)



Info

Only squeeze the air filter to dry it; never wring it out.

- Oil the dry air filter with a high quality filter oil.


Oil for foam air filter (☞ p. 117)

- Clean the air filter box.
- Clean the intake flange and check it for damage and tightness.

Finishing work

- Install the air filter. ☞ (☞ p. 51)
- Install the air filter box cover. (☞ p. 50)


11.26 Installing the air filter



Main work (TC 125)


- Mount the clean air filter on the air filter support.
- Grease the air filter in area A.

Long-life grease (☞ p. 117)



- Insert the air filter and position the top retaining pin **1** in bushing **B**.
✓ The air filter is correctly positioned.
- Fix the bottom retaining pin with holding tab **2**.


i Info
If the air filter is not mounted correctly, dust and dirt may enter the engine and result in damage.



(TC 250)

- Mount the clean air filter on the air filter support.
- Grease the air filter in area **A**.

Long-life grease (☛ p. 117)



- Insert both parts together, position them, and secure them using air filter holding bracket **1** in area **B**.
✓ The arrow of marking **UP** faces up.

i Info
If the air filter is not mounted correctly, dust and dirt may enter the engine and result in damage.

Finishing work

- Install the air filter box cover. (☛ p. 50)


11.27 Sealing the air filter box ☛ (TC 250)

Preparatory work

- Remove the air filter box cover. (☛ p. 49)

Main work

- Seal the air filter box in marked area **A**.



Finishing work

- Install the air filter box cover. (☛ p. 50)

11.28 Removing the main silencer




Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.


- Allow the exhaust system to cool down. Do not touch hot components.

Preparatory work

- Remove the right side cover. (☛ p. 54)




- Main work**
(TC 125)
- Remove screws ❶ with the washers.
 - Pull off the main silencer from the manifold at rubber sleeve ❷.



- (TC 250)**
- Remove screws ❶ with the washers.
 - Pull off the main silencer from the manifold at rubber sleeve ❷.


11.29 Installing the main silencer



- Main work**
(TC 125)
- Position the main silencer with rubber sleeve ❶.
 - Mount and tighten screws ❷ with the washers.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- (TC 250)**
- Position the main silencer with rubber sleeve ❶.
 - Mount and tighten screws ❷ with the washers.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Finishing work**
- Install the right side cover. (☛ p. 55)


11.30 Changing the glass fiber yarn filling in the main silencer ☛

Warning
Danger of burns The exhaust system gets very hot when the vehicle is driven.

- Allow the exhaust system to cool down. Do not touch hot components.

i Info
Over time, the fibers of the glass fiber yarn escape and the damper "burns" out. Not only is the noise level higher, the performance characteristic changes.

- Preparatory work**
- Remove the right side cover. (☛ p. 54)
 - Remove the main silencer. (☛ p. 52)



Main work

- Remove screws ①. Pull out inner tube ②.
- Remove the glass fiber yarn filling ③ from the inner tube.
- Clean the parts that need to be reinstalled and check for damage.
- Fit the new glass fiber yarn filling ③ into the inner tube.
- Slide outer tube ④ over the inner tube with the new glass fiber yarn filling.
- Mount and tighten all screws ①.


Guideline

Screws on the main silencer	M5	7 Nm (5.2 lbf ft)
-----------------------------	----	-------------------

Finishing work


- Install the main silencer. (☛ p. 53)
- Install the right side cover. (☛ p. 55)

11.31 Removing the right side cover



(TC 125)


- Remove screw ①.
- Pull off the side cover sideways in areas ① and ②, and remove toward the front.




(TC 250)

- Remove screw ①.
- Pull off the side cover in area ① sideways and remove it toward the rear.

11.32 Installing the right side cover



- (TC 125)
- Position side cover on collar bushings 1 and 2 and push toward the rear.
 - Engage side cover in areas A and B.
 - Mount and tighten screw 3.
- Guideline
- | | | |
|---------------------------|----|-------------------|
| Remaining screws, chassis | M5 | 5 Nm (3.7 lbf ft) |
|---------------------------|----|-------------------|



- (TC 250)
- Position the side cover and engage in area A.
 - Mount and tighten screw 1.
- Guideline
- | | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

11.33 Removing the fuel tank



Danger
Fire hazard Fuel is highly flammable.







- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.



Warning
Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that has been contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.

- Preparatory work**
- Turn handle 1 of the fuel tap to the **OFF** position. (Figure L01808-10 p. 14)
- (TC 125)
- Remove the right side cover. (p. 54)
 - Remove the seat. (p. 48)



Main work (TC 125)

- Pull off the fuel hose.



Info

Remaining fuel may flow out of the fuel hose.

- Remove screws ①.

- Remove screw ② with the rubber bushing.
- Pull the hose off the fuel tank breather on the tank lid.

- Pull both spoilers off of the sides of the radiator bracket and lift off the fuel tank.

(TC 250)

- Pull off the fuel hose.



Info

Remaining fuel may flow out of the fuel hose.

- Remove screws ① with the collar bushings.

- Remove screw ② with the rubber bushing.
- Pull the hose off the fuel tank breather on the tank lid.

- Pull both spoilers off of the sides of the radiator bracket and lift off the fuel tank.



11.34 Installing the fuel tank

- **Danger**
Fire hazard Fuel is highly flammable.
- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
 - The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

- **Warning**
Danger of poisoning Fuel is poisonous and a health hazard.
- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.

Main work
- Check throttle cable routing. (☛ p. 64)


- (TC 125)**
- Position the fuel tank and fit the two spoilers to the sides of the radiator bracket.
 - Make sure that no cables or throttle cables are trapped or damaged.



- Attach the hose to the fuel tank breather on the tank lid.
- Mount and tighten screw 1 with the rubber bushing.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------




- Mount and tighten screws 2.


Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Connect the fuel hose.




- (TC 250)**
- Position the fuel tank and fit the two spoilers to the sides of the radiator bracket.
 - Make sure that no cables or throttle cables are trapped or damaged.



- Attach the hose to the fuel tank breather on the tank lid.
- Mount and tighten screw **1** with the rubber bushing.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Mount and tighten screws **2** with the collar bushings.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Connect the fuel hose.


Finishing work

- Mount the seat. (☛ p. 49)

(TC 125)

- Install the right side cover. (☛ p. 55)

11.35 Checking the chain for dirt



- Check the chain for heavy soiling.
 - » If the chain is very dirty:
 - Clean the chain. (☛ p. 58)

11.36 Cleaning the chain



Warning

Danger of accidents Oil or grease on the tires reduces their grip.

- Remove oil and grease with a suitable cleaning material.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Info

The service life of the chain depends largely on its maintenance.

Preparatory work

- Raise the motorcycle with a lift stand. (☛ p. 37)



Main work

- Clean the chain regularly and then treat with chain spray.

Offroad chain spray (🔧 p. 117)

Finishing work


- Remove the motorcycle from the lift stand. (🔧 p. 37)

11.37 Checking the chain tension

Warning

Danger of accidents Danger caused by incorrect chain tension.

- If the chain is too taut, the components of the secondary power transmission (chain, engine sprocket, rear sprocket, bearings in the transmission and in the rear wheel) will be under additional load. In addition to premature wear, this can cause the chain or the countershaft of the transmission to break in extreme cases. If the chain is too loose, however, it may fall off the engine sprocket or rear sprocket and block the rear wheel or damage the engine. Ensure that the chain tension is correct and adjust it if necessary.



Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 37)

Main work

- Pull the chain at the end of the chain sliding component upwards to measure chain tension **A**.

Info

The bottom chain section **1** must be taut.

Chain wear is not always even; repeat this measurement at different chain positions.

Chain tension	55... 58 mm (2.17... 2.28 in)
---------------	-------------------------------

- » If the chain tension does not meet specifications:
 - Adjust the chain tension. (🔧 p. 59)

Finishing work

- Remove the motorcycle from the lift stand. (🔧 p. 37)

11.38 Adjusting the chain tension


Warning

Danger of accidents Danger caused by incorrect chain tension.

- If the chain is too taut, the components of the secondary power transmission (chain, engine sprocket, rear sprocket, bearings in the transmission and in the rear wheel) will be under additional load. In addition to premature wear, this can cause the chain or the countershaft of the transmission to break in extreme cases. If the chain is too loose, however, it may fall off the engine sprocket or rear sprocket and block the rear wheel or damage the engine. Ensure that the chain tension is correct and adjust it if necessary.

Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 37)
- Check the chain tension. (🔧 p. 59)



M01311-10

Main work (TC 125)

- Loosen nut ①.
- Loosen nuts ②.
- Adjust the chain tension by turning adjusting screws ③ left and right.

Guideline

Chain tension	55... 58 mm (2.17... 2.28 in)
Turn adjusting screws ③ on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks A. The rear wheel is then correctly aligned.	


- Tighten nuts ②.
- Make sure that chain adjusters ④ are fitted correctly on adjusting screws ③.
- Tighten nut ①.

Guideline

Nut, rear wheel spindle	M25x1.5	80 Nm (59 lbf ft)
-------------------------	---------	-------------------

i Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length. Chain adjusters ④ can be turned by 180°.



M01365-10

(TC 250)

- Loosen nut ①.
- Loosen nuts ②.
- Adjust the chain tension by turning adjusting screws ③ left and right.

Guideline

Chain tension	55... 58 mm (2.17... 2.28 in)
Turn adjusting screws ③ on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks A. The rear wheel is then correctly aligned.	

- Tighten nuts ②.
- Make sure that chain adjusters ④ are fitted correctly on adjusting screws ③.
- Tighten nut ①.

Guideline

Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)
-------------------------	---------	-------------------

i Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length. Chain adjusters ④ can be turned by 180°.


Finishing work

- Remove the motorcycle from the lift stand. (☞ p. 37)

11.39 Checking the chain, rear sprocket, engine sprocket, and chain guide

Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 37)



Main work

- Shift the transmission to idle.
- Check the rear sprocket and engine sprocket for wear.
 - » If the rear sprocket and engine sprocket are worn:
 - Change the drivetrain kit. 🛠️

Info

The engine sprocket, rear sprocket, and chain should always be replaced together.

- Pull at the top part of the chain with the specified weight **A**.

Guideline

Weight, chain wear measurement	10... 15 kg (22... 33 lb.)
--------------------------------	----------------------------

- Measure the distance **B** of 18 chain links in the lower chain section.

Info



Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance B at the longest chain section	272 mm (10.71 in)
--	-------------------

- » If the distance **B** is greater than the specified measurement:
 - Change the drivetrain kit. 🛠️

Info

When the chain is replaced, the rear sprocket and engine sprocket should also be changed.
New chains wear out faster on old, worn sprockets.




(TC 125)

- Check the chain sliding guard for wear.
 - » If the lower edge of the chain pin is at the level of or below the chain sliding guard:
 - Change the chain sliding guard. 🛠️
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten the screws on the chain sliding guard.

Guideline


Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
----------------------------	----	-------------------	---------------



- Check the chain sliding piece for wear.
 - » If the lower edge of the chain pins is in line with or below the chain sliding piece:
 - Change the chain sliding piece. 🛠️
- Check that the chain sliding piece is firmly seated.
 - » If the chain sliding piece is loose:
 - Tighten the screw on the chain sliding piece.

Guideline

Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)
----------------------------	----	------------------------




- Check the chain guide for wear.



Info

Wear can be seen on the front of the chain guide.

- » If the light part of the chain guide is worn:
 - Change the chain guide. 🛠️



- Check that the chain guide is firmly seated.
 - » If the chain guide is loose:
 - Tighten the fitting on the chain guide.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)


(TC 250)

- Check the chain sliding guard for wear.
 - » If the lower edge of the chain pin is at the level of or below the chain sliding guard:
 - Change the chain sliding guard. 🛠️
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten the screws on the chain sliding guard.

Guideline

Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
----------------------------	----	----------------------	---------------






- Check the chain sliding piece for wear.
 - » If the lower edge of the chain pins is in line with or below the chain sliding piece:
 - Change the chain sliding piece. 🛠️
- Check that the chain sliding piece is firmly seated.
 - » If the chain sliding piece is loose:
 - Tighten the screw on the chain sliding piece.

Guideline

Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)
----------------------------	----	------------------------




- Check the chain guide for wear.



Info

Wear can be seen on the front of the chain guide.

- » If the light part of the chain guide is worn:
 - Change the chain guide. 🛠️



- Check that the chain guide is firmly seated.
 - » If the chain guide is loose:
 - Tighten the fitting on the chain guide.


Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)

Finishing work

- Remove the motorcycle from the lift stand. (🔧 p. 37)

11.40 Checking the frame 🛠️




(TC 125)

- Check the frame for cracks and deformation.
 - » If the frame exhibits cracks or deformation due to a mechanical impact:
 - Change the frame. 🛠️



Info

Always replace a frame that has been damaged due to a mechanical impact. Repair of the frame is not authorized by Husqvarna Motorcycles.



(TC 250)

- Check the frame for cracks and deformation.
 - » If the frame exhibits cracks or deformation due to a mechanical impact:
 - Change the frame. 🛠️



Info

Always replace a frame that has been damaged due to a mechanical impact. Repair of the frame is not authorized by Husqvarna Motorcycles.

11.41 Checking the swingarm 🛠️



- Check the swingarm for damage, cracking, and deformation.
 - » If the swingarm shows signs of damage, cracking, or deformation:
 - Change the swingarm. 🛠️



Info

Always change a damaged swingarm. Repair of the swingarm is not authorized by Husqvarna Motorcycles.

11.42 Checking the routing of the throttle cable

Preparatory work

- Turn handle ❶ of the fuel tap to the **OFF** position. (Figure L01808-10 🛠️ p. 14)

(TC 125)

- Remove the right side cover. (🛠️ p. 54)
- Remove the seat. (🛠️ p. 48)
- Remove the fuel tank. 🛠️ (🛠️ p. 55)

Main work

(TC 125)

- Check throttle cable routing.

The throttle cable must be routed along the back of the handlebar, to the right of the frame, below the fuel tank bracket, and to the carburetor. The throttle cable must be secured behind the fuel tank contact area rubber band.

- » If the throttle cable is not routed as specified:
 - Correct the throttle cable routing.





(TC 250)

- Check the throttle cable routing.

The throttle cable must be routed along the back of the handlebar, to the right of the frame, below the fuel tank bracket, and to the carburetor. The throttle cable must be fixed on the fuel tank bracket with a rubber band.

- » If the throttle cable is not routed as specified:
 - Correct the throttle cable routing.


Finishing work

- Install the fuel tank. (🔧 p. 57)
- Mount the seat. (🔧 p. 49)

(TC 125)

- Install the right side cover. (🔧 p. 55)


11.43 Checking the rubber grip



- Check the rubber grips on the handlebar for damage and wear and to ensure they are firmly seated.
 - » If a rubber grip is damaged, worn, or loose:
 - Change and secure the rubber grip.

Grip adhesive (00062030051) (🔧 p. 117)

11.44 Additionally securing the rubber grip



Preparatory work

- Check the rubber grip. (🔧 p. 65)

Main work


- Secure the rubber grip at two points using the securing wire.

Securing wire (54812016000)

Wire twister forceps (U6907854)

- ✓ The twisted wire ends face away from the hands and are bent toward the rubber grip.

11.45 Adjusting the basic position of the clutch lever



(TC 125)

- Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ①.



Info


When the adjusting screw is turned counterclockwise, the clutch lever moves away from the handlebar.

When the adjusting screw is turned clockwise, the clutch lever moves closer to the handlebar.

The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.

Do not make any adjustments while riding!



(TC 250)

- Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ①.



Info

When the adjusting screw is turned counterclockwise, the clutch lever moves closer to the handlebar.

When the adjusting screw is turned clockwise, the clutch lever moves away from the handlebar.

The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.


Do not make any adjustments while riding!

11.46 Checking/correcting the fluid level of the hydraulic clutch



Info

The fluid level rises with increasing wear of the clutch facing discs.



(TC 125)

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Check the fluid level.


Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

» If the fluid level does not meet specifications:

- Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 (☞ p. 115)

- Position the cover with the membrane. Mount and tighten the screws.



(TC 250)

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Check the fluid level.

Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

» If the fluid level does not meet specifications:

- Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 (☞ p. 115)

- Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilled brake fluid immediately with water.


11.47 Changing the hydraulic clutch fluid




Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




- (TC 125)
- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
 - Remove screws 1.
 - Remove cover 2 with membrane 3.



- Fill bleeding syringe 4 with the appropriate hydraulic fluid.

Bleed syringe (50329050000)
Brake fluid DOT 4 (☞ p. 115)


- Remove bleeder screw 5.
- Mount bleeding syringe 4 on the clutch slave cylinder.




- Inject the liquid into the system until it emerges from drill hole 6 of the master cylinder without bubbles.
- Drain fluid occasionally from the master cylinder reservoir, to prevent overflow.
- Remove the bleeding syringe. Mount and tighten screws bleeder screw.
- Correct the fluid level of the hydraulic clutch.

Guideline	
Fluid level below container rim	4 mm (0.16 in)

- Position the cover with the membrane. Mount and tighten the screws.




- (TC 250)
- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
 - Remove screws 1.
 - Remove cover 2 with membrane 3.



- Fill bleeding syringe 4 with the appropriate hydraulic fluid.

Bleed syringe (50329050000)
Brake fluid DOT 4 (☞ p. 115)

- Remove bleeder screw 5.
- Mount bleeding syringe 4 on the clutch slave cylinder.



- Inject the liquid into the system until it emerges from drill hole ⑥ of the master cylinder without bubbles.
- Drain fluid occasionally from the master cylinder reservoir, to prevent overflow.
- Remove the bleeding syringe. Mount and tighten screws bleeder screw.
- Correct the fluid level of the hydraulic clutch.

Guideline


Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

- Position the cover with the membrane. Mount and tighten the screws.

12.1 Checking the free travel of the hand brake lever

**Warning**
Danger of accidents Brake system failure.

- If there is no free travel on the hand brake lever, pressure builds up on the front brake circuit. The front brake can fail due to overheating. Adjust the free travel on hand brake lever according to specifications.



- Push the hand brake lever forward and check free travel **A**.
- | | |
|---------------------------------|--------------------|
| Free travel of hand brake lever | ≥ 3 mm (≥ 0.12 in) |
|---------------------------------|--------------------|
- » If the free travel does not meet specifications:
 - Adjust the basic position of the hand brake lever. (🔧 p. 69)

12.2 Adjusting the basic position of the hand brake lever




- Check the free travel of the hand brake lever. (🔧 p. 69)
 - Adjust the basic setting of the hand brake lever to your hand size by turning adjusting screw **1**.
- **Info**
When the adjusting screw is turned clockwise, the hand brake lever moves away from the handlebar.
When the adjusting screw is turned counterclockwise, the hand brake lever moves closer to the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding!

12.3 Checking the brake discs

**Warning**
Danger of accidents Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check the thickness of the front and rear brake discs at several places on the disc to see if it conforms to measurement **A**.
- **Info**
Wear reduces the thickness of the brake disc around the area used by the brake linings.
- | Brake discs - wear limit | |
|--------------------------|-------------------|
| Front | 2.5 mm (0.098 in) |
| Rear | 3.5 mm (0.138 in) |
- » If the brake disc thickness is less than the specified value:
 - Change the brake disc.
 - Check the front and rear brake discs for damage, cracking and deformation.
 - » If the brake disc exhibits damage, cracking or deformation:
 - Change the brake disc.

12.4 Checking the front brake fluid level



Warning

Danger of accidents Brake system failure.


- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Preparatory work

- Check the front brake linings. (☞ p. 71)

Main work

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in the viewer ①.
 - » If the brake fluid level is below the A marking:
 - Add front brake fluid. ☞ (☞ p. 70)

12.5 Adding front brake fluid ☞



Warning

Danger of accidents Brake system failure.

- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info


Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container!

Preparatory work

- Check the front brake linings. (☞ p. 71)



Main work

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Add brake fluid to level A.

Guideline

Dimension A (brake fluid level below top edge of container)	5 mm (0.2 in)
---	---------------

Brake fluid DOT 4 (☞ p. 115)

- Position the cover with the membrane. Mount and tighten the screws.


Info

Clean up overflowed or spilled brake fluid immediately with water.

12.6 Checking the front brake linings

Warning
Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check the brake linings for minimum thickness A.

Minimum thickness A	≥ 1 mm (≥ 0.04 in)
---------------------	--------------------

- » If the minimum thickness is less than specified:
 - Change the front brake linings. ☞ (☞ p. 71)
- Check the brake linings for damage and cracking.
 - » If damage or cracking is visible:
 - Change the front brake linings. ☞ (☞ p. 71)

12.7 Changing the front brake linings ☞

Warning
Danger of accident Brake system failure.

- Maintenance work and repairs must be carried out professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info


Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container!



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.





- Manually press the brake caliper to the brake disc to push back the brake pistons. Ensure that brake fluid does not flow out of the brake fluid reservoir, extracting it by suction if it does.

Info

Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.

- Remove cotter pins ④, pull out pin ⑤, and remove the brake linings.
- Clean the brake caliper and brake caliper support.
- Check that leaf spring ⑥ in the brake caliper and sliding plate ⑦ in the brake caliper support are seated correctly.




- Insert the new brake linings, insert pin ⑤, and mount cotter pins ④.

Info

Always change the full set of brake linings.

- Operate the hand brake lever several times until the brake linings are lying correctly against the brake disc and there is a pressure point.



- Correct the brake fluid to level **A**.

Guideline

Dimension A (brake fluid level below top edge of container)	5 mm (0.2 in)
--	---------------

Brake fluid DOT 4 (☞ p. 115)


- Position cover **2** with membrane **3**.
- Mount and tighten screws **1**.

Info
Wash off overflowed or spilled brake fluid immediately with water.

12.8 Checking the free travel of foot brake lever

Warning
Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



- Disconnect spring **1**.
- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel **A**.

Guideline


Free travel at foot brake lever	3... 5 mm (0.12... 0.2 in)
---------------------------------	----------------------------

- » If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake lever. ☞ (☞ p. 73)
- Reconnect spring **1**.

12.9 Adjusting the basic position of the foot brake lever ☞

Warning
Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



(TC 125)

- Disconnect spring 1.
- Loosen nut 4 and, with push rod 5, turn it back until you have maximum free travel.
- To adjust the basic position of the foot brake lever to individual requirements, loosen nut 2 and turn screw 3 accordingly.

i Info
The range of adjustment is limited.

- Turn push rod 5 accordingly until you have free travel A. If necessary, adjust the basic position of the foot brake lever.

Guideline

Free travel at foot brake lever	3... 5 mm (0.12... 0.2 in)	
---------------------------------	----------------------------	--

- Hold screw 3 and tighten nut 2.

Guideline

Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)
----------------------------	----	------------------------

- Hold push rod 5 and tighten nut 4.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
-------------------------	----	--------------------

- Attach spring 1.

(TC 250)

- Disconnect spring 1.
- Loosen nut 4 and, with push rod 5, turn it back until you have maximum free travel.
- To adjust the basic position of the foot brake lever to individual requirements, loosen nut 2 and turn screw 3 accordingly.

i Info
The range of adjustment is limited.

- Turn push rod 5 accordingly until you have free travel A. If necessary, adjust the basic position of the foot brake lever.

Guideline

Free travel at foot brake lever	3... 5 mm (0.12... 0.2 in)	
---------------------------------	----------------------------	--

- Hold screw 3 and tighten nut 2.

Guideline


Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)
----------------------------	----	------------------------

- Hold push rod 5 and tighten nut 4.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
-------------------------	----	--------------------

- Attach spring 1.





12.10 Checking the rear brake fluid level

Warning
Danger of accidents Brake system failure.

- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Preparatory work

- Check the rear brake linings. (☞ p. 76)

Main work

(TC 125)

- Stand the vehicle upright.
- Check the brake fluid level in level viewer ①.
 - » If the brake fluid has dropped below marking A:
- Add rear brake fluid. ☞ (☞ p. 75)

(TC 250)

- Stand the vehicle upright.
- Check the brake fluid level in level viewer ①.
 - » If the brake fluid has dropped below marking A:
- Add rear brake fluid. ☞ (☞ p. 75)

12.11 Adding rear brake fluid ☞



Warning

Danger of accidents Brake system failure.

- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info


Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.

Preparatory work

- Check the rear brake linings. (☞ p. 76)



Main work (TC 125)

- Stand the vehicle upright.
- Remove screw cap ① with membrane ② and the O-ring.
- Add brake fluid to level A.


Brake fluid DOT 4 (☞ p. 115)

- Mount the screw cap with the membrane and the O-ring.



Info

Clean up overflowed or spilled brake fluid immediately with water.



(TC 250)

- Stand the vehicle upright.
- Remove screw cap ① with membrane ② and the O-ring.
- Add brake fluid to level A.

Brake fluid DOT 4 (☞ p. 115)

- Mount the screw cap with the membrane and the O-ring.



Info

Clean up overflowed or spilled brake fluid immediately with water.


12.12 Checking the rear brake linings



Warning

Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check the brake linings for minimum thickness A.

Minimum thickness A	≥ 1 mm (≥ 0.04 in)
---------------------	--------------------

- » If the minimum thickness is less than specified:
 - Change the rear brake linings. ☞ (☞ p. 76)
- Check the brake linings for damage and cracking.
 - » If damage or cracking is visible:
 - Change the rear brake linings. ☞ (☞ p. 76)

12.13 Changing the rear brake linings ☞



Warning

Danger of accident Brake system failure.

- Maintenance work and repairs must be carried out professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning


Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- 
Warning
Danger of accident Reduced braking efficiency due to the use of non-approved brake linings.
- Brake linings available in accessories stores often have not been tested and approved for use in Husqvarna motorcycles. The structure and friction coefficient of the brake linings and thus their brake power may vary greatly from that of original Husqvarna Motorcycles brake linings. If brake linings that differ from the original equipment are used, it cannot be guaranteed that these are in keeping with the original homologation. In this case, the vehicle will not correspond to its condition at delivery and the warranty shall be void.


- 
Warning
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

- 
Info
 Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
 Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
 Use only clean brake fluid from a sealed container.



(TC 125)

- Stand the vehicle upright.
- Remove screw cap ① with membrane ② and the O-ring.





- Manually press the brake caliper to the brake disc to push back the brake piston. Ensure that brake fluid does not flow out of the brake fluid reservoir, extracting it by suction if it does.

- 
Info
 Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove cotter pins ③, pull out pin ④, and remove the brake linings.
- Clean the brake caliper and brake caliper support.
- Check that leaf spring ⑤ in the brake caliper and sliding plate ⑥ in the brake caliper support are seated correctly.


- 
Info
 The arrow on the leaf spring points in the rotation direction of the brake disc.



- Insert the new brake linings, insert pin ④, and mount cotter pins ③.

- 
Info
 Always change the brake linings in pairs.
 Make sure that decoupling plate ⑦ is mounted on the piston side brake lining.

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



- Add brake fluid to level **A**.


Brake fluid DOT 4 (☞ p. 115)

- Mount and tighten screw cap **1** with membrane **2** and the O-ring.




Info

Clean up overflowed or spilled brake fluid immediately with water.



(TC 250)

- Stand the vehicle upright.
- Remove screw cap **1** with membrane **2** and the O-ring.



- Manually press the brake caliper to the brake disc to push back the brake piston. Ensure that brake fluid does not flow out of the brake fluid reservoir, extracting it by suction if it does.



Info


Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove cotter pins **3**, pull out pin **4**, and remove the brake linings.
- Clean the brake caliper and brake caliper support.
- Check that leaf spring **5** in the brake caliper and sliding plate **6** in the brake caliper support are seated correctly.



Info

The arrow on the leaf spring points in the rotation direction of the brake disc.



- Insert the new brake linings, insert pin **4**, and mount cotter pins **3**.




Info

Always change the brake linings in pairs.

Make sure that decoupling plate **7** is mounted on the piston side brake lining.

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



- Add brake fluid to level **A**.


Brake fluid DOT 4 (☞ p. 115)

- Mount and tighten screw cap **1** with membrane **2** and the O-ring.




Info

Clean up overflowed or spilled brake fluid immediately with water.



13.1 Removing the front wheel



Preparatory work


- Raise the motorcycle with a lift stand. (☛ p. 37)

Main work


- Press the brake caliper onto the brake disc by hand in order to push back the brake pistons.

Info

Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.




- Loosen screw ❶ by several rotations.
- Loosen screws ❷.
- Press on screw ❶ to push the wheel spindle out of the axle clamp.
- Remove screw ❶.



- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.

Info

Do not pull the hand brake lever when the front wheel is removed. Always lay the wheel down in such a way that the brake disc is not damaged.



- Remove spacers ❸.


13.2 Installing the front wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the front wheel bearing. ☛
- Clean and grease shaft seal rings ❶ and contact surface A of the spacers.

Long-life grease (☛ p. 117)

- Insert the spacers.
- Position the front wheel and insert the wheel spindle.
- ✓ The brake linings are correctly positioned.



- Mount and tighten screw **2**.

Guideline

Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)
----------------------------	---------	---------------------

- Operate the hand brake lever several times until the brake linings are lying correctly against the brake disc.
- Remove the motorcycle from the lift stand. (☛ p. 37)
- Operate the front brake and compress the fork a few times firmly.
✓ The fork legs straighten.
- Tighten screws **3**.

Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	---------------------

13.3 Removing the rear wheel ☛

Preparatory work

- Raise the motorcycle with a lift stand. (☛ p. 37)

Main work

(TC 125)

- Press the brake caliper onto the brake disc by hand in order to push back the brake piston.



Info

Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove nut **1**.
- Remove chain adjuster **2**. Withdraw wheel spindle **3** only enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.



Info


Cover the components to protect them against damage.

- Holding the rear wheel, withdraw the wheel spindle. Take the rear wheel out of the swingarm.



Info

Do not operate the foot brake lever when the rear wheel is removed. Always lay the wheel down in such a way that the brake disc is not damaged.



(TC 250)

- Press the brake caliper onto the brake disc by hand in order to push back the brake piston.



Info

Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.


- Remove nut **1**.
- Remove chain adjuster **2**. Withdraw wheel spindle **3** only enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.



Info


Cover the components to protect them against damage.

- Holding the rear wheel, withdraw the wheel spindle. Take the rear wheel out of the swingarm.



**Info**

Do not operate the foot brake lever when the rear wheel is removed. Always lay the wheel down in such a way that the brake disc is not damaged.




- Remove spacers 4.

13.4 Installing the rear wheel

**Warning**

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Main work


- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the rear wheel bearing.
- Clean and grease shaft seal rings 1 and contact surface A of the spacers.

Long-life grease (p. 117)
- Insert the spacers.



(TC 125)

- Position the rear wheel and insert wheel spindle 2.
 - ✓ The brake linings are correctly positioned.
- Mount the chain.




- Position chain adjuster 3. Mount nut 4, but do not tighten it yet.
- Make sure that chain adjusters 3 are fitted correctly on adjusting screws 5.
- Check the chain tension. (p. 59)
- Tighten nut 4.


Guideline		
Nut, rear wheel spindle	M25x1.5	80 Nm (59 lbf ft)

**Info**

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length. Chain adjusters 3 can be turned by 180°.




- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



(TC 250)

- Position the rear wheel and insert wheel spindle ②.
 - ✓ The brake linings are correctly positioned.
- Mount the chain.



- Position chain adjuster ③. Mount nut ④, but do not tighten it yet.
- Make sure that chain adjusters ③ are fitted correctly on adjusting screws ⑤.
- Check the chain tension. (☛ p. 59)
- Tighten nut ④.

Guideline

Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)
-------------------------	---------	-------------------

i

Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length. Chain adjusters ③ can be turned by 180°.

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

Finishing work


- Remove the motorcycle from the lift stand. (☛ p. 37)

13.5 Checking the tire condition

i

Info

Only mount tires approved and/or recommended by Husqvarna Motorcycles. Other tires could have a negative effect on handling characteristics. The type, condition, and air pressure of the tires all have a major impact on the handling of the motorcycle. The tires mounted on the front and rear wheels must have a similar profile. Worn tires have a negative effect on handling characteristics, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects, and other damage.
 - » If the tires have cuts, run-in objects, or other damage:
 - Change the tires.
- Check the tread depth.

i

Info

Adhere to the legally required minimum tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)
---------------------	--------------------

- » If the tread depth is less than the minimum tread depth:
 - Change the tires.
- Check the tire age.

i


Info

The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture. Husqvarna Motorcycles recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

- » If the tires are more than 5 years old:
 - Change the tires.

13.6 Checking the tire air pressure

i Info
Low tire air pressure leads to abnormal wear and overheating of the tire.
Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



- Remove the dust cap.
- Check the tire air pressure when the tires are cold.

Tire air pressure off road	
Front	1.0 bar (15 psi)
Rear	1.0 bar (15 psi)


- » If the tire pressure does not meet specifications:
 - Correct the tire pressure.
- Mount the dust cap.

13.7 Checking the spoke tension

! Warning
Danger of accidents Instable handling due to incorrect spoke tension.

- Ensure that the spoke tension is correct. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

i Info
A loose spoke causes wheel imbalance and rapidly leads to more loose spokes.
If the spokes are too tight, they can break due to local overload.
Check the spoke tension regularly, especially on a new motorcycle.



- Briefly strike each spoke with the tip of a screwdriver.

i Info
The tone frequency depends on the length of the spoke and the spoke diameter.
If you hear different tone frequencies from different spokes of equal length and diameter, this is an indication of different spoke tensions.

You should hear a high note.


- » If the spoke tension varies:
 - Correct the spoke tension. 🛠️
- Check the spoke torque.

Guideline

Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)

Torque wrench with various accessories in set (58429094000)


14.1 Cooling system



(TC 125)
Water pump ① in the engine circulates the coolant.
The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ②. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream.
The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.




(TC 250)
Water pump ① in the engine circulates the coolant.
The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ②. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)


Cooling is effected by the air stream.
The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

14.2 Radiator cover (TC 125)



The radiator cover is mounted in front of the left radiator between the radiator shield and radiator.
The radiator cover keeps the coolant temperature in the correct range.

Coolant temperature	65... 70 °C (149... 158 °F)
---------------------	-----------------------------




The radiator cover is installed in front of the left radiator, depending on the ambient temperature.


Full radiator cover ①	< 7 °C (< 45 °F)
Half radiator cover ②	7... 16 °C (45... 61 °F)
No radiator cover	> 16 °C (> 61 °F)

i Info
Do not use both radiator covers at the same time.

14.3 Installing the radiator cover (TC 125)




- Remove screws ①.
- Remove screws ②.
- Take off radiator shield ③.



- Position the matching radiator cover (☛ p. 84).
- ✓ The larger catch is located at the top left.

Info
Do not use both radiator covers at the same time.




- Position radiator shield ③.
- Mount and tighten screws ②.

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

- Mount and tighten screws ①.

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

14.4 Removing the radiator cover (TC 125)



- Remove screws ①.
- Remove screws ②.
- Take off radiator shield ③.
- Remove the radiator cover.
- Position radiator shield ③.
- Mount and tighten screws ②.

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

- Mount and tighten screws ①.

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

14.5 Checking the antifreeze and coolant level


Warning
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

Warning
Danger of poisoning Coolant is poisonous and a health hazard.

- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.

Condition
The engine is cold.



- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the antifreeze in the coolant.

-25... -45 °C (-13... -49 °F)

- » If the antifreeze in the coolant does not match the specified value:
 - Correct the antifreeze in the coolant.

- Check the coolant level in the radiator.

Coolant level A above the radiator fins	10 mm (0.39 in)
--	-----------------

- » If the coolant level does not match the specified value:
 - Correct the coolant level.

Coolant (🔧 p. 115)

- Mount the radiator cap.

14.6 Checking the coolant level



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.




Warning

Danger of poisoning Coolant is poisonous and a health hazard.

- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.

Condition
The engine is cold.



- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the coolant level in the radiator.

Coolant level A above the radiator fins	10 mm (0.39 in)
--	-----------------

- » If the coolant level does not match the specified value:
 - Correct the coolant level.

Coolant (🔧 p. 115)

- Mount the radiator cap.

14.7 Draining the coolant 🛠



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.




Warning

Danger of poisoning Coolant is poisonous and a health hazard.

- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.

Condition
The engine is cold.




- Position the motorcycle upright.
- Place a suitable container under the water pump cover.

(TC 125)

- Remove screw 1. Take off radiator cap 2.
- Completely drain the coolant.
- Mount and tighten screw 1 with a new seal ring.

Guideline

Drain plug, water pump cover	M6	8 Nm (5.9 lbf ft)
------------------------------	----	-------------------



(TC 250)

- Remove screw 1. Take off radiator cap 2.
- Completely drain the coolant.
- Mount and tighten screw 1 with a new seal ring.

Guideline


Drain plug, water pump cover	M10x1	15 Nm (11.1 lbf ft)
------------------------------	-------	------------------------

14.8 Refilling with coolant

Warning

Danger of poisoning Coolant is poisonous and a health hazard.


- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.



(TC 125)

- Make sure that screw 1 is tightened.
- Position the motorcycle upright.
- Completely fill the radiator with coolant.

Coolant	1.2 l (1.3 qt.)	Coolant (☛ p. 115)
---------	-----------------	--------------------



- Loosen screw 2 until coolant escapes without bubbles.
- Replace and retighten screw 2.

Guideline

Bleeder screw, cylinder head	M6	8 Nm (5.9 lbf ft)
------------------------------	----	-------------------


- Check the coolant level. (☛ p. 86)
- Mount the radiator cap.

Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.


- Allow the engine to warm up and cool down again.
- Check the cooling system for leaks.



(TC 250)

- Make sure that screw 1 is tightened.
- Position the motorcycle upright.
- Completely fill the radiator with coolant.

Coolant	1.2 l (1.3 qt.)	Coolant (☛ p. 115)
---------	-----------------	--------------------



- Move the vehicle into the position shown and prevent it from rolling away. Height difference A must be reached.

Guideline

Height difference A	75 cm (29.5 in)
---------------------	-----------------

**Info**

For all of the air to be able to escape from the cooling system, the vehicle must be raised at the front. If the cooling system is poorly de-aerated, its cooling power will be reduced and the engine may over-heat.

- Return the vehicle to the horizontal position.
- Check the coolant level. (☛ p. 86)
- Mount the radiator cap.

**Danger**

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Allow the engine to warm up and cool down again.
- Check the cooling system for leaks.

Finishing work

- Check the coolant level. (☛ p. 86)

15.1 Checking the play in the throttle cable



- Check the throttle grip for smooth operation.
- Move the handlebar to the straight-ahead position. Move the throttle grip back and forth slightly to determine the play in throttle cable **A**.

Play in throttle cable	2... 3 mm (0.08... 0.12 in)
------------------------	-----------------------------

- » If the throttle cable play does not meet specifications:
- Adjust the play in the throttle cable. (p. 89)



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:
- Adjust the play in the throttle cable. (p. 89)

15.2 Adjusting the play in the throttle cable

Preparatory work



- Turn handle **1** of the fuel tap to the **OFF** position. (Figure L01808-10 p. 14)

(TC 125)

- Remove the right side cover. (p. 54)
- Remove the seat. (p. 48)
- Remove the fuel tank. (p. 55)
- Check throttle cable routing. (p. 64)

Main work

- Move the handlebar to the straight-ahead position.
- Push back sleeve **1**.
- Ensure that the throttle cable sleeve is pushed all the way into barrel adjuster **2**.
- Loosen nut **3**.



- Turn adjusting screw **2** in such a way there is throttle cable play **A** in the throttle grip.

Guideline

Play in throttle cable	2... 3 mm (0.08... 0.12 in)
------------------------	-----------------------------

- Tighten nut **3**.
- Slide on sleeve **1**.


Finishing work

- Check the throttle grip for smooth operation.
- Install the fuel tank. (p. 57)
- Mount the seat. (p. 49)

(TC 125)

- Install the right side cover. (p. 55)
- Check the play in the throttle cable. (p. 89)

15.3 Carburetor – idle



The idle setting of the carburetor has a big influence on the starting behavior, stable idling, and the response to throttle opening. This means that an engine with a correctly set idle speed is easier to start than if the idle speed is set wrongly.



Info

The carburetor and its components are subject to increased wear caused by engine vibration. Wear can result in malfunctioning.

The factory setting for the carburetor is set for the following values.

(TC 125)


Height above sea level	500 m (1,640 ft)
Ambient temperature	20 °C (68 °F)
Super unleaded (98 octane) mixed with 2-stroke engine oil (1:40)	(☛ p. 116)

(TC 250)

Height above sea level	500 m (1,640 ft)
Ambient temperature	20 °C (68 °F)
Super unleaded (95 octane) mixed with 2-stroke engine oil (1:60)	(☛ p. 116)

The idle speed is adjusted with adjusting screw ❶.

The idle mixture is adjusted with idle air adjusting screw ❷.



Idle air range A

Operation with the throttle slide closed. This range is influenced by adjusting screw ❶ and idle air adjusting screw ❷.

Transition range B

Behavior of the engine when the throttle slide is being opened. This range is influenced by the idling jet and by the form of the throttle slide.

If the engine sputters and smokes heavily when it starts despite a good idle and part-load setting, and if it abruptly reaches full power at a high rpm, the carburetor setting is too rich, the float level is too high, or the float needle valve is leaky.

Part-load range C

Operation with the throttle slide partially open. This range is influenced by the jet needle (form and position). The idle setting influences the engine tuning in the lower range, and the main jet influences the engine tuning in the upper range.


If the engine stutters when accelerating with a partially open throttle slide, the jet needle must be lowered by one notch. If the engine knocks when accelerating at the full power rpm range, the jet needle must be raised. If the phenomena described above occur during idling or just above, the idling system must be regulated more leanly during stuttering and less so during knocking.

Full-load range D

Operation with the throttle slide open (full throttle). This range is influenced by the main jet and jet needle.

If the insulator of a new spark plug is very light or white after a brief ride at full throttle, or if the engine knocks, a larger main jet needs to be used. If the insulator is dark brown or sooty, a smaller main jet needs to be used.

15.4 Carburetor – adjusting the idle speed



- Screw in idle air adjusting screw ❶ all the way and turn it to the specified basic position.

Guideline

Idle air adjusting screw (TC 125)	
Open	2 turns
Idle air adjusting screw (TC 250)	
Open	2 turns

- Run the engine until warm.

Guideline

Warm-up time	≥ 5 min
--------------	---------



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Adjust the idle speed with adjusting screw ❷.

Guideline

Choke function deactivated – The choke lever is pushed in to the stop. (☞ p. 14)	
Idle speed	1,400... 1,500 rpm

- Turn idle air adjusting screw ❶ slowly in a clockwise direction until the idle speed begins to fall.
- Note the position and turn the idle air adjusting screw slowly counterclockwise until the idle speed again begins to fall.
- Adjust to the point between these two positions with the highest idle speed.



Info

If there is a big engine speed rise, reduce the idle speed to a normal level and repeat the above steps.

If the procedure described here does not lead to satisfactory results, the cause may be a wrongly dimensioned idling jet.

If you can turn the idle air adjusting screw to the end without any change of engine speed, mount a smaller idling jet.

After changing the jet, start from the beginning with the adjusting steps. Following extreme air temperature or altitude changes, adjust the idle speed again.

15.5 Emptying the carburetor float chamber ☞



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that has been contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.



Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.




Info

Carry out this work with a cold engine.
Water in the float chamber results in malfunctioning.

Preparatory work


- Turn handle ❶ of the fuel tap to the **OFF** position. (Figure L01808-10☞ p. 14)
✓ Fuel no longer flows from the fuel tank to the carburetor.



Main work

- Place a cloth beneath the carburetor to soak up emerging fuel.
- Remove plug ①.
- Completely drain the fuel.
- Mount and tighten the plug.

15.6 Ignition curve plug-in connector (TC 125)



Plug-in connector ① is located on the frame under the fuel tank.

Possible states

- PERFORMANCE – The plug-in connector is connected to achieve higher performance.
- SOFT – The plug-in connector is disconnected to achieve better rideability.

15.7 Changing the ignition timing map

Switch the ignition timing map from Performance to Soft (TC 125)

- Disconnect plug-in connector ①. (Figure M01340-10 p. 92)
- ✓ Soft – better rideability

(TC 250)

- Turn switch ① to position II. (Figure M01264-10 p. 13)
- ✓ Soft – better rideability

Switch the ignition timing map from Soft to Performance

(TC 125)

- Connect plug-in connector ①. (Figure M01340-10 p. 92)
- ✓ Performance – better performance

(TC 250)


- Turn switch ① to position I. (Figure M01264-10 p. 13)
- ✓ Performance – better performance

15.8 Checking the basic position of the shift lever



Info

When driving, the shift lever must not touch the rider's boot when in the basic position.
When the shift lever keeps touching the boot, the transmission will be subject to an excessive load.




- Sit on the vehicle in the riding position and determine distance ① between the upper edge of your boot and the shift lever.


Distance between shift lever and upper edge of boot	10... 20 mm (0.39... 0.79 in)
---	-------------------------------

- » If the distance does not meet specifications:
 - Adjust the basic position of the shift lever. (p. 93)

15.9 Adjusting the basic position of the shift lever ↘



- Remove screw 1 with washers and take off shift lever 2.



- Clean gear teeth A of the shift lever and shift shaft.
- Mount the shift lever on the shift shaft in the required position and engage the gearing.

Info


The range of adjustment is limited.
The shift lever must not come into contact with any other vehicle components during the shift procedure.

- Locate and tighten screw 1 with washers.

Guideline

Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
--------------------	----	------------------------	---------------

15.10 Engine characteristic – auxiliary spring (TC 250)



The auxiliary spring is located on the right side of the engine below the water pump cover.

Possible states

- Auxiliary spring with yellow marking – Auxiliary spring mounted at the factory with medium tuning (standard) for good rideability.
- Auxiliary spring with green marking – Auxiliary spring for even softer performance.
- Auxiliary spring with red marking – Auxiliary spring for aggressive performance.

The engine characteristic can be influenced by different spring strengths of auxiliary spring 1.


15.11 Engine characteristic – setting the auxiliary spring ↘ (TC 250)


Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.


- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

- Preparatory work**
- Tilt the motorcycle approx. 45 ° to the left and secure it to prevent it from falling.
- Main work**
- Remove screws 1.





- Remove cap 2, adjusting spring 3, auxiliary spring 4, and spring insert 5 from the clutch cover.
- Pull both springs off of the spring insert.



- Mount the required auxiliary spring 4 and adjusting spring 3 and position them together in the clutch cover.

Auxiliary spring with yellow marking (54637072300)
Auxiliary spring with green marking (54837072100)
Auxiliary spring with red marking (54837072000)

✓ The recess in spring insert 5 engages in the angle lever.

Info

Screw 6 must not be turned as this would worsen the engine characteristic.


- Check the O-ring in the cap.
- Position the cap.
- Mount and tighten the screws.

Guideline

Screw, exhaust control cover	M5	6 Nm (4.4 lbf ft)
------------------------------	----	-------------------

16.1 Checking the gear oil level

i **Info**
The gear oil level must be checked when the engine is cold.



- Preparatory work**
- Stand the motorcycle upright on a horizontal surface.

Main work
(TC 125)


- Remove gear oil monitoring screw **1**.
- Check the gear oil level.
- Mount and tighten the gear oil monitoring screw.

A small quantity of gear oil must run out of the drilled hole.

- » If no gear oil runs out:
 - Add gear oil. (p. 97)

Guideline

Screw, gear oil level check	M6	8 Nm (5.9 lbf ft)
-----------------------------	----	-------------------



- (TC 250)**
- Remove gear oil monitoring screw **1**.
 - Check the gear oil level.
 - Mount and tighten the gear oil monitoring screw.


A small quantity of gear oil must run out of the drilled hole.

- » If no gear oil runs out:
 - Add gear oil. (p. 97)


Guideline

Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)
-----------------------------	----	--------------------

16.2 Changing the gear oil



- Drain the gear oil. (p. 96)



- Refill with gear oil. (p. 97)

16.3 Draining the gear oil

 **Warning**
Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.

 **Warning**
Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

 **Info**
The gear oil must be drained with the engine at normal operating temperature.

- Preparatory work**
- Park the motorcycle on a level surface.
 - Place a suitable container under the engine.

Main work
(TC 125)

- Remove the gear oil drain plug with magnet **1**.
- Remove gear oil drain plug **2**.
- Remove filler plug **3**.
- Let the gear oil drain fully.
- Clean the gear oil drain plug thoroughly.
- Clean the sealing surface on the engine.
- Mount and tighten gear oil drain plug with magnet **1** and seal ring.

Guideline

Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
---------------------------------	---------	------------------------

- Mount gear oil drain plug **2** with the seal ring and tighten.

Guideline

Gear oil drain plug	M10x1	15 Nm (11.1 lbf ft)
---------------------	-------	------------------------

- Mount and tighten filler plug **3**.




(TC 250)

- Remove the gear oil drain plug with magnet **1**.
- Remove filler plug **2**.
- Let the gear oil drain fully.
- Thoroughly clean the gear oil drain plug with magnet.
- Clean the sealing surface on the engine.
- Mount and tighten gear oil drain plug with magnet **1** and seal ring.

Guideline


Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
---------------------------------	---------	------------------------

- Mount and tighten filler plug **2**.



16.4 Refilling with gear oil

Info
Too little gear oil or poor-quality oil results in premature wear of the transmission.



- Main work**
- Remove filler plug **1** and fill up with gear oil.
- | | | |
|----------|-----------------|------------------------------------|
| Gear oil | 0.8 l (0.8 qt.) | Engine oil (SAE 10W/40) (☛ p. 115) |
|----------|-----------------|------------------------------------|
- Mount and tighten the oil filler plug.




Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.
- Finishing work**
- Check the gear oil level. (☛ p. 95)

16.5 Adding gear oil

Info
Too little gear oil or poor-quality gear oil results in premature wear to the transmission.
Gear oil must only be topped up when the engine is cold.



- Preparatory work**
- Park the motorcycle on a level surface.
- Main work**
(TC 125)
- Remove gear oil monitoring screw **1**.

- (TC 250)
- Remove gear oil monitoring screw **1**.

- Remove filler plug **2**.
 - Fill in gear oil until it emerges from the drilled hole of the gear oil monitoring screw.
- | |
|------------------------------------|
| Engine oil (SAE 10W/40) (☛ p. 115) |
|------------------------------------|
- Mount and tighten the gear oil monitoring screw.

Guideline

(TC 125)		
Screw, gear oil level check	M6	8 Nm (5.9 lbf ft)

(TC 250)		
Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)

- Mount and tighten filler plug ②.

Finishing work



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
-
- Start the engine and check that it is oil-tight.

17.1 Cleaning the motorcycle

Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

- When cleaning the vehicle with a pressure cleaner, do not point the water jet directly onto electrical components, connectors, cables, bearings, etc. Maintain a minimum distance of 60 cm between the nozzle of the pressure cleaner and the component. Excessive pressure can cause malfunctions or destroy these parts.



Warning


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

If you clean the motorcycle regularly, its value and appearance will be maintained over a long period. Avoid direct sunlight on the motorcycle during cleaning.



- Close off the exhaust system to prevent water from entering.
- Remove coarse dirt particles by spraying gently with water.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a soft brush.



Info

Use warm water containing normal motorcycle cleaner and a soft sponge. Never apply motorcycle cleaner to the dry vehicle; always rinse with water first.

- After rinsing the motorcycle with a gentle water spray, allow it to dry thoroughly.
- Empty the carburetor float chamber. (🔧 p. 91)
- Remove the plug from the exhaust system.



Warning

Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

- Clean or dry a dirty or wet brake system by riding and braking gently.

- After cleaning, take a short ride until the engine reaches operating temperature.



Info

The heat produced causes water at inaccessible locations in the engine and brake system to evaporate.

- Push back the protection caps on the handlebar controls to allow water that may have penetrated there to evaporate.
- After the motorcycle has cooled off, lubricate all moving parts and bearings.
- Clean the chain. (🔧 p. 58)
- Treat bare metal parts (except for brake discs and exhaust system) with anti-corrosion materials.

Preserving materials for paints, metal and rubber (🔧 p. 117)

- Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

18.1 Storage


**Warning**

Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that has been contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.

**Info**

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed. Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.
- Refuel. (☛ p. 25)
- Clean the motorcycle. (☛ p. 99)
- Change the gear oil. ☛ (☛ p. 95)
- Check the antifreeze and coolant level. (☛ p. 85)
- Empty the carburetor float chamber. ☛ (☛ p. 91)
- Check the tire air pressure. (☛ p. 83)
- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.

**Info**

Husqvarna Motorcycles recommends raising the motorcycle.


- Raise the motorcycle with a lift stand. (☛ p. 37)
- Cover the vehicle with a tarp or similar cover that is permeable to air.

**Info**

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.

Avoid running the engine for a short time only. Because the engine will not warm up sufficiently, the water vapor produced during combustion will condense, causing engine parts and the exhaust system to rust.

18.2 Preparing for use after storage



- Remove the motorcycle from the lift stand. (☛ p. 37)
- Perform checks and maintenance work when preparing the vehicle for use. (☛ p. 22)
- Make a test ride.

Faults	Possible cause	Action
Engine turns but does not start	Operating error	– Go through the steps of starting the engine. (☞ p. 22)
	Motorcycle was out of use for a long time and there is old fuel in the float chamber	– Empty the carburetor float chamber. ☞ (☞ p. 91)
	Fuel feed interrupted	– Check the fuel tank breather. – Clean the fuel tap. – Check/set the carburetor components.
	Spark plug oily or wet	– Clean and dry the spark plug, or change it if necessary.
	Electrode distance (plug gap) of spark plug too wide	– Adjust the plug gap. Guideline (TC 125) Spark plug electrode gap 0.60 mm (0.0236 in) (TC 250) Spark plug electrode gap 0.60 mm (0.0236 in)
	Fault in ignition system	– Check the ignition system. ☞
	Kill switch cable in wiring harness frayed, kill switch defective	– Check the kill switch. ☞
	The connector or ignition coil is loose or oxidized	– Clean the connector and treat it with contact spray.
Engine has no idle	Water in carburetor or jets blocked	– Check/set the carburetor components.
	Idling jet blocked	– Check/set the carburetor components.
	Adjusting screws on carburetor distorted	– Carburetor – adjust the idle speed. ☞ (☞ p. 90)
	Spark plug defective	– Change the spark plug.
Engine does not speed up	Ignition system defective	– Check the ignition coil. ☞ – Check the spark plug connector. ☞
	Carburetor running over because float needle dirty or worn	– Check/set the carburetor components.
	Loose carburetor jets	– Check/set the carburetor components.
Engine has too little power	Fault in ignition system	– Check the ignition system. ☞
	Fuel feed interrupted	– Check the fuel tank breather. – Clean the fuel tap. – Check/set the carburetor components.
	Air filter very dirty	– Clean the air filter and air filter box. ☞ (☞ p. 51)
	Exhaust system leaky, deformed or too little glass fiber yarn filling in main silencer	– Check exhaust system for damage. – Change glass fiber yarn filling in the main silencer. ☞ (☞ p. 53)
	Diaphragm or reed valve housing damaged	– Check the diaphragm and reed valve housing.
Engine stalls or is popping into the carburetor	Lack of fuel	– Turn handle ❶ of the fuel tap to the ON position. (Figure L01808-10☞ p. 14) – Refuel. (☞ p. 25)
	Engine takes in bad air	– Check the intake flange and carburetor for tightness.
	The connector or ignition coil is loose or oxidized	– Clean the connector and treat it with contact spray.
Engine overheats	Too little coolant in cooling system	– Check the cooling system for leakage. – Check the coolant level. (☞ p. 86)
	Too little air stream	– Switch off engine when stationary.
	Radiator fins very dirty	– Clean the radiator fins.

Faults	Possible cause	Action
Engine overheats	Foam formation in cooling system	– Drain the coolant. 🛠️ (🔧 p. 86) – Refill with coolant. 🛠️ (🔧 p. 87)
	Damaged cylinder head or cylinder head gasket	– Check the cylinder head and cylinder head gasket.
	Bent radiator hose	– Change the radiator hose. 🛠️
	Incorrect ignition point due to loose stator	– Adjust the ignition. 🛠️
White smoke emission (steam in exhaust gas)	Damaged cylinder head or cylinder head gasket	– Check the cylinder head and cylinder head gasket.
Gear oil exits at the vent hose	Too much gear oil added	– Check the gear oil level. (🔧 p. 95)
Water in the gear oil	Damaged shaft seal ring or water pump	– Check the shaft seal ring and water pump.

20.1 Engine**20.1.1 TC 125**

Design	1-cylinder 2-stroke engine, water-cooled, with reed intake and exhaust control
Displacement	124.8 cm ³ (7.616 cu in)
Stroke	54.5 mm (2.146 in)
Bore	54 mm (2.13 in)
Crankshaft bearing	1 grooved ball bearing/1 roller bearing
Conrod bearing	Needle bearing
Piston pin bearing	Needle bearing
Pistons	Cast aluminum
Piston rings	2 half keystone rings
X (upper edge of piston to upper edge of cylinder)	0... 0.10 mm (0... 0.0039 in)
Z (height of control flap)	36.5 mm (1.437 in)
Primary transmission	23:73
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	6-gear, claw shifted
Transmission ratio	
First gear	14:32
Second gear	15:30
Third gear	17:28
Fourth gear	20:28
Fifth gear	19:23
Sixth gear	22:24
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment, type Kokusan
Spark plug	NGK BR9 ECMVX
Spark plug electrode gap	0.60 mm (0.0236 in)
Starting aid	Kick starter

20.1.2 TC 250

Design	1-cylinder 2-stroke engine, water-cooled, with reed intake and exhaust control
Displacement	249 cm ³ (15.19 cu in)
Stroke	72 mm (2.83 in)
Bore	66.4 mm (2.614 in)
Exhaust valve - Beginning of adjustment	5,700 rpm
Exhaust valve - end of adjustment with red auxiliary spring	7,300 rpm
Exhaust valve - end of adjustment with yellow auxiliary spring	8,000 rpm
Exhaust valve - end of adjustment with green auxiliary spring	8,500 rpm
Crankshaft bearing	1 grooved ball bearing/1 roller bearing
Conrod bearing	Needle bearing
Piston pin bearing	Needle bearing
Pistons	Aluminum cast
Piston rings	2 half keystone rings
X (upper edge of piston to upper edge of cylinder)	0... 0.10 mm (0... 0.0039 in)
Z (height of control flap)	48 mm (1.89 in)
Primary transmission	26:72
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	5-gear, claw shifted
Transmission ratio	

First gear	2:28 PM
Second gear	3:24 PM
Third gear	6:24 PM
Fourth gear	9:24 PM
Fifth gear	10:21 PM
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment, type Kokusan
Spark plug	NGK BR8 ECM
Spark plug electrode gap	0.60 mm (0.0236 in)
Starting aid	Kick starter and electric starter

20.2 Engine tightening torques

20.2.1 TC 125

Screw, inner membrane sheets	EJOT DELTA PT® 35x25	1 Nm (0.7 lbf ft)	–
Screw, membrane core plate	EJOT DELTA PT® 30x12	1 Nm (0.7 lbf ft)	–
Screw, outer membrane sheets	EJOT DELTA PT® 30x6	1 Nm (0.7 lbf ft)	–
Screw, control lever, exhaust control	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, crankshaft position sensor	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, exhaust control cover	M5	6 Nm (4.4 lbf ft)	–
Screw, locking lever	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, retaining bracket, rotary valve	M5	6 Nm (4.4 lbf ft)	–
Screw, stator	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, water pump wheel	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Bleeder screw, cylinder head	M6	8 Nm (5.9 lbf ft)	–
Clutch slave cylinder screw	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Drain plug, water pump cover	M6	8 Nm (5.9 lbf ft)	–
Nut, adjusting screw, power valve	M6	8 Nm (5.9 lbf ft)	–
Screw, alternator cover	M6	8 Nm (5.9 lbf ft)	–
Screw, bearing retainer	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch intermediate cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch spring retainer	M6	10 Nm (7.4 lbf ft)	–
Screw, control lever, exhaust control	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, engine case	M6	10 Nm (7.4 lbf ft)	–
Screw, exhaust flange	M6	10 Nm (7.4 lbf ft)	–
Screw, gear oil level check	M6	8 Nm (5.9 lbf ft)	–
Screw, intake flange/reed valve housing	M6	6 Nm (4.4 lbf ft)	–
Screw, kick starter stop plate	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, outer clutch cover	M6	8 Nm (5.9 lbf ft)	–
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, stop plate of exhaust control	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	–
Screw, cylinder head	M7	18 Nm (13.3 lbf ft)	–
Nut, cylinder base	M8	23 Nm (17 lbf ft)	–
Screw, cylinder base	M8	20 Nm (14.8 lbf ft)	–
Screw, kick starter	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Gear oil drain plug	M10x1	15 Nm (11.1 lbf ft)	–
Nut, rotor	M12x1	60 Nm (44.3 lbf ft)	–
Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Spark plug	M14x1.25	25 Nm (18.4 lbf ft)	–

Nut, primary gear	M16LHx1.5	130 Nm (95.9 lbf ft)	Loctite® 243™
Nut, inner clutch hub	M18x1.5	100 Nm (73.8 lbf ft)	Loctite® 243™

20.2.2 TC 250

Screw, inner membrane sheets	EJOT DELTA PT® 35x25	1 Nm (0.7 lbf ft)	–
Screw, membrane support plate	EJOT DELTA PT® 30x12	1 Nm (0.7 lbf ft)	–
Screw, outer membrane sheets	EJOT DELTA PT® 30x6	1 Nm (0.7 lbf ft)	–
Screw, alternator cover	M5	5 Nm (3.7 lbf ft)	–
Screw, angle lever, exhaust control	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, clutch spring retainer	M5	6 Nm (4.4 lbf ft)	–
Screw, crankshaft position sensor	M5	6 Nm (4.4 lbf ft)	Loctite® 222™
Screw, exhaust control cap	M5	5 Nm (3.7 lbf ft)	–
Screw, exhaust control cover	M5	6 Nm (4.4 lbf ft)	–
Screw, locking lever	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, retaining bracket of exhaust control	M5	7 Nm (5.2 lbf ft)	Loctite® 2701™
Screw, stator	M5	6 Nm (4.4 lbf ft)	Loctite® 222™
Screw, water pump wheel	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, bearing retainer	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	–
Screw, control flap, exhaust control	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, engine case	M6x40	10 Nm (7.4 lbf ft)	–
Screw, engine case	M6x55	10 Nm (7.4 lbf ft)	–
Screw, engine case	M6x60	10 Nm (7.4 lbf ft)	–
Screw, exhaust flange	M6	8 Nm (5.9 lbf ft)	–
Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)	–
Screw, intake flange/reed valve housing	M6	10 Nm (7.4 lbf ft)	–
Screw, intermediate wheel bolt	M6	8 Nm (5.9 lbf ft)	Loctite® 648™
Screw, kick starter spring	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, kick starter stop plate	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, slave cylinder of the clutch	M6	10 Nm (7.4 lbf ft)	–
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	–
Screw, cylinder head	M8	27 Nm (19.9 lbf ft)	–
Screw, kick starter	M8	25 Nm (18.4 lbf ft)	Loctite® 2701™
Nut, cylinder base	M10	35 Nm (25.8 lbf ft)	–
Drain plug, water pump cover	M10x1	15 Nm (11.1 lbf ft)	–
Nut, rotor	M12x1	60 Nm (44.3 lbf ft)	–
Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Spark plug	M14x1.25	25 Nm (18.4 lbf ft)	–
Nut, inner clutch hub	M18x1.5	120 Nm (88.5 lbf ft)	Loctite® 648™
Nut, primary gear	M18LHx1.5	150 Nm (110.6 lbf ft)	Loctite® 648™

20.3 Carburetor**20.3.1 TC 125**

Carburetor type	KEIHIN PWK 38S AG
Carburetor identification number	BS5_0
Needle position	3rd position from top
Jet needle	N1EF (N1EE, N1EG)
Main jet	182 (180, 185)
Idling jet	50 (48, 52)
Starting jet	85
Idle air adjusting screw	
Open	2 turns
Throttle slide	7 with cut-out

20.3.2 Carburetor - basic setting for sandy surfaces (TC 125)

Idle air adjusting screw	
Open	1 turn
Idling jet	52
Jet needle	N1EE
Needle position	4th position from top
Main jet	192

**Info**

If the engine is not running smoothly, use a smaller main jet.

20.3.3 Carburetor tuning (TC 125)

KEIHIN PWK 38S AG							
M/FT ASL ↓	TEMP →	-20°C ... -7°C -2°F ... 20°F	-6°C ... 5°C 19°F ... 41°F	6°C ... 15°C 42°F ... 60°F	16°C ... 24°C 61°F ... 78°F	25°C ... 36°C 79°F ... 98°F	37°C ... 49°C 99°F ... 120°F
3.000 m 10,000 ft ↑ 2.301 m 7,501 ft	ASO IJ NDL POS MJ	2 50 N1E F 3 182	2 48 N1E F 3 182	2 48 N1E G 3 180	2 45 N1E G 3 178	2 45 N1E G 2 178	
2.300 m 7,500 ft ↑ 1.501 m 5,001 ft	ASO IJ NDL POS MJ	2 52 N1E F 3 185	2 50 N1E F 3 182	2 48 N1E F 3 182	2 48 N1E G 3 180	2 45 N1E G 3 178	2 45 N1E G 2 178
1.500 m 5,000 ft ↑ 751 m 2,501 ft	ASO IJ NDL POS MJ	2 52 N1E F 4 185	2 52 N1E F 3 185	2 50 N1E F 3 182	2 48 N1E F 3 182	2 48 N1E G 3 180	2 45 N1E G 3 178
750 m 2,500 ft ↑ 301 m 1,001 ft	ASO IJ NDL POS MJ	2 52 N1E E 4 188	2 52 N1E F 4 185	2 52 N1E F 3 185	2 50 N1E F 3 182	2 48 N1E F 3 182	2 48 N1E G 3 180
300 m 1,000 ft ↑ 0 m 0 ft	ASO IJ NDL POS MJ	1 52 N1E E 4 190	2 52 N1E E 4 188	2 52 N1E F 4 185	2 52 N1E F 3 185	2 50 N1E F 3 182	2 48 N1E F 3 182

402548-01

M/FT ASL	Sea level
TEMP	Temperature
ASO	Idle air adjusting screw open
IJ	Idling jet
NDL	Needle
POS	Needle position from above
MJ	Main jet



Info

Not for sandy surfaces

20.3.4 TC 250

Carburetor type	KEIHIN PWK 36S AG
Carburetor identification number	BS8_0
Needle position	4th position from top
Jet needle	N1EH (N1EF, N1EG)
Main jet	158 (160, 162)
Idling jet	42 (45)
Starting jet	85
Idle air adjusting screw	
Open	2 turns
Throttle slide	6.5 with cut-out

20.3.5 Carburetor - basic setting for sandy surfaces (TC 250)

Idle air adjusting screw	
Open	1.5 turns
Idling jet	45
Jet needle	N1EF
Needle position	5th position from top
Main jet	170

**Info**

If the engine is not running smoothly, use a smaller main jet.

20.3.6 Carburetor tuning (TC 250)

KEIHIN PWK 36S AG							
M/FT ASL ↓	TEMP →	-20°C ... -7°C -2°F ... 20°F	-6°C ... 5°C 19°F ... 41°F	6°C ... 15°C 42°F ... 60°F	16°C ... 24°C 61°F ... 78°F	25°C ... 36°C 79°F ... 98°F	37°C ... 49°C 99°F ... 120°F
3.000 m 10,000 ft ↑ 2.301 m 7,501 ft	ASO IJ NDL POS MJ	2 42 N1E G 4 158	2 42 N1E H 4 158	2 42 N1E H 3 158	2 40 N1E I 3 155	2 40 N1E I 2 155	
2.300 m 7,500 ft ↑ 1.501 m 5,001 ft	ASO IJ NDL POS MJ	2 45 N1E G 4 160	2 42 N1E G 4 158	2 42 N1E H 4 158	2 42 N1E H 3 158	2 40 N1E I 3 155	2 40 N1E I 2 155
1.500 m 5,000 ft ↑ 751 m 2,501 ft	ASO IJ NDL POS MJ	2 45 N1E F 4 162	2 45 N1E G 4 160	2 42 N1E G 4 158	2 42 N1E H 4 158	2 42 N1E H 3 158	2 40 N1E I 3 155
750 m 2,500 ft ↑ 301 m 1,001 ft	ASO IJ NDL POS MJ	1,5 48 N1E F 4 165	2 45 N1E F 4 162	2 45 N1E G 4 160	2 42 N1E G 4 158	2 42 N1E H 4 158	2 42 N1E H 3 158
300 m 1,000 ft ↑ 0 m 0 ft	ASO IJ NDL POS MJ	1,5 48 N1E E 5 168	1,5 48 N1E F 4 165	2 45 N1E F 4 162	2 45 N1E G 4 160	2 42 N1E G 4 158	2 42 N1E H 4 158

402550-01


M/FT ASL	Sea level
TEMP	Temperature
ASO	Idle air adjusting screw open
IJ	Idling jet
NDL	Needle
POS	Needle position from top
MJ	Main jet



Info

Not for sandy surfaces

20.3.7 General carburetor tuning 🐞



1... 5

Needle position from top

The five possible needle positions are shown here.

The carburetor tuning depends on the defined ambient and operating conditions.

20.4 Capacities

20.4.1 Gear oil

Gear oil	0.8 l (0.8 qt.)	Engine oil (SAE 10W/40) (🐞 p. 115)
----------	-----------------	------------------------------------

20.4.2 Coolant

Coolant	1.2 l (1.3 qt.)	Coolant (🐞 p. 115)
---------	-----------------	--------------------

20.4.3 Fuel

Total fuel tank capacity, approx. (TC 125)	7 l (1.8 US gal)	Super unleaded (98 octane) mixed with 2-stroke engine oil (1:40) (🐞 p. 116)
Total fuel tank capacity, approx. (TC 250)	7.5 l (1.98 US gal)	Super unleaded (95 octane) mixed with 2-stroke engine oil (1:60) (🐞 p. 116)

20.5 Chassis

Frame	Central tube frame made of chrome molybdenum steel tubing	
Fork (TC 125)	WP Performance Systems Up Side Down 4860 MXMA 4CS	
Fork (TC 250)	WP Performance Systems Upside down 4860 MXMA 4CS	
Suspension travel (TC 125)		
Front	300 mm (11.81 in)	
Rear	300 mm (11.81 in)	
Suspension travel (TC 250)		
Front	300 mm (11.81 in)	
Rear	317 mm (12.48 in)	
Fork offset	22 mm (0.87 in)	
Shock absorber (TC 125)	WP Performance Systems 5018 DCC Link	
Shock absorber (TC 250)	WP Performance Systems 5018 DCC Link	
Brake system	Disc brakes, brake calipers on floating bearings	
Brake discs - diameter		
Front	260 mm (10.24 in)	
Rear	220 mm (8.66 in)	
Brake discs - wear limit		
Front	2.5 mm (0.098 in)	
Rear	3.5 mm (0.138 in)	
Tire air pressure off road		
Front	1.0 bar (15 psi)	
Rear	1.0 bar (15 psi)	
Secondary ratio (TC 125)	1:50 PM	
Secondary ratio (TC 250)	1:48 PM	
Chain	5/8 x 1/4"	
Rear sprockets available	48, 50, 52	

Steering head angle (TC 125)	63.9°
Steering head angle (TC 250)	63.5°
Wheelbase (TC 125)	1,485±10 mm (58.46±0.39 in)
Wheelbase (TC 250)	1,495±10 mm (58.86±0.39 in)
Seat height unloaded (TC 125)	960 mm (37.8 in)
Seat height unloaded (TC 250)	992 mm (39.06 in)
Ground clearance unloaded (TC 125)	375 mm (14.76 in)
Ground clearance unloaded (TC 250)	385 mm (15.16 in)
Weight without fuel, approx. (TC 125)	89.1 kg (196.4 lb.)
Weight without fuel, approx. (TC 250)	97.7 kg (215.4 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)
Maximum permissible overall weight	335 kg (739 lb.)

20.6 Tires

Validity	Front tires	Rear tires
(TC 125)	80/100 - 21 51M TT Dunlop GEOMAX MX52 F	100/90 - 19 57M TT Dunlop Geomax MX52
(TC 250)	80/100 - 21 51M TT Dunlop GEOMAX MX52 F	110/90 - 19 62M TT Dunlop Geomax MX52

Additional information is available in the Service section under:
www.husqvarna-motorcycles.com

20.7 Fork

20.7.1 TC 125

Fork part number	24.18.7P.51
Fork	WP Performance Systems Up Side Down 4860 MXMA 4CS
Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring length with preload spacer(s)	475 mm (18.7 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	4.0 N/mm (22.8 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	4.2 N/mm (24 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	4.4 N/mm (25.1 lb/in)
Fork length	940 mm (37.01 in)
Air chamber length	60 mm (2.36 in)

Oil capacity per fork leg	685 ml (23.16 fl. oz.)	Fork oil (SAE 4) (48601166S1) (☛ p. 115)
---------------------------	------------------------	--

20.7.2 TC 250

Fork part number	24.18.7O.53
Fork	WP Performance Systems Upside down 4860 MXMA 4CS
Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

Rebound damping		
Comfort		17 clicks
Standard		15 clicks
Sport		13 clicks
Spring length with preload spacer(s)		480 mm (18.9 in)
Spring rate		
Weight of rider: 65... 75 kg (143... 165 lb.)		4.4 N/mm (25.1 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)		4.6 N/mm (26.3 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)		4.8 N/mm (27.4 lb/in)
Fork length		940 mm (37.01 in)
Air chamber length		68 mm (2.68 in)
Oil capacity per fork leg	665 ml (22.48 fl. oz.)	Fork oil (SAE 4) (48601166S1) (🔧 p. 115)

20.8 Shock absorber

20.8.1 TC 125

Shock absorber article number	18.18.7P.51
Shock absorber	WP Performance Systems 5018 DCC Link
Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring preload	7 mm (0.28 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	39 N/mm (223 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	42 N/mm (240 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	45 N/mm (257 lb/in)
Spring length	247 mm (9.72 in)
Gas pressure	10 bar (145 psi)
Static sag	40 mm (1.57 in)
Riding sag	110 mm (4.33 in)
Fitted length	477 mm (18.78 in)
Shock absorber fluid (🔧 p. 116)	SAE 2.5

20.8.2 TC 250

Shock absorber part number	18.18.7O.53
Shock absorber	WP Performance Systems 5018 DCC Link
Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Compression damping, high-speed	
Comfort	2.5 turns

Standard	2 turns
Sport	1.5 turns
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring preload	8 mm (0.31 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	51 N/mm (291 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	54 N/mm (308 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	57 N/mm (325 lb/in)
Spring length	260 mm (10.24 in)
Gas pressure	10 bar (145 psi)
Static sag	30 mm (1.18 in)
Riding sag	100 mm (3.94 in)
Fitted length	490 mm (19.29 in)
Shock absorber fluid (☛ p. 116)	SAE 2.5

20.9 Chassis tightening torques

Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)	–
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)	–
Remaining nuts, chassis	M5	5 Nm (3.7 lbf ft)	–
Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)	–
Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)	–
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)	–
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)	–
Screw, ball joint of push rod on foot brake cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, front brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, throttle grip	M6	5 Nm (3.7 lbf ft)	–
Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)	–
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft)	Loctite® 2701™
Nut, rim lock	M8	12 Nm (8.9 lbf ft)	–
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)	–
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)	–
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)	–
Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)	–
Screw, engine brace	M8	33 Nm (24.3 lbf ft)	Loctite® 2701™
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	–
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	–
Screw, subframe	M8x20	30 Nm (22.1 lbf ft)	Loctite® 2701™
Screw, subframe	M8x30	30 Nm (22.1 lbf ft)	Loctite® 2701™
Screw, top steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)	–
Engine bracket screw	M10	60 Nm (44.3 lbf ft)	–
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)	–
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)	–
Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	Loctite® 243™

Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
Nut, frame on linkage lever	M14x1.5	80 Nm (59 lbf ft)	–
Nut, linkage lever on swingarm	M14x1.5	80 Nm (59 lbf ft)	–
Nut, linkage lever to angle lever	M14x1.5	80 Nm (59 lbf ft)	–
Nut, swingarm pivot	M16x1.5	100 Nm (73.8 lbf ft)	–
Nut, rear wheel spindle (TC 250)	M20x1.5	80 Nm (59 lbf ft)	–
Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)	–
Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)	–
Screw-in nozzles, cooling system	M20x1.5	12 Nm (8.9 lbf ft)	Loctite® 243™
Nut, rear wheel spindle (TC 125)	M25x1.5	80 Nm (59 lbf ft)	–

Brake fluid DOT 4**Standard/classification**

- DOT

Guideline

- Use only brake fluid that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties.

Recommended supplier**Bel-Ray®**

- **Super DOT 4 Brake Fluid**

Coolant**Guideline**

- Only use high quality coolant with corrosion inhibitor for aluminum motors (even in countries with high temperatures). Using inferior antifreeze can result in corrosion and foaming.

Mixture ratio

Antifreeze protection: -25... -45 °C (-13... -49 °F)	anti-corrosion/antifreeze distilled water
--	--

Recommended supplier**Bel-Ray®**

- **Moto Chill Racing Coolant**

Engine oil (SAE 10W/40)**Standard/classification**

- JASO T903 MA (☛ p. 118)
- SAE (☛ p. 118) (SAE 10W/40)

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

mineral engine oil

Recommended supplier**Bel-Ray®**

- **EXL Mineral 4T**

Engine oil, 2-stroke**Standard/classification**

- JASO FD (☛ p. 118)

Guideline

- Only use high grade 2-stroke engine oil of a reputable brand.

Synthetic engine oil

Recommended supplier**Bel-Ray®**

- **Si-7 Synthetic 2T**

Fork oil (SAE 4) (48601166S1)**Standard/classification**

- SAE (☛ p. 118) (SAE 4)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Shock absorber fluid (SAE 2.5) (50180751S1)

Standard/classification

- SAE (☛ p. 118) (SAE 2.5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Super unleaded (ROZ 98 / RON 98 / PON 94)

Standard/classification

- DIN EN 228 (ROZ 98 / RON 98 / PON 94)

Super unleaded (ROZ 95/RON 95/PON 91)

Standard/classification

- DIN EN 228 (ROZ 95/RON 95/PON 91)

Guideline

- Only use unleaded super fuel that matches or is equivalent to the specified fuel grade.
- Fuel with an ethanol content of up to 10 % (E10 fuel) is safe to use.



Info

Do **not** use fuel containing methanol (e. g. M15, M85, M100) or more than 10 % ethanol (e. g. E15, E25, E85, E100).

Super unleaded (95 octane) mixed with 2-stroke engine oil (1:60)

Standard/classification

- DIN EN 228
- JASO FD (☛ p. 118) (1:60)

Mixture ratio

1:60	Engine oil, 2-stroke (☛ p. 115) Super unleaded (ROZ 95/RON 95/PON 91) (☛ p. 116)
------	---

Recommended supplier

Bel-Ray®

- Si-7 Synthetic 2T

Super unleaded (98 octane) mixed with 2-stroke engine oil (1:40)

Standard/classification

- DIN EN 228
- JASO FD (☛ p. 118) (1:40)

Mixture ratio

1:40	Engine oil, 2-stroke (☛ p. 115) Super unleaded (ROZ 98 / RON 98 / PON 94) (☛ p. 116)
------	---

Recommended supplier

Bel-Ray®

- Si-7 Synthetic 2T

Air filter cleaning agent

Recommended supplier

Bel-Ray®

- Foam Filter Cleaner & Degreaser

Grip adhesive (00062030051)

Recommended supplier

KTM AG

- GRIP GLUE

High viscosity grease

Recommended supplier

SKF®

- LGHB 2

Long-life grease

Recommended supplier

Bel-Ray®

- Waterproof Grease

Offroad chain spray

Guideline

Recommended supplier

Bel-Ray®

- Blue Tac Chain Lube

Oil for foam air filter

Recommended supplier

Bel-Ray®

- Foam Filter Oil

Preserving materials for paints, metal and rubber

Recommended supplier

Bel-Ray®

- Silicone Detailer & Protectant Spray

Universal oil spray

Recommended supplier

Bel-Ray®

- 6 in 1

JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles – the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. In most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

JASO FD

JASO FD is a classification for a 2-stroke engine oil that was specifically developed for the extreme demands of racing. Thanks to first rate synthetic esters and specially designed additives, superb combustion is achieved even under extreme operating conditions.

Art. no.	Article number
ca.	circa
cf.	compare
e.g.	for example
etc.	et cetera
i.a.	inter alia
no.	number
poss.	possibly

A	
Accessories	8
Air filter	
cleaning	51
installing	51
removing	50
Air filter box	
cleaning	51
sealing	52
Air filter box cover	
installing	50
removing	49
Antifreeze	
checking	85
Auxiliary substances	8
B	
Basic chassis setting	
checking with rider's weight	28
Brake discs	
checking	69
Brake fluid	
front brake, adding	70
rear brake, adding	75
Brake fluid level	
front brake, checking	70
rear brake, checking	74
Brake linings	
front brake, changing	71
front brake, checking	71
rear brake, changing	76
rear brake, checking	76
C	
Capacity	
Coolant	87-88, 110
Gear oil	97, 110
Carburetor	90
float chamber, emptying	91
idle speed, adjusting	90
Chain	
checking	60
cleaning	58
Chain guide	
checking	60
Chain tension	
adjusting	59
checking	59
Chassis number	11
Choke	14
Clutch	
fluid level, checking/correcting	66
fluid, changing	67
Clutch lever	12
basic position, adjusting	66

Compression damping	
fork, adjusting	35
Compression damping, low-speed	
shock absorber, adjusting	28
Coolant	
draining	86
refilling	87
Coolant level	
checking	85-86
Cooling system	84
Customer service	8
D	
Difficult operating conditions	
high temperatures	20
riding at low speeds	20
Difficult riding conditions	17
dry sand	17
low temperature	21
muddy surfaces	20
snow	21
wet sand	19
wet surfaces	20
E	
Engine	
running in	17
Engine characteristic	
auxiliary spring	93
auxiliary spring, setting	93
Engine number	11
Engine sprocket	
checking	60
Environment	7
F	
Figures	8
Filler cap	
closing	13
opening	13
Foot brake lever	15
basic position, adjusting	73
free travel, checking	73
Fork	
basic setting, checking	34
Fork legs	
bleeding	37
dust boots, cleaning	37
installing	39
removing	38
Fork part number	11
Fork protector	
installing	38
removing	38
Frame	
checking	63

Front fender

installing	44
removing	44

Front wheel

installing	79
removing	79

Fuel tank

installing	57
removing	55

Fuel tap

G

Gear oil

adding	97
changing	95
draining	96
refilling	97

Gear oil level

checking	95
----------	----

H

Hand brake lever

basic position, adjusting	69
free travel, checking	69

Handlebar position

adjusting	36
-----------	----

High Speed compression damping

shock absorber, adjusting	29
---------------------------	----

I

Ignition timing map

changing	92
plug-in connector	92

Implied warranty

Intended use

K

Kick starter

Kill switch

L

Lower triple clamp

installing	40
removing	39

M

Main silencer

glass fiber yarn filling, changing	53
installing	53
removing	52

Map-Select switch

Motorcycle

cleaning	99
lift stand, raising with	37
lift stand, removing from	37

O

Operating substances

Owner's Manual

P

Plug-in stand

Preparing for use

advice on first use	16
after storage	100
checks and maintenance work when preparing for use	22

Protective clothing

R

Radiator cover

installing	84
removing	85

Rear sprocket

checking	60
----------	----

Rear wheel

installing	81
removing	80

Rebound damping

fork, adjusting	35
shock absorber, adjusting	30

Refueling

fuel	25
------	----

Riding sag

adjusting	34
-----------	----

Right side cover

installing	55
removing	54

Rubber grip

checking	65
securing	65

S

Safe operation

Seat

mounting	49
removing	48

Service

Shift lever

basic position, adjusting	93
basic position, checking	92

Shock absorber

compression damping, general	28
installing	46
removing	44
riding sag, checking	32
spring preload, adjusting	33
static sag, checking	31

Shock absorber article number

Spare parts

Spoke tension

checking	83
----------	----

Start number plate

installing	43
removing	43

Starting

Steering head bearing

greasing 43

Steering head bearing play

adjusting 42

checking 42

Storage 100

Swingarm

checking 64

T

Technical data

capacities 110

carburetor 106

chassis 110

chassis tightening torques 113

engine 103

engine tightening torques 104

fork 111

shock absorber 112

tires 111

Throttle cable play

adjusting 89

checking 89

Throttle cable routing

checking 64

Throttle grip 12

Tire air pressure

checking 83

Tire condition

checking 82

Transport 24

Troubleshooting 101-102

Type label 11

U

Use definition 6

V

View of vehicle

front left 9

rear right 10

W

Warranty 8

Work rules 7



3402058en

07/2015

