

OWNER'S MANUAL 2016



FC 350

Art. no. 3402060en

DEAR HUSQVARNA MOTORCYCLES CUSTOMER

1

Congratulations on your decision to purchase a Husqvarna motorcycle. You are now the owner of a state-of-the-art sports motorcycle that will give you enormous pleasure if you service and maintain it accordingly.

We wish you a lot of enjoyment in riding this vehicle.

Enter the serial numbers of your vehicle below.

Chassis number (☛ p. 10)	Dealer's stamp
Engine number (☛ p. 10)	

The Owner's Manual contained the latest information for this model series at the time of going to print. Slight deviations resulting from continuing development and design can, however, not be completely excluded.

All specifications are non-binding. Husqvarna Motorcycles GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. Husqvarna Motorcycles accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2015 Husqvarna Motorcycles GmbH, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

Husqvarna Motorcycles applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.

Issued by: TÜV Management Service

REG.NO. 12 100 6061

Husqvarna Motorcycles GmbH
5230 Mattighofen, Austria

This document is valid for the following models:

FC 350 (F2201P1)



3402060en

09/2015

TABLE OF CONTENTS

2

1	MEANS OF REPRESENTATION.....	4	7.9	Preparing for rides at low temperature and in snow	19
1.1	Symbols used	4	8	RIDING INSTRUCTIONS	20
1.2	Formats used	4	8.1	Checks and maintenance work when preparing for use.....	20
2	SAFETY ADVICE	5	8.2	Starting	20
2.1	Use definition – intended use	5	8.3	Activating Launch Control	21
2.2	Safety advice	5	8.4	Starting off	21
2.3	Degrees of risk and symbols	5	8.5	Shifting, riding.....	21
2.4	Tampering warning	5	8.6	Applying the brakes	22
2.5	Safe operation.....	5	8.7	Stopping, parking	22
2.6	Protective clothing	6	8.8	Transport.....	22
2.7	Work rules.....	6	8.9	Refueling	23
2.8	Environment	6	9	SERVICE SCHEDULE.....	24
2.9	Owner's Manual.....	6	9.1	Additional information.....	24
3	IMPORTANT NOTES	7	9.2	Required work.....	24
3.1	Manufacturer and implied warranty	7	9.3	Recommended work.....	25
3.2	Operating and auxiliary substances	7	10	TUNING THE CHASSIS.....	26
3.3	Spare parts, accessories	7	10.1	Checking the basic chassis setting with the rider's weight	26
3.4	Service	7	10.2	Compression damping of the shock absorber ...	26
3.5	Figures	7	10.3	Adjusting the low-speed compression damping of the shock absorber.....	26
3.6	Customer service.....	7	10.4	Adjusting the high-speed compression damping of the shock absorber.....	27
4	VIEW OF VEHICLE	8	10.5	Adjusting the rebound damping of the shock absorber.....	27
4.1	View of vehicle, front left (example)	8	10.6	Measuring the rear wheel dimension unloaded	28
4.2	View of vehicle, rear right (example)	9	10.7	Checking the static sag of the shock absorber.....	28
5	SERIAL NUMBERS.....	10	10.8	Checking the riding sag of the shock absorber.....	29
5.1	Chassis number	10	10.9	Adjusting the spring preload of the shock absorber 🏍.....	29
5.2	Type label.....	10	10.10	Adjusting the riding sag 🏍.....	30
5.3	Engine number.....	10	10.11	Checking the basic setting of the fork.....	30
5.4	Fork part number	10	10.12	Adjusting the compression damping of the fork.....	30
5.5	Shock absorber article number	10	10.13	Adjusting the rebound damping of the fork	31
6	CONTROLS	11	10.14	Handlebar position.....	31
6.1	Clutch lever.....	11	10.15	Adjusting the handlebar position 🏍.....	31
6.2	Hand brake lever.....	11	11	SERVICE WORK ON THE CHASSIS	33
6.3	Throttle grip.....	11	11.1	Raising the motorcycle with a lift stand.....	33
6.4	Kill switch.....	11	11.2	Removing the motorcycle from the lift stand.....	33
6.5	Electric starter button	11	11.3	Bleeding the fork legs.....	33
6.6	Map-Select switch for the basic setting	12	11.4	Cleaning the dust boots of the fork legs.....	34
6.7	Map-Select switch for ride mode.....	12	11.5	Removing the fork protector	34
6.8	Launch control.....	12	11.6	Installing the fork protector.....	34
6.9	Overview of indicator lamps	12	11.7	Removing the fork legs 🏍.....	35
6.10	Opening the filler cap.....	13	11.8	Installing the fork legs 🏍.....	35
6.11	Closing the filler cap	13	11.9	Removing the lower triple clamp 🏍.....	36
6.12	Cold start button.....	14	11.10	Installing the lower triple clamp 🏍.....	36
6.13	Idle speed adjusting screw	14	11.11	Checking the steering head bearing play	38
6.14	Shift lever	14	11.12	Adjusting the steering head bearing play 🏍.....	39
6.15	Foot brake lever	15	11.13	Greasing the steering head bearing 🏍.....	39
6.16	Plug-in stand.....	15	11.14	Removing the start number plate	39
7	PREPARING FOR USE.....	16	11.15	Installing the start number plate	39
7.1	Advice on first use	16	11.16	Removing the front fender.....	40
7.2	Running in the engine	17	11.17	Installing the front fender	40
7.3	Starting power of lithium-ion batteries at low temperatures.....	17	11.18	Removing the shock absorber 🏍.....	40
7.4	Preparing the vehicle for difficult riding conditions	17			
7.5	Preparing for rides on dry sand	18			
7.6	Preparing for rides on wet sand.....	18			
7.7	Preparing for rides on wet and muddy surfaces	19			
7.8	Preparing for rides at high temperature and slow speed.....	19			

11.19	Installing the shock absorber 	42	14.3	Recharging the battery 	72
11.20	Removing the seat	43	14.4	Main fuse, changing.....	73
11.21	Mounting the seat	44	15	COOLING SYSTEM	75
11.22	Removing the air filter box cover	44	15.1	Cooling system	75
11.23	Installing the air filter box cover	44	15.2	Checking the antifreeze and coolant level.....	75
11.24	Removing the air filter 	45	15.3	Checking the coolant level.....	76
11.25	Installing the air filter 	45	15.4	Draining the coolant 	76
11.26	Cleaning the air filter and air filter box 	45	15.5	Refilling coolant 	77
11.27	Removing the main silencer.....	46	16	TUNING THE ENGINE	78
11.28	Installing the main silencer.....	46	16.1	Checking the play in the throttle cable	78
11.29	Changing the glass fiber yarn filling of the main silencer 	46	16.2	Adjusting the play in the throttle cable 	78
11.30	Removing the right side cover	47	16.3	Setting the characteristic map of the throttle response 	79
11.31	Installing the right side cover	47	16.4	Changing the mapping	80
11.32	Removing the fuel tank 	48	16.5	Adjusting the idle speed 	80
11.33	Installing the fuel tank 	49	16.6	Program throttle valve position.....	80
11.34	Checking for chain dirt accumulation	50	16.7	Checking the basic position of the shift lever.....	81
11.35	Cleaning the chain	50	16.8	Adjusting the basic position of the shift lever 	81
11.36	Checking the chain tension	51	17	SERVICE WORK ON THE ENGINE	82
11.37	Adjusting the chain tension.....	51	17.1	Changing the fuel screen 	82
11.38	Checking the chain, rear sprocket, motor sprocket, and chain guide	52	17.2	Checking the engine oil level	82
11.39	Checking the frame 	53	17.3	Changing the engine oil and oil filter, cleaning the oil screen 	83
11.40	Checking the swingarm 	54	17.4	Adding engine oil	85
11.41	Checking the throttle cable routing	54	18	CLEANING, CARE	86
11.42	Checking the rubber grips	54	18.1	Cleaning the motorcycle	86
11.43	Adjusting the basic position of the clutch lever	55	19	STORAGE.....	87
11.44	Checking/correcting the fluid level of the hydraulic clutch.....	55	19.1	Storage	87
11.45	Changing the hydraulic clutch fluid 	55	19.2	Preparing for use after storage	87
12	BRAKE SYSTEM	57	20	TROUBLESHOOTING	88
12.1	Checking the free travel of the hand brake lever	57	21	BLINK CODE	90
12.2	Adjusting the basic position of the hand brake lever	57	22	TECHNICAL DATA	92
12.3	Checking the brake discs	57	22.1	Engine	92
12.4	Checking the brake fluid level of the front brake	58	22.2	Engine tightening torques.....	92
12.5	Adding front brake fluid 	58	22.3	Capacities	94
12.6	Checking the front brake linings	59	22.3.1	Engine oil.....	94
12.7	Changing the front brake linings 	59	22.3.2	Coolant.....	94
12.8	Checking the free travel of foot brake lever.....	61	22.3.3	Fuel.....	94
12.9	Adjusting the basic position of the foot brake lever 	61	22.4	Chassis	94
12.10	Checking the rear brake fluid level	62	22.5	Electrical system	95
12.11	Adding rear brake fluid 	62	22.6	Tires	95
12.12	Checking the rear brake linings	63	22.7	Fork.....	95
12.13	Changing the rear brake linings 	64	22.8	Shock absorber	95
13	WHEELS, TIRES	66	22.9	Chassis tightening torques	96
13.1	Removing the front wheel 	66	23	SUBSTANCES.....	98
13.2	Installing the front wheel 	66	24	AUXILIARY SUBSTANCES.....	99
13.3	Removing the rear wheel 	67	25	STANDARDS	100
13.4	Installing the rear wheel 	68	26	INDEX OF SPECIAL TERMS	101
13.5	Checking the tire condition.....	68	27	LIST OF ABBREVIATIONS	102
13.6	Checking the tire air pressure.....	69	28	LIST OF SYMBOLS	103
13.7	Checking the spoke tension	69	28.1	Yellow and orange symbols.....	103
14	ELECTRICAL SYSTEM.....	71	INDEX		104
14.1	Removing the battery 	71			
14.2	Installing the battery 	71			

1.1 Symbols used

The meaning of specific symbols is described below.

	Indicates an expected reaction (e.g. of a work step or a function).
	Indicates an unexpected reaction (e.g. of a work step or a function).
	All work marked with this symbol requires specialist knowledge and technical understanding. In the interests of your own safety, have these jobs performed by an authorized Husqvarna Motorcycles workshop. There, your motorcycle will be optimally cared for by specially trained experts using the specialist tools required.
	Indicates a page reference (more information is provided on the specified page).
	Indicates information with more details or tips.
	Indicates the result of a testing step.

1.2 Formats used

The typographical formats used in this document are explained below.

Proprietary name	Indicates a proprietary name.
Name[®]	Indicates a protected name.
Brand[™]	Indicates a brand available on the open market.
<u>Underlined terms</u>	Refer to technical details of the vehicle or indicate technical terms, which are explained in the glossary.

2.1 Use definition – intended use

Husqvarna motorcycles are designed and built to withstand the normal stresses and strains of competitive use. The motorcycles comply with currently valid regulations and categories of the top international motorsport organizations.



Info

The motorcycle may only be used in closed off areas remote from public road traffic.

2.2 Safety advice

A number of safety instructions need to be followed to operate the vehicle safely. Therefore, read this manual carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.



Info

The vehicle has various information and warning labels at prominent locations. Do not remove information/warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.3 Degrees of risk and symbols



Danger

Indicates a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Indicates a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Indicates a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Indicates a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



Warning

Indicates a danger that will lead to environmental damage if the appropriate measures are not taken.

2.4 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

- 1 The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- 1 Removal or puncturing of the main silencer, baffles, header pipes or any other components which conduct exhaust gases.
- 2 Removal or puncturing of parts of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing moving part of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

2.5 Safe operation



Danger

Danger of accidents Danger arising from the rider's judgement being impaired.

- Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.

The vehicle should only be used by trained persons.

Have malfunctions that impair safety promptly eliminated by an authorized Husqvarna Motorcycles workshop.

Adhere to the information and warning labels on the vehicle.

2.6 Protective clothing



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.

In the interest of your own safety, Husqvarna Motorcycles recommends that you only operate the vehicle while wearing protective clothing.

2.7 Work rules

Special tools are necessary for certain tasks. The tools are not contained in the vehicle but can be ordered under the number in parentheses. E.g.: bearing puller (15112017000)

During assembly, non-reusable parts (e.g. self-locking screws and nuts, seals and seal rings, O-rings, pins, lock washers) must be replaced by new parts.

In some instances, a thread locker (e.g. **Loctite**®) is required. The manufacturer instructions for use must be followed.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.

After you complete the repair or service work, check the operating safety of the vehicle.

2.8 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and regulations of the respective country.

Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

2.9 Owner's Manual

It is important that you read this Owner's Manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and maintain your motorcycle. Only then will you find out how to customize the vehicle ideally for your own use and how you can protect yourself from injury.

Keep the Owner's Manual in an accessible place to enable you to refer to it as needed.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized Husqvarna Motorcycles dealer.

The Owner's Manual is an important component of the vehicle and must be handed over to the new owner if the vehicle is sold.

3.1 Manufacturer and implied warranty

The work prescribed in the service schedule must be carried out by an authorized Husqvarna Motorcycles workshop only and confirmed both in the customer's Service & Warranty Booklet and in the **Husqvarna Motorcycles Dealer.net**; otherwise, all warranty claims will be void. No warranty claims can be considered for damage or secondary damage resulting from modifications and/or alterations to the vehicle.

Additional information on the manufacturer or implied warranty and the procedures involved can be found in the service & warranty booklet.

3.2 Operating and auxiliary substances



Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.

Use operating and auxiliary substances (such as fuel and lubricants) as specified in the Owner's Manual.

3.3 Spare parts, accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by Husqvarna Motorcycles and have them installed by an authorized Husqvarna Motorcycles workshop. Husqvarna Motorcycles accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessory products are specified in parentheses in the descriptions. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

The current Husqvarna Motorcycles accessories for your vehicle can be found on the Husqvarna Motorcycles website.
International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. Incorrect adjustment and tuning of the engine and chassis can lead to damage and breakage of components.

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

3.5 Figures

The figures contained in the manual may depict special equipment.

In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.

3.6 Customer service

Your authorized Husqvarna Motorcycles dealer will be happy to answer any questions you may have regarding your vehicle and Husqvarna Motorcycles.

A list of authorized Husqvarna Motorcycles dealers can be found on the Husqvarna Motorcycles website.
International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

4.1 View of vehicle, front left (example)



120356-10


1	Hand brake lever (☞ p. 11)
2	Fork compression adjustment
3	Clutch lever (☞ p. 11)
4	Filler cap
5	Plug-in stand (☞ p. 15)
6	Air filter box cover
7	Cold start button (☞ p. 14)
8	Engine number (☞ p. 10)
9	Shift lever (☞ p. 14)

4.2 View of vehicle, rear right (example)




1	Kill switch (☞ p. 11)
2	Electric starter button (☞ p. 11)
3	Throttle grip (☞ p. 11)
4	Fork rebound adjustment
5	Fork part number (☞ p. 10)
6	Foot brake lever (☞ p. 15)
7	Level viewer, engine oil
8	Shock absorber compression adjustment
9	Shock absorber rebound adjustment

5.1 Chassis number




The chassis number ❶ is stamped on the right side of the steering head.

5.2 Type label




The type label ❶ is fixed to the front of the steering head.

5.3 Engine number




Engine number ❶ is stamped onto the engine case at the top near the engine sprocket.

5.4 Fork part number




The fork part number ❶ is stamped on the inner side of the axle clamp.

5.5 Shock absorber article number




The shock absorber article number ❶ is stamped on the top of the shock absorber above the adjusting ring towards the engine side.

6.1 Clutch lever




The clutch lever **1** is fitted on the left side of the handlebar. The clutch is hydraulically operated and self-adjusting.

6.2 Hand brake lever




Hand brake lever **1** is fitted on the right side of the handlebar. The front brake is engaged using the hand brake lever.

6.3 Throttle grip



The throttle grip **1** is fitted on the right side of the handlebar.

6.4 Kill switch



Kill switch **1** is fitted on the left side of the handlebar.

Possible states

- Kill switch  in basic position – In this position, the ignition circuit is closed and the engine can be started.
- Kill switch  pressed – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

6.5 Electric starter button




Electric starter button **1** is fitted on the right side of the handlebar.

Possible states

- Electric starter button  in basic position
- Electric starter button  pressed – In this position, the electric starter is actuated.

6.6 Map-Select switch for the basic setting




The **Map-Select** switch for the basic setting ❶ is fitted under the air filter box cover.

Possible states

1	SOFT – Mapping for softer response is activated. The Launch Control can be activated.
2	ADVANCED – Mapping for direct response is activated. The Launch Control can be activated.
3 - 9, 0	STANDARD – Mapping for balanced response is activated. The Launch Control cannot be activated.

The **Map-Select** switch for the basic setting is used to preselect the engine characteristics.

6.7 Map-Select switch for ride mode



The **Map-Select** switch for vehicle operation ❶ is fitted on the right side of the handlebar.

Possible states

I	STANDARD – In this position, STANDARD mapping is always activated.
II	SOFT or ADVANCED – In this position, the mapping that is set on the Map-Select switch for the basic setting is activated.

The engine characteristics can be changed on the handlebar using the **Map-Select** switch for vehicle operation. This change is activated while the engine is idling or on restarting.

In addition, the **Map-Select** switch controls the **Launch Control** (☛ p. 12).

6.8 Launch control

The **Launch Control** assists the rider in optimally starting the motorcycle at the beginning of a race. The maximum speed of the engine with the throttle valve fully opened (full throttle) is reduced. After the start, it is gradually increased up to the maximum engine speed. Throughout this procedure, the rider opens the throttle fully and the best possible acceleration is achieved. The clutch must be activated exactly as it would be without an active **Launch Control**.

The Launch Control is deactivated in the following cases (FI warning lamp (MIL) no longer flashes):

- After full throttle, the throttle valve was closed by more than 1/3 of the way.
- There is no start within 3 minutes.

i Info

Several seconds after the vehicle starts, **Launch Control** is deactivated automatically.

6.9 Overview of indicator lamps



Possible states

FI	FI warning lamp (MIL) lights up/flashes orange – The OBD has detected an emission- or safety-critical fault.
FI	FI warning lamp (MIL) flashes fast in orange – The Launch Control (☛ p. 12) is activated.

6.10 Opening the filler cap



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.


- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that has been contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.



Warning


Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Turn filler cap ① counterclockwise and lift it off.

6.11 Closing the filler cap





- Mount filler cap ① and turn it clockwise until the fuel tank is tightly closed.



Info

Run the fuel tank breather hose ② without kinks.

6.12 Cold start button



120310-10

The cold start button **1** is fitted on the bottom of the throttle valve body. The injection system extends the injection time if the engine is cold and the outside temperature is low. To help the engine burn the increased amount of fuel, it must be supplied with additional oxygen by pushing the cold start button. After briefly opening up the throttle and then releasing the throttle grip again, or turning the throttle grip towards the front, the cold start button returns to its original position.


Info

Check whether the cold start button has returned to its basic position.

Possible states

- The cold start button is activated – The cold start button is pushed in all the way.
- The cold start button is deactivated – The cold start button is in its basic position.

6.13 Idle speed adjusting screw



120311-10


The idle setting of the throttle valve body has a big influence on the vehicle's starting behavior, on stable idling, and on vehicle response when the throttle is opened. An engine with a correctly set idle speed is easier to start than an engine with the idle speed set incorrectly.

The idle speed is adjusted using idle speed adjusting screw **1** (red).

Increase the idle speed by turning the idle speed adjusting screw clockwise.


Decrease the idle speed by turning the idle speed adjusting screw counterclockwise.

6.14 Shift lever




401950-10

Shift lever **1** is mounted on the left side of the engine.




The gear positions can be seen in the photograph.
The neutral or idle position is between the first and second gears.

6.15 Foot brake lever



Foot brake lever ❶ is located in front of the right footrest.
The foot brake lever is used to activate the rear brake.

6.16 Plug-in stand



The holder for the plug-in stand ❶ is the left side of the wheel spindle.
The plug-in stand is used to park the motorcycle.

i Info
Remove the plug-in stand before starting on a trip.

7.1 Advice on first use

-
-  **Danger**
Danger of accidents Danger arising from the rider's judgement being impaired.
- Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.
-  **Warning**
Risk of injury Missing or poor protective clothing presents an increased safety risk.
- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.
-  **Warning**
Danger of crashing Poor vehicle handling due to different tire tread patterns on front and rear wheels.
- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.
-  **Warning**
Danger of accidents Critical riding behavior due to inappropriate riding.
- Adapt your riding speed to the road conditions and your riding ability.
-  **Warning**
Danger of accidents Accident risk caused by presence of a passenger.
- Your vehicle is not designed to carry passengers. Do not ride with a passenger.
-  **Warning**
Danger of accidents Failure of brake system.
- If the foot brake lever is not released, the brake linings drag continuously. The rear brake may fail due to overheating. Take your foot off the foot brake lever when you are not braking.
-  **Warning**
Danger of accidents Unstable riding behavior.
- Do not exceed the maximum permissible weight and axle loads.
-  **Warning**
Risk of misappropriation Usage by unauthorized persons.
- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.
-

 **Info**
When using your motorcycle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-delivery inspection work has been carried out by an authorized Husqvarna Motorcycles workshop.
 You receive a delivery certificate and the Service and Warranty Booklet at vehicle handover.
 - Before your first trip, read the entire Owner's Manual carefully.
 - Get to know the controls.
 - Adjust the basic position of the clutch lever. (👉 p. 55)
 - Adjust the basic position of the hand brake lever. (👉 p. 57)
 - Adjust the basic position of the foot brake lever. 🦶 (👉 p. 61)
 - Adjust the basic position of the shift lever. 🦶 (👉 p. 81)
 - Get used to handling the motorcycle on a suitable piece of land before undertaking a more challenging trip.
-

 **Info**
Your motorcycle is not authorized for riding on public roads.
When offroad, being accompanied by another person on another vehicle so that you can help each other is recommended.

- Try also to ride as slowly as possible and in a standing position to get a better feeling for the motorcycle.
- Do not make any off-road trips that exceed your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.

- Do not take luggage along.
- Do not exceed the maximum permissible weight and the maximum permissible axle loads.

Guideline

Maximum permissible overall weight	335 kg (739 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)

- Run in the engine. (🔧 p. 17)

7.2 Running in the engine


- During the running-in phase, do not exceed the specified engine speed and engine performance.

Guideline

Maximum engine speed	
During the first operating hour	7,000 rpm
Maximum engine performance	
During the first 3 operating hours	≤ 75 %

- Avoid fully opening the throttle!

7.3 Starting power of lithium-ion batteries at low temperatures



Lithium-ion batteries are far lighter than lead batteries, have a low self-discharge rate, and have more starting power at temperatures over 15 °C (60 °F). At low temperatures, however, the starting power of lithium-ion batteries drops to below that of lead batteries.

Multiple starting attempts may be needed. Press the electric starter button for 5 seconds, and wait 30 seconds between attempts. The pauses are necessary so that the created heat can distribute through the lithium-ion battery and the battery is not damaged.

If the charged lithium-ion battery does not or only weakly turns over the electric starter when temperatures are below 15 °C (60 °F), then the battery is not faulty, but needs to be warmed up internally to increase its starting power (current output).

The starting power increases as the battery warms up.

7.4 Preparing the vehicle for difficult riding conditions



Info

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

- Clean the air filter and air filter box. 🛠️ (🔧 p. 45)



Info

Check the air filter approx. every 30 minutes.

- Check the electrical connector for humidity and corrosion and to ensure it is firmly seated.
 - » If humidity, corrosion, or damage is found:
 - Clean and dry the connector, or change it if necessary.

Difficult riding conditions are:

- Rides on dry sand. (🔧 p. 18)
- Rides on wet sand. (🔧 p. 18)
- Rides on wet and muddy surfaces. (🔧 p. 19)
- Rides at high temperature and slow speed. (🔧 p. 19)
- Riding at low temperature and in snow. (🔧 p. 19)

7.5 Preparing for rides on dry sand



- Fit a dust cover on the air filter.

Dust cover for air filter (79006920000)



Info

See the **Husqvarna Motorcycles** accessories fitting instructions.



- Fit a sand cover on the air filter.

Sand cover for air filter (79006922000)



Info

See the **Husqvarna Motorcycles** accessories fitting instructions.



- Clean the chain.
- Fit the steel sprocket.



Tip

Do not grease the chain.

- Clean the radiator fins.
- Straighten bent radiator fins carefully.
- If used in sand regularly, replace the piston every 20 operating hours.

7.6 Preparing for rides on wet sand



- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (79006921000)



Info

See the **Husqvarna Motorcycles** accessories fitting instructions.



- Clean the chain.
- Fit the steel sprocket.



Tip

Do not grease the chain.

- Clean the radiator fins.
- Straighten bent radiator fins carefully.
- If used in sand regularly, replace the piston every 20 operating hours.

7.7 Preparing for rides on wet and muddy surfaces



102137-01

- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (79006921000)



Info

See the **Husqvarna Motorcycles** accessories fitting instructions.



600868-01

- Fit the steel sprocket.
- Clean the motorcycle. (☛ p. 86)
- Straighten bent radiator fins carefully.

7.8 Preparing for rides at high temperature and slow speed



600868-01

- Adjust the secondary drive to the road conditions.



Info

The engine oil quickly gets hot if the clutch has to be operated very often due to an excessively high secondary drive.

- Clean the chain.
- Clean radiator fins.
- Straighten bent radiator fins carefully.
- Check the coolant level. (☛ p. 76)

7.9 Preparing for rides at low temperature and in snow



102137-01

- Fit a waterproofing device on the air filter.

Waterproofing device for air filter (79006921000)



Info

See the **Husqvarna Motorcycles** accessories fitting instructions.

8.1 Checks and maintenance work when preparing for use



Info

Before riding the vehicle, always check its condition and operating safety.
The vehicle must be in perfect technical condition when used.

- Check the engine oil level. (☞ p. 82)
- Check the brake fluid level of the front brake. (☞ p. 58)
- Check the rear brake fluid level. (☞ p. 62)
- Check the front brake linings. (☞ p. 59)
- Check the rear brake linings. (☞ p. 63)
- Check that the brake system is functioning properly.
- Check the coolant level. (☞ p. 76)
- Check for chain dirt accumulation. (☞ p. 50)
- Check the chain, rear sprocket, motor sprocket, and chain guide. (☞ p. 52)
- Check the chain tension. (☞ p. 51)
- Check the tire condition. (☞ p. 68)
- Check the tire air pressure. (☞ p. 69)
- Check the spoke tension. (☞ p. 69)
- Clean the dust boots of the fork legs. (☞ p. 34)
- Bleed the fork legs. (☞ p. 33)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts and hose clamps regularly for tightness.
- Check the fuel supply.

8.2 Starting



Danger


Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

Note

Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.




- Remove the plug-in stand ❶.
- Shift the transmission to idle.

Condition

Ambient temperature: < 20 °C (< 68 °F)

- Push the cold start button in all the way.



- Press the electric starter button ❸.



Info

Press the electric starter button for at most 5 seconds. Wait for a least 5 seconds before trying again.

At temperatures below 15 °C (60 °F), several attempts at starting may be necessary to warm-up the lithium-ion battery and thereby increase the starting power.

When starting **FI** warning lamp lights up briefly as a function check.

8.3 Activating Launch Control


Condition

Map-Select switch for the basic setting is at position **1** or **2**.

The motorcycle is stationary.

The engine is running at idle speed.

The transmission is in neutral.



- Using the **Map-Select** switch **1** for the ride mode, briefly change the setting (from **I** to **II** or vice-versa).

Guideline

Maximum duration of the shifting procedure	5 s
--	-----

- ✓ **FI** warning lamp flashes orange rapidly.

**Info**

The **Launch Control** can only be activated if the **Map-Select** switch for the basic setting (under the air filter box cover) is in position **1** (SOFT) or **2** (ADVANCED).

The **Launch Control** stays active for 3 minutes, and the start should occur within this period. If no start is detected, it is deactivated after 3 minutes; the **FI** warning lamp stops flashing.

For the **Launch Control** to function, the throttle must be fully opened at the start. If the throttle valve is closed by more than 1/3 of the way following full throttle, **Launch Control** is deactivated (**FI** warning lamp no longer flashes).

Several seconds after the vehicle starts, **Launch Control** is deactivated automatically.

To reactivate **Launch Control**, the engine must first be switched off for at least 10 seconds for safety reasons. This must happen regardless of whether a start occurred.

8.4 Starting off

- Pull the clutch lever, engage 1st gear, release the clutch lever slowly and simultaneously open the throttle carefully.

8.5 Shifting, riding

**Warning**

Danger of accidents If you change down at high engine speed, the rear wheel can lock up.

- Do not change into a low gear at high engine speed. The engine races and the rear wheel can lock up.

**Info**

If unusual noises occur while riding, stop immediately, switch off the engine, and contact an authorized Husqvarna Motorcycles workshop.

First gear is used for starting off or for steep inclines.

- Shift into a higher gear when conditions allow (incline, road situation, etc.). To do so, release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the throttle.
- If you pushed the cold start button while starting, open the throttle briefly and release the throttle grip or turn the throttle grip forward.
 - ✓ The cold start button goes to the basic position.
- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is $\frac{3}{4}$ open. This will barely reduce the speed but fuel consumption will be considerably lower.
- Always open the throttle only as much as the engine can handle – abrupt throttle opening increases fuel consumption.
- Apply the brakes and close the throttle at the same time to shift down.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and either open the throttle or shift again.
- Switch off the engine if running at idle or standing for a long time.

Guideline

≥ 1 min

- Avoid frequent and longer slipping of the clutch. As a result the engine oil, engine and cooling system heat up.
- Ride at a low engine speed instead of at a high engine speed with a slipping clutch.

8.6 Applying the brakes



Warning

Danger of accidents If you brake too hard, the wheels can lock.

- Adapt your braking to the traffic situation and the road conditions.



Warning

Danger of accidents Reduced braking efficiency caused by spongy pressure point of front or rear brake.

- Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

- Clean or dry a dirty or wet brake system by riding and braking gently.

- On sandy, wet or slippery surfaces, use the rear brake.
- Braking should always be completed before you go into a bend. Change down to a lower gear appropriate to your road speed.
- On long downhill stretches, use the braking effect of the engine. Change down one or two gears, but do not overstress the engine. In this way, you have to apply the brakes far less frequently and the brake system does not overheat.

8.7 Stopping, parking



Warning

Risk of misappropriation Usage by unauthorized persons.

- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.

- Brake the motorcycle.
- Shift the transmission to idle.
- Press and hold the kill switch  while the engine is idling until the engine stops.
- Park the motorcycle on firm ground.

8.8 Transport

Note


Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.



- Switch off the engine.
- Use tension belts or other suitable devices to secure the motorcycle against accidents or falling over.

8.9 Refueling

Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.

Note


Material damage Premature clogging of the fuel filter.

- In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Only refuel with clean fuel that meets the specified standards.

Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Switch off the engine.
- Open the filler cap. (☞ p. 13)
- Fill the fuel tank with fuel up to measurement **A**.

Guideline		
Measurement of A	35 mm (1.38 in)	
Total fuel tank capacity, approx.	7 l (1.8 US gal)	Super unleaded (ROZ 95/RON 95/PON 91) (☞ p. 98)

- Close the filler cap. (☞ p. 13)

9.1 Additional information

Any further work that results from the required work or from the recommended work must be ordered separately and can be invoiced separately.

9.2 Required work

	Every 30 operating hours			
	Every 20 operating hours			
	Every 10 operating hours/after every race			
	Once after 1 operating hour			
Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 	○	●	●	●
Check and charge the battery. 		●	●	●
Check the front brake linings. ( p. 59)		●	●	●
Check the rear brake linings. ( p. 63)		●	●	●
Check the brake discs. ( p. 57)		●	●	●
Check the brake lines for damage and leakage.		●	●	●
Check the rear brake fluid level. ( p. 62)		●	●	●
Check the free travel of the foot brake lever. ( p. 61)		●	●	●
Check the frame and swingarm. 		●	●	●
Check the swingarm bearing for play. 			●	
Check the heim joints at the top of the shock absorber. 		●	●	●
Check the shock absorber linkage. 		●	●	●
Check the tire condition. ( p. 68)	○	●	●	●
Check the tire air pressure. ( p. 69)	○	●	●	●
Check the wheel bearing for play. 		●	●	●
Check the wheel hubs. 		●	●	●
Check the rim run-out. 	○	●	●	●
Check the spoke tension. ( p. 69)	○	●	●	●
Check the chain, rear sprocket, motor sprocket, and chain guide. ( p. 52)		●	●	●
Check the chain tension. ( p. 51)	○	●	●	●
Grease all moving parts (e.g., hand lever, chain, ...) and check for smooth operation. 		●	●	●
Check/correct the fluid level of the hydraulic clutch. ( p. 55)		●	●	●
Check the brake fluid level of the front brake. ( p. 58)		●	●	●
Check the free travel of the hand brake lever. ( p. 57)		●	●	●
Check the steering head bearing play. ( p. 38)	○	●	●	●
Check the valve clearance. 	○			●
Check the clutch. 			●	
Change the cover seal and shaft seal rings of the water pump. 				●
Change the engine oil and oil filter, clean the oil screen.  ( p. 83)	○	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and sleeves for cracking, leaks, and incorrect routing. 	○	●	●	●
Check the antifreeze and coolant level. ( p. 75)	○	●	●	●
Check the cables for damage and routing without sharp bends. 		●	●	●
Check that the throttle cables are undamaged, routed without sharp bends, and set correctly.	○	●	●	●
Clean the air filter and air filter box.  ( p. 45)		●	●	●
Change the glass fiber yarn filling of the main silencer.  ( p. 46)			●	
Check the screws and nuts for tightness. 	○	●	●	●
Change the fuel screen.  ( p. 82)	○	●	●	●

	Every 30 operating hours			
	Every 20 operating hours			
	Every 10 operating hours/after every race			
	Once after 1 operating hour			
Check the fuel pressure. 		•	•	•
Check idle. 	○	•	•	•
Final check: Final check: Check the vehicle for safe operation and take a test ride.	○	•	•	•
Read out the fault memory after the test ride using the Husqvarna Motorcycles diagnostics tool. 	○	•	•	•
Make the service entry in the Husqvarna Motorcycles Dealer.net and in the Service and Warranty Booklet. 	○	•	•	•

○ One-time interval

• Periodic interval

9.3 Recommended work


	Annually			
	Every 100 operating hours			
	Every 50 operating hours			
	Every 40 operating hours			
	Once after 20 operating hours			
	Once after 10 operating hours			
Change the front brake fluid. 				•
Change the rear brake fluid. 				•
Change the hydraulic clutch fluid.  (☞ p. 55)				•
Grease the steering head bearing.  (☞ p. 39)				•
Service the fork. 	○	•		
Service the shock absorber. 		○	•	
Change the fuel filter. 				•
Perform minor engine service including removing and installing the engine. (Change spark plug and spark plug connector. Change the piston, check and measure the cylinder, and check the cylinder head. Check the camshaft and cam lever. Check the timing assembly. Change intake flange.) 			•	•
Perform major engine service including removing and installing engine. (Change valves, valve springs, valve spring seats, and valve spring retainers. Change the connecting rod, conrod bearing, and crank pin. Check the transmission and shift mechanism. Check the oil pressure regulator valve. Change the suction pump. Check the pressure pump and lubrication system. Replace the timing chain. Change all engine bearings. Change freewheel.) 				•

○ One-time interval

• Periodic interval

10.1 Checking the basic chassis setting with the rider's weight

i Info
When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, swingarm and frame, the basic settings of the suspension components must match the rider's weight.
 - As delivered, Husqvarna motorcycles are adjusted for an average rider's weight (with full protective clothing).
- Guideline
- | | |
|-----------------------|------------------------------|
| Standard rider weight | 75... 85 kg (165... 187 lb.) |
|-----------------------|------------------------------|
- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
 - Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.

10.2 Compression damping of the shock absorber


The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed. High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed. The high-speed setting, for example, has an effect on the landing after a jump: the rear wheel suspension compresses quickly. The low-speed setting, for example, has an effect when riding over long ground swells: the rear wheel suspension compresses slowly. These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

10.3 Adjusting the low-speed compression damping of the shock absorber

⚠ Caution
Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

i Info
The effect of the low-speed setting can be seen in slow to normal compression of the shock absorber.



- Turn adjusting screw ① clockwise with a screwdriver up to the last perceptible click.
- i Info**
Do not loosen fitting ②!

- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.
- Guideline
- | Compression damping, low-speed | |
|--------------------------------|-----------|
| Comfort | 17 clicks |
| Standard | 15 clicks |
| Sport | 13 clicks |



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.4 Adjusting the high-speed compression damping of the shock absorber



Caution


Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

The effect of the high-speed setting can be seen in fast compression of the shock absorber.



- Using an open end wrench, turn adjusting screw ❶ clockwise all the way.



Info

Do not loosen fitting ❷!

- Turn counterclockwise by the number of turns corresponding to the shock absorber type.
- Guideline

Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.


10.5 Adjusting the rebound damping of the shock absorber



Caution

Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Turn adjusting screw ❶ clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline


Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.6 Measuring the rear wheel dimension unloaded



Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 33)

Main work

- Position the sag gauge in the rear axle and measure the distance to marking **SAG** on the rear fender.

Sag gauge (00029090500)


Pin for sag gauge (00029990010)

- Note down the value as dimension **A**.

Finishing work

- Remove the motorcycle from the lift stand. (☞ p. 33)

10.7 Checking the static sag of the shock absorber



- Measure dimension **A** of rear wheel unloaded. (☞ p. 28)
- Hold the motorcycle upright with the aid of an assistant.
- Again measure the distance between the rear axle and marking **SAG** on the rear fender using the sag gauge.
- Note down the value as dimension **B**.



Info


The static sag is the difference between measurements **A** and **B**.

- Check the static sag.

Static sag	40 mm (1.57 in)
------------	-----------------

- » If the static sag is less or more than the specified value:
 - Adjust the spring preload of the shock absorber. ☞ (☞ p. 29)

10.8 Checking the riding sag of the shock absorber



- Measure dimension **A** of rear wheel unloaded. (☞ p. 28)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
 - ✓ The rear wheel suspension levels out.
- Another person again measures the distance between the rear axle and marking **SAG** on the rear fender using the sag gauge.
- Note down the value as dimension **C**.

i Info

The riding sag is the difference between measurements **A** and **C**.

- Check the riding sag.

Riding sag	110 mm (4.33 in)
------------	------------------

- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. ☞ (☞ p. 30)

10.9 Adjusting the spring preload of the shock absorber ☞

- ⚠ Caution**
Danger of accidents Disassembly of pressurized parts can lead to injury.
- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

- i** Info
 Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.

Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 33)
- Remove the shock absorber. ☞ (☞ p. 40)
- After removing the shock absorber, clean it thoroughly.

Main work

- Loosen screw **1**.
- Turn adjusting ring **2** until the spring is no longer under tension.

Hook wrench (T106S)

- Measure the overall spring length while the spring is not under tension.
- Tighten the spring by turning adjusting ring **2** to measurement **A**.

Guideline

Spring preload	7 mm (0.28 in)
----------------	----------------


i Info

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten screw **1**.

Guideline

Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)
--------------------------------------	----	-------------------




Finishing work

- Install the shock absorber. ☞ (☞ p. 42)
- Check the free travel of the foot brake lever. (☞ p. 61)

- Remove the motorcycle from the lift stand. (🔧 p. 33)

10.10 Adjusting the riding sag 🛠️



Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 33)
- Remove the shock absorber. 🛠️ (🔧 p. 40)
- After removing the shock absorber, clean it thoroughly.

Main work

- Choose and mount a suitable spring.

Guideline

Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	45 N/mm (257 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	48 N/mm (274 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	51 N/mm (291 lb/in)



Info

The spring rate is shown on the outside of the spring.

Finishing work


- Install the shock absorber. 🛠️ (🔧 p. 42)
- Check the free travel of the foot brake lever. (🔧 p. 61)
- Check the static sag of the shock absorber. (🔧 p. 28)
- Check the riding sag of the shock absorber. (🔧 p. 29)
- Adjust the rebound damping of the shock absorber. (🔧 p. 27)
- Remove the motorcycle from the lift stand. (🔧 p. 33)

10.11 Checking the basic setting of the fork



Info

For various reasons, no exact riding sag can be determined for the forks.



- As with the shock absorber, smaller differences in the rider's weight can be compensated by the spring preload.
- However, if the fork is often overloaded (hard end stop on compression), harder springs must be fit to avoid damage to the fork and frame.

10.12 Adjusting the compression damping of the fork



Info

The hydraulic compression damping determines the fork suspension behavior.



- Turn the white adjusting screw ❶ all the way clockwise.



Info

The adjusting screw ❶ is located at the upper end of the left fork leg. The compression damping is located in the left fork leg **COMP** (white adjusting screw). The rebound damping is located in the right fork leg **REB** (red adjusting screw).

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



Info


Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.13 Adjusting the rebound damping of the fork



Info

The hydraulic rebound damping determines the fork suspension behavior.



- Turn the red adjusting screw **1** all the way clockwise.



Info

The adjusting screw **1** is located at the upper end of the right fork leg. The rebound damping is located in the right fork leg **REB** (red adjusting screw). The compression damping is located in the left fork leg **COMP** (white adjusting screw).

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline


Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.14 Handlebar position




The holes on the handlebar support are placed at a distance of **A** from the center.

Hole distance A	3.5 mm (0.138 in)
-----------------	-------------------

The handlebar can be mounted in 2 different positions. In this way, the handlebar can be mounted in the most comfortable position for the rider.

10.15 Adjusting the handlebar position

- Preparatory work**
- Remove the handlebar cushion.



Main work

- Remove screws ①. Take off the handlebar clamps. Remove the handlebar and lay it to one side.



Info
Cover the components to protect them against damage.
Do not kink the cables and lines.

- Remove screws ②. Remove handlebar support ③.
- Position rubber bushings ④ and push through nuts ⑤ from below.
- Place the handlebar support in the required position. Mount and tighten screws ②.

Guideline

Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	Loctite® 243™
--------------------------	-----	------------------------	---------------

- Position the handlebar.



Info
Make sure the cables and wiring are positioned correctly.

- Position the handlebar clamps. Mount screws ①. Screw the handlebar clamps so that both parts touch at the front and tighten all of the screws.

Guideline

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
------------------------	----	---------------------

Finishing work


- Mount the handlebar cushion.

11.1 Raising the motorcycle with a lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Raise the motorcycle at the frame underneath the engine.
 - ✓ Neither wheel is in contact with the ground.
- Secure the motorcycle against falling over.


Lift stand (81329955100)

11.2 Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.




- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, insert plug-in stand ① into the left side of the wheel spindle.



Info

Remove the plug-in stand before riding.

11.3 Bleeding the fork legs



Preparatory work

- Raise the motorcycle with a lift stand. (☛ p. 33)


Main work

- Release bleeder screws ①.
 - ✓ Any excess pressure escapes from the interior of the fork.
- Tighten the bleeder screws.

Finishing work

- Remove the motorcycle from the lift stand. (☛ p. 33)

11.4 Cleaning the dust boots of the fork legs



Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 33)
- Remove the fork protector. (🔧 p. 34)

Main work

- Push dust boots ❶ of both fork legs downward.



Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean and oil the dust boots and inner fork tubes of both fork legs.


Universal oil spray (🔧 p. 99)

- Press the dust boots back into their normal position.
- Remove excess oil.

Finishing work


- Install the fork protector. (🔧 p. 34)
- Remove the motorcycle from the lift stand. (🔧 p. 33)

11.5 Removing the fork protector



- Remove screws ❶ on the left fork leg. Take off the clamp.
- Remove screws ❷ on the left fork leg. Take off the left fork protector.
- Remove screws ❸ on the right fork leg. Take off the right fork protector.

11.6 Installing the fork protector





- Position the fork protector on the left fork leg. Mount and tighten screws ❶.
- Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Position the brake line and clamp. Mount and tighten screws ❷.
 - Position the fork protector on the right fork leg. Mount and tighten screws ❸.
- Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

11.7 Removing the fork legs






- Preparatory work**
- Raise the motorcycle with a lift stand. (p. 33)
 - Remove the front wheel. (p. 66)

- Main work**
- Remove screws 1 and take off the clamp.
 - Remove screws 2 and take off the brake caliper.
 - Allow the brake caliper and brake line to hang tension-free to the side.

Info
Do not pull the hand brake lever if the front wheel has been removed.

- Loosen screws 3. Take out the left fork leg.
- Unscrew screws 4. Take out the right fork leg.

11.8 Installing the fork legs



- Main work**
- Position the fork legs.
 - ✓ Bleeder screws 1 are positioned toward the front.

Info
The rebound damping is located in the right fork leg **REB** (red adjusting screw). The compression damping is located in the left fork leg **COMP** (white adjusting screw).
Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.

- Tighten screws 2.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------

- Tighten screws 3.

Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
----------------------------	----	--------------------

- Position the brake caliper. Mount and tighten screws 4.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
----------------------------	----	---------------------	---------------

- Position the brake line and clamp. Mount and tighten screws 5.

- Finishing work**
- Install the front wheel. (p. 66)

11.9 Removing the lower triple clamp

Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 33)
- Remove the front wheel. ☞ (☞ p. 66)
- Remove the fork legs. ☞ (☞ p. 35)
- Remove the start number plate. (☞ p. 39)
- Remove the front fender. (☞ p. 40)
- Remove the handlebar cushion.


Main work

- Remove the holder with FI warning lamp.
- Open cable holders ❶ on the left and right and detach the wiring harness.
- Remove screw ❷.
- Remove screw ❸.
- Take off the upper triple clamp with the handlebar and set it aside.



Info

Cover the components to protect them against damage.
Do not kink the cables and lines.



- Remove O-ring ❷. Remove protective ring ❸.
- Take off the lower triple clamp with the steering stem.
- Remove the upper steering head bearing.


11.10 Installing the lower triple clamp

Main work

- Clean the bearing and sealing elements, check for damage, and grease.


High viscosity grease (☞ p. 99)

- Insert the lower triple clamp with the steering stem. Mount the upper steering head bearing.
- Check whether the upper steering head seal ❶ is correctly positioned.
- Slide on protective ring ❷ and O-ring ❸.





- Position the upper triple clamp with the handlebar.
- Mount screw 4 but do not tighten yet.




- Position the fork legs.
- ✓ Bleeder screws 5 are positioned toward the front.



Info

The rebound damping is located in the right fork leg **REB** (red adjusting screw). The compression damping is located in the left fork leg **COMP** (white adjusting screw). Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.



- Tighten screws 6.

Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
----------------------------	----	--------------------



- Tighten screw 4.

Guideline


Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
--------------------------	---------	--------------------



- Mount and tighten screw 7.

Guideline

Screw, top steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
--------------------------	----	---------------------	---------------



- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
- Tighten screws 8.


Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------

- Secure the wiring harness with cable holders 9 on the left and right.
- Mount the holder with FI warning lamp.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Position the brake caliper. Mount and tighten screws 10.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
----------------------------	----	------------------------	---------------

- Position the brake line and clamp. Mount and tighten screws 11.

Finishing work

- Install the front fender. (☞ p. 40)
- Install the start number plate. (☞ p. 39)
- Install the front wheel. ☞ (☞ p. 66)
- Check that the wiring harness, throttle cables, and brake and clutch lines can move freely and are routed correctly.
- Check the steering head bearing play. (☞ p. 38)
- Remove the motorcycle from the lift stand. (☞ p. 33)
- Mount the handlebar cushion.

11.11 Checking the steering head bearing play



Warning


Danger of accidents Unstable vehicle handling from incorrect steering head bearing play.

- Adjust the steering head bearing play without delay. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

If the bike is ridden with play in the steering head bearing, the bearing and the bearing seats in the frame can become damaged over time.



Preparatory work

- Raise the motorcycle with a lift stand. (☞ p. 33)

Main work

- Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

No play should be noticeable in the steering head bearing.

» If there is noticeable play present:

- Adjust the steering head bearing play. ☞ (☞ p. 39)
- Move the handlebar to and fro over the entire steering range.

The handlebar must be able to move easily over the entire steering range. No resting locations should be noticeable.


» If click positions are noticeable:

- Adjust the steering head bearing play. ☞ (☞ p. 39)
- Check the steering head bearing and change if necessary.

Finishing work

- Remove the motorcycle from the lift stand. (☞ p. 33)

11.12 Adjusting the steering head bearing play



Preparatory work

- Raise the motorcycle with a lift stand. (p. 33)
- Remove the handlebar cushion.

Main work

- Loosen screws ①. Remove screw ②.
- Loosen and retighten screw ③.

Guideline

Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
--------------------------	---------	--------------------

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
- Mount and tighten screw ②.

Guideline

Screw, top steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
--------------------------	----	---------------------	---------------

- Tighten screws ①.

Guideline


Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------

- Check the steering head bearing play. (p. 38)

Finishing work


- Mount the handlebar cushion.
- Remove the motorcycle from the lift stand. (p. 33)

11.13 Greasing the steering head bearing




- Remove the lower triple clamp. (p. 36)
- Install the lower triple clamp. (p. 36)

11.14 Removing the start number plate



- Remove screw ①. Swivel the start number plate to one side.
- Remove screw ② and take off the brake line guide and start number plate.

11.15 Installing the start number plate



- Position the brake line and brake line guide on the start number plate.
- Mount and tighten screw ①.
- Position the start number plate.
- ✓ The holding lugs engage in the fender.
- Mount and tighten screw ②.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------


11.16 Removing the front fender

Preparatory work

- Remove the start number plate. (🔧 p. 39)

Main work

- Remove screws ❶ and ❷. Remove the front fender.




11.17 Installing the front fender

Main work

- Position the front fender. Mount and tighten screws ❶ and ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------




Finishing work

- Install the start number plate. (🔧 p. 39)

11.18 Removing the shock absorber 🛠


Preparatory work

- Raise the motorcycle with a lift stand. (🔧 p. 33)



Main work

- Remove the cable tie(s).
- Remove screws ①.
- Remove screws ② with the washers.
- Remove the frame protector on the left and right.




- Remove screw ③.
- Remove screw cap ④.




Info


Raise the wheel slightly to be able to remove the screws more easily.




- Press angle lever ⑤ toward the rear.
- Press linkage lever ⑥ downward.




- Remove screws ⑦.
- Pull off foot brake cylinder from the push rod.



- Remove the connecting link of the chain.
- Take off the chain.



- Remove nut ⑧ and pull out the swingarm pivot.
- Push the swingarm back and secure it against falling over.



K00287-10




102300-01

- Hold the shock absorber and remove screw 9.

- Remove the shock absorber carefully at the bottom.

11.19 Installing the shock absorber




120322-11

Main work

- Carefully position the shock absorber into the vehicle from the bottom.
- Mount and tighten screw 1.

Guideline

Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
---------------------------	-----	------------------------	----------------



120324-10

- Position the swingarm and mount the swingarm pivot.




Info

Pay attention to the flat area A.

- Mount and tighten the nut 2.

Guideline

Nut, swingarm pivot	M16x1.5	100 Nm (73.8 lbf ft)
---------------------	---------	-------------------------




120325-10

- Mount the chain.
- Connect the chain with connecting link 3.

Guideline

The closed side of the chain joint lock must face in the direction of travel.



120326-10

- Position the foot brake cylinder.
- ✓ Push rod 4 engages in the foot brake cylinder.




Info

Ensure that the dust boot is correctly seated.

- Mount and tighten screws 5.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Position the angle lever and linkage lever.
- Mount and tighten screw cap **6**.

Guideline

Nut, linkage lever to angle lever	M14x1.5	80 Nm (59 lbf ft)
-----------------------------------	---------	-------------------



Info

Pay attention to the flat area **B**.

- Mount and tighten screw **7**.


Guideline

Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
------------------------------	-----	---------------------	----------------



Info

Raise the wheel slightly to be able to mount the screw more easily.



- Position the frame protector on the left and right.
- Mount and tighten screws **8**.

Guideline

Screw, frame protector	M5	3 Nm (2.2 lbf ft)
------------------------	----	-------------------

- Mount and tighten screws **9** with washers.

Guideline

Screw, frame protector	M5	3 Nm (2.2 lbf ft)
------------------------	----	-------------------

- Mount the new cable ties.

Finishing work

- Check the free travel of the foot brake lever. (☛ p. 61)
- Remove the motorcycle from the lift stand. (☛ p. 33)


11.20 Removing the seat

Preparatory work


- Remove the air filter box cover. (☛ p. 44)

Main work

- Remove screw **1**.
- Pull seat back and lift it off.



11.21 Mounting the seat



Main work

- Mount the front of the seat on the collar bushing of the fuel tank and the rear in the bracket.
- Push the seat forward.
- Make sure that the seat is correctly locked in.
- Mount and tighten screw ①.


Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Finishing work


- Install the air filter box cover. (☛ p. 44)

11.22 Removing the air filter box cover



- Pull off the air filter box cover sideways in areas ①, ② and ③, and remove toward the front.

11.23 Installing the air filter box cover



- Position air filter box cover on collar bushings ① and ② and push toward the rear.
- Engage the air filter box cover in areas ①, ② and ③.

11.24 Removing the air filter

Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never operate the vehicle without an air filter as dust and dirt will enter the engine and lead to increased wear.

Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Preparatory work

- Remove the air filter box cover. (p. 44)

Main work

- Detach retaining tab ①. Remove air filter with air filter support.
- Take off air filter from air filter support.


11.25 Installing the air filter



Main work

- Mount the clean air filter on the air filter support.
- Grease the air filter in area A.

Long-life grease (p. 99)



- Insert air filter and position retaining pin ① into socket B.
- ✓ The air filter is correctly positioned.
- Insert retaining tab ③.
- ✓ Retaining pin ② is secured by the retaining tab ③.



Info

If the air filter is not mounted correctly, dust and dirt may enter the engine and result in damage.

Finishing work

- Install the air filter box cover. (p. 44)

11.26 Cleaning the air filter and air filter box

Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.

Preparatory work

- Remove the air filter box cover. (p. 44)
- Remove the air filter. (p. 45)



Main work

- Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaning agent (☞ p. 99)



Info

Only press the air filter to dry it, never wring it out.

- Oil the dry air filter with a high quality filter oil.

Oil for foam air filter (☞ p. 99)

- Clean the air filter box.
- Check the intake flange for damage and looseness.

Finishing work

- Install the air filter. ☞ (☞ p. 45)
- Install the air filter box cover. (☞ p. 44)


11.27 Removing the main silencer



Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.

- Allow the exhaust system to cool down. Do not touch hot components.



Preparatory work

- Remove the right side cover. (☞ p. 47)


Main work

- Disconnect spring ①.

Spring hook (50305017000)

- Remove screws ② and take off the main silencer.

11.28 Installing the main silencer



Main work

- Mount the main silencer. Mount screws ①, but do not tighten yet.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Attach spring ②.
- Tighten screws ①.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Finishing work

- Install the right side cover. (☞ p. 47)

11.29 Changing the glass fiber yarn filling of the main silencer ☞



Warning


Danger of burns The exhaust system gets very hot when the vehicle is driven.

- Allow the exhaust system to cool down. Do not touch hot components.



Info

Over time, the fibers of the glass fiber yarn escape and the damper "burns" out. Not only is the noise level higher, the performance characteristic changes.



Preparatory work

- Remove the right side cover. (☛ p. 47)
- Remove the main silencer. (☛ p. 46)

Main work

- Remove all screws on the main silencer.
- Take off silencer cap ① and O-ring ②.
- Take off outer tube ③ and O-ring ④.
- Pull glass fiber yarn filling ⑤ off of inner tube ⑥.
- Clean the parts that need to be reinstalled and check for damage.
- Mount new glass fiber yarn filling ⑤ on inner tube ⑥.
- Slide O-ring ④ and outer tube ③ over the glass fiber yarn filling ⑤.
- Insert O-ring ② and silencer cap ① into outer tube ③.
- Mount and tighten all of the screws.


Guideline

Screws on the main silencer	M5	7 Nm (5.2 lbf ft)
-----------------------------	----	-------------------

Finishing work


- Install the main silencer. (☛ p. 46)
- Install the right side cover. (☛ p. 47)

11.30 Removing the right side cover




- Remove screw ①.
- Pull off the side cover sideways in areas A and B, and remove toward the front.

11.31 Installing the right side cover



- Position the side cover on collar bushings ① and ②, and push toward the rear.



- Engage the side cover in areas A and B.
- Mount and tighten screw ③.

Guideline

Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)
---------------------------	----	-------------------

11.32 Removing the fuel tank



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that has been contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.

Preparatory work

- Remove the right side cover. (☛ p. 47)
- Remove the air filter box cover. (☛ p. 44)
- Remove the seat. (☛ p. 43)


Main work

- Unplug connector ① of the fuel pump.
- Clean plug-in connection ② of the fuel line thoroughly with compressed air.



Info

Dirt should not be allowed to get into the fuel line under any circumstances. Dirt in the fuel line clogs the injection valve!



- Disconnect the plug-in connection of the fuel line.




Info

Remaining fuel may run out of the fuel pipe.


- Mount wash cap set ①.

Wash cap set (81212016100)

- Pull the hose off the fuel tank breather on the tank lid.



- Remove screws ③.



- Remove screw ④ with the rubber bushing.





- Pull both spoilers off of the sides of the radiator bracket and lift off the fuel tank.

11.33 Installing the fuel tank

Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.

Main work


- Check the throttle cable routing. (☛ p. 54)
- Position the fuel tank and fit the two spoilers to the sides of the radiator bracket.
- Make sure that no cables or throttle cables are trapped or damaged.



- Attach the hose to the fuel tank breather on the tank lid.
- Mount and tighten screw 1 with the rubber bushing.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Mount and tighten screws 2.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Plug in connector ③ for the fuel pump.
- Remove the wash cap set and thoroughly clean the plug-in connection of the fuel line using compressed air.



Info

Dirt should not be allowed to get into the fuel line under any circumstances. Dirt in the fuel line clogs the injection valve!

- Lubricate the O-ring and connect plug-in connection ④ for the fuel line.




Info

Route the cable and fuel line at a safe distance from the exhaust system.

Finishing work

- Mount the seat. (☛ p. 44)
- Install the air filter box cover. (☛ p. 44)
- Install the right side cover. (☛ p. 47)

11.34 Checking for chain dirt accumulation



- Check the chain for coarse dirt accumulation.
 - » If the chain is very dirty:
 - Clean the chain. (☛ p. 50)

11.35 Cleaning the chain



Warning

Danger of accidents Oil or grease on the tires reduces their grip.

- Remove oil and grease with a suitable cleaning material.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

The service life of the chain depends largely on its maintenance.


Preparatory work

- Raise the motorcycle with a lift stand. (☛ p. 33)

Main work

- Clean the chain regularly and then treat with chain spray.

Offroad chain spray (☛ p. 99)




Finishing work

- Remove the motorcycle from the lift stand. (☛ p. 33)

11.36 Checking the chain tension

Warning
Danger of accidents Danger caused by incorrect chain tension.

- If the chain is too taut, the components of the secondary power transmission (chain, engine sprocket, rear sprocket, bearings in the transmission and in the rear wheel) will be under additional load. In addition to premature wear, this can cause the chain or the countershaft of the transmission to break in extreme cases. If the chain is too loose, however, it may fall off the engine sprocket or rear sprocket and block the rear wheel or damage the engine. Ensure that the chain tension is correct and adjust it if necessary.



Preparatory work
- Raise the motorcycle with a lift stand. (☞ p. 33)

Main work
- Pull the chain at the end of the chain sliding component upwards to measure chain tension **A**.

Info
The lower chain section **1** must be taut.
Chain wear is not always even, so you should repeat this measurement at different chain positions.

Chain tension	55... 58 mm (2.17... 2.28 in)
---------------	-------------------------------


- » If the chain tension does not meet specifications:
- Adjust the chain tension. (☞ p. 51)

Finishing work
- Remove the motorcycle from the lift stand. (☞ p. 33)

11.37 Adjusting the chain tension

Warning
Danger of accidents Danger caused by incorrect chain tension.

- If the chain is too taut, the components of the secondary power transmission (chain, engine sprocket, rear sprocket, bearings in the transmission and in the rear wheel) will be under additional load. In addition to premature wear, this can cause the chain or the countershaft of the transmission to break in extreme cases. If the chain is too loose, however, it may fall off the engine sprocket or rear sprocket and block the rear wheel or damage the engine. Ensure that the chain tension is correct and adjust it if necessary.



Preparatory work
- Raise the motorcycle with a lift stand. (☞ p. 33)
- Check the chain tension. (☞ p. 51)

Main work
- Loosen nut **1**.
- Loosen nuts **2**.
- Adjust the chain tension by turning adjusting screws **3** left and right.

Guideline

Chain tension	55... 58 mm (2.17... 2.28 in)
Turn adjusting screws 3 on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks A . The rear wheel is then correctly aligned.	

- Tighten nuts **2**.
- Make sure that chain adjusters **4** are fitted correctly on adjusting screws **3**.
- Tighten nut **1**.

Guideline

Nut, rear wheel spindle	M25x1.5	80 Nm (59 lbf ft)
-------------------------	---------	-------------------



Info
The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.
Chain adjusters ④ can be turned by 180°.

Finishing work

- Remove the motorcycle from the lift stand. (☛ p. 33)

11.38 Checking the chain, rear sprocket, motor sprocket, and chain guide

Preparatory work



- Raise the motorcycle with a lift stand. (☛ p. 33)

Main work

- Shift the transmission to idle.
- Check the rear sprocket and motor sprocket for wear.
 - » If the rear sprocket or engine sprocket is worn:
 - Change the drivetrain kit. ☛



Info
The motor sprocket, rear sprocket, and chain should always be replaced together.



- Pull at the top part of the chain with the specified weight ①.

Guideline

Weight, chain wear measurement	10... 15 kg (22... 33 lb.)
--------------------------------	----------------------------

- Measure the distance ② of 18 chain links in the lower chain section.



Info
Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance ② at the longest chain section	272 mm (10.71 in)
---	-------------------

- » If distance ② is greater than the specified measurement:
 - Change the drivetrain kit. ☛





Info
When the chain is replaced, the rear sprocket and engine sprocket should also be changed.
New chains wear out faster on an old, worn rear sprocket or engine sprocket.

- Check the chain sliding guard for wear.
 - » If the lower edge of the chain pin is at the level of or below the chain sliding guard:
 - Change the chain sliding guard. ☛
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten the screws on the chain sliding guard.

Guideline

Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
----------------------------	----	-------------------	---------------






- Check the chain sliding piece for wear.
 - » If the lower edge of the chain pins is in line with or below the chain sliding piece:
 - Change the chain sliding piece. 🛠️
- Check that the chain sliding piece is firmly seated.
 - » If the chain sliding piece is loose:
 - Tighten the screw on the chain sliding piece.

Guideline


Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)
----------------------------	----	------------------------



- Check the chain guide with a slide gauge for dimension **C**.

Minimum thickness C of the chain guide	6 mm (0.24 in)
---	----------------

- » If the measured value is less than the specification:
 - Change the chain sliding piece. 🛠️



- Check that the chain guide is firmly seated.
 - » If the chain guide is loose:
 - Tighten the screws on the chain guide.


Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

Finishing work

- Remove the motorcycle from the lift stand. (🔧 p. 33)

11.39 Checking the frame 🛠️




- Check the frame for cracks and deformation.
 - » If the frame exhibits cracks or deformation due to a mechanical impact:
 - Change the frame. 🛠️

**Info**

Always replace a frame that has been damaged due to a mechanical impact. Repair of the frame is not authorized by Husqvarna Motorcycles.

11.40 Checking the swingarm



- Check the swingarm for damage, cracking, and deformation.
 - » If the swingarm shows signs of damage, cracking, or deformation:
 - Change the swingarm.



Info

Always change a damaged swingarm. Repair of the swingarm is not authorized by Husqvarna Motorcycles.

11.41 Checking the throttle cable routing



Preparatory work

- Remove the right side cover. (p. 47)
- Remove the air filter box cover. (p. 44)
- Remove the seat. (p. 43)
- Remove the fuel tank. (p. 48)

Main work

- Check the throttle cable routing.


Both throttle cables must be routed, side by side, behind the handlebars and above the fuel tank bracket, to the throttle valve body. Both throttle cables must be secured behind the fuel tank contact area rubber band.

- » If the throttle cable is not routed as specified:
 - Correct the throttle cable routing.

Finishing work

- Install the fuel tank. (p. 49)
- Mount the seat. (p. 44)
- Install the air filter box cover. (p. 44)
- Install the right side cover. (p. 47)

11.42 Checking the rubber grips



- Check the rubber grips on the handlebar for damage, wear, and looseness.




Info

The rubber grips are vulcanized onto a sleeve on the left and onto the handle tube of the throttle grip on the right. The left sleeve is clamped onto the handlebar.

The rubber grip can only be replaced with the sleeve or the throttle tube.

- » If a rubber grip is damaged or worn:
 - Change the rubber grip.




- Check that screw 1 is firmly seated.

Guideline

Screw, fixed grip	M4	5 Nm (3.7 lbf ft)	Loctite® 243™
-------------------	----	----------------------	---------------

The diamond A must be located at the top.

11.43 Adjusting the basic position of the clutch lever



- Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw 1.

Info

Turn the adjusting screw counterclockwise to decrease the distance between the clutch lever and the handlebar.

Turn the adjusting screw clockwise to increase the distance between the clutch lever and the handlebar.

The range of adjustment is limited.


Turn the adjusting screw by hand only, and do not apply any force.

Do not make any adjustments while riding!

11.44 Checking/correcting the fluid level of the hydraulic clutch

Info

The fluid level rises with increasing wear of the clutch facing discs.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Remove cover 2 with membrane 3.
- Check the fluid level.

Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

- » If the fluid level does not meet specifications:
 - Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 (☛ p. 98)

- Position the cover with the membrane. Mount and tighten the screws.

Info


Clean up overflowed or spilled brake fluid immediately with water.

11.45 Changing the hydraulic clutch fluid


Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Remove cover 2 with membrane 3.




- Fill bleeding syringe ④ with the appropriate hydraulic fluid.

Bleed syringe (50329050000)
Brake fluid DOT 4 (☞ p. 98)

- Mount bleeding syringe ④ on bleeder screw ⑤ using a fitting section of hose.
- Only loosen bleeder screw ⑤ on the clutch slave cylinder to the point where filling is possible.

Info

Clean up overflowed or spilt brake fluid immediately with water!
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container!



- Inject the liquid into the system until it escapes from drill hole ⑥ of the master cylinder without bubbles.
- Drain fluid occasionally from the master cylinder reservoir, to prevent overflow.
- Tighten the bleeder screw and remove the bleeding syringe with the hose.
- Correct the fluid level of the hydraulic clutch.


Guideline	
Fluid level below container rim	4 mm (0.16 in)

- Position the cover with the membrane. Mount and tighten the screws.

12.1 Checking the free travel of the hand brake lever


**Warning**
Danger of accidents Brake system failure.

- If there is no free travel on the hand brake lever, pressure builds up on the front brake circuit. The front brake can fail due to overheating. Adjust the free travel on hand brake lever according to specifications.



- Push the hand brake lever forward and check free travel **A**.
- | | |
|---------------------------------|--------------------|
| Free travel of hand brake lever | ≥ 3 mm (≥ 0.12 in) |
|---------------------------------|--------------------|
- » If the free travel does not meet specifications:
 - Adjust the basic position of the hand brake lever. (🔧 p. 57)

12.2 Adjusting the basic position of the hand brake lever



- Preparatory work**
- Check the free travel of the hand brake lever. (🔧 p. 57)
- Main work**
- Adjust the basic setting of the hand brake lever to your hand size by turning adjusting screw **1**.


**Info**

Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.
Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding!

12.3 Checking the brake discs

**Warning**
Danger of accidents Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check the thickness of the front and rear brake discs at multiple points on each brake disc to ensure it is at least thickness **A**.

**Info**

Wear reduces the thickness of the brake disc around the area used by the brake linings.

Brake discs - wear limit	
Front	2.5 mm (0.098 in)
Rear	3.5 mm (0.138 in)

- » If the brake disc thickness is less than the specified value:
 - Change the front brake disc. 🛠️
 - Change the rear brake disc. 🛠️
- Check the front and rear brake discs for damage, cracking, and deformation.
 - » If the brake disc exhibits damage, cracking, or deformation:
 - Change the front brake disc. 🛠️
 - Change the rear brake disc. 🛠️

12.4 Checking the brake fluid level of the front brake



Warning

Danger of accidents Brake system failure.


- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Preparatory work

- Check the front brake linings. (☞ p. 59)

Main work

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in level viewer **1**.
 - » If the brake fluid level has dropped below marking **A**:
 - Add front brake fluid. ☞ (☞ p. 58)

12.5 Adding front brake fluid ☞



Warning

Danger of accidents Brake system failure.

- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info


Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.

Preparatory work

- Check the front brake linings. (☞ p. 59)



Main work

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Add brake fluid to level A.

Guideline

Level A (brake fluid level below container rim)	5 mm (0.2 in)
---	---------------

Brake fluid DOT 4 (☞ p. 98)

- Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilt brake fluid immediately with water.


12.6 Checking the front brake linings



Warning

Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check the brake linings for minimum thickness A.

Minimum thickness A	≥ 1 mm (≥ 0.04 in)
---------------------	--------------------

» If the minimum thickness is less than specified:

- Change the front brake linings. ☞ (☞ p. 59)

- Check the brake linings for damage and cracking.

» If damage or cracking is visible:

- Change the front brake linings. ☞ (☞ p. 59)

12.7 Changing the front brake linings ☞



Warning

Danger of accident Brake system failure.

- Maintenance work and repairs must be carried out professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.


Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.



H00295-10

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.




120342-10

- Manually press the brake caliper to the brake disc to push back the brake pistons. Ensure that brake fluid does not flow out of the brake fluid reservoir, extracting it by suction if it does.

Info

Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.

- Remove cotter pins ④, pull out pin ⑤, and remove the brake linings.
- Clean the brake caliper and brake caliper support.
- Check that leaf spring ⑥ in the brake caliper and sliding plate ⑦ in the brake caliper support are seated correctly.




100397-01

- Insert the new brake linings, insert pin ⑤, and mount cotter pins ④.


Info

Always change the brake linings in pairs.

- Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



120342-11



- Add brake fluid to level **A**.

Guideline

Dimension A (brake fluid level below top edge of container)	5 mm (0.2 in)
--	---------------

Brake fluid DOT 4 (🔧 p. 98)

- Position cover **2** with membrane **3**.
- Mount and tighten screws **1**.

 **Info**


Clean up overflowed or spilt brake fluid immediately with water.

12.8 Checking the free travel of foot brake lever

 **Warning**

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



- Disconnect spring **1**.
- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel **A**.

Guideline

Free travel at foot brake lever	3... 5 mm (0.12... 0.2 in)
---------------------------------	----------------------------


- » If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake lever. 🛠️ (🔧 p. 61)
- Reconnect spring **1**.

12.9 Adjusting the basic position of the foot brake lever 🛠️

 **Warning**

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



- Disconnect spring ①.
- Loosen nut ④ and, with push rod ⑤, turn it back until you have maximum free travel.
- To adjust the basic position of the foot brake lever individually, loosen nut ② and turn screw ③ accordingly.

**Info**

The range of adjustment is limited.

- Turn push rod ⑤ accordingly until you have free travel A. If necessary, adjust the basic position of the foot brake lever.

Guideline

Free travel at foot brake lever	3... 5 mm (0.12... 0.2 in)
---------------------------------	----------------------------

- Hold push rod ⑤ and tighten nut ④.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
-------------------------	----	--------------------

- Hold screw ③ and tighten nut ②.

Guideline

Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)
----------------------------	----	---------------------

- Reconnect spring ①.

12.10 Checking the rear brake fluid level

**Warning**

Danger of accidents Brake system failure.

- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

**Warning**

Danger of accidents Reduced braking efficiency due to old brake fluid.


- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Preparatory work

- Check the rear brake linings. (☞ p. 63)

Main work

- Stand the vehicle upright.
- Check the brake fluid level in the viewer ①.
 - » If the brake fluid level drops below marking A:
 - Add rear brake fluid. ☞ (☞ p. 62)



12.11 Adding rear brake fluid ☞


**Warning**

Danger of accidents Brake system failure.

- If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

- Warning**
Skin irritation Brake fluid can cause skin irritation on contact.
- Avoid contact with skin and eyes, and keep out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.
- Warning**
Danger of accidents Reduced braking efficiency due to old brake fluid.
- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

i Info
 Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
 Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
 Use only clean brake fluid from a sealed container.



Preparatory work

- Check the rear brake linings. (☞ p. 63)

Main work

- Stand the vehicle upright.
- Remove screw cap ① with membrane ② and the O-ring.
- Add brake fluid to level A.


Brake fluid DOT 4 (☞ p. 98)

- Mount and tighten the screw cap with the membrane and O-ring.

i Info
 Clean up overflowed or spilt brake fluid immediately with water.

12.12 Checking the rear brake linings

- Warning**
Danger of accidents Reduced braking efficiency caused by worn brake linings.
- Change worn brake linings immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check the brake linings for minimum thickness A.

Minimum thickness A $\geq 1 \text{ mm } (\geq 0.04 \text{ in})$

- » If the minimum thickness is less than specified:
 - Change the rear brake linings. ☞ (☞ p. 64)
- Check the brake linings for damage and cracking.
 - » If damage or cracking is visible:
 - Change the rear brake linings. ☞ (☞ p. 64)


12.13 Changing the rear brake linings

- Warning**
Danger of accident Brake system failure.
- Maintenance work and repairs must be carried out professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Warning**
Skin irritation Brake fluid can cause skin irritation on contact.
- Avoid contact with skin and eyes, and keep out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.
- Warning**
Danger of accidents Reduced braking efficiency due to old brake fluid.
- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

- i Info**
Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container.



- Stand the vehicle upright.
- Remove screw cap **1** with membrane **2** and the O-ring.





- Manually press the brake caliper to the brake disc to push back the brake piston. Ensure that brake fluid does not flow out of the brake fluid reservoir, extracting it by suction if it does.

- i Info**
Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove cotter pin **3**, pull out pin **4** and remove the brake linings.
- Clean the brake caliper and brake caliper support.
- Check that leaf spring **5** in the brake caliper and sliding plate **6** in the brake caliper support are seated correctly.

- i Info**
The arrow on the leaf spring points in the rotation direction of the brake disc.





- Insert the new brake linings, insert pin ④, and mount cotter pins ③.




Info

Always change the brake linings in pairs.

Make sure that the decoupling plate ⑦ is mounted on the piston side of the brake lining.

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



- Add brake fluid to level ①.

Brake fluid DOT 4 (☞ p. 98)

- Mount and tighten screw cap ① with membrane ② and the O-ring.



Info

Clean up overflowed or spilt brake fluid immediately with water.

13.1 Removing the front wheel

Preparatory work



- Raise the motorcycle with a lift stand. (p. 33)

Main work


- Press the brake caliper onto the brake disc by hand in order to push back the brake pistons.

Info

Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.




- Loosen screw ① by several rotations.
- Release screws ②.
- Press on screw ① to push the wheel spindle out of the axle clamp.
- Remove screw ①.



- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.

Info

Do not activate the hand brake lever while the front wheel is removed. Always lay the wheel down in such a way that the brake disc is not damaged.



- Remove spacers ③.


13.2 Installing the front wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the front wheel bearing.
- Clean and grease the shaft seal rings ① and contact surface A of the spacers.

Long-life grease (p. 99)

- Insert the spacers.
- Position the front wheel and insert the wheel spindle.
- ✓ The brake linings are correctly positioned.



- Mount and tighten screw ②.

Guideline


Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)
----------------------------	---------	---------------------

- Activate the hand brake lever multiple times until the brake linings are in contact with the brake disc.
- Remove the motorcycle from the lift stand. (☛ p. 33)
- Pull the front brake and compress the fork powerfully a few times.
✓ The fork legs straighten.
- Tighten screws ③.

Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	---------------------

13.3 Removing the rear wheel ☛



Preparatory work

- Raise the motorcycle with a lift stand. (☛ p. 33)

Main work

- Press the brake caliper onto the brake disc by hand in order to push back the brake piston.



Info

Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove nut ①.
- Remove chain adjuster ②. Withdraw wheel spindle ③ only enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.



Info

Cover the components to protect them against damage.



Warning

Danger of accidents Reduced braking efficiency due to damaged brake disc.

- Always lay the wheel down in such a way that the brake disc is not damaged.


- Holding the rear wheel, withdraw the wheel spindle. Take the rear wheel out of the swingarm.



Info

Do not operate the foot brake lever when the rear wheel is removed.

- Remove spacers ④.




13.4 Installing the rear wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.




Main work


- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the rear wheel bearing.
- Clean and grease shaft seal rings **1** and bearing surface **A** of the spacers.

Long-life grease (☛ p. 99)

- Insert the spacers.



- Position the rear wheel and insert wheel spindle **2**.
 - ✓ The brake linings are correctly positioned.
- Mount the chain.



- Position chain adjuster **3**. Mount nut **4**, but do not tighten it yet.
- Make sure that chain adjusters **3** are fitted correctly on adjusting screws **5**.
- Check the chain tension. (☛ p. 51)
- Tighten nut **4**.

Guideline

Nut, rear wheel spindle	M25x1.5	80 Nm (59 lbf ft)
-------------------------	---------	-------------------



Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length. Chain adjusters **3** can be turned by 180°.

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

13.5 Checking the tire condition



Info


Only mount tires approved and/or recommended by Husqvarna Motorcycles.

Other tires could have a negative effect on handling characteristics.

The type, condition, and air pressure of the tires all have a major impact on the handling of the motorcycle.

The tires mounted on the front and rear wheels must have a similar profile.

Worn tires have a negative effect on handling characteristics, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects, and other damage.
 - » If the tires have cuts, run-in objects, or other damage:
 - Change the tires.
- Check the tread depth.



Info

Adhere to the legally required minimum tread depth.

Minimum tread depth	$\geq 2 \text{ mm } (\geq 0.08 \text{ in})$
---------------------	---

- » If the tread depth is less than the minimum tread depth:
 - Change the tires.
- Check the tire age.



Info

The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.

Husqvarna Motorcycles recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.


- » If the tires are more than 5 years old:
 - Change the tires.

13.6 Checking the tire air pressure



Info

Low tire air pressure leads to abnormal wear and overheating of the tire. Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



- Remove the protection cap.
- Check the tire air pressure when the tires are cold.

Tire air pressure off road	
Front	1.0 bar (15 psi)
Rear	1.0 bar (15 psi)

- » If the tire pressure does not meet specifications:
 - Correct the tire pressure.
- Mount the protection cap.

13.7 Checking the spoke tension



Warning


Danger of accidents Instable handling due to incorrect spoke tension.

- Ensure that the spoke tension is correct. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

A loose spoke causes wheel imbalance and rapidly leads to more loose spokes. If the spokes are too tight, they can break due to local overload. Check the spoke tension regularly, especially on a new motorcycle.



- Briefly strike each spoke with the tip of a screwdriver.

**Info**

The tone frequency depends on the length of the spoke and the spoke diameter.

If you hear different tone frequencies from different spokes of equal length and diameter, this is an indication of different spoke tensions.

You should hear a high note.


- » If the spoke tension varies:
 - Correct the spoke tension. 🛠️
- Check the spoke torque.

Guideline		
Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)
Torque wrench with various accessories in set (58429094000)		

14.1 Removing the battery


Warning
Risk of injury Batteries contain harmful substances.

- Keep batteries out of the reach of children.
- Keep sparks and open flames away from the battery.
- Only charge in well-ventilated rooms.
- Maintain the minimum clearance to inflammable materials while charging.
Minimum clearance 1 m (3 ft)
- Over-discharged batteries with a charge of less than 9 V are not permitted to be charged. They must be disposed of.



- Preparatory work**
- Switch off all power consumers and switch off the engine.
 - Remove the air filter box cover. (p. 44)
 - Remove the seat. (p. 43)
- Main work**
- Pull back the negative terminal cover 1 and disconnect negative cable 2 from the battery.
 - Pull back the positive terminal cover 3 and disconnect positive cable 4 from the battery.
 - Remove screw 5.
 - Pull holding bracket 6 forward and take out the battery toward the top.

14.2 Installing the battery



- Main work**
- Insert the battery into the battery compartment with the terminals facing forward and secure with the holding bracket 1.
- Battery (C22S) (p. 95)
- Mount and tighten screw 2.
- Guideline
- | | | |
|--------------------------------|----|--------------------|
| Screw, battery support bracket | M6 | 10 Nm (7.4 lbf ft) |
|--------------------------------|----|--------------------|

i Info
Contact disks A must be mounted between screws 3 and cable sockets 4 with the claws facing down.

- Connect positive cable 5 to the battery.
- Guideline
- | | | |
|-------------------------|----|----------------------|
| Screw, battery terminal | M5 | 2.5 Nm (1.84 lbf ft) |
|-------------------------|----|----------------------|
- Slide positive terminal cover 6 over the positive terminal.
 - Connect negative cable 7 to the battery.

Guideline

Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)
-------------------------	----	-------------------------

- Slide the negative terminal cover **8** over the negative terminal.

Finishing work

- Mount the seat. (🔧 p. 44)
- Install the air filter box cover. (🔧 p. 44)

14.3 Recharging the battery 🔧



Warning

Risk of injury Batteries contain harmful substances.

- Keep batteries out of the reach of children.
- Keep sparks and open flames away from the battery.
- Only charge in well-ventilated rooms.
- Maintain the minimum clearance to inflammable materials while charging.
Minimum clearance 1 m (3 ft)
- Over-discharged batteries with a charge of less than 9 V are not permitted to be charged. They must be disposed of.



Warning

Environmental hazard Batteries contain environmentally-hazardous materials.

- Do not dispose of batteries as household waste.
- Return batteries to your authorized Husqvarna Motorcycles dealer or dispose of them at a collection point for used batteries.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

Even when there is no load on the battery, it discharges steadily.
The charging level and the method of charging are very important for the service life of the battery.
Rapid recharging with a high charging current shortens the service life of the battery.
If the charging current, charging voltage, or charging time are exceeded, the battery will be destroyed.
If the battery is depleted by repeated starting, the battery must be charged immediately.
If the battery is left in a discharged state for an extended period, it will become over-discharged and sulfated, destroying the battery.
The battery is maintenance-free.

Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the air filter box cover. (🔧 p. 44)
- Remove the seat. (🔧 p. 43)
- Remove the battery. 🔧 (🔧 p. 71)

Main work

- Check the battery voltage.
 - » Battery voltage: < 9 V
 - Do not charge the battery.
 - Replace the battery and dispose of the old battery properly.
 - » If the specifications have been met:
Battery voltage: ≥ 9 V
 - Recharge the battery.



Guideline

The charging current, charging voltage, and charging time must not be exceeded.	
Maximum loading voltage	14.4 V
Maximum loading current	3.0 A
Charge the battery regularly when the motorcycle is not in use	6 months

 **Info**
Never remove lid ❶.

- Connect the battery charger to the battery. Switch on the battery charger.

Battery charger (81229074000)

You can also use the battery charger to test the open-circuit voltage and start potential of the battery, and to test the alternator. With this device, you cannot overcharge the battery. The charging time may be longer at low temperatures.

- Switch off the battery charger after charging and disconnect from the battery.

Finishing work

- Install the battery. (🔧 p. 71)
- Mount the seat. (🔧 p. 44)
- Install the air filter box cover. (🔧 p. 44)

14.4 Main fuse, changing

 **Warning**
Fire hazard The electrical system can be overloaded if the wrong fuses are used.

- Use only fuses with the prescribed amperage. Never bypass or repair fuses.


 **Info**
The main fuse protects all power consumers of the vehicle. It is located in the starter relay housing under the seat.


Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the air filter box cover. (🔧 p. 44)
- Remove the seat. (🔧 p. 43)

Main work

- Pull starter relay ❶ from the holder.





- Take off protection caps ②.
- Remove the faulty main fuse ③.

i Info

A defective fuse is indicated by a burned-out fuse wire **A**.
A spare fuse ④ is located in the starter relay.

- Install a new main fuse.

Fuse (58011109110) (☛ p. 95)

- Check that the electrical equipment is functioning properly.

i Tip


Insert a spare fuse so that it is available if needed.

- Mount the protection caps.
- Mount the starter relay onto the holder and lay the cable.

Finishing work

- Mount the seat. (☛ p. 44)
- Install the air filter box cover. (☛ p. 44)

15.1 Cooling system




Water pump ❶ in the engine circulates the coolant.
The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ❷. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream.
The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

15.2 Checking the antifreeze and coolant level

- **Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.



- Condition**
The engine is cold.
- Stand the motorcycle upright on a horizontal surface.
 - Remove the radiator cap.
 - Check antifreeze of coolant.
- 25... -45 °C (-13... -49 °F)
- » If the antifreeze in the coolant does not match the specified value:
 - Correct the antifreeze of the coolant.
 - Check the coolant level in the radiator.
- | | |
|---|-----------------|
| Coolant level ❸ above the radiator fins | 10 mm (0.39 in) |
|---|-----------------|
- » If the coolant level does not match the specified value:
 - Correct the coolant level.
- Coolant (🔧 p. 98)
- Mount the radiator cap.

15.3 Checking the coolant level

- **Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.

Condition

The engine is cold.

- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the coolant level in the radiator.

Coolant level A above the radiator fins	10 mm (0.39 in)
--	-----------------

- » If the coolant level does not match the specified value:
 - Correct the coolant level.

Coolant (🔧 p. 98)

- Mount the radiator cap.

15.4 Draining the coolant 🛠

- **Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.



Condition

The engine is cold.

- Position the motorcycle upright.
- Place a suitable container under the water pump cover.
- Remove screw **1**. Take off radiator cap **2**.
- Completely drain the coolant.
- Mount and tighten screw **1** with a new seal ring.

Guideline


Screw, water pump cover	M6	10 Nm (7.4 lbf ft)
-------------------------	----	--------------------



15.5 Refilling coolant 🛠️

 **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.

- Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.




- Make sure that screw 1 is tightened.
- Position the motorcycle upright.
- Pour coolant in up to measurement A above the radiator fins.

Guideline

Dimension A over the radiator fins		10 mm (0.39 in)
Coolant	0.95 l (1 qt.)	Coolant (🔧 p. 98)

- Mount the radiator cap.
- Take a short test ride.
- Check the coolant level. (🔧 p. 76)

16.1 Checking the play in the throttle cable



- Check the throttle grip for smooth operation.
- Move the handlebar to the straight-ahead position. Turn the throttle grip back and forth slightly and determine the play in throttle cable **A**.

Play in throttle cable	3... 5 mm (0.12... 0.2 in)
------------------------	----------------------------

- » If the throttle cable play does not meet specifications:
- Adjust the play in the throttle cable. ↗ (p. 78)



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:
- Adjust the play in the throttle cable. ↗ (p. 78)

16.2 Adjusting the play in the throttle cable ↗

Preparatory work

- Remove the right side cover. (p. 47)
- Remove the air filter box cover. (p. 44)
- Remove the seat. (p. 43)
- Remove the fuel tank. ↗ (p. 48)
- Check the throttle cable routing. (p. 54)


Main work

- Move the handlebar to the straight-ahead position.
- Push back sleeve **1**.
- Loosen nut **2**. Turn adjusting screw **3** in as far as possible.
- Loosen nut **4**.
- Push cold start button **6** all the way to the stop.
- Turn adjusting screw **5** so that the cold start button moves to the basic position when the throttle grip is turned to the front.
- Tighten nut **4**.
- Turn adjusting screw **3** so that there is play in the throttle cable at the throttle grip.

Guideline

Play in throttle cable	3... 5 mm (0.12... 0.2 in)
------------------------	----------------------------

- Tighten nut **2**.
- Slide on sleeve **1**. Check the throttle grip for smooth operation.




Finishing work


- Check the play in the throttle cable. (p. 78)
- Install the fuel tank. ↗ (p. 49)
- Mount the seat. (p. 44)
- Install the air filter box cover. (p. 44)
- Install the right side cover. (p. 47)

16.3 Setting the characteristic map of the throttle response

Info
On the throttle grip, the characteristic map of the throttle response is changed by changing the guide plate. A guide plate with a different characteristic map is supplied.



- Main work**
- Push back sleeve 1.
 - Remove screws 2 and half-shells 3.
 - Detach the throttle cables and take off the grip tube.




- Remove guide plate 4 from handle tube 5.
- Position the required guide plate on the grip tube.

Guideline
The label **OUTSIDE** must be visible. Marking **A** must be positioned at marking **B**.


Alternative 1
Grey guide plate (79002014000)

Alternative 2
Black guide plate (79002014100)

Info
The gray guide plate opens the throttle valve more slowly.
The black guide plate opens the throttle valve more quickly.
The gray guide plate is mounted upon delivery.



- Clean the outside of the handlebar and the inside of the grip tube. Mount the grip tube on the handlebar.
- Attach the throttle cables to the guide plate and route correctly.



- Position half-shells 3, mount and tighten screws 2.


Guideline
Screw, throttle grip M6 5 Nm (3.7 lbf ft)

- Slide on sleeve 1 and check the throttle grip for ease of movement.

Finishing work
- Check the play in the throttle cable. (p. 78)

16.4 Changing the mapping

i Info
To be able to enable the desired engine characteristic via the **Map-Select** riding mode switch in position **II**, the desired mapping must first be selected at the **Map-Select** switch for the basic setting.



Switch the mapping from **STANDARD** to **SOFT** or **ADVANCED**

- Turn switch **1** to position **II**.
 - ✓ **SOFT** – soft response
 - ✓ **ADVANCED** – direct response

Switch the mapping from **STANDARD** to **SOFT** or **ADVANCED**

- Turn switch **1** to position **I**.
 - ✓ **STANDARD** – balanced response

16.5 Adjusting the idle speed

! Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

! Warning
Danger of accidents The engine may go out spontaneously if the idle speed is set too low.


- Set the idle speed to the specified value.



- Run the engine until warm.
 - ✓ The cold start button is deactivated – The cold start button is in its basic position. (☛ p. 14)
- Set the idle speed by turning the idle speed adjusting screw **1**.

Guideline


Idle speed	2,250... 2,350 rpm
Tachometer (45129075000)	



i Info
Turning counterclockwise lowers the idle speed.
Turning clockwise raises the idle speed.

16.6 Program throttle valve position

i Info
If the control unit detects that the throttle valve idle position needs to be retaught, then the **MIL** flashes 2x per second.



Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Allow the vehicle to idle.
- ✓ The **MIL** stops flashing once teaching is completed.




Info
If the engine becomes too hot, perform a cool-down ride at medium revs. Then do not switch off the engine after this, but leave it running at idle speed until teaching is completed.

16.7 Checking the basic position of the shift lever



Info
When driving, the shift lever must not touch the rider's boot when in the basic position.
When the shift lever keeps touching the boot, the transmission will be subject to an excessive load.




- Sit on the vehicle in the riding position and determine distance **A** between the upper edge of your boot and the shift lever.


Distance between shift lever and upper edge of boot	10... 20 mm (0.39... 0.79 in)
---	-------------------------------

- » If the distance does not meet specifications:
 - Adjust the basic position of the shift lever. (p. 81)

16.8 Adjusting the basic position of the shift lever



- Remove screw **1** with washers and take off shift lever **2**.



- Clean gear teeth **A** of the shift lever and shift shaft.
- Mount the shift lever on the shift shaft in the required position and engage the gearing.



Info
The range of adjustment is limited.
The shift lever must not come into contact with any other vehicle components during the shift procedure.

- Locate and tighten screw **1** with washers.

Guideline

Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
--------------------	----	---------------------	---------------

17.1 Changing the fuel screen



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.


- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.



Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Clean plug-in connection **1** of the fuel line thoroughly with compressed air.



Info

Dirt should not be allowed to get into the fuel line under any circumstances. Dirt in the fuel line clogs the injection valve!

- Disconnect the plug-in connection of the fuel line.



Info

Remaining fuel may run out of the fuel pipe.

- Pull fuel screen **2** out of the connecting piece.
- Insert the new fuel screen all the way into the connecting piece.
- Lubricate the O-ring and connect plug-in connection of the fuel line.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
- Start the engine and check the response.

17.2 Checking the engine oil level



Info

The engine oil level can be checked when the engine is cold or warm.



Preparatory work

- Stand the motorcycle upright on a horizontal surface.


Condition

The engine is cold.

- Check the engine oil level.

The engine oil reaches the middle of level viewer **A**.

- » If the engine oil does not reach the middle of the level viewer:
 - Add engine oil. (p. 85)



Condition

The engine is at operating temperature.

- Check the engine oil level.



Info

After switching off the engine, wait one minute before checking the level.

The engine oil level is between the middle of the level viewer **A** and the upper edge of the level viewer **B**.

- » If the engine oil does not reach the middle of level viewer **A**:
 - Add engine oil. (➡ p. 85)

17.3 Changing the engine oil and oil filter, cleaning the oil screen



Warning

Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

Check the O-rings for damage.

Replace damaged O-rings.

Drain the engine oil while the engine is at operating temperature.

Preparatory work

- Park the motorcycle on a level surface.



Main work

- Place a suitable container under the engine.
- Remove oil drain plug **1** with the magnet and seal ring.




Info


Do not remove screws **2** on both sides.



- Remove screw plug **3** with oil screen **4**.
- Completely drain the engine oil.
- Thoroughly clean the parts and sealing surfaces.



- Position oil screen **4** with the O-rings on a pin wrench.
- Position the pin wrench through the drilled hole of the screw plug in the opposite section of the engine case.
- Push the oil screen all the way into the engine case.



- Mount and tighten screw plug **3** with the O-ring.


Guideline

Screw plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
------------------------	---------	---------------------


- Mount and tighten the oil drain plug **1** with the magnet and a new seal ring.

Guideline

Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
----------------------------	---------	---------------------




- Remove screws **5**. Remove the oil filter cover with the O-ring.



- Pull oil filter **6** out of the oil filter housing.

Circlip pliers reverse (51012011000)

- Completely drain the engine oil.
- Thoroughly clean the parts and sealing surfaces.




- Lay the motorcycle on its side and fill the oil filter housing to about $\frac{1}{3}$ full with engine oil.
- Fill the oil filter with engine oil and position the oil filter in the housing.
- Oil the O-ring of the oil filter cover and mount it with the oil filter cover **7**.
- Mount and tighten the screws.

Guideline

Screw, oil filter cover	M6	10 Nm (7.4 lbf ft)
-------------------------	----	--------------------

- Stand the motorcycle upright.



- Remove the oil filler plug **8** with the O-ring from the clutch cover and fill up with engine oil.

Engine oil	1.0 l (1.1 qt.)	Engine oil (SAE 10W/50) (☛ p. 98)
------------	-----------------	-----------------------------------



Info

Too little engine oil or poor-quality engine oil results in premature wear to the engine.

- Install and tighten the oil filler plug with O-ring.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.

Finishing work



- Check the engine oil level. (☛ p. 82)

17.4 Adding engine oil



Info

Too little engine oil or poor-quality engine oil results in premature wear to the engine.



Main work

- Remove oil filler plug ① with the O-ring from the clutch cover.
- Fill engine oil to the middle ① of the level viewer.
- Add the same engine oil that was used when the last oil change was carried out.

Engine oil (SAE 10W/50) (☛ p. 98)



Info

For optimal performance of the engine oil, do not mix different types of engine oil.

If appropriate, change the engine oil.

- Install and tighten the oil filler plug with O-ring.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.

Finishing work

- Check the engine oil level. (☛ p. 82)

18.1 Cleaning the motorcycle

Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

- When cleaning the vehicle with a pressure cleaner, do not point the water jet directly onto electrical components, connectors, cables, bearings, etc. Maintain a minimum distance of 60 cm between the nozzle of the pressure cleaner and the component. Excessive pressure can cause malfunctions or destroy these parts.


Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info

If you clean the motorcycle regularly, its value and appearance will be maintained over a long period.
Avoid direct sunshine on the motorcycle during cleaning.



- Close off the exhaust system to prevent water from entering.
- First remove coarse dirt particles with a gentle spray of water.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a paintbrush.

Info

Use warm water containing normal motorcycle cleaner and a soft sponge.
Never apply motorcycle cleaner to the dry vehicle; always rinse with water first.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Remove the plug from the exhaust system.



Warning

Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

- Clean or dry a dirty or wet brake system by riding and braking gently.

- After cleaning, ride a short distance until the engine reaches operating temperature.

Info

The heat produced causes water at inaccessible locations in the engine and the brake system to evaporate.

- After the motorcycle has cooled off, lubricate all moving parts and bearings.
- Clean the chain. (☛ p. 50)
- Treat bare metal parts (except for brake discs and the exhaust system) with a corrosion inhibitor.

Preserving materials for paints, metal and rubber (☛ p. 99)

- Treat all plastic parts and powder-coated parts with a mild cleaning and care agent.

19.1 Storage



Warning


Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that has been contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.



Info

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed. Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.
- Refuel. (🔧 p. 23)
- Clean the motorcycle. (🔧 p. 86)
- Change the engine oil and oil filter, clean the oil screen. 🛢️ (🔧 p. 83)
- Check the antifreeze and coolant level. (🔧 p. 75)
- Check the tire air pressure. (🔧 p. 69)
- Remove the battery. 🛢️ (🔧 p. 71)
- Recharge the battery. 🛢️ (🔧 p. 72)

Guideline

Storage temperature of battery with-out direct sunshine	0... 35 °C (32... 95 °F)
---	--------------------------

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.



Info

Husqvarna Motorcycles recommends raising the motorcycle.

- Raise the motorcycle with a lift stand. (🔧 p. 33)
- Cover the vehicle with a tarp or similar cover that is permeable to air.




Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.

Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and the exhaust system to rust.

19.2 Preparing for use after storage



- Install the battery. 🛢️ (🔧 p. 71)
- Remove the motorcycle from the lift stand. (🔧 p. 33)
- Perform checks and maintenance work when preparing the vehicle for use. (🔧 p. 20)
- Make a test ride.

Faults	Possible cause	Action
The engine does not turn when the starter button is pressed	Operating error	– Carry out the start procedure. (☞ p. 20)
	Battery is discharged	– Recharge the battery. ☞ (☞ p. 72) – Check the charging voltage. ☞ – Check the quiescent current. ☞ – Check the stator winding of the alternator. ☞
	Main fuse blown	– Change the main fuse. (☞ p. 73)
	Starter relay defective	– Check the starter relay. ☞
	Starter motor defective	– Check the starter motor. ☞
Engine turns but does not start	The plug-in connection of the fuel hose connection is not connected	– Connect the plug-in connection of the fuel line.
	Fuel screen in the fuel hose connection is clogged	– Change the fuel screen. ☞ (☞ p. 82)
	Idle speed is not set correctly	– Adjust the idle speed. ☞ (☞ p. 80)
	Spark plug oily or wet	– Clean and dry the spark plug, or change it if necessary.
	Electrode distance (plug gap) of spark plug too wide	– Adjust the plug gap. Guideline Spark plug electrode gap 0.8 mm (0.031 in)
	Short circuit cable in wiring harness frayed, kill switch defective	– Check the wiring harness. (visual check) – Check the electrical system.
	Defect in fuel injection system	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. ☞
Engine does not speed up	Defect in fuel injection system	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. ☞
Engine has too little power	Air filter is very dirty	– Clean the air filter and air filter box. ☞ (☞ p. 45)
	Fuel filter is very dirty	– Change the fuel filter. ☞
	Defect in fuel injection system	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. ☞
	Exhaust system leaky, deformed or too little glass fiber yarn filling in main silencer	– Check exhaust system for damage. – Change the glass fiber yarn filling of the main silencer. ☞ (☞ p. 46)
	Valve clearance too little	– Adjust the valve clearance. ☞
Engine dies during the trip	Lack of fuel	– Refuel. (☞ p. 23)
Engine overheats	Too little coolant in cooling system	– Check the cooling system for leakage. – Check the coolant level. (☞ p. 76)
	Too little air stream	– Switch off the engine when standing.
	Radiator fins very dirty	– Clean radiator fins.
	Foam formation in cooling system	– Drain the coolant. ☞ (☞ p. 76) – Refill the coolant. ☞ (☞ p. 77)
	Bent radiator hose	– Change the radiator hose. ☞
FI warning lamp (MIL) lights up/flashes	Defect in fuel injection system	– Stop the motorcycle and identify the faulty part using the blink code. – Check the cabling for damage and the electrical plug-in connections for corrosion and damage. – Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. ☞
High oil consumption	Engine vent hose bent	– Route the vent hose without bends or change it if necessary.
	Engine oil level too high	– Check the engine oil level. (☞ p. 82)
	Engine oil too thin (low viscosity)	– Change the engine oil and oil filter, clean the oil screen. ☞ (☞ p. 83)

Faults	Possible cause	Action
High oil consumption	Piston or cylinder worn	– Measure the piston/cylinder mounting clearance.
Battery is discharged	Battery is not charging	– Check the charging voltage. 🔧 – Check the stator winding of the alternator. 🔧
	Unwanted power consumer	– Check the quiescent current. 🔧

Blink code of FI warning lamp (MIL)	 02a FI warning lamp (MIL) flashes 2x per second
Error level condition	Teaching of throttle valve position required
Blink code of FI warning lamp (MIL)	 02 FI warning lamp (MIL) flashes 2x short
Error level condition	Crankshaft position sensor - circuit fault
Blink code of FI warning lamp (MIL)	 06 FI warning lamp (MIL) flashes 6x short
Error level condition	Throttle position sensor circuit A - input signal too low Throttle position sensor circuit A - input signal too high
Blink code of FI warning lamp (MIL)	 09 FI warning lamp (MIL) flashes 9x short
Error level condition	Manifold absolute pressure sensor cylinder 1 - input signal too low Manifold absolute pressure sensor cylinder 1 - input signal too high
Blink code of FI warning lamp (MIL)	 12 FI warning lamp (MIL) flashes 1x long, 2x short
Error level condition	Engine coolant temperature sensor - input signal too low Engine coolant temperature sensor - input signal too high
Blink code of FI warning lamp (MIL)	 13 FI warning lamp (MIL) flashes 1x long, 3x short
Error level condition	Intake air temperature sensor - input signal too low Intake air temperature sensor - input signal too high
Blink code of FI warning lamp (MIL)	 15 FI warning lamp (MIL) flashes 1x long, 5x short
Error level condition	Rollover sensor (A/D type) - input signal too low Rollover sensor (A/D type) - input signal too high
Blink code of FI warning lamp (MIL)	 21 FI warning lamp (MIL) flashes 2x long, 1x short
Error level condition	Battery voltage – input voltage too high
Blink code of FI warning lamp (MIL)	 22 FI warning lamp (MIL) flashes 2x long, 2x short
Error level condition	Gear position sensor - input voltage too high Gear position sensor - input voltage too low
Blink code of FI warning lamp (MIL)	 33 FI warning lamp (MIL) flashes 3x long, 3x short
Error level condition	Injector cylinder 1 - circuit fault
Blink code of FI warning lamp (MIL)	 37 FI warning lamp (MIL) flashes 3x long, 7x short
Error level condition	Ignition coil 1, cylinder 1 - circuit fault

Blink code of FI warning lamp (MIL)	41 FI warning lamp (MIL) flashes 4x long, 1x short
Error level condition	Fuel pump relay - short circuit to ground or open circuit
	Fuel pump relay - Input signal too low

22.1 Engine

Design	1-cylinder 4-stroke engine, water-cooled
Displacement	349.7 cm ³ (21.34 cu in)
Stroke	57.5 mm (2.264 in)
Bore	88 mm (3.46 in)
Compression ratio	14.0:1
Idle speed	2,250... 2,350 rpm
Control	DOHC, four valves controlled via cam lever, drive via timing chain
Valve diameter, intake	36.3 mm (1.429 in)
Valve diameter, exhaust	29.1 mm (1.146 in)
Valve clearance	
Intake at: 20 °C (68 °F)	0.10... 0.15 mm (0.0039... 0.0059 in)
Exhaust at: 20 °C (68 °F)	0.13... 0.18 mm (0.0051... 0.0071 in)
Crankshaft bearing	2 cylinder bearings
Conrod bearing	Plain bearing
Piston pin bearing	Bearing bush
Pistons	Forged light alloy
Piston rings	1 compression ring, 1 oil scraper ring
Engine lubrication	Pressure circulation lubrication with two Eaton pumps
Primary transmission	24:73
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	5-gear, claw shifted
Transmission ratio	
1st gear	14:28
2nd gear	16:26
3rd gear	18:24
4th gear	21:24
5th gear	22:21
Alternator	12 V, 66 W
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment
Spark plug	NGK LMAR9AI-8
Spark plug electrode gap	0.8 mm (0.031 in)
Cooling	Water cooling, permanent circulation of coolant by water pump
Starting aid	Electric starter

22.2 Engine tightening torques

Nozzle, crank chamber ventilation	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Oil nozzle for alternator cooling	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Oil nozzle for balancer shaft lubrication	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Oil nozzle for clutch lubrication	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Oil nozzle for conrod bearing lubrication	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Screw, oil nozzle for piston cooling	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Locking screw for bearing	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Oil channel screw plug in alternator cover	M5	1.2 Nm (0.89 lbf ft)	Loctite® 648™
Oil nozzle for cam lever lubrication	M5	3 Nm (2.2 lbf ft)	Loctite® 243™
Oil nozzle, piston cooling	M5	2 Nm (1.5 lbf ft)	Loctite® 243™

Screw, bearing bolt, oil pump idler gear	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, crankshaft position sensor	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, gear position sensor	M5	5 Nm (3.7 lbf ft)	Loctite® 243™
Screw, locking lever	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, oil pump cover	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, stator	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Nut, cylinder head	M6	10 Nm (7.4 lbf ft)	Lubricated with engine oil
Nut, water-pump wheel	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, alternator cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch slave cylinder	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch spring	M6	10 Nm (7.4 lbf ft)	–
Screw, engine case	M6	10 Nm (7.4 lbf ft)	–
Screw, exhaust flange	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, oil filter cover	M6	10 Nm (7.4 lbf ft)	–
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, starter motor	M6	10 Nm (7.4 lbf ft)	–
Screw, timing chain guide rail	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, timing chain securing guide	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, valve cover	M6	8 Nm (5.9 lbf ft)	–
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	–
Stud, cylinder head	M6	10 Nm (7.4 lbf ft)	–
Screw, auto decompression	M7x1	15 Nm (11.1 lbf ft)	Loctite® 243™
Screw, camshaft bearing bridge	M7x1	14 Nm (10.3 lbf ft)	Lubricated with engine oil
Screw plug, crankshaft location	M8	10 Nm (7.4 lbf ft)	–
Screw, timing chain tensioning rail	M8	15 Nm (11.1 lbf ft)	Loctite® 243™
Screw, engine sprocket	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
Plug, oil channel	M10x1	15 Nm (11.1 lbf ft)	Loctite® 243™
Rotor screw	M10x1	70 Nm (51.6 lbf ft)	Thread, oiled with engine oil/cone degreased
Screw plug, cam lever axis	M10x1	10 Nm (7.4 lbf ft)	–
Screw, unlocking of timing chain tensioner	M10x1	8 Nm (5.9 lbf ft)	–
Spark plug	M10x1	10... 12 Nm (7.4... 8.9 lbf ft)	–
Coolant temperature sensor	M10x1.25	12 Nm (8.9 lbf ft)	–
Nut, cylinder head	M10x1.25	Tightening sequence: Tighten diagonally. 1st tightening stage 10 Nm (7.4 lbf ft) 2nd tightening stage 30 Nm (22.1 lbf ft) 3rd tightening stage 50 Nm (36.9 lbf ft)	Thread, oiled with engine oil/cone greased
Stud, cylinder head	M10x1.25	20 Nm (14.8 lbf ft)	Loctite® 243™
Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Plug, oil pressure regulator valve	M12x1.5	20 Nm (14.8 lbf ft)	–
Oil drain plug	M14x1.5	15 Nm (11.1 lbf ft)	–
Nut, inner clutch hub	M18x1.5	100 Nm (73.8 lbf ft)	Loctite® 243™
Nut, primary gear	M18LHx1.5	100 Nm (73.8 lbf ft)	Loctite® 243™
Screw plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)	–
Plug, timing chain tensioner	M24x1.5	40 Nm (29.5 lbf ft)	–
Screw, alternator cover	M24x1.5	18 Nm (13.3 lbf ft)	–

22.3 Capacities**22.3.1 Engine oil**

Engine oil	1.0 l (1.1 qt.)	Engine oil (SAE 10W/50) (☛ p. 98)
------------	-----------------	-----------------------------------

22.3.2 Coolant

Coolant	0.95 l (1 qt.)	Coolant (☛ p. 98)
---------	----------------	-------------------

22.3.3 Fuel

Total fuel tank capacity, approx.	7 l (1.8 US gal)	Super unleaded (ROZ 95/RON 95/PON 91) (☛ p. 98)
-----------------------------------	------------------	---

22.4 Chassis

Frame	Central tube frame made of chrome molybdenum steel tubing
Fork	WP Performance Systems Up Side Down 4860 MXMA 4CS
Suspension travel	
front	300 mm (11.81 in)
rear	300 mm (11.81 in)
Fork offset	22 mm (0.87 in)
Shock absorber	WP Performance Systems 5018 DCC Link
Brake system	Disc brakes, brake calipers on floating bearings
Brake discs - diameter	
Front	260 mm (10.24 in)
Rear	220 mm (8.66 in)
Brake discs - wear limit	
Front	2.5 mm (0.098 in)
Rear	3.5 mm (0.138 in)
Tire air pressure off road	
Front	1.0 bar (15 psi)
Rear	1.0 bar (15 psi)
Secondary ratio	14:50
Chain	5/8 x 1/4"
Rear sprockets available	48, 50, 52
Steering head angle	63.9°
Wheelbase	1,485±10 mm (58.46±0.39 in)
Seat height, unloaded	960 mm (37.8 in)
Ground clearance, unloaded	370 mm (14.57 in)
Weight without fuel, approx.	101.7 kg (224.2 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)
Maximum permissible overall weight	335 kg (739 lb.)

22.5 Electrical system

Battery	C22S	Lithium-ion battery Battery voltage: 12 V Nominal capacity: 2.2 Ah maintenance-free
Fuse	58011109110	10 A
FI warning lamp		LED

22.6 Tires

Front tires	Rear tires
80/100 - 21 51M TT Dunlop Geomax MX52F	110/90 - 19 62M TT Dunlop Geomax MX52
Additional information is available in the Service section under: www.husqvarna-motorcycles.com	

22.7 Fork

Fork part number	24.18.7P.57
Fork	WP Performance Systems Up Side Down 4860 MXMA 4CS
Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring length with preload spacer(s)	475 mm (18.7 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	4.6 N/mm (26.3 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	4.8 N/mm (27.4 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	5.0 N/mm (28.6 lb/in)
Fork length	940 mm (37.01 in)
Oil capacity per fork leg	670 ml (22.65 fl. oz.)
Fork oil (SAE 4) (48601166S1) (☛ p. 98)	

22.8 Shock absorber

Shock absorber article number	18.18.7P.57
Shock absorber	WP Performance Systems 5018 DCC Link
Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring preload	7 mm (0.28 in)

Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	45 N/mm (257 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	48 N/mm (274 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	51 N/mm (291 lb/in)
Spring length	
Weight of rider: 65... 75 kg (143... 165 lb.)	247 mm (9.72 in)
Weight of rider: 75... 85 kg (165... 187 lb.)	247 mm (9.72 in)
Weight of rider: 85... 95 kg (187... 209 lb.)	252 mm (9.92 in)
Gas pressure	10 bar (145 psi)
Static sag	40 mm (1.57 in)
Riding sag	110 mm (4.33 in)
Fitted length	477 mm (18.78 in)
Shock absorber oil	Shock absorber fluid (SAE 2.5) (50180751S1) (☛ p. 98)

22.9 Chassis tightening torques

Screw air intake temperature sensor	EJOT PT® 45x12-Z	0.7 Nm (0.52 lbf ft)	–
Screw, pressure regulator	EJOT PT® K60x25-Z	3 Nm (2.2 lbf ft)	–
Screw, fixed grip	M4	5 Nm (3.7 lbf ft)	Loctite® 243™
Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)	–
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)	–
Remaining nuts, chassis	M5	5 Nm (3.7 lbf ft)	–
Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)	–
Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)	–
Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)	–
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)	–
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)	–
Screw, ball joint of push rod on foot brake cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, electric starter cable connection	M6	4 Nm (3 lbf ft)	–
Screw, front brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, throttle grip	M6	5 Nm (3.7 lbf ft)	–
Fuel connection on fuel tank	M8	10 Nm (7.4 lbf ft)	–
Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)	–
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft)	Loctite® 2701™
Nut, rim lock	M8	12 Nm (8.9 lbf ft)	–
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)	–
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)	–
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)	–
Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)	–
Screw, engine brace	M8	25 Nm (18.4 lbf ft)	Loctite® 2701™
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	–
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	–
Screw, subframe	M8	30 Nm (22.1 lbf ft)	Loctite® 2701™
Screw, top steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)	–
Engine carrying screw	M10	60 Nm (44.3 lbf ft)	–
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)	–
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)	–

Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	Loctite® 243™
Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)	Loctite® 2701™
Nut, fuel pump	M12	15 Nm (11.1 lbf ft)	–
Nut, frame to linkage lever	M14x1.5	80 Nm (59 lbf ft)	–
Nut, linkage lever on swingarm	M14x1.5	80 Nm (59 lbf ft)	–
Nut, linkage lever to angle lever	M14x1.5	80 Nm (59 lbf ft)	–
Nut, swingarm pivot	M16x1.5	100 Nm (73.8 lbf ft)	–
Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)	–
Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)	–
Screw-in nozzles, cooling system	M20x1.5	12 Nm (8.9 lbf ft)	Loctite® 243™
Nut, rear wheel spindle	M25x1.5	80 Nm (59 lbf ft)	–

Brake fluid DOT 4**Standard/classification**

- DOT

Guideline

- Use only brake fluid that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties.

Recommended supplier**Bel-Ray®**

- **Super DOT 4 Brake Fluid**

Coolant**Guideline**

- Only use high quality coolant with corrosion inhibitor for aluminum motors (even in countries with high temperatures). Using inferior antifreeze can result in corrosion and foaming.

Mixture ratio

Antifreeze protection: -25... -45 °C (-13... -49 °F)	anti-corrosion/antifreeze distilled water
--	---

Recommended supplier**Bel-Ray®**

- **Moto Chill Racing Coolant**

Engine oil (SAE 10W/50)**Standard/classification**

- JASO T903 MA (☛ p. 100)
- SAE (☛ p. 100) (SAE 10W/50)

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Synthetic engine oil

Recommended supplier**Bel-Ray®**

- **Works Thumper Racing Synthetic Ester 4T**

Fork oil (SAE 4) (48601166S1)**Standard/classification**

- SAE (☛ p. 100) (SAE 4)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Shock absorber fluid (SAE 2.5) (50180751S1)**Standard/classification**

- SAE (☛ p. 100) (SAE 2.5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Super unleaded (ROZ 95/RON 95/PON 91)**Standard/classification**

- DIN EN 228 (ROZ 95/RON 95/PON 91)

Guideline

- Only use unleaded super fuel that matches or is equivalent to the specified fuel grade.
- Fuel with an ethanol content of up to 10 % (E10 fuel) is safe to use.

**Info**

Do **not** use fuel containing methanol (e. g. M15, M85, M100) or more than 10 % ethanol (e. g. E15, E25, E85, E100).

Air filter cleaning agent

Recommended supplier

Bel-Ray®

- Foam Filter Cleaner & Degreaser

High viscosity grease

Recommended supplier

SKF®

- LGHB 2

Long-life grease

Recommended supplier

Bel-Ray®

- Waterproof Grease

Offroad chain spray

Guideline

Recommended supplier

Bel-Ray®

- Blue Tac Chain Lube

Oil for foam air filter

Recommended supplier

Bel-Ray®

- Foam Filter Oil

Preserving materials for paints, metal and rubber

Recommended supplier

Bel-Ray®

- Silicone Detailer & Protectant Spray

Universal oil spray

Recommended supplier

Bel-Ray®

- 6 in 1

JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles – the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. In most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

MIL	Malfunction indicator lamp	Indicator lamp that supports vehicle diagnostics through flash codes
OBD	On-board diagnosis	Vehicle system that monitors emission- and safety-related values

Art. no.	Article number
ca.	circa
cf.	compare
e.g.	for example
etc.	et cetera
i.a.	inter alia
no.	number
poss.	possibly

28.1 Yellow and orange symbols

Yellow and orange symbols indicate an error condition that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	FI warning lamp (MIL) lights up/flashes orange – The OBD has detected an emission- or safety-critical fault.
---	--

A	
Accessories	7
Air filter	
cleaning	45
installing	45
removing	45
Air filter box	
cleaning	45
Air filter box cover	
installing	44
removing	44
Antifreeze	
checking	75
Auxiliary substances	7
B	
Basic chassis setting	
checking with rider's weight	26
Battery	
installing	71
recharging	72
removing	71
starting power	17
Blink code	90-91
Brake discs	
checking	57
Brake fluid	
front brake, adding	58
rear brake, adding	62
Brake fluid level	
front brake, checking	58
rear brake, checking	62
Brake linings	
front brake, changing	59
front brake, checking	59
rear brake, changing	64
rear brake, checking	63
C	
Capacity	
Coolant	77, 94
Engine oil	84, 94
Fuel	23, 94
Chain	
checking	52
cleaning	50
Chain guide	
checking	52
Chain tension	
adjusting	51
checking	51
Characteristic map of the throttle response	
adjusting	79
Chassis number	10

Clutch	
fluid level, checking/correcting	55
fluid, changing	55
Clutch lever	11
basic position, adjusting	55
Cold start button	14
Compression damping	
fork, adjusting	30
Compression damping, high-speed	
shock absorber, adjusting	27
Compression damping, low-speed	
shock absorber, adjusting	26
Coolant	
draining	76
refilling	77
Coolant level	
checking	75-76
Cooling system	75
Customer service	7
D	
Difficult riding conditions	17
dry sand	18
high temperature	19
low temperature	19
muddy surfaces	19
slow speed	19
snow	19
wet sand	18
wet surfaces	19
E	
Electric starter button	11
Engine	
running in	17
Engine number	10
Engine oil	
adding	85
changing	83
Engine oil level	
checking	82
Environment	6
F	
Figures	7
Filler cap	
closing	13
opening	13
Foot brake lever	15
basic position, adjusting	61
free travel, checking	61
Fork legs	
basic setting, checking	30
bleeding	33
compression damping, adjusting	30
dust boots, cleaning	34
installing	35

rebound damping, adjusting	31
removing	35
Fork protector	
installing	34
removing	34
Frame	
checking	53
Front fender	
installing	40
removing	40
Front wheel	
installing	66
removing	66
Fuel screen	
changing	82
Fuel tank	
installing	49
removing	48
Fuse	
main fuse, changing	73
H	
Hand brake lever	11
basic position, adjusting	57
free travel, checking	57
Handlebar position	31
adjusting	31
I	
Idle speed	
adjusting	80
Idle speed adjusting screw	14
Implied warranty	7
Intended use	5
K	
Kill switch	11
L	
Launch Control	12
activating	21
Lower triple clamp	
installing	36
removing	36
M	
Main fuse	
changing	73
Main silencer	
glass fiber yarn filling, changing	46
installing	46
removing	46
Mapping	
changing	80
Map-Select switch	
for ride mode	12
for the basic setting	12

Motor sprocket	
checking	52
Motorcycle	
cleaning	86
raising with lift stand	33
removing from lift stand	33
O	
Oil filter	
changing	83
Oil screen	
cleaning	83
Operating substances	7
Overview of indicator lamps	12
Owner's Manual	6
P	
Plug-in-stand	15
Preparing for use	
advice on first use	16
after storage	87
checks and maintenance work when preparing for use	20
Protective clothing	6
R	
Rear sprocket	
checking	52
Rear wheel	
installing	68
removing	67
Rebound damping	
fork, adjusting	31
shock absorber, adjusting	27
Refueling	
fuel	23
Riding sag	
adjusting	30
Right side cover	
installing	47
removing	47
Rubber grips	
checking	54
S	
Safe operation	5
Seat	
mounting	44
removing	43
Service	7
Service schedule	24-25
Shift lever	14
basic position, adjusting	81
basic position, checking	81
Shock absorber	
compression damping, general	26
high-speed compression damping, setting	27
installing	42

low speed compression damping, setting	26
rebound damping, adjusting	27
removing	40
riding sag, checking	29
spring preload, adjusting	29
static sag, checking	28
Shock absorber article number	10
Spare parts	7
Spoke tension	
checking	69
Start number plate	
installing	39
removing	39
Starting	20
Starting power of lithium-ion batteries at low temperatures	17
Steering head bearing	
greasing	39
Steering head bearing play	
adjusting	39
checking	38
Storage	87
Swingarm	
checking	54

T

Technical data	
capacities	94
chassis	94
chassis tightening torques	96
electrical system	95
engine	92
engine tightening torques	92
Fork	95
shock absorber	95
Tires	95
Throttle cable play	
adjusting	78
checking	78
Throttle cable routing	
checking	54
Throttle grip	11
Throttle valve position	
teaching	80
Tire air pressure	
checking	69
Tire condition	
checking	68
Transport	22
Troubleshooting	88-89
Type label	10

U

Use definition	5
-----------------------	---

V

View of vehicle	
front left	8
rear right	9

W

Warranty	7
Work rules	6



3402060en

09/2015

