

OWNER'S MANUAL 2024



Norden 901
Norden 901 Expedition
Art. no. 3402762en



DEAR HUSQVARNA MOTORCYCLES CUSTOMER

Congratulations on your decision to purchase a Husqvarna motorcycle. You are now the owner of a state-of-the-art sports vehicle which, with appropriate care, will bring you pleasure for a long time to come.

We wish you good and safe riding at all times!

Please enter the serial numbers of your vehicle below.

Vehicle identification number (📖 p. 18)	Dealer's stamp
Engine number (📖 p. 19)	
Key number (📖 p. 18)	

The Owner's Manual contained the latest information for this model series at the time of publication. However, minor differences due to further developments in design cannot be ruled out completely.

All specifications contained herein are non-binding. Husqvarna Motorcycles GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. Husqvarna accepts no liability for delivery options, deviations from figures and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2024 Husqvarna Motorcycles GmbH, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



REG.NO. 12 100 6061

ISO 9001(12 100 6061)

Husqvarna Motorcycles applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.

Issued by: TÜV SÜD Management Service GmbH

Husqvarna Motorcycles GmbH
Stallhofnerstraße 3
5230 Mattighofen, Austria

This document is valid for the following models:

Norden 901 US (F2875X1)

Norden 901 Expedition US (F2875X2)



3402762en

26.04.2024

TABLE OF CONTENTS

1	MEANS OF REPRESENTATION.....	6	6.4	Switches on the left side of the handlebar	20
1.1	Symbols used	6	6.4.1	Combination switch.....	20
1.2	Formats used	6	6.4.2	Light switch	21
2	SAFETY ADVICE	7	6.4.3	Cruise control system tip switch	21
2.1	Use definition – intended use	7	6.4.4	Menu buttons	22
2.2	Misuse.....	7	6.4.5	Turn signal switch	23
2.3	Safety advice	7	6.4.6	Horn button	23
2.4	Degrees of risk and symbols	7	6.5	Switches on the right side of the handlebar	23
2.5	Overview of labels.....	8	6.5.1	Start button/emergency OFF switch	23
2.6	Reporting safety defects.....	10	6.5.2	Hazard warning flasher switch	24
2.7	Noise emission warranty.....	10	6.6	Ignition and steering lock.....	24
2.8	Operating noise warning.....	11	6.7	Locking the steering	24
2.9	Manufacturer warranty for the exhaust monitoring system.....	11	6.8	Unlocking the steering	25
2.10	Consumer rights	11	6.9	Supplementary headlight switch	25
2.11	Tampering warning	12	6.10	Socket for electrical accessories	25
2.12	Safe operation.....	12	6.11	USB socket.....	25
2.13	Protective clothing	13	6.12	Opening the fuel tank filler cap	26
2.14	Work rules.....	13	6.13	Closing the fuel tank filler cap.....	26
2.15	Environment.....	13	6.14	Fuel cocks.....	27
2.16	Owner's Manual.....	14	6.15	Opening the storage compartment on the left	27
3	IMPORTANT NOTES	15	6.16	Closing the storage compartment on the left	28
3.1	Manufacturer warranty, implied warranty	15	6.17	Opening the storage compartment on the right.....	28
3.2	Fuel, auxiliary substances.....	15	6.18	Closing the storage compartment on the right.....	29
3.3	Spare parts, technical accessories.....	15	6.19	Tool set	30
3.4	Service	15	6.20	Grab handles	30
3.5	Figures	15	6.21	Luggage rack	30
3.6	Customer service	15	6.22	Seat lock	30
4	VIEW OF VEHICLE	16	6.23	Passenger foot pegs.....	31
4.1	View of vehicle, front left (example)	16	6.24	Shift lever	31
4.2	View of vehicle, rear right (example).....	17	6.25	Foot brake lever	31
5	SERIAL NUMBERS.....	18	6.26	Side stand	32
5.1	Vehicle identification number.....	18	6.27	Center stand (Expedition)	32
5.2	Type label.....	18	7	COMBINATION INSTRUMENT	33
5.3	Key number.....	18	7.1	Combination instrument	33
5.4	Engine number.....	19	7.2	Activation and test	33
5.5	Fork part number	19	7.3	Warnings	34
5.6	Shock absorber article number	19	7.4	Ice warning.....	34
5.7	Steering damper article number	19	7.5	Indicator lamps	35
6	CONTROLS	20	7.6	Display	36
6.1	Clutch lever	20	7.7	Explorer display (optional)	37
6.2	Hand brake lever.....	20	7.8	Speed.....	38
6.3	Throttle grip.....	20	7.9	Shift warning light	38
			7.10	Speedometer	39
			7.11	Cruise control indicator.....	39
			7.12	Time	39

7.13	Ambient air temperature indicator	39	7.24.41	Date Format	61
7.14	Ride-Mode display	40	7.24.42	Units	61
7.15	ABS display	40	7.24.43	Distance	61
7.16	MTC display	40	7.24.44	Temperature	61
7.17	Coolant temperature indicator	40	7.24.45	Pressure	62
7.18	Fuel level display	41	7.24.46	Consumption	62
7.19	Heated grip (optional)	41	7.24.47	Language	62
7.20	Seat heating (optional)	42	7.24.48	Extra Functions	63
7.21	Favorites display	42	7.24.49	Setting the time and date	63
7.22	Navigation display	42	8	ERGONOMICS	65
7.23	Call display	42	8.1	Setting the front rider's seat	65
7.24	Menu	43	8.2	Handlebar position	65
7.24.1	Motorcycle	43	8.3	Adjusting the handlebar position 	65
7.24.2	Ride Mode	43	8.4	Adjusting the basic position of the clutch lever	66
7.24.3	ABS Mode	44	8.5	Adjusting the basic position of the hand brake lever	67
7.24.4	MTC + MSR	45	8.6	Adjusting foot brake lever stub	67
7.24.5	Easy Shift	45	8.7	Adjusting the basic position of the foot brake lever 	67
7.24.6	Heating (optional)	46	8.8	Checking the basic position of the shift lever	68
7.24.7	Heating Grips (optional)	46	8.9	Adjusting the basic position of the shift lever 	69
7.24.8	Heating Rider Seat (optional)	46	9	PREPARING FOR USE	70
7.24.9	Interface	47	9.1	Advice on preparing for first use	70
7.24.10	Throttle (optional)	47	9.2	Running in the engine	71
7.24.11	Slip Adjuster (optional)	47	9.3	Loading the vehicle	71
7.24.12	Bike Info	48	10	RIDING INSTRUCTIONS	73
7.24.13	Bike Info	48	10.1	Checks and maintenance measures when preparing for use	73
7.24.14	Trip Info	48	10.2	Starting the vehicle	73
7.24.15	Trip 1	49	10.3	Starting off	74
7.24.16	Trip 2	49	10.4	Easy Shift	75
7.24.17	Navigation	50	10.5	Shifting, riding	75
7.24.18	Last search (optional)	50	10.6	MSR	78
7.24.19	Favorites (optional)	51	10.7	Braking	78
7.24.20	Skip Waypoint (optional)	52	10.8	Stopping, parking	80
7.24.21	Volume (optional)	52	10.9	Transporting	81
7.24.22	Stop Navigation (optional)	53	10.10	Towing in the event of a breakdown	81
7.24.23	Audio (optional)	54	10.11	Refueling	82
7.24.24	Call out	54	11	SERVICE SCHEDULE	83
7.24.25	Settings	55	11.1	Additional information	83
7.24.26	Favorites	55	11.2	Service work	83
7.24.27	Favorites-Anzeige 1-4	55	12	TUNING THE CHASSIS	85
7.24.28	Quick Selector Up	55	12.1	Fork/shock absorber	85
7.24.29	Quick Selector Down	56			
7.24.30	Ride Husqvarna (optional)	56			
7.24.31	Bluetooth (optional)	56			
7.24.32	Phone Pairing (optional)	57			
7.24.33	Riders Headset (optional)	58			
7.24.34	Headset Type (optional)	58			
7.24.35	Shift Light	59			
7.24.36	Shift Light State	59			
7.24.37	Shift Light RPM1	59			
7.24.38	Shift Light RPM2	60			
7.24.39	Clock & Date	60			
7.24.40	Clock Format	60			

TABLE OF CONTENTS

12.2	Adjusting the compression damping of the fork.....	85	13.26	Removing the center fuel tank spoiler	108
12.3	Adjusting the rebound damping of the fork.....	86	13.27	Installing the center fuel tank spoiler	109
12.4	Adjusting the spring preload of the fork (Expedition).....	87	13.28	Removing left fuel tank spoiler	109
12.5	Compression damping of the shock absorber (Expedition).....	88	13.29	Installing the left fuel tank spoiler	110
12.6	Adjusting the low-speed compression damping of the shock absorber (Expedition).....	88	13.30	Removing the right fuel tank spoiler	111
12.7	Adjusting the high-speed compression damping of the shock absorber (Expedition).....	89	13.31	Installing the right fuel tank spoiler	111
12.8	Adjusting the rebound damping of the shock absorber	89	13.32	Removing the front fender	112
12.9	Adjusting the spring preload of the shock absorber	90	13.33	Installing the front fender	112
13	SERVICE WORK ON THE CHASSIS	92	13.34	Cleaning the dust boots of the fork legs 	113
13.1	Raising the motorcycle with rear lifting gear	92	13.35	Removing the windshield.....	113
13.2	Removing the rear of the motorcycle from the lifting gear	92	13.36	Installing the windshield.....	114
13.3	Lifting the motorcycle with the front lifting gear	92	13.37	Removing left fuel tank cover	114
13.4	Taking the motorcycle off the front lifting gear	93	13.38	Installing the left fuel tank cover	115
13.5	Raising the vehicle with the center stand (Expedition)	93	13.39	Removing right fuel tank cover	115
13.6	Removing the vehicle from the center stand (Expedition).....	94	13.40	Installing the right fuel tank cover.....	116
13.7	Removing the passenger seat	94	13.41	Removing the engine guard.....	116
13.8	Mounting the passenger seat	94	13.42	Installing the engine guard.....	118
13.9	Removing the front rider's seat	95	14	BRAKE SYSTEM	120
13.10	Mounting the front rider's seat	95	14.1	Anti-lock braking system (ABS)	120
13.11	Checking for chain dirt.....	95	14.2	Checking brake discs	121
13.12	Cleaning the chain	96	14.3	Checking the front brake fluid level.....	122
13.13	Checking the chain tension	96	14.4	Adding front brake fluid 	122
13.14	Adjusting the chain tension.....	97	14.5	Checking that the brake linings of the front brake are secured	123
13.15	Checking the chain, rear sprocket, engine sprocket, and chain guide.....	98	14.6	Checking the free travel of the foot brake lever	124
13.16	Removing the side bag rack (Expedition)	100	14.7	Checking the rear brake fluid level ...	125
13.17	Fitting the side bag rack (Expedition)	101	14.8	Adding rear brake fluid 	125
13.18	Removing the side bags (Expedition)	103	14.9	Checking that the brake linings of the rear brake are secured.....	126
13.19	Fitting the side bags (Expedition)	104	15	WHEELS, TIRES	128
13.20	Removing the left side cover	105	15.1	Removing the front wheel 	128
13.21	Installing the left side cover	106	15.2	Installing the front wheel 	129
13.22	Removing the right side cover	106	15.3	Removing the rear wheel 	131
13.23	Installing the right side cover.....	107	15.4	Installing the rear wheel 	132
13.24	Removing the battery cover.....	107	15.5	Checking the rear hub damping rubber pieces 	133
13.25	Installing the battery cover.....	108	15.6	Checking the tire condition.....	134
			15.7	Checking tire pressure.....	135
			15.8	Checking spoke tension	136
			15.9	Tubeless tire system	137
			15.10	Using tire repair spray.....	137
			16	ELECTRICAL SYSTEM.....	138
			16.1	Removing the 12-V battery 	138
			16.2	Installing the 12-V battery 	139

16.3	Charging the 12-V battery 	141	23.3.2	Coolant.....	168
16.4	Changing the main fuse	142	23.3.3	Fuel.....	169
16.5	Changing the ABS fuses.....	143	23.4	Chassis	169
16.6	Changing the fuses of individual electrical power consumers.....	144	23.5	Electrical system.....	170
16.7	Checking the headlight setting.....	146	23.6	Tires	171
16.8	Adjusting the headlight range.....	146	23.7	Fork.....	171
16.9	Checking the supplementary headlight setting	147	23.7.1	Standard model.....	171
16.10	Adjusting the supplementary headlight range	147	23.7.2	Expedition	171
16.11	Diagnostics connector	148	23.8	Shock absorber	172
16.12	Front ACC1 and ACC2	148	23.8.1	Standard model.....	172
16.13	ACC1 and ACC2 rear.....	148	23.8.2	Expedition	172
17	COOLING SYSTEM.....	150	23.9	Chassis tightening torques	173
17.1	Cooling system	150	24	DECLARATIONS OF CONFORMITY	179
17.2	Checking the coolant level in the compensating tank	150	24.1	Declarations of conformity.....	179
17.3	Correcting the coolant level in the compensating tank	151	24.2	Country-specific declarations of conformity	179
18	TUNING THE ENGINE.....	153	24.3	Country-specific declarations of conformity (CCU-2)	180
18.1	Motorcycle traction control (Cornering MTC)	153	25	SUBSTANCES.....	181
18.2	Slip adjustment (optional)	153	26	AUXILIARY SUBSTANCES.....	183
18.3	Throttle (optional)	153	27	STANDARDS	184
19	SERVICE WORK ON THE ENGINE	154	28	INDEX OF SPECIAL TERMS	185
19.1	Checking the engine oil level	154	29	LIST OF ABBREVIATIONS	186
19.2	Changing the engine oil and oil filter, cleaning the oil screens 	154	30	LIST OF SYMBOLS	187
19.3	Adding engine oil	156	30.1	Red symbols.....	187
19.4	Checking the free travel of the clutch lever.....	157	30.2	Yellow and orange symbols.....	187
19.5	Setting the free travel of the clutch lever 	157	30.3	Green and blue symbols.....	187
20	CLEANING, CARE	158	INDEX.....		188
20.1	Cleaning the motorcycle.....	158			
20.2	Checks and maintenance steps for winter operation	159			
21	STORAGE.....	161			
21.1	Storage	161			
21.2	Preparing for use after storage.....	162			
22	TROUBLESHOOTING	163			
23	TECHNICAL SPECIFICATIONS.....	165			
23.1	Engine.....	165			
23.2	Engine tightening torques.....	166			
23.3	Capacities	168			
23.3.1	Engine oil.....	168			

1 MEANS OF REPRESENTATION

1.1 Symbols used

The meaning of specific symbols is described below.

	Indicates an expected reaction (e.g., of a work step or a function).
	Indicates an unexpected reaction (e.g., of a work step or a function).
	Indicates work that requires expert knowledge and technical understanding. In the interest of your own safety, have this work performed by an authorized Husqvarna Motorcycles workshop. Your motorcycle will be cared for there to the highest degree by specially trained experts using the special tools required.
	Indicates a page reference (more information is provided on the specified page).
	Indicates information with more details or tips.
	Indicates the result of a testing step.
	Indicates the end of an activity, including potential reworking.

1.2 Formats used

The typographical formats used in this document are explained below.

Proprietary name	Indicates a proprietary name.
Name[®]	Indicates a protected name.
Brand[™]	Indicates a brand available on the open market.
<u>Underlined terms</u>	Refer to technical details of the vehicle or indicate technical terms, which are explained in the glossary.

2.1 Use definition – intended use

The vehicle is designed and constructed to withstand the usual demands of regular traffic and use on gentle terrain (unpaved roads). This vehicle is not suitable for use on race tracks.



Info

This vehicle is only authorized for operation on public roads in its homologated version.

2.2 Misuse

The vehicle must only be used as intended.

Dangers can arise for people, property and the environment through use not as intended.

Any use of the vehicle beyond the intended and defined use constitutes misuse.

Misuse also includes the use of operating and auxiliary fluids which do not meet the required specification for the respective use.

2.3 Safety advice

A number of safety instructions need to be followed to operate the product described safely. Therefore read this instruction and all further instructions included carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.



Info

Various information and warning labels are attached in prominent locations on the product described. Do not remove any information or warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.4 Degrees of risk and symbols



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note


Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



Note

Indicates a danger that will lead to environmental damage if the appropriate measures are not taken.

2.5 Overview of labels



1	Information on emission control
2	Fuses
3	Standard suspension setting information
4	Information on chain tension
5	USA type label
6	Information on noise emission
7	Canada type label
8	Information on starting up

VEHICLE EMISSION CONTROL INFORMATION	
Husqvarna MANUFACTURER: KTM AG, Mattighofen, Austria	
IMPORTER: KTM NORTH AMERICA, INC.	
ENGINE DISPLACEMENT	889 cc
ENGINE FAMILY	RKTXC0289EXP
EVAPORATIVE FAMILY	RKTXU0004EXP
PERMEATION FAMILY	RKTXP101R27
MODEL NAME	
Norden 901	
THIS VEHICLE CONFORMS WITH US EPA AND CALIFORNIA REGULATIONS APPLICABLE TO 2024 MODEL YEAR NEW MOTORCYCLES AND IS CERTIFIED TO 0.8 G/M HC+NOX, 12 G/M CO EXHAUST EMISSION STANDARDS IN CALIFORNIA.	
ENGINE TUNEUP SPECIFICATIONS	
IGNITION TIMING:	NON ADJUSTABLE
IDLE SPEED:	1600 RPM IN NEUTRAL
IDLE MIXTURE:	NON ADJUSTABLE
VALVE CLEARANCE:	0.10 - 0.15 mm INTAKE 0.15 - 0.20 mm EXHAUST
SPARK PLUG:	NGK LHARSAI-10
SPARK PLUG GAP:	1.0 mm
FUEL:	UNLEADED GASOLINE ONLY - 91 (R+M)2 OCTANE OR HIGHER
OIL:	SAE 10 W 90

Information on emission control

FUSE 25A	ABS control unit
FUSE 15A	ABS control unit
FUSE 10 - 10A	headlight control unit
FUSE 9 - 10A	ABS control unit, headlight control unit, TPMS (opt.), SD sensor, OBD
FUSE 8 - 10A	ACC2, socket
FUSE 7 - 10A	ACC1
FUSE 6 - 10A	high beam, position, tail, license plate light
FUSE 5 - 10A	horn, combination instrument, brake light, turn signal relay
FUSE 4 - 15A	radiator fans
FUSE 3 - 10A	fuel pump
FUSE 2 - 10A	ignition, ECU, EVAP, A sensor, immobilizer, fuel injection
FUSE 1 - 10A	ignition, combination instrument, alarm system (optional)
SPARE 30A	
FUSE - 30A	main fuse

635.06.097.000


Fuses

B06283-10

901 NORDEN 221.06.098.000	FORK	SHOCK
SETTING look owner's manual	Compression (clicks)	Rebound (clicks)
	Rebound (clicks)	Spring preload (mm)
		Preload adjuster (turns)
Comfort	21 21	18 10 3
Standard	15 15	12 10 3
Sport	9 9	7 12 5
Max. payload	9 9	5 17 10

Standard suspension setting information

V02490-01



Information on chain tension

V02488-01

Husqvarna	MFD. BY KTM AG AUSTRIA	DATE	11/23/2
MOTORCYCLE			
GAWR	592 lbs	450 kg	
GAWR FRONT	386 lbs	175 kg WITH 90/90-21 TIRE, 54V TYPE,	
	2.50x21 RIM, AT	35 psi 2.4 bar COLD	
GAWR REAR	606 lbs	275 kg WITH 150/70 R18 TIRE, 70V TYPE,	
	4.50x18 RIM, AT	35 psi 2.4 bar COLD	
THIS VEHICLE CONFORMS TO ALL APPLICABLE U.S. FEDERAL MOTOR VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURER SHOWN ABOVE.			
DUMMY*			

USA type label

B06280-10

MOTORCYCLE NOISE EMISSION CONTROL INFORMATION
KTM AG, AUSTRIA
THIS 2024 KTM6360889 MOTORCYCLE, 221.05.082.000, MEETS EPA NOISE EMISSION REQUIREMENTS OF 80 dBA AT 4400 RPM BY THE FEDERAL TEST PROCEDURE. MODIFICATIONS WHICH CAUSE THIS MOTORCYCLE TO EXCEED FEDERAL NOISE STANDARDS ARE PROHIBITED BY U.S. FEDERAL LAW. SEE OWNER'S MANUAL.
Motorcycle Type : Husqvarna Norden 901

Information on noise emission

B06281-11

MANUFACTURED BY/FABRIQUE PAR: KTM AG					
CYRSPRNBV: 450		KG	DATE: 11/23		
VIN A/V: DUMMY*					
TYPE: MC					
GAWR/PNBE		TIRE/PNEU-DIMENSION-RIMUANTE		COLD INFL. PRESS PRESS. DE GONFL. A FROID PSI/KPA	
1st	175	KG	90/90-21	2.50x21	35 240
2nd	275	KG	150/70 R18	4.00x18	35 240
THIS VEHICLE CONFORMS TO ALL APPLICABLE STANDARDS PRESCRIBED UNDER THE CANADIAN MOTOR VEHICLE SAFETY REGULATIONS IN EFFECT ON THE DATE OF MANUFACTURE. CE VEHICULE EST CONFORME A TOUTES LES NORMES QUI LUI SONT APPLICABLES ES VERTU DU REGLEMENT SUR LA SECURITE DES VEHICLES AUTOMOBILES DU CANADA EN VIGUEUR A LA DATE DE SA FABRICATION.					
B06282-10					

Canada type label

ACHTUNG Lesen Sie vor der ersten Inbetriebnahme des Fahrzeuges die gesamte Bedienungsanleitung aufmerksam durch!	
IMPORTANT Please read the entire owner's manual carefully before putting the vehicle into operation for the first time.	
ATTENZIONE Prima della messa in funzione iniziale del veicolo, leggere con attenzione l'intero manuale d'uso!	
ATTENTION Lire attentivement l'ensemble du manuel d'utilisation avant de mettre le véhicule en service!	
ATENCIÓN Lea completa y atentamente el manual de instrucciones antes de poner en servicio por primera vez el vehículo!	
F00491-01	

Information on starting up

2.6 Reporting safety defects

If you believe that your vehicle has a defect which could cause an accident resulting in injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Husqvarna Motorcycles North America, Inc.

If the NHTSA receives multiple similar complaints, it may open an investigation. and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Husqvarna Motorcycles North America, Inc.

You can contact the NHTSA via the toll-free “Auto Safety Hotline” on 1–888–327–4236, visit the www.nhtsa.dot.gov website, or write to: NHTSA Headquarters, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590, USA. You can also obtain other information about motor vehicle safety from the hotline.

2.7 Noise emission warranty

Husqvarna Motorcycles warrants that this exhaust system, at the time of sale, meets all applicable U.S. EPA Federal noise standards.

This manufacturer's warranty extends to the first person who purchases this exhaust system for purposes other than resale, and to all subsequent buyers.

Warranty claims should be directed to:

Husqvarna Motorcycles North America, Inc., c/o KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (440) 985–3553

www.husqvarna-motorcycles.com

Husqvarna Motorcycles North America, Inc., c/o KTM Canada, Inc., 8701 Rue Samuel-Hatt, Chambly, QC J3L 6V4, Canada

Phone: (450) 441-4451

www.husqvarna-motorcycles.com

2.8 Operating noise warning

This product should be checked for necessary repair or replacement parts if the motorcycle noise has increased significantly through use. Otherwise, the owner may become subject to penalties under the applicable ordinances.

2.9 Manufacturer warranty for the exhaust monitoring system

Husqvarna Motorcycles North America, Inc., c/o KTM North America, Inc. guarantees that, at the time of sale, the exhaust monitoring system complies with all the standards of the US Environmental Protection Agency (EPA) and the California Air Resources Board (CARB).

This manufacturer warranty applies in respect of the first owner of the motorcycle and all subsequent owners. Your exhaust monitoring system may include parts, such as the fuel injection system, ignition, catalytic converter, control units, hoses, connectors and other emission related assemblies, fuel tank, crankcase breather, fuel tank lid for vehicles with fuel evaporation monitoring, oil filler cap, pressure control valve, fuel/vapor separator, canister, ignition coils, ignition wire, capacitors and spark plugs, if a fault occurs before the first scheduled replacement; it may also include the hoses, fittings, and pipes that are used directly in these components. If the warranty conditions are met, Husqvarna Motorcycles will repair your motorcycle for you free of charge, including diagnosis, parts and labor.

As the owner of the motorcycle, you are responsible for the required maintenance specified in the Owner's Manual.

Please note that Husqvarna Motorcycles is entitled to reject warranty claims if your motorcycle or a part fails due to misuse, negligence, an accident, participation in racing or similar events, improper service work, or unauthorized modifications.

Scope of the manufacturer's warranty

- Five (5) years or 30,000 kilometers (18,641 miles), whichever occurs first.

If you have any questions regarding the manufacturer warranty for the exhaust monitoring system, please address these to:

Husqvarna Motorcycles North America, Inc., c/o KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (888) 985-6090

U.S. Environmental Protection Agency, 2000 Traverwood Drive, Ann Arbor, MI 48105, USA

California Air Resources Board, 1001 "I" Street, Sacramento, CA 95814, USA

2.10 Consumer rights

Warranty claims should be submitted to a Husqvarna Motorcycles workshop. If you are not satisfied, please contact:

Husqvarna Motorcycles North America, Inc., c/o KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (440) 985-3553

www.husqvarna-motorcycles.com

Husqvarna Motorcycles North America, Inc., c/o KTM Canada, Inc., 8701 Rue Samuel-Hatt, Chambly, QC J3L 6V4, Canada

Phone: (450) 441-4451

www.husqvarna-motorcycles.com

Different rights may apply, according to national or regional legislation.

2.11 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

- 1 The removal or rendering inoperative by any person other than for purposes of servicing, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- 1 Removal or puncturing of the main silencers, baffles, header pipes or any other components which conduct exhaust gases.
- 2 Removal or puncturing of parts of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing moving parts of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

2.12 Safe operation



Danger

Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.



Warning

Danger of burns Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.

The vehicle should only be used by trained persons. An appropriate driver's license is needed to drive the vehicle on public roads.

Have malfunctions that impair safety immediately eliminated by an authorized Husqvarna Motorcycles workshop.

Adhere to the information and warning labels on the vehicle.

2.13 Protective clothing



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.

In the interest of your own safety, Husqvarna Motorcycles recommends that you only operate the vehicle while wearing protective clothing.

2.14 Work rules

Unless specified otherwise, the ignition must be turned off during all work (models with ignition lock, models with transponder key) or the motor must be at a standstill (models without ignition lock or transponder key). Special tools are necessary for certain tasks. If these special tools are not included in the scope of supply of the vehicle, the special tools can be ordered using the specified article number. Example: bearing puller (15112017000)

Unless otherwise noted, normal conditions apply to all tasks and descriptions.

Ambient temperature	20 °C (68 °F)
Ambient air pressure	1,013 mbar (14.69 psi)
Relative air humidity	60 ± 5 %

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, expansion screws, seals, sealing rings, O-rings, pins, and lock washers).

In the case of certain screw connections, a thread locker (e.g., **Loctite**®) is required. Observe the manufacturer's instructions.

If a thread locker (e.g. **Precote**®) has already been applied to a new part, do not apply any additional thread locker.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.

Ensure that the work area is clean and clean components before disassembly if necessary. Penetrating dirt can lead to increased wear and consequential damage.

After completing a repair or service work, check the operating safety of the vehicle.

2.15 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, be environmentally aware, and respect the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and guidelines of the country in which you are disposing of them.

Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

2.16 Owner's Manual

Read this owner's manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and service your motorcycle. This is the only way to find out how best to customize the vehicle for your own use and how you can protect yourself from injury.



Tip

Store the Owner's Manual on your terminal device, for example, so that you can read it whenever you need to.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized Husqvarna Motorcycles dealer.

The Owner's Manual is an important component of the vehicle. If the vehicle is sold, the Owner's Manual must be downloaded again by the new owner.

The Owner's Manual can be downloaded several times using the QR code or the link on the delivery certificate.

The Owner's Manual is also available for download from your authorized Husqvarna Motorcycles dealer and on the Husqvarna Motorcycles website. A printed copy can also be ordered from your authorized Husqvarna Motorcycles dealer.

International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3.1 Manufacturer warranty, implied warranty

The work prescribed in the service schedule must be carried out in an authorized Husqvarna Motorcycles workshop only and confirmed in the electronic proof of service, as otherwise no warranty claims will be recognized. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the manufacturer warranty.

3.2 Fuel, auxiliary substances



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.

Use fuels and auxiliary substances in accordance with the Owner's Manual and specification.

3.3 Spare parts, technical accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by Husqvarna Motorcycles, and have them installed by an authorized Husqvarna Motorcycles workshop. Husqvarna accepts no liability for other products and any damage or loss resulting from their use.

Certain spare parts and accessory products are specified in parentheses in the descriptions. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

The current **Husqvarna Motorcycles Technische Zubehör** for your vehicle can be found on the Husqvarna Motorcycles website.

International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. An incorrect suspension setting can lead to damage and breakage of chassis components.

Use of the vehicle in difficult conditions, such as in rain, dusty or sandy environments, high heat or with a heavy payload, can lead to significantly increased wear on components such as the drivetrain, air filter, brake systems or suspension components. It may therefore be necessary to check parts before each journey or to replace parts before the next service interval is reached.

It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

The relevant mileage or time interval is whichever occurs first.

3.5 Figures

The figures contained in the manual may depict special equipment.

In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.

3.6 Customer service

Your authorized Husqvarna Motorcycles dealer will be happy to answer any questions you may have regarding your vehicle and Husqvarna Motorcycles.

A list of authorized Husqvarna Motorcycles dealers can be found on the Husqvarna Motorcycles website.

International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

4 VIEW OF VEHICLE

4.1 View of vehicle, front left (example)



B06271-01

- ❶ Clutch lever (📖 p. 20)
- ❷ Seat lock (📖 p. 30)
- ❸ Grab handles (📖 p. 30)
- ❹ Storage compartment on the left
- ❺ Passenger foot pegs (📖 p. 31)
- ❻ Side stand (📖 p. 32)
- ❼ Rider footrests
- ❽ Shift lever (📖 p. 31)

4.2 View of vehicle, rear right (example)




B06272-01

- ❶ Storage compartment on the right
- ❷ Light switch (📖 p. 21)
- ❷ Menu buttons (📖 p. 22)
- ❷ Turn signal switch (📖 p. 23)
- ❷ Horn button (📖 p. 23)
- ❸ Fuel tank filler cap
- ❹ Socket for electrical accessories (📖 p. 25)
- ❺ Start button/emergency OFF switch (📖 p. 23)
- ❺ Hazard warning flasher switch (📖 p. 24)
- ❻ Hand brake lever (📖 p. 20)
- ❼ Engine oil level viewer
- ❸ Foot brake lever (📖 p. 31)


5 SERIAL NUMBERS

5.1 Vehicle identification number



The vehicle identification number **1** is stamped on the right side of the steering head.


5.2 Type label



The USA type label **1** is located on the frame on the left.

The Canada type label **2** is located on the frame on the right.

5.3 Key number




The key number **1** can be found on the **KEYCODECARD**.



Info


The key number is needed to order a replacement key. Keep the **KEYCODECARD** in a safe place.

5.4 Engine number




The engine number ❶ is stamped onto the engine case at the top.

5.5 Fork part number




The fork part number ❶ is stamped on the inner side of the fork stub.

5.6 Shock absorber article number



Shock absorber article number ❶ is attached the top of the shock absorber.


5.7 Steering damper article number



Steering damper article number ❶ is embossed on the underside of the steering damper.


6 CONTROLS

6.1 Clutch lever



Clutch lever ❶ is fitted on the handlebar on the left.


6.2 Hand brake lever



The hand brake lever ❶ is fitted on the right side of the handlebar.

The front brake is engaged using the hand brake lever.


6.3 Throttle grip



The throttle grip ❶ is fitted on the right side of the handlebar.

6.4 Switches on the left side of the handlebar

6.4.1 Combination switch




The combination switch is fitted on the left side of the handlebar.

Overview of the left combination switch

- ❶ Light switch (📖 p. 21)
- ❷ Cruise control system tip switch (📖 p. 21)
- ❸ Menu buttons (📖 p. 22)
- ❹ Turn signal switch (📖 p. 23)
- ❺ Horn button (📖 p. 23)

6.4.2 Light switch




The light switch ① is fitted on the combination switch on the left.

Possible states

	Low beam on – Light switch in position ①. In this position, the low beam and the tail light are switched on.
	High beam on – Push the light switch to position ②. In this position, the high beam and the tail light are switched on.
	Headlight flasher – Push the light switch into position ③.

6.4.3 Cruise control system tip switch



The cruise control system tip switch ① is fitted on the left side of the combination switch.

Possible states

- Cruise control system tip switch ① in the basic position.
- Cruise control system tip switch ① pressed to the left. – In this position, the cruise control system function is switched on and off. The operating mode is displayed in the combination instrument.
- Briefly press cruise control system tip switch ① at the top. – The last saved speed is reached and maintained. Every subsequent brief pressing increases the target speed by 1 km/h or 1 mph.
- Press and hold cruise control system tip switch ① at the top. – The target speed increases in increments of 5 km/h or 5 mph.
- Briefly press cruise control system tip switch ① at the bottom. – The cruise control function is activated and the current speed is maintained. Every subsequent brief press reduces the target speed by 1 km/h or 1 mph.
- Press and hold cruise control system tip switch ① at the bottom. – The target speed decreases in increments of 5 km/h or 5 mph.



Info

After activating the cruise control function, the throttle grip can be turned back to the basic position. The selected speed will be maintained.

If the cruise speed is exceeded for less than 30 seconds by turning the throttle grip, the cruise control remains activated.

To switch off the cruise control system function, press the cruise control system tip switch ① to the left.

In addition, the cruise control system function is deactivated when one of the following events occurs:

- Operating the hand brake lever
- Operating the foot brake lever
- Operating the clutch lever
- Turning the throttle grip beyond the basic position
- Control of the motorcycle traction control (**MTC**)
- Slip at the rear wheel or lifting front wheel
- A malfunction occurring, which impairs the cruise control system function
- Exceeding the target speed for more than 30 seconds when overtaking



Warning

Danger of accidents The cruise control system function is not suitable for all riding situations.

The selected target speed will not be reached, if the engine power is not sufficient for a gradient.

The selected target speed will be exceeded if the engine braking effect is not sufficient on an incline.

- Do not use the cruise control systems function on winding roads.
- Do not use the cruise control systems on slippery road surfaces (e.g. rain, ice or snow), where there is poor visibility or on unpaved surfaces (e.g. sand, stones or gravel).
- Do not use the cruise control systems function if the traffic does not permit a constant speed.

The cruise control system function is only available when motorcycle traction control (**MTC**) is activated.


When motorcycle traction control (**MTC**) is switched off, the cruise control system function is also switched off.

The cruise control system function cannot be activated during rapid acceleration.

The cruise control function can only be activated in 2nd, 3rd, 4th, 5th and 6th gear.

The control range is from 30 to 160 km/h or from 18 to 98 mph.

6.4.4 Menu buttons



The menu buttons are fitted in the middle of the left combination switch.

The menu buttons are used to control the display on the combination instrument.

Button **1** is the **UP** button.

Button **2** is the **DOWN** button.

Button **3** is the **SET** button.

Button **4** is the **BACK** button.

6.4.5 Turn signal switch



Turn signal switch **1** is fitted on the combination switch on the left.

Possible states

	Turn signal off
	Left turn signal, on – Turn signal switch pressed to the left. The turn signal switch returns to the center position after activation.
	Right turn signal, on – Turn signal switch pressed to the right. The turn signal switch returns to the center position after activation.

To switch off the turn signal, press the turn signal switch towards the switch case.

6.4.6 Horn button



Horn button **1** is fitted on the left side of the handlebar.

Possible states

- The horn button  is in the basic position
- The horn button  is pressed – The horn is operated in this position.

6.5 Switches on the right side of the handlebar

6.5.1 Start button/emergency OFF switch




The start button/emergency OFF switch **1** is fitted on the right side of the combination switch.

Possible states

	Start button/emergency OFF switch off (upper position) – In this position, the ignition circuit is interrupted, a running engine stops, and cannot be started. A message appears on the display.
	Start button/emergency OFF switch on (middle position) – This position is required for operation; the ignition circuit is closed.
	Starter motor on (lower position) – In this position, the starter motor is actuated.

6.5.2 Hazard warning flasher switch




The hazard warning flasher switch ❶ is fitted on the right side of the switch.
The hazard warning flasher is used to indicate emergency situations.

i **Info**

The hazard warning flasher can be activated or deactivated while the ignition is switched on or up to 60 seconds after the ignition is switched off.
Only keep the hazard warning flasher activated as long as necessary as it depletes the 12-V battery.

- Possible states**
- The hazard warning flasher switch ▲ is in the basic position
 - The hazard warning flasher switch ▲ is pressed – All four turn signals and the indicator lamp for the hazard warning flasher in the combination instrument flash.

6.6 Ignition and steering lock




The ignition and steering lock is located in front of the upper triple clamp.

Possible states	
	Ignition off – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start. The ignition key can be removed.
	Ignition on – In this position, the ignition circuit is closed and the engine can be started.
	Steering locked – In this position, the ignition circuit is interrupted and the steering locked. The ignition key can be removed.


6.7 Locking the steering

Note
Danger of damage The parked vehicle can roll away or fall over.
– Park the vehicle on a firm and level surface.



- Park the vehicle.
- Turn the handlebar all the way to the left.
- Insert the ignition key into the ignition and steering lock, press in, and turn to the left. Remove the ignition key.
- ✓ Steering is no longer possible.

6.8 Unlocking the steering



- Insert the ignition key into the ignition and steering lock, press in, and turn to the right. Remove the ignition key.
- ✓ The handlebar can now be moved again.



6.9 Supplementary headlight switch




Supplementary headlight switch **1** is located on the left, next to the combination instrument.

i Info

When the symbol lights up on the switch, the supplementary headlights are switched on.

6.10 Socket for electrical accessories




Socket **1** for electrical accessories is located on the right, next to the combination instrument.

It is connected to the ignition plus and is fuse-protected.

Socket for electrical accessories

Voltage	12 V
Maximum current output	10 A

6.11 USB socket



USB socket **1** for the power supply to external devices is mounted on the left side of the mask support.

The USB socket is activated when the ignition is switched on.

USB socket

Voltage	5 V
Maximum current consumption	2.1 A

6.12 Opening the fuel tank filler cap



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is harmful to health.


- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Lift cover **1** of the fuel tank filler cap and insert the ignition key into the lock.


Note

Danger of damage The ignition key may break if overloaded.

Damaged ignition keys must be replaced.

- Push down on the fuel tank filler cap to take pressure off the ignition key.
- Turn the ignition key 90° clockwise.
- Lift the fuel tank filler cap.

6.13 Closing the fuel tank filler cap



- Fold down the fuel tank filler cap.
- Turn the ignition key 90° clockwise.
- Push down the fuel tank filler cap and turn the ignition key counterclockwise until the lock closes.



Warning


Fire hazard Fuel is highly flammable and a health hazard.

- Check that the fuel tank filler cap is locked correctly after closing.
- Change your clothing if fuel spills on them.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.

- Remove the ignition key and close the cover.



6.14 Fuel cocks



A fuel cock ① is located on each side of the fuel tank.



Info

The fuel cocks are located behind the fuel tank covers. The fuel cocks must always be open during operation. The fuel cocks are only closed to remove the fuel tank.

Possible states

- Fuel cocks are closed – Level equalization cannot take place and the fuel supply to the throttle valve body is shut off.
- Fuel cocks are open – Level equalization can take place and the fuel supply to the throttle valve body is open.


6.15 Opening the storage compartment on the left

Preparatory work


- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the left side cover. (📖 p. 105)

Main work

- Lift the elastic fastener ① and detach in area A.
- Open storage compartment.



6.16 Closing the storage compartment on the left



Main work

- Close the storage compartment.
- Raise elastic fastener **1** and hang up in area **A**.


Finishing work

- Install the left side cover. (📖 p. 106)
- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)

6.17 Opening the storage compartment on the right

Preparatory work


- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the right side cover. (📖 p. 106)



Main work

- Lift the elastic fastener ① and detach in area ①A.
- Open storage compartment.

6.18 Closing the storage compartment on the right



Main work

- Close the storage compartment.
- Raise elastic fastener ① and hang up in area ①A.

Finishing work

- Install the right side cover. (📖 p. 107)
- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)

6.19 Tool set



The left or right storage compartment contains the on-board tool set 1.

6.20 Grab handles



The grab handles 1 are used for moving the motorcycle around.
If you carry a passenger, the passenger can hold onto the grab handles during the trip.

6.21 Luggage rack




Luggage rack 1 is located behind the seat.
The base plate of a luggage system (optional) can be secured on the luggage rack plate.
The luggage rack must not be loaded with more than the specified weight.

Maximum permissible luggage rack load	5 kg (11 lb.)
---------------------------------------	---------------


i Info
Follow the instructions provided by the luggage manufacturer.

6.22 Seat lock



Seat lock 1 is located on the left side of the vehicle.
It can be unlocked using the ignition key.

6.23 Passenger foot pegs




The passenger foot pegs can be folded up and down.


Possible states

- Passenger foot pegs folded up – For operation without a passenger.
- Passenger foot pegs folded down – For operation with a passenger.

6.24 Shift lever




Shift lever ❶ is mounted on the left of the engine.



The gear positions can be seen in the figure.


The neutral or idle position is between the first and second gears.

6.25 Foot brake lever



Foot brake lever ❶ is located in front of the right footrest.
The rear brake is activated using the foot brake lever.

6.26 Side stand



The side stand ❶ is located on the left of the vehicle.
The side stand is used for parking the motorcycle.




Info

The side stand must be folded up during motorcycle use.
The side stand is coupled with the safety starting system;
follow the riding instructions.

Possible states

- Side stand folded out – The vehicle can be supported on the side stand. The safety starting system is active.
- Side stand folded in – This position is mandatory when riding the motorcycle. The safety starting system is inactive.

6.27 Center stand (Expedition)



In addition to the side stand, the vehicle is equipped with a center stand ❶.

7.1 Combination instrument



V02176-10

The combination instrument is attached in front of the handlebar.

The combination instrument is divided into two function areas.

① indicator lamps (p. 35)

Display ②




Caution

Danger of burns Parts of the combination instrument become hot in certain situations.

In particular, the display gets hot in ambient temperatures above 55 °C (131 °F), during extended stationary periods, for example, at a traffic light, or in direct sunlight.

- Do not touch the combination instrument with bare hands in the situations referred to.
- Where appropriate protective clothing.
- If you have been burned, hold the area affected under lukewarm water immediately.

7.2 Activation and test



Activation

The combination instrument is activated when the ignition is switched on.



Info

The brightness of the displays is controlled by an ambient light sensor in the combination instrument.

Test

The welcome text appears on the display and all indicator lamps are briefly activated for a function check.

i


Info

The malfunction indicator lamp  always lights up as long as the engine is not running. If the engine is running and the malfunction indicator lamp  lights up, stop (taking care not to endanger yourself or other road users in the process) and contact an authorized Husqvarna Motorcycles workshop.

The oil pressure warning lamp  always lights up as long as the engine is not running. If the engine is running and the oil pressure warning lamp  lights up, stop immediately (taking care not to endanger yourself or other road users in the process) and switch off the engine.

The ABS warning lamp  and TC indicator lamp  light up until a speed of approx. 6 km/h (approx. 4 mph) or more has been reached.

7.3 Warnings



Warnings appear in the middle of the display; these are marked yellow or red depending on their relevance. Yellow warnings indicate malfunctions or information which require prompt intervention or an adjustment to the riding style. Red warnings indicate malfunctions or information which require immediate intervention.

i

Info

Warnings can be hidden by pressing any button. All the existing warnings are displayed in the **Warning** submenu until they are no longer active.

7.4 Ice warning



The ice warning  goes on when there is an increased risk of ice on the roads. The ice warning  appears on the display when the ambient temperature drops below the specified value.

Temperature	≤ 4 °C (≤ 39 °F)
-------------	------------------

The ice warning  goes out on the display when the ambient temperature rises above the specified value again.

Temperature	≥ 6 °C (≥ 43 °F)
-------------	------------------

i

Info

When the ice warning  lights up, the warning **Ice Warning** also appears.

7.5 Indicator lamps



V02180-10

The indicator lamps offer additional information about the operating state of the motorcycle. When the ignition is switched on, all indicator lamps light up briefly.

i Info

The malfunction indicator lamp  always lights up as long as the engine is not running. If the engine is running and the malfunction indicator lamp  lights up, stop (taking care not to endanger yourself or other road users in the process) and contact an authorized Husqvarna Motorcycles workshop.

The oil pressure warning lamp  always lights up as long as the engine is not running. If the engine is running and the oil pressure warning lamp  lights up, stop immediately (taking care not to endanger yourself or other road users in the process) and switch off the engine.

The ABS warning lamp  and TC indicator lamp  light up until a speed of approx. 6 km/h (approx. 4 mph) or more has been reached.

Possible states

	The alarm system indicator lamp lights up or flashes red – Status or error message of the alarm system.
	The idle indicator lamp lights up green – The transmission is in neutral.
	The oil pressure warning lamp lights up red – The oil pressure is too low. Stop immediately, taking care not to endanger yourself or other road users in the process, and switch off the engine.
	The general warning lamp lights up yellow – A note/warning note on operating safety has been detected. This is also shown in the display.
	The malfunction indicator lamp lights up yellow – The <u>OBD</u> has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized Husqvarna Motorcycles workshop.
	The high beam indicator lamp lights up blue – The high beam is switched on.

7 COMBINATION INSTRUMENT

	The cruise control system indicator lamp lights up yellow – The cruise control system function is switched on, but cruise control is not activated.
	The cruise control system indicator lamp lights up green – The cruise control system function is switched on and cruise control is activated.
	Ice warning is active in the display – The warning lamp lights up when there is increased risk of icy roads.
	TC indicator lamp lights up/flashs yellow – MTC (p. 153) is not enabled or is currently intervening. The TC indicator lamp also lights up if a malfunction is detected. Contact an authorized Husqvarna Motorcycles workshop. The TC indicator lamp flashes if MTC or MSR actively engage.
	ABS warning lamp lights up yellow – Status or error messages relating to ABS .
	The turn signal indicator lamp flashes green simultaneously with the turn signal – The turn signal is switched on.

7.6 Display




V02179-10

- ❶ Time (p. 39)
- ❷ Speed (p. 38)
- ❷ Shift warning light (p. 38)
The shift warning light is integrated into the tachometer display.
- ❸ Unit for the engine speed display
- ❹ Ambient air temperature indicator (p. 39)
- ❺ **Favorites** display (p. 42)
- ❻ Heated grip (optional) (p. 41)
- ❼ Seat heating (optional) (p. 42)
- ❽ Coolant temperature indicator (p. 40)

- ⑨ Unit for the speedometer
- ⑩ Speedometer (📖 p. 39)
- ⑪ Fuel range display
- ⑫ Fuel level display (📖 p. 41)
- ⑬ ABS display (📖 p. 40)
- ⑭ Ride-Mode display (📖 p. 40)
- ⑮ MTC display (📖 p. 40)
- ⑯ Gear display

7.7 Explorer display (optional)




i Info

The figure shows the start screen of the combination instrument in active riding mode **Explorer** (optional). If the menu is open, the speed and the selected gear are still displayed.

- ① Time (📖 p. 39)
- ② Speed (📖 p. 38)
- ② Shift warning light (📖 p. 38)
The shift warning light is integrated into the tachometer display.
- ③ Gear display
- ④ Ambient air temperature indicator (📖 p. 39)
- ⑤ Favorites display (📖 p. 42)
- ⑥ Throttle (optional) (📖 p. 153)
- ⑦ MTC display (📖 p. 40)
- ⑧ ABS display (📖 p. 40)
- ⑨ Heated grip (optional) (📖 p. 41)


- 10 Seat heating (optional) (📖 p. 42)
- 11 Unit for the engine speed display
- 12 Coolant temperature indicator (📖 p. 40)
- 13 Fuel range display
- 14 Fuel level display (📖 p. 41)
- 15 Slip adjustment (optional) (📖 p. 153)
- 16 Speedometer (📖 p. 39)
- 17 Unit for the speedometer

7.8 Speed



The speed is measured in revolutions per minute.

7.9 Shift warning light



The shift light is integrated in the rpm gauge display. In the **Shift Light** submenu, the engine speed for the shift warning light can be set. The shift warning light is always active during the running-in phase (up to 1,000 km / 621 mi). The shift warning light can only be deactivated, and the values for **RPM1** and **RPM2** can only be adjusted after this. At **RPM1**, the engine speed display flashes, and at **RPM2** the entire display flashes yellow.

i Info
After the first service, the shift warning light is deactivated when the engine is warm in sixth-gear.

Coolant temperature	≤ 35 °C (≤ 95 °F)
ODO	< 1,000 km (< 620 mi)
The shift warning light always flashes at	6,500 rpm

Coolant temperature	> 35 °C (> 95 °F)
ODO	> 1,000 km (> 620 mi)
RPM1 shift warning light	flashes
RPM2 shift warning light	flashes and changes color

7.10 Speedometer




The speed is shown in area ❶ of the display.

Speed is shown in kilometers per hour **km/h** or in miles per hour **mph**.

The unit of speed can be configured in the **Units** menu.

7.11 Cruise control indicator



The operating state and active cruise control are shown in the ❶ area of the display.


Cruise control is operated using the cruise control tip switch (p. 21).

i Info

If the cruise control system function is switched on but cruise control is not activated, the cruise control system indicator lamp lights up yellow.

If the cruise control system function is switched on and cruise control is activated, the cruise control system indicator lamp lights up green.

7.12 Time



The time is shown in area ❶ of the display.

The time can be displayed in 24-hour format or 12-hour format in all languages.

The format of the time can be configured in the **Units** menu.

i Info

The time must be reset if the 12-V battery was disconnected from the vehicle or the fuse was removed.

7.13 Ambient air temperature indicator



The ambient temperature is shown in area ❶ of the display.

The ambient air temperature is displayed in **°C** or **°F**.

The unit of the ambient air temperature can be configured in the **Units** menu.

7.14 Ride-Mode display



The **Ride Mode** setting is shown in area **1** of the display.
The riding mode can be configured in the menu **Ride Mode**.

7.15 ABS display



The ABS mode setting is shown in the **1** area of the display.
The ABS can be configured in the **ABS Mode** menu.

i Info

When the ABS mode **Road** is active, ABS controls both wheels.
When the **Offroad** ABS mode is active, ABS only controls the front wheel. The rear wheel is not controlled by ABS and may lock during braking maneuvers.


7.16 MTC display



The **1** area of the display indicates whether **MTC** (p. 153) is switched on or off.

The motorcycle traction control can be switched on or off in the **MTC + MSR** menu.

7.17 Coolant temperature indicator



The coolant temperature indicator is a bar. The higher the bar is filled, the hotter the coolant.

Emergency mode operation is automatically activated at a coolant temperature of 120 °C.

Note

Engine failure Overheating damages the engine.

- If the coolant temperature warning is displayed, stop immediately and take care not to endanger yourself or other traffic participants in the process.
- Allow the engine and cooling system to cool down.
- Check and, if necessary, correct the coolant level on the cooling system while it is in a cooled state.


**Info**

If the coolant temperature indicator shows **HOT**, the indicator also starts to flash.

If the cooling system overheats, the maximum engine speed is limited.

Possible states

- The engine is cold – The coolant temperature indicator shows **LOW**.
- Engine warm – The coolant temperature indicator shows **O.K.**.
- Engine hot – The coolant temperature indicator shows **HOT**.

7.18 Fuel level display

The fuel level display consists of the fuel range display and a bar. The higher the bar is filled, the more fuel is in the fuel tank

**Info**

If the fuel level is getting low, the last segment flashes red and the following warning **Low Fuel** also appears.

The fuel level is displayed with a slight delay to prevent the indicator from constantly moving while riding.

The fuel level display is not updated while the side stand is folded out or the emergency off switch is switched off.


Once the side stand is folded up and the emergency OFF switch is switched on, the fuel level display is next updated after 2 minutes.

The fuel level display flashes if the combination instrument does not receive a signal from the fuel level sensor.

7.19 Heated grip (optional)

The status of the grip heater is shown in area **1** of the display. The grip heater can be configured in the **Heating** menu.

7.20 Seat heating (optional)



The status of the seat heating is shown in area **1** of the display. The seat heating can be configured in the **Heating** menu.

Info

The heating level for the passenger seat heating (optional) can be controlled by a switch next to the right grab handle.

7.21 Favorites display



Up to four items of information are shown on the **Favorites** indicator. The **Favorites** indicator can be freely configured in the **Favorites** menu.

7.22 Navigation display




The **Navigation** indicator appears when the navigation function is activated. In the **Navigation** display, the direction arrow, the distance from the destination, the estimated arrival time of the cellphone, the distance to the next waypoint, and the street name are displayed.

Info

If the visual navigation is activated, the **Favorites** indicator is hidden.

7.23 Call display



Warning


Danger of accidents Headphone volume which is too high distracts attention from traffic activity.

- Always select headphone volume which is low enough for you to still clearly hear acoustic signals.

The **Call** indicator appears for incoming or active calls. Press the **SET** button to accept an incoming call. Press the **BACK** button to reject an incoming call. Press the **UP** button to increase the audio volume. Press the **DOWN** button to reduce the audio volume.

i Info


It is not possible to change the audio volume using the combination switch with every cellphone. The call duration and contact are displayed. Depending on the cellphone settings, the contact is shown by name. You cannot navigate in the menu during an active phone conversation.

7.24 Menu**i Info**

Press **SET** button **1** in the start screen to open the menu.

Navigate through the menu using the **UP** button **2** or the **DOWN** button **3**.

By pressing the **BACK** button **4**, the menu structure jumps one step back, or the menu is closed.

7.24.1 Motorcycle

- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.

In **Motorcycle**, you can set the riding mode, ABS mode, traction control, motor slip regulation, Easy Shift, seat heating, grip heater, and interface.

When the **Ride Mode Explorer** (optional) is activated, the characteristics of the throttle response and slip on the rear wheel can also be configured.

7.24.2 Ride Mode**Condition**

- Start button/emergency OFF switch on (middle position)
 - This position is required for operation; the ignition circuit is closed. (p. 23)
- Cruise control function deactivated.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.

**Warning**

Danger of accidents An incorrectly selected riding mode makes control of the vehicle considerably more difficult.

The riding modes are each only suitable for certain conditions.

- Always select a riding mode that suits the surface on which you are riding, the weather and the riding situation.

- Press the **UP** or **DOWN** button until **Ride Mode** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to select the **Ride Mode**, which changes coordinated settings for the engine and motorcycle traction control.

Guideline


Only use riding modes Street and Rain on asphalt.
Only use riding modes Offroad and Explorer (optional) on unpaved roads.

- ✓ **Street** - Homologated performance with balanced response; the motorcycle traction control allows normal slip on the rear wheel. The anti-wheelie mode is active. ABS regulates both wheels.
- ✓ **Rain** - Reduced homologated performance with soft response for improved rideability on surfaces with low road grip; the motorcycle traction control allows very little slip on the rear wheel. The anti-wheelie mode is active. ABS regulates both wheels.
- ✓ **Offroad**- Reduced homologated performance for better rideability on unpaved roads; the motorcycle traction control allows high slip on the rear wheel. The anti-wheelie mode is deactivated. The ABS only controls the front wheel.
- ✓ **Explorer** (optional) - Setting with homologated performance and extremely direct response. The motorcycle traction control and the characteristics of the throttle response can be set individually. The anti-wheelie mode is deactivated. ABS can be configured separately.

 **Info**

Do not open the throttle during the selection.

7.24.3 ABS Mode



Condition

- **Explorer Mode** (optional)
 - Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
 - Press the **UP** or **DOWN** button until **ABS Mode** is highlighted. Press **SET** button to open the menu.
 - Activate the menu item using the **UP** or **DOWN** button.

 **Warning**

Danger of accidents An incorrectly selected ABS mode makes control of the vehicle considerably more difficult.

The ABS modes are each only suitable for certain conditions.

- Always select an ABS mode that is compatible with the surface of the ground.


- Press the **SET** button to select the desired ABS mode.



Info

The ABS mode can be switched during the journey.
Do not open the throttle during the selection.
When the ABS mode **Road** is active, ABS controls both wheels.
When the **Offroad** ABS mode is active, ABS only controls the front wheel. The rear wheel is not controlled by ABS and may lock during braking maneuvers.

7.24.4 MTC + MSR



- Condition**
- Cruise control function deactivated.
 - Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
 - Press the **UP** or **DOWN** button until **MTC + MSR** is highlighted. Press **SET** button to open the menu.
 - Activate the menu item using the **UP** or **DOWN** button.
 - Switch **MTC + MSR** on or off by pressing the **SET** button.



Info

Do not open the throttle when switching on or off.
Press the **SET** button briefly when activating the motorcycle traction control and the engine traction torque control.
Hold down the **SET** button when switching off the motorcycle traction control and engine traction torque control.
When ABS mode **Offroad** is active, the **MSR** is not active.
After the ignition is switched on, the motorcycle traction control and engine traction torque control are enabled again.

Press and hold the SET button for 3 - 5 seconds.	Switching off the motorcycle traction control and the engine traction torque control.
---	---

7.24.5 Easy Shift



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Easy Shift** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Switch Easy Shift (📖 p. 75) on or off by pressing the **SET** button.

7 COMBINATION INSTRUMENT


7.24.6 Heating (optional)



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Heating** is highlighted. Press the **SET** button to open the menu.

The grip heater and rider's seat heating (function optional) can be configured in **Heating**.


7.24.7 Heating Grips (optional)



Condition

- Model with heated grip.
- **Heated Grips** menu (optional) activated.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Heating** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Grips** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to select the heating level or to switch the heated grip on or off.


7.24.8 Heating Rider Seat (optional)



Condition

- Model with seat heater.
- **Heated Seat** menu (optional) activated.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Heating** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Rider Seat** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to select the heating level or to switch the front rider's seat heating on or off.

7.24.9 Interface



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Interface** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to select the desired display mode.
 - ✓ **Default** - Display with favorites indicator.
 - ✓ **No Favorites** - Display without a favorites indicator.
 - ✓ **Reduced** (not in explorer riding mode) - Display only with tachometer, gear indicator and speedometer.

7.24.10 Throttle (optional)



Condition

- The ride mode **Explorer** (optional) is activated.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Throttle** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to select **Throttle** mode.
 - ✓ **Street** - Balanced response.
 - ✓ **Explorer** - Extremely direct response.
 - ✓ **Offroad** - Gentle response.



Info

Do not open the throttle when setting the throttle response.

7.24.11 Slip Adjuster (optional)



Condition

- The ride mode **Explorer** (optional) is activated.
- **MTC + MSR** is activated.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Slip Adjuster** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to set the maximum permitted slip for the motorcycle traction control.



Info

Do not open the throttle during the selection.

The spin adjuster is a motorcycle traction control function. The slip adjustment allows the motorcycle traction control to be tuned through nine levels to the desired characteristic map.

7 COMBINATION INSTRUMENT

Level 1 allows the maximum slip on the rear wheel, and level 9 the minimum.

If the cruise control function is deactivated, the **UP** and **DOWN** buttons in the main display or in the **Slip Adjuster** menu can be used to adjust the **Slip Adjuster**.


i

Info

The slip adjustment is only available in **Explorer** riding mode (optional).


The slip adjustment is only available when motorcycle traction control is activated.

7.24.12 Bike Info




- Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Bike Info** is highlighted. Press the **SET** button to open the menu.
- General information and warnings that may be available can be called up in **Bike Info**.

7.24.13 Bike Info




- Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Bike Info** is highlighted. Press the **SET** button to open the menu.
- Tire Pressure** (optional function) shows the current tire pressure of the front and rear tires.
- Water** displays the coolant temperature.
- Fuel Range** displays the possible distance you can cover with the fuel reserve.
- Battery** displays the battery voltage.
- Odometer** displays the total distance covered.
- Service** displays when the next service is due.
- Warnings** displays warnings that have occurred until they are no longer active.

7.24.14 Trip Info



- Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Trip Info** is highlighted. Press the **SET** button to open the menu.
- General information on the odometer, riding time, average fuel consumption, and average speed can be accessed in **Trip**.

7.24.15 Trip 1



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Trip Info** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Trip 1** is highlighted. Press the **SET** button to open the menu.

Information on **Trip 1** can be accessed in the **Trip 1** menu.

**Info**

Distance displays the distance since the last reset, such as between two refueling stops. **Distance** is running and counts up to **9999**.

Trip Time shows the riding time on the basis of **Distance** and runs as soon as a speed signal is received.

ØFuel Con indicates the average fuel consumption based on **Distance**.

ØSpeed1 indicates the average speed based on **Distance** and **Trip Time**.

**Info**

Press the **UP** or **DOWN** button until **Reset Trip** is highlighted. Press the **SET** button to reset all entries in the **Trip 1** menu.

7.24.16 Trip 2



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Trip Info** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Trip 2** is highlighted. Press the **SET** button to open the menu.

Information on **Trip 2** can be accessed in the **Trip 2** menu.

**Info**

Distance displays the distance since the last reset, such as between two refueling stops. **Distance** is running and counts up to **9999**.

Trip Time shows the riding time on the basis of **Distance** and runs as soon as a speed signal is received.

ØFuel Con indicates the average fuel consumption based on **Distance**.

ØSpeed2 indicates the average speed based on **Distance** and **Trip Time**.

**Info**

Press the **UP** or **DOWN** button until **Reset Trip** is highlighted. Press the **SET** button to reset all entries in the **Trip 2** menu.

7.24.17 Navigation



Condition

- **Bluetooth®** function is activated.
 - The **Ride Husqvarna Navigation** app is installed and opened on a suitable cellphone (**Android®** devices Version 6.0 and higher, iOS devices Version 10 and higher).
 - The combination instrument is connected to a suitable phone.
 - The GPS function is activated on the connected phone.
 - For voice navigation: The combination instrument is connected to a suitable headset and an appropriate language package has been downloaded in the **Ride Husqvarna Navigationn** app.
- Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Ride Husqvarna Navigation** is highlighted. **SET** button opens the menu.
 - Press **UP** or **DOWN** button until **Navigation** is highlighted. Press the **SET** button to open the submenu.
 - Activate the menu item using the **UP** or **DOWN** button.
 - Press the **SET** button to switch the visual navigation on or off.




Info

Voice navigation remains switched on if it has been activated.

The volume of the activated voice navigation is identical to the volume of the audio player on the cellphone. If the volume on the cellphone is changed, the volume of the activated voice navigation also changes.

7.24.18 Last search (optional)



Condition

- **Bluetooth®** function is activated.
 - The **Ride Husqvarna** app (optional) is installed and opened on a suitable cellphone (Android devices Version 7.0 and higher, iOS devices Version 13 and higher).
 - The combination instrument is connected to a suitable phone.
 - The GPS function is activated on the connected phone.
- Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Ride Husqvarna Navigation** is highlighted. **SET** button opens the menu.
 - Press **UP** or **DOWN** button until **Navigation** is highlighted. Press the **SET** button to open the submenu.
 - Activate the menu item using the **UP** or **DOWN** button.
 - Press the **SET** button to switch the visual navigation on or off.

**Info**

Voice navigation remains switched on if it has been activated.


The volume of the activated voice navigation is identical to the volume of the audio player on the cellphone. If the volume on the cellphone is changed, the volume of the activated voice navigation also changes.

- Press **UP** or **DOWN** button until **Last search** is highlighted. Press the **SET** button to open the submenu.
- Press **UP** or **DOWN** button to select an address.
- Press the **SET** button to confirm the selection and start navigation.

**Info**

The last 10 addresses searched for in the **Ride Husqvarna** app (optional) are saved in **Last search**.

7.24.19 Favorites (optional)

**Condition**

- **Bluetooth®** function is activated.
 - The **Ride Husqvarna** app (optional) is installed and opened on a suitable cellphone (Android devices Version 7.0 and higher, iOS devices Version 13 and higher).
 - The combination instrument is connected to a suitable phone.
 - The GPS function is activated on the connected phone.
 - Favorites are saved in the **Ride Husqvarna** app (optional).
- Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Ride Husqvarna Navigation** is highlighted. **SET** button opens the menu.
 - Press **UP** or **DOWN** button until **Navigation** is highlighted. Press the **SET** button to open the submenu.
 - Activate the menu item using the **UP** or **DOWN** button.
 - Press the **SET** button to switch the visual navigation on or off.

**Info**

Voice navigation remains switched on if it has been activated.

The volume of the activated voice navigation is identical to the volume of the audio player on the cellphone. If the volume on the cellphone is changed, the volume of the activated voice navigation also changes.

- Press **UP** or **DOWN** button until **Favorites** is highlighted. Press the **SET** button to open the submenu.
- Press **UP** or **DOWN** button to select an address.
- Press the **SET** button to confirm the selection and start navigation.



Info

10 addresses in the **Ride Husqvarna** app (optional) can be stored in **Favorites**.

7.24.20 Skip Waypoint (optional)



Condition

- Navigation with at least one interim destination has been started in the **Ride Husqvarna** app.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Ride Husqvarna Navigation** is highlighted. **SET** button opens the menu.
- Press **UP** or **DOWN** button until **Navigation** is highlighted. Press the **SET** button to open the submenu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch the visual navigation on or off.




Info

Voice navigation remains switched on if it has been activated.

The volume of the activated voice navigation is identical to the volume of the audio player on the cellphone. If the volume on the cellphone is changed, the volume of the activated voice navigation also changes.

- Press **UP** or **DOWN** button until **Skip Waypoint** is highlighted. Press **SET** to select the waypoint.
- Press the **SET** button again to confirm the selection and the waypoint is removed.

7.24.21 Volume (optional)



Condition

- The **Ride Husqvarna** app (optional) is installed and opened on a suitable phone (**Android**® devices from version 6.0 and higher, iOS devices from version 10 and higher).
- The combination instrument is connected to a suitable phone.
- For voice navigation: The combination instrument is connected to a suitable headset and an appropriate language package has been downloaded in the **Ride Husqvarna** app (optional).
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Ride Husqvarna Navigation** is highlighted. **SET** button opens the menu.
- Press **UP** or **DOWN** button until **Navigation** is highlighted. Press the **SET** button to open the submenu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch the visual navigation on or off.

**Info**

Voice navigation remains switched on if it has been activated.


The volume of the activated voice navigation is identical to the volume of the audio player on the cellphone. If the volume on the cellphone is changed, the volume of the activated voice navigation also changes.

**Warning**

Danger of accidents Headphone volume which is too high distracts attention from traffic activity.

- Always select headphone volume which is low enough for you to still clearly hear acoustic signals.

- Press **UP** or **DOWN** button until **Volume** is highlighted. Press the **SET** button to open the submenu.
- Press the **UP** button to increase the volume of the activated voice navigation.
- Press the **DOWN** button to reduce the volume of the activated voice navigation.

7.24.22 Stop Navigation (optional)**Condition**

- **Bluetooth®** function is activated.
- The **Ride Husqvarna** app (optional) is installed and opened on a suitable cellphone (Android devices Version 7.0 and higher, iOS devices Version 13 and higher).
- The combination instrument is connected to a suitable phone.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Ride Husqvarna Navigation** is highlighted. **SET** button opens the menu.
- Press **UP** or **DOWN** button until **Navigation** is highlighted. Press the **SET** button to open the submenu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch the visual navigation on or off.

**Info**

Voice navigation remains switched on if it has been activated.

The volume of the activated voice navigation is identical to the volume of the audio player on the cellphone. If the volume on the cellphone is changed, the volume of the activated voice navigation also changes.

- Press **UP** or **DOWN** button until **Stop Navigation** is highlighted. Press the **SET** button to confirm the selection.
- Press **SET** button again to confirm the selection and end navigation.

7.24.23 Audio (optional)



Condition

- **Bluetooth®** function is activated.
- The combination instrument is connected to a suitable cell-phone.
- The combination instrument is connected to a suitable headset or the **Headset TypeCorded** is selected.
- Press the **SET** button when the menu is closed.



Warning

Danger of accidents Headphone volume which is too high distracts attention from traffic activity.

- Always select headphone volume which is low enough for you to still clearly hear acoustic signals.

- Press the **UP** or **DOWN** button until **Audio** is highlighted. Press the **SET** button to open the menu.
- Press and hold the **UP** button to increase the audio volume.
- Press and hold **DOWN** button to reduce the audio volume.
- Press the **UP** button briefly to change to the next audio track.
- Briefly pressing the **DOWN** button twice changes to the previous audio title or plays the current audio title from the start, depending on the cellphone model.
- Press the **SET** button to play or pause the audio track.



Info

With some cellphones, the audio player needs to be started before playback is possible.

The audio function can be added to **Quick Selector Up** or **Quick Selector Down** for easier operation.


7.24.24 Call out



Condition

- The combination instrument is connected to a suitable phone.
- The combination instrument is connected to a suitable headset.
- Press the **SET** button when the menu is closed.
- Press **UP** or **DOWN** button until **Call** appears. Press the **SET** button to open the menu.
- Press **UP** or **DOWN** button until **Last Calls** or **Favourites** is marked. Press the **SET** button to open the submenu.
- Press **UP** or **DOWN** button until the desired person is marked.
- Press the **SET** button.
- ✓ The selected person is called.

7.24.25 Settings



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.

In the **Settings** menu, favorites, quick selections, **Ride Husqvarna** (optional), and the shift warning light can be configured. Settings can be made for units or various values. Several functions can be enabled or disabled.

7.24.26 Favorites



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Favorites** is highlighted. Press the **SET** button to open the menu.

In **Favorites**, up to four items of information can be selected and displayed on the **Favorites** indicator on the display.


7.24.27 Favorites-Anzeige 1-4



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Favorites** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button to select **Favorites 1**, **Favorites 2**, **Favorites 3**, or **Favorites 4**. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button to select the desired information. Press the **SET** button to confirm the selection.

7.24.28 Quick Selector Up



Condition


- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Quick Selector** is highlighted. Press the **SET** button to open the menu.
- Activate the **Up** menu item using the **UP** or **DOWN** button.
- Press the **SET** button to set a direct selection menu for **Quick Selector Up**.



Info

When it is closed, the menu set in **Quick Selector Up** is opened by pressing the **UP** button.
Press the **BACK** button to close the **Quick Selector Up** indicator.

7.24.29 Quick Selector Down



Condition


- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Quick Selector** is highlighted. Press the **SET** button to open the menu.
- Activate the **Down** menu item using the **UP** or **DOWN** button.
- Press the **SET** button to set a direct selection menu for **Quick Selector Down**.



Info

When it is closed, the menu set in **Quick Selector Down** is opened by pressing the **DOWN** button.
Press the **BACK** button to close the **Quick Selector Down** indicator.

7.24.30 Ride Husqvarna (optional)



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Ride Husqvarna** is highlighted. Press the **SET** button to open the menu.


A suitable cellphone or headset can be paired with the combination instrument via **Bluetooth®** in the **Ride Husqvarna** menu.



Info

Not every cellphone and headset is suitable for pairing with the combination instrument.
The standard **Bluetooth®** 2.1 must be supported.

7.24.31 Bluetooth (optional)



Condition


- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Ride Husqvarna** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Bluetooth** is highlighted. Press the **SET** button to open the submenu.
- Activate the menu item using the **UP** or **DOWN** button.

- Press the **SET** button to switch the **Bluetooth®** function on or off.

The **Bluetooth®** function must be activated to pair a suitable phone or headset with the vehicle.

Not every phone and headset is suitable for pairing with the vehicle.

7.24.32 Phone Pairing (optional)



Condition

- The motorcycle is stationary.
 - **Bluetooth®** function is activated.
 - The **Bluetooth®** function should also be activated in the device to be paired.
- Press the **SET** button when the menu is closed.
 - Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
 - Press the **UP** or **DOWN** button until **Ride Husqvarna** is highlighted. Press the **SET** button to open the menu.
 - Press the **UP** or **DOWN** button until **Phone Pairing** is highlighted. Press the **SET** button to open the menu.



Info

Only one cellphone can be paired with the vehicle.

- Press the **UP** or **DOWN** button until **New Pairing** is marked. Press the **SET** button to open the menu.
- The vehicle starts searching for a suitable cellphone. If the search was successful, the name of the cellphone is displayed in the **New Pairing** menu. Press the **SET** button to start the pairing.



Info

The cellphone must be visible via **Bluetooth®** for the vehicle to find the cellphone.

- A message appears on the combination instrument indicating that the vehicle is now ready for pairing. The pairing is completed successfully by confirming the **Passkey** on the cellphone and on the combination instrument.



Info

Press the **UP** or **DOWN** button until **Delete Pairing** is highlighted. The paired device can be deleted by pressing the **SET** button.

Not every cellphone is suitable for pairing with the vehicle.

- Move the previously paired device into the range of the vehicle while the **Bluetooth®** function is active.
 - ✓ The device is automatically connected with the vehicle.
 - ✗ If the device is not automatically connected with the vehicle after approx. 30 seconds:
 - Switch on the vehicle again or repeat the **New Pairing** procedure.

A suitable cellphone can be paired with the vehicle in the **New Pairing** menu.

7.24.33 Riders Headset (optional)



Condition

- The motorcycle is stationary.
- **Bluetooth®** function is activated.
- The **Bluetooth®** function should also be activated in the device to be paired.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Ride Husqvarna** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Riders Headset** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **New Pairing** is marked. Press the **SET** button to open the menu.
- The vehicle starts searching for a suitable headset. If the search was successful, the name of the rider's headset is displayed in the **New Pairing** submenu. Press the **SET** button to start the pairing.

Info

The headset must be in pairing mode for the vehicle to find the headset. Follow the instructions in the headset owner's manual.


Press the **UP** or **DOWN** button until **Delete Pairing** is highlighted. The paired device can be deleted by pressing the **SET** button.

Not every headset is suitable for pairing with the vehicle.

- Move the previously paired device into the range of the vehicle while the **Bluetooth®** function is active.
- ✓ The device is automatically connected with the vehicle.
- ✗ If the device is not automatically connected with the vehicle after approx. 30 seconds:
 - Switch on the vehicle again or repeat the **New Pairing** procedure.

In the **Riders Headset** menu, a suitable rider headset can be paired with the vehicle.

7.24.34 Headset Type (optional)



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Ride Husqvarna** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Headset Type** is highlighted. Press the **SET** button to change the rider headset type.

The connection mode for the rider headset can be selected in the **Headset Type** menu.

The headset is connected to the vehicle wirelessly via **Bluetooth®** in **Bluetooth Headset** mode.

The headset is connected directly to the smartphone by a cable in **Corded Headset** mode.



Info

The **Riders Headset** menu item is only available in **Headset Type Bluetooth**.

7.24.35 Shift Light




Condition

- The motorcycle is stationary.
- **ODO** > 1,000 km (621 mi).
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Shift Light** is highlighted. Press the **SET** button to open the submenu.

The speed for the shift warning light can be set in **Shift Light**.


7.24.36 Shift Light State



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Shift Light** is highlighted. Press the **SET** button to open the submenu.
- Press the **UP** or **DOWN** button until **State** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch the shift warning light on or off.

7.24.37 Shift Light RPM1



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Shift Light** is highlighted. Press the **SET** button to open the submenu.
- Press the **UP** or **DOWN** button until **RPM1** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch the value for **RPM1** on or off.

7 COMBINATION INSTRUMENT



Info

RPM1 can be set in intervals of 500 between 5,500 and 10,000 rpm.

RPM1 must not be larger than **RPM2**.

If the engine speed reaches set value **RPM1**, the shift warning light flashes yellow.

7.24.38 Shift Light RPM2



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Shift Light** is highlighted. Press the **SET** button to open the submenu.
- Press the **UP** or **DOWN** button until **RPM2** is highlighted.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch the value for **RPM2** on or off.




Info

RPM2 can be set in intervals of 500 between 7,000 and 10,000 rpm.

RPM2 must not be smaller than **RPM1**.

If the engine speed reaches set value **RPM2**, the entire display flashes yellow.

7.24.39 Clock & Date




Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Clock & Date** is highlighted.
- Press the **SET** button to open the menu.

In **Clock & Date**, the time, date, and display formats can be set.


7.24.40 Clock Format



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Clock & Date** is highlighted.
- Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Clock Format** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to select the time format.


7.24.41 Date Format



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Clock & Date** is highlighted.
- Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Date Format** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to select the date format.

7.24.42 Units




Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Units** is highlighted. Press the **SET** button to open the menu.

In the **Units** menu, settings for units or various values can be made.


7.24.43 Distance



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Units** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Distance** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to confirm the desired unit.


7.24.44 Temperature



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Units** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Temperature** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to confirm the desired unit.


7.24.45 Pressure



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Units** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Pressure** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to confirm the desired unit.

7.24.46 Consumption



Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Units** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Consumption** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to confirm the desired unit.

7.24.47 Language



Condition


- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Language** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to confirm the desired language.



Info

The menu languages are US English, UK English, German, Italian, French, and Spanish.

7.24.48 Extra Functions



Condition

- The motorcycle is stationary.
- Motorcycle with optional supplementary function.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Extra Functions** is highlighted. Press the **SET** button to open the menu.
- Use the **UP** or **DOWN** button to navigate through the extra functions.



Info

The optional extra functions are listed.
The current **Husqvarna Motorcycles Technisches Zubehör** and available software for your vehicle can be found on the Husqvarna Motorcycles website.


7.24.49 Setting the time and date



Condition

The motorcycle is stationary.

- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Clock & Date** is highlighted. Press the **SET** button to open the menu.



Setting the clock

- Press the **UP** or **DOWN** button until **Set Clock** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Hours** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until the current hour is set.
- Press the **SET** button.
 - ✓ The selected hour is stored.
- Press the **UP** or **DOWN** button until **Minutes** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until the current minute is set.
- Press the **SET** button.
 - ✓ The selected minute is stored.

7 COMBINATION INSTRUMENT




Setting the date

- Press the **UP** or **DOWN** button until **Set Date** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Day** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until the current day is set.
- Press the **SET** button.
 - ✓ The selected day is stored.
- Press the **UP** or **DOWN** button until **Month** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until the current month is set.
- Press the **SET** button.
 - ✓ The selected month is stored.
- Press the **UP** or **DOWN** button until **Year** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until the current year is set.
- Press the **SET** button.
 - ✓ The selected year is stored.

8.1 Setting the front rider's seat


Preparatory work

- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)



Alternative 1

- Attach the front rider's seat to the fuel tank at the recesses 1, and push the front rider's seat down and forward at the same time.



Alternative 2


- Attach the front rider's seat to the fuel tank at the recesses 1, and push the rider's seat up and forward at the same time.
- Finally, check that the front rider's seat is correctly mounted.

Finishing work

- Mount the passenger seat. (📖 p. 94)



8.2 Handlebar position



On the upper triple clamp, there are three holes at a distance of **A** to each other.

The holes on the handlebar support are placed at a distance of **B** from the center.

Hole distance A	15 mm (0.59 in)
Hole distance B	3.5 mm (0.138 in)

The handlebar can be mounted in six different positions. This allows the handlebar to be mounted in the most comfortable position for the rider.

8.3 Adjusting the handlebar position 🛠️




Warning

Danger of accidents A repaired handlebar poses a safety risk.

If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

- Change the handlebar if the handlebar is damaged or bent.



- Remove screws 1. Take off the handlebar clamps 2. Position the handlebar so that screws 3 are accessible.

Info

Cover the components to protect them against damage.

Do not kink the cables and lines.

- Remove screws 3. Take off handlebar supports 4.
- Move the handlebar supports into the desired position B, A or C. Mount and tighten screws 3.

Guideline

Mount the left and right handlebar supports in the same position.		
Screw, handlebar support	M10	45 Nm (33.2 lbf ft) Loctite®243™

- Position the handlebar.

Info


Make sure the cables and wiring are positioned correctly.

- Position handlebar clamp. Mount screws 1 and tighten evenly.

Guideline

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
------------------------	----	---------------------

8.4 Adjusting the basic position of the clutch lever



- Push clutch lever forward.
- Adjust the basic position of the clutch lever to your hand size by turning adjusting screw 1.

Info

When the adjusting screw is turned clockwise, the clutch lever moves closer to the handlebar.


When the adjusting screw is turned counterclockwise, the clutch lever moves away from the handlebar.

The range of adjustment is limited.

Only turn the adjusting screw by hand, and do not use force.

Do not make any adjustments while riding.

8.5 Adjusting the basic position of the hand brake lever



- Push hand brake lever forward.
- Adjust the basic position of the hand brake lever to your hand size by turning adjusting screw ①.



Info

Turn the adjusting screw clockwise to decrease the distance between the hand brake lever and the handlebar.

Turn the adjusting screw counterclockwise to increase the distance between the hand brake lever and the handlebar.


The range of adjustment is limited.

Only turn the adjusting screw by hand, and do not use force.

Do not make any adjustments while riding.



8.6 Adjusting foot brake lever stub



- Remove screws ① with the foot brake lever stub.
- Move the foot brake lever stub into desired position A or B. Mount and tighten screws ①.

Guideline

Screw, foot brake lever stub	M5	10 Nm (7.4 lbf ft) Loctite®243™
------------------------------	----	---



8.7 Adjusting the basic position of the foot brake lever




Warning

Danger of accidents The brake system will fail if it overheats or is adjusted incorrectly.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

- Set the free travel on the foot brake lever in accordance with the specification.
- Ensure that the adjustment steps are performed properly. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)




- Detach spring ❶.
- Loosen nut ❷.

i Tip
Press the foot brake lever downwards to make this easier.

- Turn the push rod ❸ to set the basic position of the foot brake lever.

i Info
The range of adjustment is limited.
The screw must be screwed in by at least five full turns.
Screwing the push rod into the ball joint adjusts the foot brake lever downwards.
Screwing the push rod out of the ball joint adjusts the brake lever upwards.



- Loosen nut ❹ and turn screw ❺ correspondingly until the free travel A is present. If necessary, adjust the basic position of the foot brake lever.

Guideline

Free travel at foot brake lever	3 ... 5 mm (0.12 ... 0.2 in)	
---------------------------------	------------------------------	--

- Hold screw ❺ and tighten nut ❹.

Guideline

Nut, foot brake lever adjustment	M6	6 Nm (4.4 lbf ft)
----------------------------------	----	-------------------


- Tighten nut ❷.

Guideline

Nut, push rod, foot brake lever	M6	6 Nm (4.4 lbf ft)
---------------------------------	----	-------------------


i Tip
Press the foot brake lever downwards to make this easier.

- Attach spring ❶.



8.8 Checking the basic position of the shift lever

i Info
When driving, the shift lever must not touch the rider's boot when in the basic position.
If the shift lever is permanently touching the boot, the transmission will be subject to excessive load; this can cause a malfunction of the Easy Shift.




- Sit on the vehicle in the riding position and determine distance **A** between the upper edge of your boot and the shift lever.

Distance between shift lever and upper edge of boot	10 ... 20 mm (0.39 ... 0.79 in)
---	---------------------------------

- » If the distance does not meet specifications:
 - Adjust the basic position of the shift lever. 📖 (p. 69)

8.9 Adjusting the basic position of the shift lever 📖



- Loosen nut **1**, holding threaded rod **2**.
- Loosen nut **3**, holding threaded rod **2**.



Info

Nut **3** has a left-handed thread.

- Turn threaded rod **2** to adjust the shift lever.



Info

The range of adjustment is limited.

The shift lever must not come into contact with any other vehicle components during the shift procedure.

- Tighten nut **3** while holding threaded rod **2**.

Guideline

Nut, shift rod	M6LH	6 Nm (4.4 lbf ft)
----------------	------	-------------------

- Tighten nut **1** while holding threaded rod **2**.

Guideline

Nut, shift rod	M6	6 Nm (4.4 lbf ft)
----------------	----	-------------------

9.1 Advice on preparing for first use



Danger

Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.



Warning

Danger of crashing Different tire tread patterns on the front and rear wheel impair the handling characteristic.

Different tire tread patterns can make the vehicle significantly more difficult to control.

- Make sure that only tires with a similar tire tread pattern are fitted to the front and rear wheel.



Warning

Danger of accidents Non-approved or non-recommended tires and wheels impact the handling characteristic.

- Only use tires/wheels approved by Husqvarna Motorcycles with the corresponding speed index.



Warning

Danger of accidents New tires have reduced road grip.

The contact surface on new tires is not yet roughened.

- Run in new tires with moderate riding and only gradually increase the lean angle.

Run-in distance 200 km (124 mi)



Warning

Danger of accidents The brake system fails in the event of overheating.

If the foot brake lever is not released, the brake linings drag continuously.

- Take your foot off the foot brake lever if you do not want to brake.



Info

When using your vehicle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-sale inspection work has been carried out by an authorized Husqvarna Motorcycles workshop.
 - ✓ You will receive a delivery certificate when the vehicle is handed over.
- Before riding for the first time, read the entire Owner's Manual carefully.
- Get to know the controls.
- Adjust basic position of the clutch lever. (📖 p. 66)
- Adjust basic position of the hand brake lever. (📖 p. 67)
- Adjust the basic position of the foot brake lever. 🦶 (📖 p. 67)
- Get used to the handling characteristic of the motorcycle in a suitable area before making a longer trip. Try also to ride as slowly as possible to get a better feel for the motorcycle.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.

- Run the engine in. (📖 p. 71)



9.2 Running in the engine

- During the running-in time, do not exceed the specified engine speed.

Guideline

Maximum engine speed	
During the first: 1,000 km (620 mi)	6,500 rpm
After the first: 1,000 km (620 mi)	9,800 rpm

- Avoid fully opening the throttle.



Info

If the maximum engine speed is exceeded before the first service, the shift warning light flashes.



9.3 Loading the vehicle



Warning

Danger of accidents Total weight and axle loads influence the handling characteristic.

The total weight consists of: operational motorcycle with a full tank, rider and, if necessary, a passenger with protective clothing and helmet, and, if necessary, mounted luggage.

- Do not exceed the maximum permissible overall weight or the axle loads.



Warning

Danger of accidents Improper mounting of cases, tank rucksacks or other luggage impairs the handling characteristics.

Luggage mounted incorrectly can slip while the vehicle is in motion.

- Mount and secure all luggage according to the manufacturer's instructions.
- Check that your luggage is fixed properly at regular intervals.



Warning

Danger of accidents Carrying luggage alters handling characteristics at high speed.

- Adapt your speed to your payload.
 - Ride more slowly if your motorcycle is loaded with cases or other luggage.
- Maximum speed with luggage 150 km/h (93.2 mph)



Warning

Danger of accidents The luggage system will be damaged if it is overloaded.

- Read the manufacturer information on maximum payload when mounting cases.



Warning

Danger of accidents Luggage which has slipped impairs visibility.

If the tail light is covered, you are less visible to traffic behind you, especially when it is dark.

- Check that your luggage is fixed properly at regular intervals.



Warning

Danger of accidents A high payload alters the handling characteristic and increases the stopping distance.

- Adapt your speed to your payload.



Warning

Fire hazard The hot exhaust system may burn luggage.

- Fasten your luggage in such a way that it cannot be burned or singed by the hot exhaust system.

- If you carry luggage, make sure you secure it firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.
- Do not exceed the maximum permissible weight and the maximum permissible axle loads.

Guideline


Maximum permissible total weight	450 kg (992 lb.)
Maximum permissible front axle load	175 kg (386 lb.)
Maximum permissible rear axle load	275 kg (606 lb.)

10.1 Checks and maintenance measures when preparing for use



Info

Before every trip, check the condition of the vehicle and ensure that it is roadworthy. The vehicle must be in perfect technical condition when it is being operated.



- Check the engine oil level. (📖 p. 154)
- Check the front brake fluid level. (📖 p. 122)
- Check the rear brake fluid level. (📖 p. 125)
- Check that the brake linings of the front brake are secured. (📖 p. 123)
- Check that the brake linings of the rear brake are secured. (📖 p. 126)
- Check that the brake system is functioning properly.
- Check the coolant level in the compensating tank. (📖 p. 150)
- Check the chain for dirt. (📖 p. 95)
- Check the chain tension. (📖 p. 96)
- Check the tire condition. (📖 p. 134)
- Check tire pressure. (📖 p. 135)
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check that the electrical system is functioning properly.
- Check that luggage is properly secured.
- Sit on the motorcycle and check the rear mirror setting.
- Check the fuel level.



10.2 Starting the vehicle



Danger


Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.

Note

Engine damage High revving speed with a cold engine negatively impacts the lifespan of the engine.

- Always run the engine warm at a low speed.



- Take the motorcycle off the stand and sit on the motorcycle.
- Make sure that the start button/emergency OFF switch is in the middle position ○.
- Switch on the ignition by turning the ignition key to the position ○.

Guideline

To avoid malfunctions in the control unit communication, do not switch the ignition off and on in rapid succession.

- ✓ After you switch on the ignition, you can hear the fuel pump working for about two seconds. The function check of the combination instrument is run at the same time.
- ✓ The ABS warning lamp lights up and goes back out after starting off.
- Shift the transmission into neutral **N**.
- ✓ The green idle indicator lamp **N** lights up.
- Briefly press the start button/emergency OFF switch into the lower position .



Info

Only press the start button/emergency OFF switch into the lower position  when the combination instrument function check has been completed.

Do not open the throttle to start.

If the starting attempt is unsuccessful, wait for 15 seconds before making another attempt at starting.


After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other malfunctions instead.

This motorcycle is equipped with a safety starting system. You can only start the engine if the transmission is in neutral or if the clutch lever is pulled when a gear is engaged. If the side stand is folded out and you shift into gear and release the clutch lever, the engine stops.

10.3 Starting off

- Pull the clutch lever, engage 1st gear, release the clutch lever slowly and simultaneously open the throttle carefully.

10.4 Easy Shift



If Easy Shift is activated, you can shift up and down without operating the clutch.

Because there is no need to close the throttle grip, uninterrupted gear shifts are possible.

Easy Shift uses the shifter shaft position to check whether or not a shift should be initiated, and sends a corresponding signal to the engine control unit.

If Easy Shift is disabled in the combination instrument, the clutch needs to be operated in the normal way for each shift.

10.5 Shifting, riding



Warning

Danger of accidents Abrupt load alterations can cause the vehicle to get out of control.

- Avoid abrupt load alterations and sudden braking actions.
- Adapt your speed to the road conditions.



Warning

Danger of accidents If you change down at high engine speed, the rear wheel blocks and the engine races.

- Do not change into a low gear at high engine speed.



Warning

Danger of accidents An incorrect ignition key position causes malfunctions.

- Do not change the ignition key position while driving.



Warning

Danger of accidents Adjustments to the vehicle distract attention from traffic activity.

- Make all adjustments when the vehicle is at a standstill.



Warning

Risk of injury The passenger may fall from the motorcycle if they conduct themselves incorrectly.

- Ensure that the passenger sits correctly on the passenger seat, places his or her feet on the passenger foot pegs and holds on to the rider or the grab handles.
- Note the regulations governing the minimum age of passengers in your country.



Warning

Danger of accidents A risky riding style constitutes a major risk.

- Comply with traffic regulations and ride defensively and with foresight to detect sources of danger as early as possible.



Warning

Danger of accidents Cold tires have reduced road grip.

- Ride the first miles carefully on every journey at moderate speed until the tires reach operating temperature.



Warning

Danger of accidents New tires have reduced road grip.

The contact surface on new tires is not yet roughened.

- Run in new tires with moderate riding and only gradually increase the lean angle.
Run-in distance 200 km (124 mi)



Warning

Danger of accidents Total weight and axle loads influence the handling characteristic.

The total weight consists of: operational motorcycle with a full tank, rider and, if necessary, a passenger with protective clothing and helmet, and, if necessary, mounted luggage.

- Do not exceed the maximum permissible overall weight or the axle loads.



Warning

Danger of accidents Improper mounting of cases, tank rucksacks or other luggage impairs the handling characteristics.

Luggage mounted incorrectly can slip while the vehicle is in motion.

- Mount and secure all luggage according to the manufacturer's instructions.
- Check that your luggage is fixed properly at regular intervals.



Warning

Danger of accidents A fall can damage the vehicle more seriously than it may first appear.

- Check the vehicle after a fall as you do when preparing for use.

Note

Engine damage Unfiltered intake air has a negative effect on the service life of the engine.

Dust and dirt will enter the engine without an air filter.

- Only operate the vehicle if it is equipped with an air filter.

Note

Engine failure Overheating damages the engine.

- If the coolant temperature warning is displayed, stop immediately and take care not to endanger yourself or other traffic participants in the process.
- Allow the engine and cooling system to cool down.
- Check and, if necessary, correct the coolant level on the cooling system while it is in a cooled state.

Note

Transmission damage Incorrect use of Easy Shift will damage the transmission.


Easy Shift can only be used if the function is activated in the combination instrument.

Easy Shift is not active if you pull the clutch lever.

- Only use Easy Shift in the permitted speed range shown.

i Info

If unusual noises occur while riding, stop immediately (taking care not to endanger yourself or other road users in the process), switch off the engine, and contact an authorized Husqvarna Motorcycles workshop.



- Shift into a higher gear when conditions allow (incline, road situation, etc.).
- Release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever, and open the throttle.

i Info

You can see the positions of the 6 forward gears in the figure. The neutral or idle position is between the first and second gears. First gear is used for starting off or for steep inclines.

The operating temperature is reached when 5 bars of the temperature indicator light up.


- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is $\frac{3}{4}$ open. This will barely reduce the speed, but fuel consumption will be considerably lower.
- Only accelerate up to a speed suitable for the road surface and weather conditions. Particularly in bends, do not shift, and accelerate very carefully.
- Brake if necessary and close the throttle at the same time in order to shift down.
- Pull clutch lever and shift into a lower gear, release the clutch lever slowly, and open the throttle or shift again.
- If the engine stalls (e.g., at a crossroads), just pull clutch lever and press the start button/emergency OFF switch into the lower position (3). The transmission must not be shifted into neutral.
- Switch off the engine if running at idle speed or stationary for a long time.
- If the oil pressure warning lamp  lights up during a trip, stop immediately and switch off the engine. Contact an authorized Husqvarna Motorcycles workshop.
- If the malfunction indicator lamp  lights up during a trip, please contact an authorized Husqvarna Motorcycles workshop as soon as possible.
- If the general warning lamp  lights up during a trip, the display shows a message.

i Info

Very important messages are stored in the **Warning** menu.

- If the ice warning appears in the combination instrument, the roads may be icy. Adjust your speed to the road conditions.

10 RIDING INSTRUCTIONS




- If Easy Shift is enabled in the combination instrument, you can shift up in the speed range shown without pulling the clutch lever.



Info

The minimum engine speed before shifting up in revolutions per minute is shown in the figure.

Pull the shift lever quickly back to the stop without changing the throttle twist grip position.



- If Easy Shift is enabled in the combination instrument, you can shift down in the speed range shown without pulling the clutch lever.




Info

The maximum engine speed before shifting down in revolutions per minute is shown in the figure.

Depress the shift lever quickly back to the stop without changing the throttle twist grip position.

10.6 MSR



The **MSR** is a function of the engine control.

If the engine braking effect is too great, the **MSR** prevents the rear wheel from locking or sliding away on a sloping position.

To avoid slip of the rear wheel, the **MSR** only opens the throttle valve as far as absolutely necessary.

The **MSR** is applied on surfaces, where the friction coefficient is too low to open the slipper clutch.

To further increase ride safety, the **MSR** is slope dependent.



Info

When ABS mode **Offroad** is active, the **MSR** is not active.

10.7 Braking



Warning

Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.



Warning

Danger of accidents A spongy pressure point on the front or rear brake reduces braking efficiency.

- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents The brake system fails in the event of overheating.

If the foot brake lever is not released, the brake linings drag continuously.

- Take your foot off the foot brake lever if you do not want to brake.

**Warning****Danger of accidents** Higher total weight increases the stopping distance.

- Take the longer stopping distance into account when carrying a passenger or luggage with you.

**Warning****Danger of accidents** Salt on the roads impairs the brake system.

- Brake carefully several times to remove salt from the brake linings and the brake discs.

**Warning****Danger of accidents** ABS may increase the stopping distance in certain situations.

- Adjust application of the brakes to the respective riding situation and riding surface conditions.

**Warning****Danger of accidents** Excessively forceful application of the brakes blocks the wheels.

The ABS effectiveness is only ensured if it is switched on.

- Leave the ABS switched on in order to benefit from the protective effect.

**Warning****Danger of accidents** The rear wheel can lock due to the engine braking effect.

- Pull in the clutch, if you perform emergency or full braking, or if you brake on a slippery ground.

**Warning****Danger of accidents** Driving aids can reduce the probability of a fall only within physical limits.

It is not always possible to compensate for certain riding situations, for example with luggage loaded with a high center of gravity, varying road surfaces, steep descents or full braking without disengaging the gear.

- Adapt your riding style to the road conditions and your driving ability.

- When braking, release the throttle and apply the front and rear brakes at the same time.

**Info**

When the ABS is enabled, maximum braking power can be achieved even on surfaces with low road grip such as sandy, wet, or slippery terrain without the danger of the wheels locking.

**Warning****Danger of accidents** Banked or laterally sloping ground reduces the maximum possible delay.

- If possible finish braking before going into a bend.

- Always finish braking before the going into a bend. Shift down to a lower gear appropriate to your speed.
- Use the braking effect of the engine on long downhill stretches. To do so, shift back one or two gears, but do not overrev the engine. This means that significantly less braking is required and the brake system does not overheat.



10.8 Stopping, parking



Warning

Risk of injury People who act without authorization endanger themselves and others.

- Do not leave the vehicle unattended if the engine is running.
- Protect the vehicle against access by unauthorized persons.
- Lock the steering and remove the ignition key if you leave the vehicle unattended.



Warning

Danger of burns Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.

-
- Apply the brakes on the motorcycle.
 - Shift the transmission into neutral
 - Switch off the ignition by turning the ignition key to the position



Info

If the engine is switched off with the emergency OFF switch and the ignition remains switched on at the ignition lock, power continues to flow to most electrical power consumers. This discharges the 12-V battery. You should therefore always switch off the engine with the ignition lock – the emergency OFF switch is intended for emergencies only.

-
- Park the motorcycle on a firm surface.

Alternative 1

- Swing side stand forward with your foot as far as it will go and lean the vehicle on it.

Alternative 2

(Expedition)

- Raise the vehicle with the center stand. () p. 93)
- Lock the steering by turning the handlebar fully to the left, pressing down the ignition key to the position and turning it to the position . To make the steering lock engage more easily, move the handlebar a little to the left and right. Remove the ignition key.

10.9 Transporting

Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.


The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.



- Switch off the engine.
- Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.


10.10 Towing in the event of a breakdown

Note

Danger of damage Towing away using a towing vehicle is not an appropriate vehicle recovery method.

Damage to the drive train or transmission may occur during towing.

- Do not use towing equipment where the wheels of the broken down vehicle remain on the road and rotate as it is towed.
- Always transport a broken down vehicle on a trailer or on the loading area of a transport vehicle.



- Ensure that the broken down vehicle is properly secured on the trailer or transport vehicle.
- Observe local regulations for the recovery of broken down vehicles.

10.11 Refueling



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.

Note

Material damage Inadequate fuel quality causes the fuel filter to quickly become clogged.

In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system.


- Refuel only with clean fuel that meets the specified standards. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Switch off the engine.
 - Open the fuel tank filler cap. (📖 p. 26)
 - Fill the fuel tank with fuel up to the lower edge **A** of the filler neck.
- | | | |
|-----------------------------------|-----------------|---------------------------------------|
| Total fuel tank capacity, approx. | 19 l (5 US gal) | Super unleaded (ROZ 95)
(📖 p. 182) |
|-----------------------------------|-----------------|---------------------------------------|
- Close the fuel tank filler cap. (📖 p. 26)

11.1 Additional information

Any further work that results from the service work must be ordered separately and invoiced separately. Different service intervals may apply in your country, depending on the local operating conditions. Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule is available for authorized Husqvarna Motorcycles dealers for the electronic proof of service. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

11.2 Service work

	every 48 months					
	every 24 months					
	every 12 months					
	every 30,000 km (18,600 mi)					
	every 15,000 km (9,300 mi)					
	after 1,000 km (620 mi)					
Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 	○	●	●	●	●	●
Program the shift shaft sensor. 	○	●	●	●	●	●
Check that the electrical system is functioning properly.	○	●	●	●	●	●
Check that the brake linings of the front brake are secured. (📖 p. 123)	○	●	●	●	●	●
Check that the brake linings of the rear brake are secured. (📖 p. 126)	○	●	●	●	●	●
Check brake discs. (📖 p. 121)	○	●	●	●	●	●
Check the brake lines for damage and leakage. 	○	●	●	●	●	●
Check the front brake fluid level. (📖 p. 122)	○	●	●	●		
Change the front brake fluid. 					●	●
Check the rear brake fluid level. (📖 p. 125)	○	●	●	●		
Change the rear brake fluid. 					●	●
Check the free travel of the clutch lever. (📖 p. 157)	○	●	●	●	●	●
Check the free travel of the foot brake lever. (📖 p. 124)	○	●	●	●	●	●
Change the engine oil and the oil filter, clean the oil screens.  (📖 p. 154)	○	●	●	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage hoses, etc.) and sleeves for cracking, tightness, and correct routing. 		●	●	●	●	●
Empty the drainage hoses. 	○	●	●	●	●	●
Check the cables for damage and for routing without kinks. 		●	●	●	●	●
Check the frame. 			●			
Check the link fork. 			●			
Check the fork bearing for play.		●	●			
Check the steering head bearing play.	○	●	●			
Check the wheel bearing for play.		●	●			
Check the shock absorber and fork for leaks. Perform a fork service and shock absorber service as needed, when possible and depending on how the vehicle is used. 	○	●	●	●	●	●
Check the tire condition. (📖 p. 134)	○	●	●	●	●	●
Check tire pressure. (📖 p. 135)	○	●	●	●	●	●
Check the rim run-out. 	○	●	●	●	●	●
Retighten the spokes. 	○					
Check the spoke tension. (📖 p. 136)		●	●	●	●	●
Check the chain, rear sprocket, engine sprocket, and chain guide. (📖 p. 98)		●	●	●	●	●


11 SERVICE SCHEDULE

	every 48 months					
	every 24 months					
	every 12 months					
	every 30,000 km (18,600 mi)					
	every 15,000 km (9,300 mi)					
	after 1,000 km (620 mi)					
Check the chain tension. (📖 p. 96)	○	●	●	●	●	●
Grease all moving parts (e.g. side stand, hand lever, chain, etc.) and check for smooth operation. 🛠	○	●	●	●	●	●
Change the spark plugs. 🛠			●			
Check the valve clearance. 🛠			●			
Change the air filter, clean the air filter box. 🛠		●	●			
Check the fuel pressure. 🛠		●	●	●	●	●
Check the headlight setting. (📖 p. 146)	○	●	●			
Check the tightness of the safety-relevant screws and nuts which are easily accessible. 🛠	○	●	●	●	●	●
Clean the dust boots of the fork legs. 🛠 (📖 p. 113)		●	●			
Check the coolant fill level and antifreeze. 🛠	○	●	●	●	●	
Change the coolant. 🛠						●
Check that the radiator fan is functioning properly. 🛠	○	●	●	●	●	●
Final check: Check the vehicle is roadworthy and take a test ride. 🛠	○	●	●	●	●	●
Read out the fault memory after the test ride using the Husqvarna Motorcycles diagnostics tool. 🛠	○	●	●	●	●	●
Adjust the service display using Husqvarna Motorcycles diagnostics tool. 🛠	○	●	●	●	●	●
Enter electronic proof of service in the dealer portal. 🛠	○	●	●	●	●	●

○ One-time interval

● Periodic interval

12.1 Fork/shock absorber



The fork and the shock absorber offer many options of adapting the suspension to the riding style and the payload.



Info

The recommendations for the suspension setting are shown in table ①. The table is located under the seat on the air filter box.


These adjustments are guidelines and should always be the basis for a suspension setting. If the guidelines are not adhered to, the riding characteristics could deteriorate, particularly at high speeds.

12.2 Adjusting the compression damping of the fork



Info

The hydraulic compression damping determines the fork suspension behavior.



(Standard model)

- Turn white adjuster ① clockwise as far as it will go.



Info

Adjuster ① is located at the upper end of the left fork leg.

The compression damping is located in left fork leg **COMP** (white adjuster). The rebound damping is located in right fork leg **REB** (red adjuster).

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Compression damping	
Comfort	21 clicks
Standard	15 clicks
Sport	9 clicks
Full payload	9 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping during compression.

(Expedition)

- Turn white adjuster ① clockwise as far as it will go.



Info

Adjuster ① is located at the upper end of the left fork leg.

The compression damping is located in left fork leg **COMP** (white adjuster). The rebound damping is located in right fork leg **REB** (red adjuster).

- Turn counterclockwise by the number of clicks corresponding to the fork type.



Guideline

Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	15 clicks

i

Info

Turn clockwise to increase damping; turn counter-clockwise to reduce damping during compression.

12.3 Adjusting the rebound damping of the fork

i

Info

The hydraulic rebound damping determines the fork suspension behavior.



- (Standard model)
- Turn red adjuster **1** clockwise as far as it will go.

i

Info

Adjuster **1** is located at the upper end of the right fork leg.

The rebound damping is located in right fork leg **REB** (red adjuster). The compression damping is located in left fork leg **COMP** (white adjuster).

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	21 clicks
Standard	15 clicks
Sport	9 clicks
Full payload	9 clicks

i

Info

Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.



- (Expedition)
- Turn red adjuster **1** clockwise as far as it will go.

i

Info

Adjuster **1** is located at the upper end of the right fork leg.

The rebound damping is located in right fork leg **REB** (red adjuster). The compression damping is located in left fork leg **COMP** (white adjuster).

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	15 clicks

i Info
Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.



12.4 Adjusting the spring preload of the fork (Expedition)

Preparatory work

- Raise the vehicle with the center stand. (📖 p. 93)

Main work

- Turn T-grips **1** counterclockwise all the way.
✓ Marking **+0** aligns with the right-hand part of the grip.

i Info
Make the adjustment by hand only. Do not use a tool.
Make the same adjustment on both fork legs.

- Turn the T-grips clockwise.

Guideline


Spring preload – preload adjuster	
Comfort	+0
Standard	+0
Sport	+0
Full payload	+3

- ✓ The T-grips engage noticeably at the numerical values.

i Info
Adjust the spring preload to the numerical values only as the preload will not engage between the numerical values.
Turn clockwise to increase the spring preload; turn counterclockwise to reduce the spring preload.
Adjusting the spring preload has no influence on the absorption setting of the rebound.
Basically, however, you should set the rebound damping higher with a higher spring preload.

Finishing work

- Remove the vehicle from the center stand. (📖 p. 94)



12.5 Compression damping of the shock absorber (Expedition)

The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed. High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.

The high-speed compression adjuster, for example, has an effect when riding over an asphalt edge: the rear wheel suspension compresses quickly.

The low-speed compression adjuster has an effect, for example, when riding over long ground swells: the rear wheel suspension compresses slowly.

These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, modifications in the high-speed range affect the compression damping in the low-speed range and vice versa.

12.6 Adjusting the low-speed compression damping of the shock absorber (Expedition)



Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.


The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

The effect of the low-speed compression adjuster can be seen in slow to normal compression of the shock absorber.



- Turn adjusting screw **1** clockwise with a screwdriver as far as the last perceptible click.



Info

Do not loosen fitting **2**!

- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Low-speed compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	7 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

12.7 Adjusting the high-speed compression damping of the shock absorber (Expedition)



Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.


The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

The effect of the high speed compression adjuster can be seen in the fast compression of the shock absorber.



- Turn adjusting screw ① all the way clockwise with a socket wrench.



Info

Do not loosen fitting ②!

- Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

High-speed compression damping	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	0.5 turns



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.



12.8 Adjusting the rebound damping of the shock absorber




Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.

The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Turn adjusting screw ❶ clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

(Standard model)

Rebound damping	
Comfort	18 clicks
Standard	12 clicks
Sport	7 clicks
Full payload	5 clicks

(Expedition)

Rebound damping	
Comfort	20 clicks
Standard	12 clicks
Sport	5 clicks
Full payload	5 clicks



Info

Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.

12.9 Adjusting the spring preload of the shock absorber



Warning

Danger of accidents Modifications to the suspension setting may seriously alter the handling characteristic.

- Ride slowly to start with after making adjustments to get the feel of the new handling characteristic.



Info

The spring preload defines the initial status of the spring operation on the shock absorber. The best spring preload setting is achieved when it is set for the weight of the rider and that of any luggage and a passenger, thus ensuring an ideal compromise between handling and stability.

Condition

The link fork is relieved of weight.

(Standard model)

- Turn handwheel ❶ counterclockwise as far as it will go.
- Turn it clockwise by the number of turns corresponding to the shock absorber type and use.

Guideline

Spring preload – preload adjuster	
Comfort	3 turns
Standard	3 turns
Sport	5 turns
Full payload	10 turns





Info

Turn clockwise to increase the spring preload; turn counterclockwise to reduce the spring preload.

(Expedition)

- Turn handwheel **1** counterclockwise as far as it will go.
- Turn it clockwise by the number of turns corresponding to the shock absorber type and use.

Guideline

Spring preload – preload adjuster	
Comfort	3 turns
Standard	3 turns
Sport	5 turns
Full payload	10 turns

Info


Turn clockwise to increase the spring preload; turn counterclockwise to reduce the spring preload.

13.1 Raising the motorcycle with rear lifting gear

Note

Danger of damage The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.



- Mount retaining adapter on the link fork.
- Insert the adapter in the rear lifting gear.

Retaining adapter (61029955144)

Rear wheel work stand (6932995500033)


- Stand motorcycle upright, align lifting gear to the link fork with the adapters, and raise motorcycle.

13.2 Removing the rear of the motorcycle from the lifting gear

Note

Danger of damage The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.



- Secure the motorcycle against falling over.
- Remove the rear lifting gear and lean the vehicle on side stand ①.
- Remove the retaining adapter from the link fork.

13.3 Lifting the motorcycle with the front lifting gear

Note

Danger of damage The parked vehicle can roll away or fall over.


- Park the vehicle on a firm and level surface.


Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 92)

Main work

- Remove screws ①.
- Take off retaining bracket ②.





- Move the handlebar to the straight-ahead position.
- Use suitable lifting gear when attaching the steering stem.
- Align the front lifting gear with the fork legs.



Info

Always raise the motorcycle at the rear first.

- Lift the motorcycle at the front.




13.4 Taking the motorcycle off the front lifting gear


Note

Danger of damage The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.



- Secure the motorcycle against falling over.
- Remove the front lifting gear.



- Position retaining bracket **1**.
- Mount and tighten screws **2**.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



13.5 Raising the vehicle with the center stand (Expedition)

Note


Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

13 SERVICE WORK ON THE CHASSIS




- Stand to the left of the vehicle.
- Hold the handlebar with your left hand and push the center stand onto the ground with your right foot.
- Put your entire weight on arm ① of the center stand while pulling the vehicle up at the left grab handle.
- ✓ The center stand is folded out to the stop.

13.6 Removing the vehicle from the center stand (Expedition)

Note


Danger of damage The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.




- Make sure that the steering is unlocked.
- Move the vehicle forward with both hands on the handlebar.
- While the vehicle tips off the center stand, actuate the front brake to stop the vehicle from rolling away.
- Check that the center stand ① is folded all the way up.

13.7 Removing the passenger seat



- Insert the ignition key in seat lock ① and turn it clockwise.
- Raise the front of the passenger seat, pull it toward the tank, and take off from above.
- Remove the ignition key from the seat lock.

13.8 Mounting the passenger seat



- Hook holding lugs of the passenger seat into the bushings on the subframe, lower the front, and simultaneously push backward.
- Insert locking pin ① into the lock housing and push down the front of the passenger seat until the locking pin engages with an audible click.



Warning

Danger of accidents The seat can come loose from the anchoring if it is not mounted correctly.

- After assembly, check whether the seat is correctly locked and cannot be pulled up.

- Finally, check that the passenger seat is correctly mounted.



13.9 Removing the front rider's seat

Preparatory work


- Remove the passenger seat. (📖 p. 94)

Main work

- Lift the rider's seat back and unhook in the **A** area.

(Expedition)

- Disconnect the seat heating plug-in connector.




13.10 Mounting the front rider's seat

Main work

(Expedition)

- Connect the seat heating plug-in connector.
- Attach the recesses on the front rider's seat to the fuel tank at the desired seat position **A** or **B**, and push the front rider's seat forward while lowering it at the rear.
- Finally, check that the front rider's seat is correctly mounted.




Finishing work

- Mount the passenger seat. (📖 p. 94)



13.11 Checking for chain dirt



- Check the chain for coarse dirt accumulation.
 - » If the chain is very dirty:
 - Clean the chain. (📖 p. 96)



13.12 Cleaning the chain



Warning

Danger of accidents Lubricants on the tires reduces the road grip.

- Remove lubricants from the tires using a suitable cleaning agent.



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



Note


Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

The service life of the chain depends largely on its maintenance.



Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 92)

Main work

- Rinse off loose dirt with a soft jet of water.
- Remove old grease residue with chain cleaner.

Chain cleaner (📖 p. 183)

- After drying, apply chain spray.

Street chain spray (📖 p. 183)

Finishing work

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 92)

13.13 Checking the chain tension



Warning

Danger of accidents Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 92)



Main work

- Shift the transmission into neutral **N**.
- Push the chain behind the chain sliding piece up and determine the chain tension **A** between the link fork and the upper edge of the chain.

Guideline

Distance B from the chain sliding piece	2.5 cm (0.98 in)
Measure the distance from the flat part of the link fork directly above the chain, not from the edge of the link fork.	

i Info

Top chain section **C** must be taut.
Chain wear is not always even. Repeat this measurement at different chain positions.

Chain tension	2 ... 5 mm (0.08 ... 0.2 in)
---------------	------------------------------

- » If the chain tension does not meet the specification:
 - Adjust the chain tension. (📖 p. 97)
- Remove the rear of the motorcycle from the lifting gear. (📖 p. 92)



13.14 Adjusting the chain tension



Warning

Danger of accidents Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 92)
- Check the chain tension. (📖 p. 96)



Main work

- Loosen nut 1.
- Loosen nuts 2.
- Adjust the chain tension by turning adjusting screws 3 left and right.

Guideline

Chain tension	2 ... 5 mm (0.08 ... 0.2 in)
Turn the adjusting screws 3 on the left and right so that the markings on the left and right chain adjusters 4 are in the same position relative to the reference marks A. The rear wheel is then correctly aligned.	



Info

The top chain section must be taut.
Chain wear is not always even. Repeat this measurement at different chain positions.

- Tighten nuts 2.
- Make sure that chain adjusters 4 are fitted correctly on adjusting screws 3.
- Tighten nut 1.

Guideline

Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft) Thread and contact area of wheel spindle greased
-------------------------	---------	---

Finishing work

- Check the chain tension. (📖 p. 96)

13.15 Checking the chain, rear sprocket, engine sprocket, and chain guide

Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 92)


Main work


- Check the chain, rear sprocket, and engine sprocket for wear.
 - » If the chain, rear sprocket or engine sprocket is worn:
 - Change the drivetrain kit. 🛠️



Info

The engine sprocket, rear sprocket, and chain should always be replaced together.





- Shift the transmission into neutral **N**.
- Pull on the lower chain section with the specified weight **A**.

Guideline

Weight, chain wear measurement	15 kg (33 lb.)
--------------------------------	----------------

- Measure distance **B** of 18 chain rollers in the lower chain section.

i Info

Chain wear is not always even. Repeat this measurement at different chain positions.

Maximum distance B from 18 chain rollers at the longest chain section	272 mm (10.71 in)
--	-------------------


- » If distance **B** is greater than the specified measurement:
 - Change the drivetrain kit. 🛠️

i Info

When a new chain is mounted, the rear sprocket and engine sprocket should also be changed.

New chains wear out faster on old, worn sprockets.


For safety reasons, the chain has no chain joint.



- Check the engine sprocket cover **1** for wear.
 - » If the engine sprocket cover is highly worn in the marked area **C**:
 - Change the engine sprocket cover. 🛠️
- Check the engine sprocket cover **1** for tightness.
 - » If the engine sprocket cover is loose:
 - Tighten the screws on the engine sprocket cover.

Guideline

Screw, engine sprocket cover	M5x17	5 Nm (3.7 lbf ft)
------------------------------	-------	-------------------



- Check the chain sliding guard for wear.
 - » If continuous signs of wear to the chain are visible on the chain sliding guard in the area **D** marked:
 - Change the chain sliding guard. 🛠️
 - » If the chain sliding guard is highly worn on the underside in the marked area **E**:
 - Change the chain sliding guard. 🛠️
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten screws on the chain sliding guard.

Guideline

Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)
---------------------------	----	-------------------

Finishing work

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 92)



13.16 Removing the side bag rack (Expedition)

Preparatory work


- Remove the side bags. (📖 p. 103)
- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the left side cover. (📖 p. 105)
- Remove the right side cover. (📖 p. 106)

Main work


- Remove screws **1**.
- Remove the connecting pipe.



- Remove screws **2**.
- Take off side bag rack **3**.



- Remove screws ②.
- Take off side bag rack ③.



- Mount and tighten screws ④.

Guideline

Screw, side bag rack	M8	25 Nm (18.4 lbf ft)
----------------------	----	---------------------

Finishing work

- Install the left side cover. (📖 p. 106)
- Install the right side cover. (📖 p. 107)
- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)

13.17 Fitting the side bag rack (Expedition)



Warning

Danger of accidents Loading luggage can significantly affect the handling characteristics.

Luggage affects the handling, cornering and braking characteristics, particularly when fully laden, and increases crosswind sensitivity.

- Ride especially carefully in strong wind.
- Slowly accelerate to the permitted maximum speed.

Maximum speed with luggage mounted 130 km/h (80.8 mph)




Warning

Danger of accidents Overloading, a one-sided payload, or the luggage slipping impairs handling characteristics.


- Make sure that the maximum payload is not exceeded.
Maximum payload per side pocket 3 kg (7 lb.)
- Distribute the luggage evenly on both sides (for side bags mounted on both sides).
- Secure the payload against slipping.

Preparatory work


- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the left side cover. (📖 p. 105)
- Remove the right side cover. (📖 p. 106)



- Main work**
- Remove screws ❶.




- Position left side bag rack ❷.




- Mount screws ❸ and nut ❹, but do not tighten yet.

Guideline

Screw, side bag rack	M8x20	25 Nm (18.4 lbf ft)
----------------------	-------	---------------------




- Position right side bag rack ❺.



- Mount screws ❸ and nut ❹, but do not tighten yet.

Guideline


Screw, side bag rack	M8x20	25 Nm (18.4 lbf ft)
----------------------	-------	---------------------



- Position connecting pipe ⑨ with washers ⑦.
- ✓ The connecting pipe is located in front of the screw connection point of the side bag rack.
- ✓ The recess of the connecting pipe points toward the rear.
- Mount screws ⑥ with washers ⑦ and nuts ⑧, but do not tighten yet.

Guideline


Screw, side bag rack	M6	10 Nm (7.4 lbf ft)
----------------------	----	--------------------



- Tighten screws ③.

Guideline

Screw, side bag rack	M8x20	25 Nm (18.4 lbf ft)
----------------------	-------	---------------------



- Tighten screws ⑥.


Guideline

Screw, side bag rack	M6	10 Nm (7.4 lbf ft)
----------------------	----	--------------------


Finishing work

- Install the left side cover. (📖 p. 106)
- Install the right side cover. (📖 p. 107)
- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)
- Fit the side bags. (📖 p. 104)


13.18 Removing the side bags (Expedition)




- To remove the bag, press locking clips ① away from the rack.



- Remove side bag ② upwards.



- To remove the bag, press locking clips ③ away from the rack.



- Remove side bag ④ upwards.

13.19 Fitting the side bags (Expedition)



Warning

Danger of accidents Loading luggage can significantly affect the handling characteristics.

Luggage affects the handling, cornering and braking characteristics, particularly when fully laden, and increases crosswind sensitivity.


- Ride especially carefully in strong wind.
 - Slowly accelerate to the permitted maximum speed.
- | | |
|------------------------------------|---------------------|
| Maximum speed with luggage mounted | 130 km/h (80.8 mph) |
|------------------------------------|---------------------|




Warning

Danger of accidents Overloading, a one-sided payload, or the luggage slipping impairs handling characteristics.


- Make sure that the maximum payload is not exceeded.
- | | |
|---------------------------------|--------------|
| Maximum payload per side pocket | 3 kg (7 lb.) |
|---------------------------------|--------------|
- Distribute the luggage evenly on both sides (for side bags mounted on both sides).
 - Secure the payload against slipping.




- Position left side bag brackets **1** above and below on the side bag rack and press downwards until they are firmly seated on the rack.



- Press locking clips **2** down until they click into place on the rack.



- Position right side bag brackets **3** above and below on the side bag rack and press downwards until they are firmly seated on the rack.



- Press locking clips **4** down until they click into place on the rack.

Guideline

Make sure that all accessory parts and pieces of luggage are carefully attached.


Check all the screw connections regularly to ensure that they are tight.

The side bags must be kept closed at all times during the ride.

13.20 Removing the left side cover

Preparatory work


- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)



Main work

- Remove left side cover from the rubber bushings in the areas **A** and **B**.
- Pull off the left side cover sideways and remove it toward the front.

13.21 Installing the left side cover



Main work

- Position the left side cover with holding lug **1** on bushing **2** and push backward.
✓ The left side cover engages under the tail part.
- Press the left side cover in area **A** into rubber bushing **3** and press into rubber bushing **B** in area **4**.

Finishing work

- Mount the front rider's seat. (p. 95)
- Mount the passenger seat. (p. 94)


13.22 Removing the right side cover

Preparatory work


- Remove the passenger seat. (p. 94)
- Remove the front rider's seat. (p. 95)

Main work

- Remove the side cover from the rubber bushings in areas **A** and **B**.
- Pull off the right side cover sideways and remove it toward the front.



13.23 Installing the right side cover



Main work

- Position the right side cover with holding lug ① on bushing ② and push backward.
- ✓ The right side cover engages under the tail part.
- Press the right side cover in the area ① into rubber bushing ③ and press into rubber bushing ④ in area ④.

Finishing work

- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)




13.24 Removing the battery cover

Preparatory work


- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)

Main work

- Pull battery cover ① toward the rear out of the brackets.



13.25 Installing the battery cover



Main work

- Position the battery cover with holding lugs **1** on brackets **2** of the center fuel tank spoiler and push it forward.
- ✓ Make sure the holding lugs engage in the brackets.

Finishing work

- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)


13.26 Removing the center fuel tank spoiler

Preparatory work


- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the battery cover. (📖 p. 107)

Main work

- Remove screws **1**.
- Pull the center fuel tank spoiler in area **A** out of the bracket.



13.27 Installing the center fuel tank spoiler



Main work

- Position the center fuel tank spoiler and press the holding lugs in area **A** into the bracket.
- ✓ Make sure the holding lugs engage in the brackets.
- Mount and tighten screws **1**.

Guideline

Screw, trim	M5	3 Nm (2.2 lbf ft)
-------------	----	-------------------

Finishing work

- Install the battery cover. (p. 108)
- Mount the front rider's seat. (p. 95)
- Mount the passenger seat. (p. 94)




13.28 Removing left fuel tank spoiler

Preparatory work


- Remove the passenger seat. (p. 94)
- Remove the front rider's seat. (p. 95)
- Remove the battery cover. (p. 107)
- Remove the center fuel tank spoiler. (p. 108)

Main work

- Remove screws **1**.
- Remove the left fuel tank spoiler from the rubber bushing in area **A**.
- Pull the left fuel tank spoiler in areas **B** out of the brackets.
- Take off the left fuel tank spoiler, pulling it sideways.




13.29 Installing the left fuel tank spoiler



Main work

- Position the left fuel tank spoiler and press it into the brackets in area **A**.
✓ Make sure the holding lugs engage in the brackets.
- Press the left fuel tank spoiler into rubber bushing **1** in area **B**.



- Mount screws **2**, but do not tighten yet.

Guideline

Screw, trim	M5	3 Nm (2.2 lbf ft)
-------------	----	-------------------

- ✓ The front edge of the left fuel tank spoiler is evenly aligned.
- Tighten all the screws of the left fuel tank spoiler.

Guideline

Screw, trim	M5	3 Nm (2.2 lbf ft)
-------------	----	-------------------

Finishing work

- Install the center fuel tank spoiler. (📖 p. 109)
- Install the battery cover. (📖 p. 108)
- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)


13.30 Removing the right fuel tank spoiler

Preparatory work

- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the battery cover. (📖 p. 107)
- Remove the center fuel tank spoiler. (📖 p. 108)

Main work

- Remove screws ❶.
- Remove the fuel tank spoiler from the rubber bushing in area ❷.
- Pull the right fuel tank spoiler in areas ❸ out of the brackets.
- Take off the right fuel tank spoiler, pulling it sideways.




B06264-10


13.31 Installing the right fuel tank spoiler

Main work

- Position the right fuel tank spoiler and press it into the brackets in area ❶.
- ✓ Make sure the holding lugs engage in the brackets.
- Press the right fuel tank spoiler into rubber bushing ❶ in area ❷.



B06265-10



- Mount screws 2, but do not tighten yet.

Guideline

Screw, trim	M5	3 Nm (2.2 lbf ft)
-------------	----	-------------------

- ✓ The front edge of the right fuel tank spoiler is evenly aligned.

- Tighten all the screws of the right fuel tank spoiler.


Guideline

Screw, trim	M5	3 Nm (2.2 lbf ft)
-------------	----	-------------------

Finishing work

- Install the center fuel tank spoiler. (p. 109)
- Install the battery cover. (p. 108)
- Mount the front rider's seat. (p. 95)
- Mount the passenger seat. (p. 94)

13.32 Removing the front fender




- Remove screws 1.
- Take the fender off to the front.



Info

Pay attention to the brake lines and the cable.

13.33 Installing the front fender



- Position the fender. Mount screws 1, but do not tighten yet.



Info

Pay attention to the routing of the brake lines and the cable.

- Mount and tighten screws 1.

Guideline

Screw, trim	M5	3 Nm (2.2 lbf ft)
-------------	----	-------------------


13.34 Cleaning the dust boots of the fork legs

Preparatory work

- Raise the motorcycle with the rear lifting gear. (p. 92)
- Lift the motorcycle with the front lifting gear. (p. 92)

Main work

- Push dust boots ① of both fork legs downward.



Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.

- Clean and oil the dust boots and inside fork tubes of both fork legs.

Universal oil spray (p. 183)


- Press the dust boots back into the installation position.
- Remove the excess oil.

Finishing work

- Take the motorcycle off the front lifting gear. (p. 93)
- Remove the rear of the motorcycle from the lifting gear. (p. 92)




13.35 Removing the windshield



- Remove screws ① and take off windshield ②.



13.36 Installing the windshield




- Position windshield ①.
- Mount and tighten screws ②.

Guideline


Screw, windshield	M5x14	5 Nm (3.7 lbf ft)
-------------------	-------	-------------------

13.37 Removing left fuel tank cover



- Remove fitting ①.
- Remove screws ②.
- Take off the left fuel tank cover, pulling it downward.

13.38 Installing the left fuel tank cover



- Position the left fuel tank cover.
- Mount screws **1**, but do not tighten yet.

Guideline

Screw, tank guard on engine guard, front	M6x25	10 Nm (7.4 lbf ft)
--	-------	--------------------

- Mount fitting **2**, but do not tighten yet.

Guideline

Screw, tank guard on engine guard, bottom	M6x18	10 Nm (7.4 lbf ft)
---	-------	--------------------

- ✓ The left fuel tank cover is directed evenly toward the front.


- Tighten all the screws of the left fuel tank cover.

Guideline

Screw, tank guard on engine guard, front	M6x25	10 Nm (7.4 lbf ft)
Screw, tank guard on engine guard, bottom	M6x18	10 Nm (7.4 lbf ft)




13.39 Removing right fuel tank cover



- Pull out hose **1** from the angle piece.
- Remove fitting **2**.
- Remove screws **3**.
- Remove right fuel tank cover.



13.40 Installing the right fuel tank cover



- Position the right fuel tank cover.
- Mount screws ①, but do not tighten yet.

Guideline

Screw, tank guard on engine guard, front	M6x25	10 Nm (7.4 lbf ft)
--	-------	--------------------

- Mount fitting ②, but do not tighten yet.

Guideline

Screw, tank guard on engine guard, bottom	M6x18	10 Nm (7.4 lbf ft)
---	-------	--------------------

- ✓ The right fuel tank cover is directed evenly toward the front.


- Tighten all the screws of the right fuel tank cover.

Guideline

Screw, tank guard on engine guard, front	M6x25	10 Nm (7.4 lbf ft)
Screw, tank guard on engine guard, bottom	M6x18	10 Nm (7.4 lbf ft)


- Attach hose ③ to the angle piece.

13.41 Removing the engine guard




(Standard model)


- Pull out hose ① from the angle piece.



- Remove screws ②.




- Remove screws ③ and engine guard ④.





(Expedition)

- Pull hose ① out of the engine guard.




- Remove screw ② and screws ③.




- Remove screws ④ and engine guard ⑤.



13.42 Installing the engine guard




- (Standard model)
- Position engine guard 1.
 - Mount screws 2, but do not tighten yet.




- Mount screws 3, but do not tighten yet.
- Tighten all the screws of the engine guard.

Guideline



Screw, engine guard	M6x8	8 Nm (5.9 lbf ft)
Screw, engine guard	M6x10	10 Nm (7.4 lbf ft) Loctite®243™




- Attach tube 4 to the angle piece.



- (Expedition)
- Position engine guard 1.
 - Mount screws 2, but do not tighten yet.



S05673-11



S05672-11

- Mount screw ③ and screws ④, but do not tighten yet.
- Tighten all the screws of the engine guard.


Guideline

Screw, engine guard	M6x13	10 Nm (7.4 lbf ft)
Screw, engine guard rack	M8x20	15 Nm (11.1 lbf ft)
Screw, retaining bracket	M8x20	15 Nm (11.1 lbf ft)

- Insert hose ⑤ through the engine guard.



14.1 Anti-lock braking system (ABS)



The ABS module **1**, which consists of a hydraulic unit, ABS control unit, and return pump, is installed under the fuel tank. One wheel speed sensor **2** is located in each case on the front and the rear wheel.



Warning

Danger of accidents Changes to the vehicle impair the function of the ABS.

- Do not make any changes to the suspension travel.
- Only use spare parts on the brake system which have been approved and recommended by Husqvarna Motorcycles.
- Only use tires/wheels approved by Husqvarna Motorcycles with the corresponding speed index.
- Maintain the specified tire pressure.
- Ensure that service work and repairs are performed professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

The ABS is a safety system that prevents the wheels locking when driving straight ahead or when cornering (within the limits of physics).



Warning

Danger of accidents Driving aids can reduce the probability of a fall only within physical limits.

It is not always possible to compensate for certain riding situations, for example with luggage loaded with a high center of gravity, varying road surfaces, steep descents or full braking without disengaging the gear.

- Adapt your riding style to the road conditions and your driving ability.



Warning

Danger of accidents An incorrectly selected ABS mode makes control of the vehicle considerably more difficult.

The ABS modes are each only suitable for certain conditions.

- Always select an ABS mode that is compatible with the surface of the ground.

The ABS control is dependent on the riding mode. ABS has two operating modes: the **Road** and **Offroad** ABS modes.

In riding modes **Street** and **Rain**, the ABS controls both wheels. In riding mode **Offroad**, there is no ABS control on the rear wheel.

ABS can be configured in riding mode **Explorer** (optional).

In ABS mode **Road**, ABS controls both wheels.

In ABS mode **Offroad** there is no ABS control on the rear wheel.

**Info**

The curve dependent control is only active in ABS mode **Road**.

The ABS operates with two independent brake circuits (front and rear brakes). When the ABS control unit detects a locking tendency in a wheel, ABS begins regulating the brake pressure. The control function causes a slight pulsing of the hand and foot brake levers.

The ABS warning lamp **3** must light up after the ignition is switched on and go out after starting off. If it does not go out after starting off or if it lights up while riding, this indicates a malfunction in the ABS. In this case, the ABS is no longer enabled and the wheels may lock during braking. The brake system itself stays functional; only ABS control is not available. The ABS warning lamp may also light up if the rotating speeds of the front and rear wheels differ greatly under extreme riding conditions, for example when making "wheelies" or if the rear wheel spins. This causes the ABS to switch off.


To reactivate the ABS, stop the vehicle and switch off the ignition. The ABS is reactivated when the vehicle is switched on again. The ABS warning lamp goes out after starting off.

14.2 Checking brake discs

**Warning**

Danger of accidents Worn-out brake discs reduce the braking effect.

- Make sure that worn-out brake discs are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check front and rear brake disc thickness at multiple points for the dimension **A**.

**Info**

Wear will reduce the thickness of the brake disc at contact surface **1** of the brake linings.

Brake discs - wear limit	
front	4.5 mm (0.177 in)
rear	4.5 mm (0.177 in)

- » If the brake disc thickness is less than the specified value.
 - Change the front brake discs. 🛠️
 - Change the rear brake disc. 🛠️
- Check front and rear brake discs for damage, cracking, and deformation.
 - » If the brake disc exhibits damage, cracking, or deformation:
 - Change the front brake discs. 🛠️
 - Change the rear brake disc. 🛠️



14.3 Checking the front brake fluid level



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.


- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in brake fluid reservoir **1**.
 - » If the brake fluid level has dropped below **MIN** marking **A**:
 - Add front brake fluid. 📖 (p. 122)

14.4 Adding front brake fluid 📖



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Note

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work

- Check that the brake linings of the front brake are secured. (p. 123)

Main work

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Take off cover ② with membrane ③.
- Add brake fluid up to the marking ④.

Brake fluid DOT 4 / DOT 5.1 (p. 181)

- Position cover ② with membrane ③.
- Mount screws ① and tighten in the order A B C.


Guideline

Brake fluid reservoir cover, front	-	2 Nm (1.5 lbf ft)
------------------------------------	---	-------------------



Info

Use water to immediately clean up any brake fluid that has overflowed or spilled.



14.5 Checking that the brake linings of the front brake are secured



Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

- Ensure that worn-out brake linings are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)




Warning

Danger of accidents Damaged brake discs reduce the braking effect.

If the brake linings are not changed in time, the brake lining carriers grind against the brake disc. As a consequence, the braking effect is greatly reduced and the brake discs are destroyed.

- Check the brake linings regularly.



- Check all brake linings on both brake calipers to ensure they have the minimum thickness **A**.
- | | |
|----------------------------|--------------------|
| Minimum thickness A | ≥ 1 mm (≥ 0.04 in) |
|----------------------------|--------------------|
- » If the minimum thickness is less than specified:
 - Change the brake linings of the front brake. 🛠️
 - Check all the brake linings on both the brake calipers for damage and cracking.
 - » If there is damage or cracking:
 - Change the brake linings of the front brake. 🛠️
 - Check that the brake linings are secured.
 - » If the brake linings are not secured correctly:
 - Secure brake linings, replace with new parts if necessary.

14.6 Checking the free travel of the foot brake lever




Warning

Danger of accidents The brake system will fail if it overheats or is adjusted incorrectly.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

- Set the free travel on the foot brake lever in accordance with the specification.
- Ensure that the adjustment steps are performed properly. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Detach spring **1**.
 - Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel **A**.
- Guideline
- | | |
|---------------------------------|------------------------------|
| Free travel at foot brake lever | 3 ... 5 mm (0.12 ... 0.2 in) |
|---------------------------------|------------------------------|
- » If the free travel does not match the specification:
 - Adjust the basic position of the foot brake lever. 📖 (p. 67) 🛠️
 - Attach spring **1**.

14.7 Checking the rear brake fluid level



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.


- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Stand the vehicle upright.
- Check brake fluid level in brake fluid reservoir ①.
 - » If the fluid level reaches the **MIN** marking A:
 - Add rear brake fluid. 📖 (p. 125)

14.8 Adding rear brake fluid 📖



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.

- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Note


Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.



Preparatory work

- Check that the brake linings of the rear brake are secured. (📖 p. 126)

Main work

- Stand the vehicle upright.
- Remove screw cover ❶ with insert and membrane ❷.
- Add brake fluid up to the **MAX** marking A.

Brake fluid DOT 4 / DOT 5.1 (📖 p. 181)

- Mount and tighten screw cover ❶ with the insert and membrane ❷.

Guideline		
Brake fluid reservoir cover, rear	-	1.5 Nm (1.11 lbf ft)



Info

Use water to immediately clean up any brake fluid that has overflowed or spilled.

14.9 Checking that the brake linings of the rear brake are secured



Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

- Ensure that worn-out brake linings are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)




Warning

Danger of accidents Damaged brake discs reduce the braking effect.

If the brake linings are not changed in time, the brake lining carriers grind against the brake disc. As a consequence, the braking effect is greatly reduced and the brake discs are destroyed.

- Check the brake linings regularly.



- Check the brake linings for minimum thickness **A**.

Minimum thickness A	$\geq 1 \text{ mm } (\geq 0.04 \text{ in})$
----------------------------	---

- » If the minimum thickness is less than specified:
 - Change the rear brake linings. 🛠️
- Check the brake linings for damage and cracking.
 - » If there is damage or cracking:
 - Change the rear brake linings. 🛠️
- Check that the brake linings are secured.
 - » If the brake linings are not secured correctly:
 - Secure brake linings, replace with new parts if necessary.



15.1 Removing the front wheel

Preparatory work

(Standard model)

- Raise the motorcycle with the rear lifting gear. (p. 92)
- Lift the motorcycle with the front lifting gear. (p. 92)

(Expedition)

- Raise the vehicle with the center stand. (p. 93)
- Place a load on the rear of the vehicle.
- ✓ The front wheel is not in contact with the ground.



Main work

- Remove screw ① and pull wheel speed sensor ② out of the hole.
- Remove screws ③ and ④.
- Press back the brake linings by slightly tilting the left and right brake caliper laterally on the brake disc. Pull the left and right brake caliper carefully back from the brake disc and hang to the side.



Info

Do not operate the hand brake lever if the brake calipers have been removed.



- Loosen screw ⑤ by several rotations.
- Loosen screws ⑥.
- Press on screw ⑤ to push the wheel spindle out of the axle clamp.
- Remove screw ⑤.




Warning

Danger of accidents Damaged brake discs reduce the braking effect.

- Always lay the wheel down in such a way that the brake discs are not damaged.

- Hold front wheel and remove wheel spindle. Take the front wheel out of the fork.



- Remove spacers 7.




15.2 Installing the front wheel ↱



Warning


Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change front wheel bearing. ↱
- Clean and grease shaft seal rings 1 and contact surfaces A of the spacers.

Long-life grease (📖 p. 183)



- Insert narrow spacer 2 on the right in the direction of travel.
- Insert wide spacer 3 on the left in the direction of travel.




Info

Arrow B indicates the direction of travel of the front wheel.

The wheel speed sensor wheel is on the left viewed in the direction of travel.






- Clean screw 4 and the wheel spindle.
- Grease wheel spindle lightly.

Long-life grease (📖 p. 183)

- Jack up the front wheel into the fork, position it, and insert the wheel spindle.
- Mount and tighten screw 4.

Guideline

Screw, front wheel spindle	M25x1.5	45 Nm (33.2 lbf ft) Thread greased
----------------------------	---------	---------------------------------------



- Position both brake calipers.
- ✓ The brake linings are correctly positioned.
- Mount screws 5 on both sides but do not tighten yet.

Guideline

Screw, front brake caliper	M10x1.25	45 Nm (33.2 lbf ft) Loctite®243™
----------------------------	----------	--

- Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point. Secure the hand brake lever in the activated position.
- ✓ The brake calipers straighten.
- Tighten screws 5 on both sides.

Guideline

Screw, front brake caliper	M10x1.25	45 Nm (33.2 lbf ft) Loctite®243™
----------------------------	----------	--

- Position wheel speed sensor 6 in the hole.
- Mount and tighten screw 7.

Guideline

Screw, front wheel speed sensor	M6	10 Nm (7.4 lbf ft)
---------------------------------	----	--------------------

- Remove the locking piece of the hand brake lever.

(Standard model)

- Take the motorcycle off the front lifting gear. (📖 p. 93)
- Remove the rear of the motorcycle from the lifting gear. (📖 p. 92)


(Expedition)

- Remove the vehicle from the center stand. (📖 p. 94)
- Operate the front brake and compress the fork a few times firmly.
- ✓ The fork legs straighten.

- Tighten screws 8.

Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	---------------------



15.3 Removing the rear wheel

Preparatory work

(Expedition)



- Raise the vehicle with the center stand. (p. 93)

(Standard model)

- Raise the motorcycle with the rear lifting gear. (p. 92)

Main work

- Manually press the brake caliper toward the brake disc to push back the brake piston.
- Remove screw ① and pull wheel speed sensor ② out of the hole.
- Remove nut ③. Take off chain adjuster ④.
- Pull out wheel spindle ⑤ far enough to allow the rear wheel to be pushed forward.



- Push the rear wheel forward as far as possible. Take the chain off the rear sprocket and place it on chain sprocket guard ⑥.



Info

Cover the components to protect them against damage.

- Hold the rear wheel and remove the wheel spindle.
- Pull the rear wheel back until the brake caliper bracket is suspended freely between the brake disc and rim.



Warning

Danger of accidents Damaged brake discs reduce the braking effect.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Take the rear wheel out of the link fork.



Info

Do not operate the foot brake lever when the rear wheel is removed.

15.4 Installing the rear wheel 🛠️



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.


- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



Warning

Danger of accidents There is no braking effect to start with at the rear brake after installing the rear wheel.

- Actuate the foot brake several times before going on a ride until you can feel a firm pressure point.



Main work

- Check the rear hub damping rubber pieces. 🛠️ (📖 p. 133)
- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the rear wheel bearing. 🛠️
- Remove spacer.
- Clean and grease shaft seal ring 1 and contact surface A of the spacer.

Long-life grease (📖 p. 183)

- Insert a spacer.
- Clean and grease the thread of the wheel spindle and nut.

Long-life grease (📖 p. 183)

- Clean and lightly grease the wheel spindle.

Long-life grease (📖 p. 183)

- Clean the contact areas on the brake caliper bracket and link fork.
- Engage the thrust bearing of brake caliper bracket B and the link fork.
- Jack up the rear wheel into the link fork, position it, and insert the wheel spindle.
 - ✓ The brake linings are correctly positioned.
- Place the chain on the sprocket.
- Position chain adjuster 2. Mount nut 3, but do not tighten it yet.




Info

Mount the left and right chain adjusters in the same position.

- Make sure that chain adjusters 2 are fitted correctly on the adjusting screws. Tighten nut 3.

Guideline

In order for the rear wheel to be correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to reference markings C.



Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft) Thread and contact area of wheel spindle greased
-------------------------	---------	---

- Position wheel speed sensor ④ in the hole.
- Mount and tighten screw ⑤.

Guideline

Screw, rear wheel speed sensor	M6	6 Nm (4.4 lbf ft)
--------------------------------	----	-------------------

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

Finishing work

- Check the chain tension. (📖 p. 96)

(Standard model)

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 92)

(Expedition)

- Remove the vehicle from the center stand. (📖 p. 94)

15.5 Checking the rear hub damping rubber pieces 🛠️

Info

The engine power is transmitted from the rear sprocket to the rear wheel via the 6 damping rubber pieces. They eventually wear out during operation. If the damping rubber pieces are not changed in time, the rear sprocket carrier and the rear hub will be damaged.

Preparatory work

(Expedition)


- Raise the vehicle with the center stand. (📖 p. 93)


(Standard model)

- Raise the motorcycle with the rear lifting gear. (📖 p. 92)
- Remove the rear wheel. 🛠️ (📖 p. 131)

Main work

- Check bearing ①.
 - » If the bearing is damaged or worn:
 - Change the bearing of the rear sprocket carrier. 🛠️
- Check damping rubber pieces ② of the rear hub for damage and wear.
 - » If the damping rubber pieces of the rear hub are damaged or worn:
 - Change all the damping rubber pieces of the rear hub.





- Lay the rear wheel on a workbench with the rear sprocket facing upwards and insert the wheel spindle in the hub.
- To check play **A**, hold the rear wheel tight and try to turn the rear sprocket with your hand.

Info
Measure the play on the outside of the rear sprocket.

Play of damping rubber pieces on rear wheel	≤ 5 mm (≤ 0.2 in)
---	-------------------

- » If clearance **A** is larger than the specified value:
- Change all the damping rubber pieces of the rear hub. 🛠️

Finishing work

- Install the rear wheel. 🛠️ (📖 p. 132)
- Check the chain tension. (📖 p. 96)

(Standard model)

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 92)

(Expedition)

- Remove the vehicle from the center stand. (📖 p. 94)

15.6 Checking the tire condition

Warning
Danger of accidents If a tire bursts while riding, the vehicle becomes uncontrollable.

- Ensure that damaged or worn tires are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Danger of crashing Different tire tread patterns on the front and rear wheel impair the handling characteristic.

Different tire tread patterns can make the vehicle significantly more difficult to control.

- Make sure that only tires with a similar tire tread pattern are fitted to the front and rear wheel.

Warning
Danger of accidents Non-approved or non-recommended tires and wheels impact the handling characteristic.

- Only use tires/wheels approved by Husqvarna Motorcycles with the corresponding speed index.

Warning
Danger of accidents New tires have reduced road grip.

The contact surface on new tires is not yet roughened.

- Run in new tires with moderate riding and only gradually increase the lean angle.


Run-in distance200 km (124 mi)



Info

Tire type, tire condition, and tire pressure influence the braking and handling characteristics of the vehicle.

Worn tires have a negative effect on handling characteristics, especially on wet surfaces.



- Check the front and rear tires for cuts, embedded objects, and other damage.
 - » If the tires have cuts, run-in objects, or other damage:
 - Change the tires. 🛠️
- Check tread depth.



Info

Adhere to the legally required minimum tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)
---------------------	--------------------

- » If the tread depth is less than the minimum tread depth:
 - Change the tires. 🛠️

- Check the tire age.



Info

The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.

Husqvarna Motorcycles recommends that the tires be changed after 5 years at the latest, regardless of the actual wear.

- » If the tires are more than five years old:
 - Change the tires. 🛠️




15.7 Checking tire pressure



Info

Low tire pressure leads to abnormal wear and overheating of the tire.

Correct tire pressure ensures optimal riding comfort and maximum tire service life.



- Remove protection cap.
- Check tire pressure when the tires are cold.

Tire pressure solo / with passenger	
front	2.4 bar (35 psi)
rear	2.4 bar (35 psi)

Offroad tire pressure	
front	1.8 bar (26 psi)
rear	1.8 bar (26 psi)

Tire pressure full payload	
front	2.6 bar (38 psi)

rear	2.6 bar (38 psi)
------	------------------

- » If the tire pressure does not meet specifications:
 - Correct tire pressure.
- Mount the protection cap.

15.8 Checking spoke tension




Warning

Danger of accidents Incorrectly tensioned spokes impair the handling characteristic and result in secondary damage.

The spokes break due to being overloaded if they are too tightly tensioned. If the tension in the spokes is too low, then lateral and radial run-out will form in the wheel. Other spokes will become looser as a result.

- Check spoke tension regularly, and in particular on a new vehicle. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Strike each spoke briefly using a screwdriver blade.



Info


The frequency of the sound depends on the spoke length and spoke diameter.

If spokes of the same length and diameter vibrate with a different tone, this is an indication that the spoke tensions differ.

You should hear a high note.

- » If the spoke tension differs:
 - Correct the spoke tension. 🛠️

15.9 Tubeless tire system



This vehicle uses a tubeless tire system in which a rim seal band **1** is used instead of the conventional tube.


The advantage of the tubeless system is that there is no danger of a faulty tube. This greatly reduces the risk of a sudden loss in pressure.

The moments of inertia of these wheels are smaller than in conventional spoked wheels with a tube. This results in better handling and riding comfort.

The rigid rim design results in a wire spoke wheel that is almost entirely maintenance-free.

Husqvarna Motorcycles recommends that the rim seal band is changed after 5 years at the latest, regardless of the actual state of wear.

15.10 Using tire repair spray



Warning

Danger of accidents Incorrect use of tire repair spray will result in the repaired tire losing pressure.

Tire repair spray cannot be used for all types of damage.

- Observe the instructions and specifications of the manufacturer of the tire repair spray.
- After repairing a tire with tire repair spray, ride slowly and carefully.
- Ride no further than to the nearest workshop and have the tire changed.

Tire repair spray should only be used in an emergency.

We recommend transporting the broken down vehicle to the nearest workshop instead of using tire repair spray.

(Option: With TPMS)

Note

Material damage Tire repair spray damages the tire pressure sensor.

- Note that after using tire repair spray, the tire pressure sensor may need to be replaced.

16.1 Removing the 12-V battery



Warning

Risk of injury Battery acid and battery gases cause serious chemical burns.

- Keep 12 V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.



Caution

Danger of accidents Electronic components and safety devices will be damaged if the 12-V battery is discharged or missing.

If the 12-V battery is discharged or defective, malfunctions in the vehicle electronics can occur, especially when starting.


- Never operate the vehicle with a discharged 12-V battery or without a 12-V battery.


Preparatory work

- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the battery cover. (📖 p. 107)

Main work

- Pull the diagnostics connector ① out of the bracket and hang to the side.
- Remove screw ②.
- Raise the battery mounting element ③ at the rear and remove in upward direction.





- Disconnect negative cable ④ from the 12-V battery.
- Remove positive terminal cover ⑤.
- Disconnect positive cable ⑥ from the 12-V battery.
- Pull the 12-V battery upwards and out of the battery compartment.

16.2 Installing the 12-V battery ↗



Warning

Risk of injury Battery acid and battery gases cause serious chemical burns.

- Keep 12 V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.




Caution

Danger of accidents Electronic components and safety devices will be damaged if the 12-V battery is discharged or missing.

If the 12-V battery is discharged or defective, malfunctions in the vehicle electronics can occur, especially when starting.

- Never operate the vehicle with a discharged 12-V battery or without a 12-V battery.



Main work

- Position the 12-V battery in the battery compartment.

12-V battery (HTZ12A-BS) (p. 170)

- ✓ The battery terminals face opposite the direction of travel.

- Connect positive cable 1 to the 12-V battery.

Guideline


Screw, battery terminal	M6	4.5 Nm (3.32 lbf ft)
-------------------------	----	----------------------

- Mount positive terminal cover 2.

- Connect negative cable 3 to the 12 V battery.

Guideline

Screw, battery terminal	M6	4.5 Nm (3.32 lbf ft)
-------------------------	----	----------------------



- Hang battery holding bracket 4 to the left and right in the holding lugs and push downward at the rear.

- Mount and tighten screw 5.

Guideline

Screw, battery holding bracket	M6	4.5 Nm (3.32 lbf ft)
--------------------------------	----	----------------------

- Position the diagnostics connector 6 in the holder.

Finishing work

- Install the battery cover. (p. 108)
- Mount the front rider's seat. (p. 95)
- Mount the passenger seat. (p. 94)
- Set time and date. (p. 63)

16.3 Charging the 12-V battery ↱



Warning

Risk of injury Battery acid and battery gases cause serious chemical burns.

- Keep 12 V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.



Note

Environmental hazard 12 V batteries contain environmentally hazardous materials.

- Do not dispose of 12 V batteries as household waste.
- Dispose of 12 V batteries at a collection point for used batteries.



Note

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Even when there is no load on the 12-V battery, it discharges steadily each day.

The charging level and the method of charging are very important for the service life of the 12-V battery.

Rapid recharging with a high charging current shortens the service life of the battery.

If the charging current, charging voltage, or charging time is exceeded, electrolyte escapes through the safety valves. This reduces the capacity of the 12-V battery.

If the 12-V battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.

If the 12-V battery is left in a discharged state for an extended period, it will become deeply discharged and sulfating occurs, destroying the battery.


The 12-V battery is maintenance-free. The acid level does not have to be checked.


Preparatory work

- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)
- Remove the battery cover. (📖 p. 107)

Main work

- Disconnect negative cable ❶ from the 12 V battery to avoid damaging the onboard electronics.
- Remove positive terminal cover ❷.





- Connect a battery charger to the 12-V battery. Switch on the battery charger.

Guideline

The battery charger must be suitable for the 12-V battery.




Info
Never remove cover ③.
Charge the 12-V battery to a maximum of 10% of the capacity specified on battery housing ④.

- Switch off the battery charger after charging and disconnect from the 12-V battery.

Guideline

The charging current, charging voltage, and charging time must not be exceeded.	
Recharge the 12-V battery regularly when the motorcycle is not being used	3 months



- Mount positive terminal cover ②.
- Connect negative cable ① to the 12 V battery.

Guideline

Screw, battery terminal	M6	4.5 Nm (3.32 lbf ft)
-------------------------	----	----------------------

Finishing work

- Install the battery cover. (p. 108)
- Mount the front rider's seat. (p. 95)
- Mount the passenger seat. (p. 94)
- Set time and date. (p. 63)

16.4 Changing the main fuse



Warning
Fire hazard Incorrect fuses overload the electrical system.


- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.




Info
The main fuse protects all electrical power consumers of the vehicle. The main fuse is under the seat.

Preparatory work

- Remove the passenger seat. (p. 94)
- Remove the front rider's seat. (p. 95)

**Main work**

- Remove protection cap ①.



- Remove faulty main fuse ②.

**Info**

A faulty fuse has a burned-out fuse wire A.

A spare fuse ③ is located in the starter relay.


- Insert a new main fuse.

Fuse (58011109130) (📖 p. 170)

**Tip**

Insert a new spare fuse into the starter relay to have it available when needed.

- Mount protection cap ①.

**Finishing work**

- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)
- Set time and date. (📖 p. 63)



16.5 Changing the ABS fuses

**Warning**

Fire hazard Incorrect fuses overload the electrical system.


- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.

**Info**

Two fuses for the ABS are located under the seat. These fuses protect the return pump and the hydraulic unit of the ABS. The third fuse, which protects the ABS control unit, is located in the fuse box.

Preparatory work

- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)



To change the fuse of the ABS hydraulic unit:

- Remove the protection cap and fuse ①.

i Info
A faulty fuse has a burned-out fuse wire **A**.

- Insert the spare fuse with the correct rating.

Fuse (75011088010) (📖 p. 170)

i Tip
Insert spare fuse ② in the fuse box so that it is available if needed.

- Mount the protection cap.

To change the fuse of the ABS return pump:

- Remove the protection cap and fuse ③.

i Info
A faulty fuse has a burned-out fuse wire **A**.

- Insert the spare fuse with the correct rating.


Fuse (75011088025) (📖 p. 170)

i Tip
Insert spare fuse ④ in the fuse box so that it is available if needed.

- Mount the protection cap.

Finishing work

- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)



16.6 Changing the fuses of individual electrical power consumers


⚠ Warning
Fire hazard Incorrect fuses overload the electrical system.

- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.


i Info
The fuse box containing the fuses of individual electrical power consumers is located under the seat.

Preparatory work

- Remove the passenger seat. (📖 p. 94)
- Remove the front rider's seat. (📖 p. 95)

**Main work**

- Open fuse box cover ❶.



- Remove the faulty fuse.

Guideline

Fuse 1 - 10 A - ignition, alarm system (optional)
Fuse 2 - 10 A - ignition, engine control unit, electronic fuel injection, fuel vapor retention system, lambda sensor, immobilizer
Fuse 4 - 15 A - radiator fan
Fuse 5 - 10 A - horn, combination instrument, brake light
Fuse 6 - 10 A - high beam, low beam, position light, tail light, license plate lamp
Fuse 7 - 10 A - ACC1
Fuse 8 - 15 A - ACC2, USB charging socket, supplementary headlight, HCU (optional)
Fuse 9 - 10 A - ABS control unit, diagnostics connector, 6D sensor, TPMS (function optional)
Fuse SPARE - 10 A – spare fuses
Fuse SPARE - 15 A – spare fuses

**Info**

A faulty fuse has a burned-out fuse wire ❸.

- Insert the spare fuse with the correct rating.

Fuse (75011088010) (📖 p. 170)
Fuse (75011088015) (📖 p. 170)

**Tip**

Put a spare fuse in the fuse box so that it is available if needed.


- Check the function of the electrical power consumers.
- Close the fuse box cover.

Finishing work

- Mount the front rider's seat. (📖 p. 95)
- Mount the passenger seat. (📖 p. 94)



16.7 Checking the headlight setting



- Park the vehicle on a horizontal surface in front of a light-colored wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance **B** under the first marking.
Guideline

Distance B	5 cm (2 in)
-------------------	-------------

- Position the vehicle upright at distance **A** from the wall and switch on the low beam.
Guideline

Distance A	5 m (16 ft)
-------------------	-------------

- The rider now mounts the motorcycle with luggage and passenger if applicable.
- Check the headlight setting.

The light-dark boundary must be exactly on the lower marking when the motorcycle is ready to be operated with the rider mounted along with any luggage and a passenger if applicable.

- » If the boundary between light and dark does not meet specifications:
 - Adjust headlight range. (p. 146)


16.8 Adjusting the headlight range

Preparatory work


- Check the headlight setting. (p. 146)

Main work

- Turn adjusting wheel **1** to adjust the headlight range.




i Info
Turn clockwise to reduce the headlight range; turn counterclockwise to increase the headlight range.
If you have a payload, you may have to correct the headlight range.



- Set the headlight to marking **B**.
Guideline

The light-dark boundary must lie exactly on lower marking **B** when the motorcycle is ready to operate with the rider mounted along with any luggage and a passenger, if applicable.

16.9 Checking the supplementary headlight setting



- Park the vehicle on a horizontal surface in front of a light-colored wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance **B** under the first marking.

Guideline

Distance B	5 cm (2 in)
-------------------	-------------

- Position the vehicle upright at distance **A** from the wall and switch on the supplementary headlight.

Guideline

Distance A	5 m (16 ft)
-------------------	-------------

- The rider now mounts the motorcycle with luggage and passenger if applicable.
- Check the headlight setting.

The light-dark boundary must be exactly on the lower marking when the motorcycle is ready to be operated with the rider mounted along with any luggage and a passenger if applicable.

- » If the boundary between light and dark does not meet specifications:
 - Adjust the supplementary headlight range. (📖 p. 147)




16.10 Adjusting the supplementary headlight range

Preparatory work

- Check the supplementary headlight setting. (📖 p. 147)

Main work


- Use adjusting screws **1** to adjust the supplementary headlight range.



Info

Turn clockwise to increase the headlight range; turn counterclockwise to reduce the headlight range.

If you have a payload, you may have to correct the supplementary headlight range.



- Set the headlight to marking **B**.

Guideline


Comply with country-specific specifications.

The light-dark boundary must lie exactly on lower marking **B** when the motorcycle is ready to operate with the rider mounted along with any luggage and a passenger, if applicable.

- ✓ Adjust the supplementary headlight range equally on both sides.




16.11 Diagnostics connector



Diagnostics connector ① is located under the battery cover.

16.12 Front ACC1 and ACC2



Installation location

- The front power supply ACC1 ① is located behind the headlight.
- The front power supply ACC2 ② is located behind the mask support cover.

i Info


The power supplies are protected by a fuse; however, this fuse also protects other electrical power consumers. The maximum continuous load is therefore significantly lower than the value of the fuse.

Do not use a stronger fuse.

The power supply ACC1 is switched to permanent positive; connected power consumers are permanently supplied with current, regardless of ignition.

The power supply ACC2 is switched to ignition plus; connected power consumers are only supplied with power when the ignition is switched on.

16.13 ACC1 and ACC2 rear



Installation location

- Power supplies ACC1 ① and ACC2 ② rear are located under the seat.

i Info

The cable insulation label indicates the type of power supply.



Info

The power supplies are protected by a fuse; however, this fuse also protects other electrical power consumers.


The maximum continuous load is therefore significantly lower than the value of the fuse.

Do not use a stronger fuse.

The power supply ACC1 is switched to permanent positive; connected power consumers are permanently supplied with current, regardless of ignition.

The power supply ACC2 is switched to ignition plus; connected power consumers are only supplied with power when the ignition is switched on.


17.1 Cooling system



Water pump **1** in the engine ensures forced circulation of the coolant.

The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap **2**. Heat expansion causes excess coolant to flow into compensating tank **3**. When the temperature falls, this surplus coolant is sucked back into the cooling system. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

115 °C (239 °F)



The coolant is cooled by the air stream and two radiator fans **4**, which are activated at high temperature.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

17.2 Checking the coolant level in the compensating tank



Warning

Danger of scalding During motorcycle operation, the coolant gets hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Warning

Danger of poisoning Coolant is harmful to health.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

Condition

The engine is cold.

The radiator is completely full.

- Park the motorcycle on a horizontal surface.



- Check the coolant level in the compensating tank.

The coolant level must be between **MIN** and **MAX**.

- » If there is no coolant in the compensating tank:
 - Check the cooling system for leaks. 🛠️

i Info

Do not start up the motorcycle!

- Fill/bleed the cooling system. 🛠️
- » If the coolant level in the compensating tank is not at the required level, but the tank is not empty:
 - Correct the coolant level in the compensating tank. (📖 p. 151)



17.3 Correcting the coolant level in the compensating tank



Warning

Danger of scalding During motorcycle operation, the coolant gets hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Warning

Danger of poisoning Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

Condition

The engine is cold.


The radiator is completely full.


Preparatory work

- Check the coolant level in the compensating tank. (📖 p. 150)

Main work

- Remove cover ❶ of the compensating tank.





- Add coolant until the coolant reaches the specified level.

Guideline

The coolant level must be between **MIN** and **MAX**.

Coolant (📖 p. 181)

- Mount cover ❶ of the compensating tank.

Guideline

Compensating tank cover	-	1.1 Nm (0.81 lbf ft)
-------------------------	---	----------------------



18.1 Motorcycle traction control (Cornering MTC)



The motorcycle traction control (**MTC**) lowers the engine torque in case of loss of traction in the rear wheel. Depending on the riding mode, different amounts of slip are allowed when traction control is activated.

i Info

When motorcycle traction control is switched off, the rear wheel may spin during strong acceleration and on surfaces with low grip, resulting in a risk of falling.

After the ignition is switched on, motorcycle traction control is enabled again.


In the combination instrument, the motorcycle traction control can be switched on or off via the **MTC** submenu.

i Info

When the motorcycle traction control is active, the TC indicator lamp  flashes.

When motorcycle traction control is switched off, the TC indicator lamp  lights up.

18.2 Slip adjustment (optional)



The spin adjuster is a motorcycle traction control function.

The slip adjustment allows the motorcycle traction control to be tuned through nine levels to the desired characteristic map.

Level 1 allows the maximum slip on the rear wheel, and level 9 the minimum.

The slip adjustment can be set while riding with a closed menu using the **UP** or **DOWN** button.

i Info

The spin adjuster is only available in **Explorer** riding mode (optional).

18.3 Throttle (optional)



Possible states

- Street – Balanced response.
- Explorer – Extremely direct response
- Offroad – Very direct response.

In the combination instrument the characteristics of the throttle response can be adjusted via the **Throttle** submenu.

The **Throttle** can also be set while riding with a closed throttle grip.


i Info

Throttle is only available in riding mode **Explorer** (optional).

19.1 Checking the engine oil level

i Info

The engine oil level must be checked at normal engine operating temperature.



- Stand motorcycle upright on a horizontal surface.
- Check the engine oil level.

i Info

After switching off the engine, wait one minute before checking the level.

The engine oil must be between marking **A** and marking **B** of the oil level viewer.

- » If the engine oil level is below the marking **B**:
 - Add engine oil. (📖 p. 156)
- » If the engine oil level is above the marking **A**:
 - Correct engine oil level.

19.2 Changing the engine oil and oil filter, cleaning the oil screens



Warning

Danger of scalding Engine and gear oil get hot when the motorcycle is operated.

- Wear suitable protective clothing and safety gloves.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Note

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

i Info


Drain the engine oil while the engine is at operating temperature.


Preparatory work

- Remove the engine guard. (📖 p. 116)


Main work

- Rest the motorcycle on its side stand on a horizontal surface.
- Position an appropriate container under the engine.
- Remove filler plug **1** with the O-ring.






- Remove oil drain plugs **2** along with the magnets, the O-rings, and the oil screens.



- Remove screws **3**. Take off oil filter cover **4** with the O-ring.
- Pull oil filter **5** out of the oil filter housing.

Lock ring plier (51012011000)

- Allow the engine oil to drain completely.
- Thoroughly clean the parts and the sealing surfaces.



- Insert new oil filter **5**.



Info



Only insert the oil filter by hand.

- Oil the new O-ring of the oil filter cover. Position oil filter cover **4**.
- Mount and tighten screws **3**.

Guideline

Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)
-------------------------	----	-------------------

- Thoroughly clean magnets **A** and oil screens **B** of the oil drain plugs.



- Mount the oil drain plugs **2** with magnets and new seal rings, and tighten.


Guideline

Plug, oil screen	M20x1.5	20 Nm (14.8 lbf ft)
------------------	---------	---------------------

- Fill up with engine oil at the clutch cover.

Engine oil	2.9 l (3.1 qt.)	Engine oil (SAE 10W/50) (p. 181)
------------	-----------------	-------------------------------------

19 SERVICE WORK ON THE ENGINE



- Mount and tighten filler plug **1** with the O-ring.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and check it for leaks.

Finishing work


- Check the engine oil level. (📖 p. 154)
- Install the engine guard. (📖 p. 118)

19.3 Adding engine oil



Info

Too little engine oil or poor-quality engine oil will result in premature wear of the engine.



Main work

- Remove filler plug **1** with the O-ring.
- Fill engine oil to the middle of the level viewer.

Engine oil (SAE 10W/50) (📖 p. 181)



Info

In order to achieve optimal engine oil performance, it is not advisable to mix different engine oils.

Husqvarna Motorcycles recommends changing the engine oil.

- Mount and tighten filler plug **1** with the O-ring.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and check it for leaks.

Finishing work

- Check the engine oil level. (📖 p. 154)


19.4

Checking the free travel of the clutch lever

Note

Clutch damage If there is no free travel by the clutch lever, the clutch will begin to slip.

- Check the free travel of the clutch lever each time before using the motorcycle.
- Adjust the free travel of the clutch lever when necessary in accordance with the specification.



- Check the clutch lever for smooth operation.
- Move the handlebar to the straight-ahead position.
- Pull the clutch lever until resistance is perceptible, and determine the free travel **A**.

Free travel A of clutch lever	5 mm (0.2 in)
--------------------------------------	---------------

- » If the free travel of the clutch lever does not meet specifications:
 - Set the free travel of the clutch lever. 🛠️ (p. 157)
- Move the handlebar to and fro over the entire steering range.


The free travel of the clutch lever must not change.
--

- » If the free travel of the clutch lever changes:
 - Check the routing of the clutch cable.



19.5


Setting the free travel of the clutch lever 🛠️



- Move the handlebar to the straight-ahead position.
- Loosen lock nut **1**.
- Adjust the free travel **A** by turning adjusting screw **2**.

Free travel A of clutch lever	5 mm (0.2 in)
--------------------------------------	---------------

- Tighten lock nut **1**.



20.1 Cleaning the motorcycle

Note

Material damage Components become damaged or destroyed if a pressure cleaner is used incorrectly.

The high pressure forces water into the electrical components, connectors, throttle cables, and bearings, etc. Pressure which is too high causes malfunctions and destroys components.

- Do not direct the water jet directly on to electrical components, connectors, throttle cables or bearings.
- Maintain a minimum distance between the nozzle of the pressure cleaner and the component.
Minimum clearance 60 cm (23.6 in)



Note


Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

To maintain the value and appearance of the motorcycle over a long period, clean it regularly. Avoid direct sunshine when cleaning the motorcycle.



- Close off exhaust system to keep water from entering.
- Remove loose dirt first with a soft jet of water.
- Spray the heavily soiled parts with a normal commercial motorcycle cleaner and clean using a brush.

Motorcycle cleaner (📖 p. 183)



Info

Use warm water containing normal motorcycle cleaner and a soft sponge.

Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

If the vehicle was operated in road salt, clean it with cold water. Warm water would enhance the corrosive effects of salt.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Remove the closure of the exhaust system.



Warning

Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.

- After cleaning, ride the vehicle a short distance until the engine warms up.



Info

The heat produced causes water at inaccessible locations in the engine and on the brake system to evaporate.

- After the motorcycle has cooled down, lubricate all moving parts and pivot points.
- Clean the chain. (📖 p. 96)
- Treat bare metal (except for brake discs and the exhaust system) with a corrosion inhibitor.

Preserving materials for paints, metal and rubber (📖 p. 183)

- Treat the painted parts with a mild paint polish.

Shine spray for paint, plastic and chromium (📖 p. 183)



Info

Do not polish parts that were matte when delivered as this would strongly impair the material quality.

- Treat the plastic parts and powder-coated parts with a mild cleaning and care product.

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces (📖 p. 183)

- Oil the ignition and steering lock, tank lock, and seat lock.

Universal oil spray (📖 p. 183)




20.2 Checks and maintenance steps for winter operation



Info

If you use the motorcycle in winter, salt can be expected on the roads. You should therefore take precautions against aggressive road salt.

After riding on salted roads, thoroughly clean the vehicle with cold water and dry it well. Warm water enhances the corrosive effects of salt.



- Clean the motorcycle. (📖 p. 158)
- Clean brake system.



Info

After **EVERY** trip on salted roads, thoroughly clean the brake calipers and brake linings, after they have cooled down and without removing them, with cold water and dry them carefully.

After riding on salted roads, thoroughly clean the motorcycle with cold water and dry it well.

- Treat engine, link fork, and all other bare or zinc-plated parts (except the brake discs) with a wax-based corrosion inhibitor.



Info

Corrosion inhibitor must not come in contact with the brake discs as this would greatly reduce the braking force.

- Clean the chain. ( p. 96)




21.1 Storage

**Info**

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed.

Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.

Fuel additive (📖 p. 183)

- Refuel. (📖 p. 82)

**Tip**

Fill the fuel tank completely as specified, using fuel with the lowest possible ethanol content.

- Clean the motorcycle. (📖 p. 158)
- Change the engine oil and the oil filter, clean the oil screens. 🛠️ (📖 p. 154)
- Check the coolant fill level and antifreeze. 🛠️
- Check tire pressure. (📖 p. 135)
- Remove the 12-V battery. 🛠️ (📖 p. 138)

Guideline

Storage temperature of the 12-V battery without direct sunlight	0 ... 35 °C (32 ... 95 °F)
---	----------------------------

- Charge the 12-V battery. 🛠️ (📖 p. 141)
- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.


(Expedition)

- Raise the vehicle with the center stand. (📖 p. 93)
- Cover the motorcycle with a tarp or cover that is permeable to air.

**Info**

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion. Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and the exhaust system to rust.

21.2 Preparing for use after storage



- Take the motorcycle off the front lifting gear. (📖 p. 93)
- Remove the rear of the motorcycle from the lifting gear. (📖 p. 92)
- Install the 12-V battery. 🔌 (📖 p. 139)
- Set the time and date.
- Perform checks and maintenance measures when preparing for use. (📖 p. 73)
- Take a test ride.

Faults	Possible cause	Action
The engine does not turn over when the start button is actuated	Operating error	– Carry out start procedure. (📖 p. 73)
	12-V battery discharged	– Charge the 12-V battery. 🛠️ (📖 p. 141) – Check the open-circuit current. 🛠️
	Fuse 1, 2 or 3 blown	– Change the fuses of individual electrical power consumers. (📖 p. 144)
	Main fuse burned out	– Change the main fuse. (📖 p. 142)
	Combination switch cable damaged	– Check the combination switch cable for damage.
	No ground connection present on the starter motor	– Check the ground connection.
The engine only turns if the clutch lever is drawn	The vehicle is in gear	– Shift the transmission into neutral N.
	The vehicle is in gear and the side stand is folded out	– Shift the transmission into neutral N.
The engine turns but does not start	Operating error	– Carry out start procedure. (📖 p. 73)
	Lack of fuel	– Refuel. (📖 p. 82)
	Fuse 3 blown	– Change the fuses of individual electrical power consumers. (📖 p. 144)
	Quick release coupling not joined	– Join quick release coupling.
	Fuel taps on the fuel tank cover closed	– Open the fuel taps on the fuel tank cover.
	Malfunction in the electronic fuel injection	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🛠️
	Throttle opened while starting	– When starting, DO NOT open the throttle. – Carry out start procedure. (📖 p. 73)
Engine has too little power	Air filter is very dirty	– Remove the air filter. 🛠️ – Install the air filter. 🛠️
	Fuel screen is very dirty	– Change the fuel screen.
	Fuel filter is very dirty	– Check the fuel pressure. 🛠️
	Malfunction in the electronic fuel injection	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🛠️
Engine overheats	Too little coolant in cooling system	– Check the cooling system for leaks. 🛠️ – Check the coolant level in the compensating tank. (📖 p. 150)
	Radiator fins very dirty	– Clean radiator fins.
	Foam formation in cooling system	– Drain the coolant. 🛠️ – Fill/bleed the cooling system. 🛠️
	Buckled or damaged radiator hose	– Change the radiator hose. 🛠️
	Thermostat defective	– Check the thermostat. 🛠️
	Fuse 4 is blown	– Change the fuses of individual electrical power consumers. (📖 p. 144)
	Defect in radiator fan system	– Check the radiator fan system. 🛠️
Malfunction indicator lamp lights up or flashes	Malfunction in the electronic fuel injection	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🛠️

Faults	Possible cause	Action
N The idling speed indicator lamp does not light up when the transmission is in neutral	Gear position sensor not programmed	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🛠️
The engine dies during the trip	Lack of fuel	– Refuel. (📖 p. 82)
	Fuse 1 , 2 or 3 blown	– Change the fuses of individual electrical power consumers. (📖 p. 144)
The ABS warning lamp lights up	ABS fuse blown	– Change the ABS fuses. (📖 p. 143)
	Wheel speeds of front and rear wheels differ greatly	– Stop, switch off the ignition, start again.
	Wheel speed sensor wheel bent or damaged	– Check the wheel speed sensor wheel for damage. 🛠️
	Wheel speed sensor damaged	– Check the wheel speed sensor for damage. 🛠️
	Malfunction in ABS	– Read out the ABS fault memory using the Husqvarna Motorcycles diagnostics tool. 🛠️
High oil consumption	Engine vent hose bent	– Route the vent hose without bends or change it if necessary.
	Engine oil level too high	– Check the engine oil level. (📖 p. 154)
	Engine oil too thin (low viscosity)	– Change the engine oil and the oil filter, clean the oil screens. 🛠️ (📖 p. 154)
The headlight, position light, tail light, and license plate lamp are not working	Fuse 6 is blown	– Change the fuses of individual electrical power consumers. (📖 p. 144)
Combination instrument, brake light, and horn are not functional	Fuse 5 is blown	– Change the fuses of individual electrical power consumers. (📖 p. 144)
Time is not displayed or not correctly displayed	Fuse 1 blown	– Change the fuses of individual electrical power consumers. (📖 p. 144)
12-V battery discharged	Ignition was not switched off when vehicle was parked	– Charge the 12-V battery. 🛠️ (📖 p. 141)
	The 12-V battery is not being charged by the alternator	– Check the charging voltage. 🛠️
The combination instrument shows nothing in the display	Fuse 1 , 2 or 5 blown	– Change the fuses of individual electrical power consumers. (📖 p. 144) – Set time and date.

23.1 Engine

Design	2-cylinder 4-stroke in-line engine, water-cooled
Displacement	889 cm³ (54.25 cu in)
Stroke	68.8 mm (2.709 in)
Bore	90.7 mm (3.571 in)
Compression ratio	13.5:1
Control	DOHC, 4 valves per cylinder controlled via cam lever, chain drive
Valve diameter, intake	37 mm (1.46 in)
Valve diameter, exhaust	30 mm (1.18 in)
Valve play, cold	
Intake at: 20 °C (68 °F)	0.10 ... 0.15 mm (0.0039 ... 0.0059 in)
Exhaust at: 20 °C (68 °F)	0.15 ... 0.20 mm (0.0059 ... 0.0079 in)
Crankshaft bearing	Slide bearing
Conrod bearing	Slide bearing
Pistons	Forged light alloy
Piston rings	1 compression ring, 1 lower compression ring, 1 oil ring with spring expander
Engine lubrication	Pressure circulation lubrication with 2 trochoidal pumps
Primary transmission	39:75
Clutch	Slipper clutch in oil bath/mechanically operated
Transmission	6-gear transmission, claw shifted
Transmission ratio	
First gear	13:37
Second gear	17:34
Third gear	20:31
Fourth gear	22:28
Fifth gear	24:26
Sixth gear	23:22
Mixture preparation	Electronic fuel injection
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment
Alternator	14 V, 406 W
Spark plug	NGK LMAR9AI-10
Spark plug electrode gap	1.0 mm (0.039 in)
Cooling	Water cooling, permanent circulation of coolant by water pump
Idle speed	1,600 ± 50 rpm
Starting aid	Starter motor

23.2 Engine tightening torques

Screw plug, water pump drain hole	EJOTALtracs® Plus 60x14	8 Nm (5.9 lbf ft) Loctite®243™
Screw, bleeder flange	EJOTALtracs® M6x12	8 Nm (5.9 lbf ft) Loctite®243™
Hose clamp, intake flange	M4	2.5 Nm (1.84 lbf ft)
Nozzle, engine vent	M5	2 Nm (1.5 lbf ft)
Oil nozzle for piston cooling	M5	2 Nm (1.5 lbf ft)
Oil nozzle in cylinder head	M5	2 Nm (1.5 lbf ft)
Remaining screws, engine	M5	6 Nm (4.4 lbf ft)
Screw, cam lever axial lock	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, crankshaft speed sensor	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, gear position sensor	M5	5 Nm (3.7 lbf ft) Loctite®243™
Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)
Screw, pressure plate	M5	3 Nm (2.2 lbf ft) Loctite®243™
Screw, shift drum retaining bracket	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, shift shaft sensor	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, thermostat case	M5	6 Nm (4.4 lbf ft) Loctite®243™
Securing screw, balancer shaft	M5	5 Nm (3.7 lbf ft) Loctite®243™
Swing angle sensor screw	M5	6 Nm (4.4 lbf ft) Loctite®243™
Nut, starter motor cable	M6	5 Nm (3.7 lbf ft)
Remaining screws, engine	M6	10 Nm (7.4 lbf ft)
Screw, alternator cover	M6x30	10 Nm (7.4 lbf ft)
Screw, alternator cover	M6x35	10 Nm (7.4 lbf ft)
Screw, camshaft bearing bridge	M6	10 Nm (7.4 lbf ft)
Screw, clutch cable retaining bracket	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)
Screw, clutch pressure plate	M6	8 Nm (5.9 lbf ft)
Screw, clutch release lever	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, cylinder head	M6	10 Nm (7.4 lbf ft)
Screw, engine case	M6x30	12 Nm (8.9 lbf ft)
Screw, engine case	M6x60	12 Nm (8.9 lbf ft)
Screw, freewheel ring	M6	14 Nm (10.3 lbf ft) Loctite®243™
Screw, ignition coil	M6	8 Nm (5.9 lbf ft)

Screw, locking lever	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, main shaft bearing support	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, oil pan	M6x30	10 Nm (7.4 lbf ft)
Screw, oil pan	M6x35	10 Nm (7.4 lbf ft)
Screw, oil pump cover	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, oil pump unit	M6	10 Nm (7.4 lbf ft)
Screw, oil/water heat exchanger	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift lever	M6	14 Nm (10.3 lbf ft) Loctite®243™
Screw, shift shaft retaining bracket	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, starter motor	M6	10 Nm (7.4 lbf ft)
Screw, stator	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, stator	M6	10 Nm (7.4 lbf ft)
Screw, timing chain shaft	M6	10 Nm (7.4 lbf ft)
Screw, upper guide rail	M6	8 Nm (5.9 lbf ft) Loctite®243™
Screw, valve cover	M6	10 Nm (7.4 lbf ft)
Screw, water pump cover	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, water pump wheel	M6	10 Nm (7.4 lbf ft) Loctite®243™
Nut, exhaust flange	M8	15 Nm (11.1 lbf ft) Copper paste
Oil nozzle for clutch lubrication	M8	5 Nm (3.7 lbf ft) Loctite®243™
Remaining screws for engine	M8	20 Nm (14.8 lbf ft)
Screw plug, locking screw	M8	15 Nm (11.1 lbf ft)
Screw with washer, engine case	M8x65	25 Nm (18.4 lbf ft)
Screw with washer, engine case	M8x90	25 Nm (18.4 lbf ft)
Screw, engine case	M8x45	25 Nm (18.4 lbf ft) Screw support greased
Screw, engine case	M8x55	25 Nm (18.4 lbf ft) Screw support greased
Screw, engine case	M8x65	25 Nm (18.4 lbf ft) Screw support greased
Screw, engine case	M8x90	25 Nm (18.4 lbf ft) Screw support greased
Screw, knock sensor	M8	20 Nm (14.8 lbf ft)
Screw, oil pump idler gear	M8	15 Nm (11.1 lbf ft) Loctite®243™

23 TECHNICAL SPECIFICATIONS

Screw, tensioning rail	M8	15 Nm (11.1 lbf ft) Loctite®243™
Stud, exhaust flange	M8	15 Nm (11.1 lbf ft) Loctite®243™
Screw, conrod bearing	M8x0.75	1st stage 5 Nm (3.7 lbf ft) 2nd stage 20 Nm (14.8 lbf ft) 3rd stage 90° Screw support and thread oiled
Spark plug	M10	11 Nm (8.1 lbf ft)
Oil pressure sensor	M10x1	10 Nm (7.4 lbf ft)
Screw plug, bearing support	M10x1	12 Nm (8.9 lbf ft) Loctite®243™
Screw plug, cam lever axis	M10x1	8 Nm (5.9 lbf ft)
Screw, unlocking of timing chain tensioner	M10x1	8 Nm (5.9 lbf ft)
Coolant temperature sensor	M10x1.25	10 Nm (7.4 lbf ft)
Screw, cylinder head	M10x1.25	Tightening sequence: Observe tightening sequence. 1st stage 5 Nm (3.7 lbf ft) 2nd stage 15 Nm (11.1 lbf ft) 3rd stage 90° 4th stage 90° Screw support greased/thread oiled
Screw plug, cylinder head oil drain	M12x1.5	15 Nm (11.1 lbf ft)
Screw, rotor	M12x1.5	90 Nm (66.4 lbf ft) Thread greased
Screw plug, water jacket	M16x1.5	20 Nm (14.8 lbf ft) Loctite®243™
Nut, inner clutch hub	M20x1.5	135 Nm (99.6 lbf ft)
Plug, oil screen	M20x1.5	20 Nm (14.8 lbf ft)
Screw plug, alternator cover	M24	8 Nm (5.9 lbf ft)
Plug, timing chain tensioner	M24x1.5	25 Nm (18.4 lbf ft)

23.3 Capacities


23.3.1 Engine oil

Engine oil	2.9 l (3.1 qt.)	Engine oil (SAE 10W/50) (p. 181)
------------	-----------------	----------------------------------

23.3.2 Coolant

Coolant	1.60 l (1.69 qt.)	Coolant (p. 181)
---------	-------------------	------------------

23.3.3 Fuel



Please observe the labels on EU fuel pumps.

Fuel reserve, approx.	3 l (3 qt.)	
Total fuel tank capacity, approx.	19 l (5 US gal)	Super unleaded (ROZ 95) (p. 182)

23.4 Chassis

Frame	Lattice frame made of chrome molybdenum steel tubing, powder-coated
Fork (Standard model)	WP APEX OC
Fork (Expedition)	WP XPLOR OC
Shock absorber (Standard model)	WPAPEX
Shock absorber (Expedition)	WP XPLOR PDS
Suspension travel (Standard model)	
front	220 mm (8.66 in)
rear	213.8 mm (8.417 in)
Suspension travel (Expedition)	
front	240 mm (9.45 in)
rear	240 mm (9.45 in)
Brake system	
front	Double disc brake with radially mounted four-piston brake calipers, floating brake discs
rear	Single disc brake with dual-piston brake caliper, floating brake disc
Brake discs - diameter	
front	320 mm (12.6 in)
rear	260 mm (10.24 in)
Brake discs - wear limit	
front	4.5 mm (0.177 in)
rear	4.5 mm (0.177 in)
Tire air pressure, solo	
front	2.4 bar (35 psi)
rear	2.4 bar (35 psi)
Tire air pressure with passenger / full payload	
front	2.6 bar (38 psi)
rear	2.6 bar (38 psi)

Secondary drive ratio	16:45
 Info Modifications to the transmission ratio are not permitted and can lead to malfunctions.	
Chain	5/8 x 1/4" (520) X-ring
Steering head angle	64.2°
Wheelbase (Standard model)	1,512.9 mm (59.563 in)
Wheelbase (Expedition)	1,529 mm (60.2 in)
Seat height, unloaded (Standard model)	
Upper position	879 mm (34.61 in)
Lower position	859 mm (33.82 in)
Seat height, unloaded (Expedition)	
Upper position	895 mm (35.24 in)
Lower position	875 mm (34.45 in)
Ground clearance, unloaded (Standard model)	252.4 mm (9.937 in)
Ground clearance, unloaded (Expedition)	270 mm (10.63 in)
Weight without fuel, approx. (Standard model)	204 kg (450 lb.)
Weight without fuel, approx. (Expedition)	214.5 kg (472.9 lb.)
Maximum permissible front axle load	175 kg (386 lb.)
Maximum permissible rear axle load	275 kg (606 lb.)
Maximum permissible total weight	450 kg (992 lb.)

23.5 Electrical system

12-V battery	HTZ12A-BS	Battery voltage: 12 V Nominal capacity: 10 Ah Maintenance-free
Fuse	75011088010	10 A
Fuse	75011088015	15 A
Fuse	75011088025	25 A
Fuse	58011109130	30 A
Low beam/high beam		LED
Daytime running light/position light		LED
Combination instrument lighting and indicator lamps		LED
Turn signal		LED
Brake/tail light		LED
License plate lamp		LED

23.6 Tires

Front tire	Rear tire
90/90 - 21 M/C 54V M+S TL Pirelli SCORPION RALLY STR	150/70 R 18 M/C 70V M+S TL Pirelli SCORPION RALLY STR
The tires specified represent one of the possible series production tires. For alternative manufacturers, if any, contact an authorized dealer or qualified tire dealership. If local road approval regulations apply, these and the respective technical specifications must be observed. Additional information is available in the Service section under: www.husqvarna-motorcycles.com	

23.7 Fork

23.7.1 Standard model

Fork article number	0221C141V201102
Fork	WP APEX OC
Compression damping	
Comfort	21 clicks
Standard	15 clicks
Sport	9 clicks
Full payload	9 clicks
Rebound damping	
Comfort	21 clicks
Standard	15 clicks
Sport	9 clicks
Full payload	9 clicks
Spring length with preload spacer(s)	486 mm (19.13 in)
Spring rate	
Medium (standard)	6.5 N/mm (37.1 lb/in)
Fork length	878.5 mm (34.587 in)
Fork oil per fork leg	475 ± 5 ml (16.06 ± 0.17 fl. oz.)
Fork oil (SAE 5) (📖 p. 182)	

23.7.2 Expedition

Fork article number	A678C141W401000
Fork	WP XPLOR OC
Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	15 clicks
Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	15 clicks
Spring length with preload spacer(s)	464 mm (18.27 in)

Spring rate		
Weight of rider: 65 ... 75 kg (143 ... 165 lb.)		6.2 N/mm (35.4 lb/in)
Weight of rider: 75 ... 85 kg (165 ... 187 lb.)		6.7 N/mm (38.3 lb/in)
Weight of rider: 85 ... 95 kg (187 ... 209 lb.)		7.2 N/mm (41.1 lb/in)
Spring preload – preload adjuster		
Comfort		+0
Standard		+0
Sport		+0
Full payload		+3
Fork length		912 mm (35.91 in)
Fork oil per fork leg	630 ± 5 ml (21.3 ± 0.17 fl. oz.)	Fork oil (SAE 4) (48601166S1) (📖 p. 182)

23.8 Shock absorber

23.8.1 Standard model

Shock absorber article number	15.15.7U.30
Shock absorber	WPAPEX
Rebound damping	
Comfort	18 clicks
Standard	12 clicks
Sport	7 clicks
Full payload	5 clicks
Spring preload	
Comfort	10 mm (0.39 in)
Standard	10 mm (0.39 in)
Sport	12 mm (0.47 in)
Full payload	17 mm (0.67 in)
Spring preload – preload adjuster	
Comfort	3 turns
Standard	3 turns
Sport	5 turns
Full payload	10 turns
Inbuilt length	371 mm (14.61 in)
Spring length	195 mm (7.68 in)
Static sag	22 mm (0.87 in)
Riding sag	52 mm (2.05 in)
Spring rate	
Medium (standard)	115 N/mm (657 lb/in)
Gas pressure	20 bar (290 psi)
Shock absorber oil	Shock absorber fluid (SAE 2.5) (50180751S1) (📖 p. 182)

23.8.2 Expedition

Shock absorber article number	A678C441W305000
-------------------------------	-----------------

Shock absorber	WP XPLOR PDS
Low-speed compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	7 clicks
High-speed compression damping	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	0.5 turns
Rebound damping	
Comfort	20 clicks
Standard	12 clicks
Sport	5 clicks
Full payload	5 clicks
Spring preload – preload adjuster	
Comfort	4 turns
Standard	4 turns
Sport	4 turns
Full payload	10 turns
Fitted length	380 mm (14.96 in)
Spring length	204.3 mm (8.043 in)
Static sag	25 mm (0.98 in)
Rider sag	80 mm (3.15 in)
Spring rate	
Weight of rider: 75 ... 85 kg (165 ... 187 lb.)	95 N/mm (542 lb/in)
Gas pressure	16 bar (232 psi)
Damper oil	Shock absorber fluid (SAE 2.5) (50180751S1) (📖 p. 182)

23.9 Chassis tightening torques

Brake fluid reservoir cover, front	-	2 Nm (1.5 lbf ft)
Brake fluid reservoir cover, rear	-	1.5 Nm (1.11 lbf ft)
Compensating tank cover	-	1.1 Nm (0.81 lbf ft)
Nut, socket		4 Nm (3 lbf ft)
Nut, valve	ISO 10V2	12 Nm (8.9 lbf ft)
		Loctite® 2701™
Remaining screws, chassis	EJOTPT® K45x12	1 Nm (0.7 lbf ft)
Remaining screws, chassis	EJOTPT® K50x12	1 Nm (0.7 lbf ft)
Remaining screws, chassis	EJOTPT® K50x14	1 Nm (0.7 lbf ft)
Remaining screws, chassis	EJOTPT® K50x16	2 Nm (1.5 lbf ft)
Remaining screws, chassis	EJOTPT® K50x18	2 Nm (1.5 lbf ft)
Throttle valve body hose clamp	-	2.8 Nm (2.07 lbf ft)
Remaining nuts, chassis	M4	3 Nm (2.2 lbf ft)

23 TECHNICAL SPECIFICATIONS

Remaining screws, chassis	M4	3 Nm (2.2 lbf ft)	
Screw, fixed grip, left	M4	3 Nm (2.2 lbf ft)	
Collar screw, bottom instrument support	M5x20	5 Nm (3.7 lbf ft)	
Mask support special screw	M5x12	5 Nm (3.7 lbf ft)	
Remaining nuts, chassis	M5	5 Nm (3.7 lbf ft)	
Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)	
Screw for throttle grip	M5	3.5 Nm (2.58 lbf ft)	
Screw, air filter box	M5	3 Nm (2.2 lbf ft)	
Screw, air filter box, downwards through subframe	M5x20	5 Nm (3.7 lbf ft)	Loctite®243™
Screw, brace for mask support on fuel tank spoiler, inside	M5x12	3 Nm (2.2 lbf ft)	Loctite®243™
Screw, brake fluid reservoir for rear brake	M5	5 Nm (3.7 lbf ft)	Loctite®243™
Screw, brake line holder on link fork	M5	1 Nm (0.7 lbf ft)	
Screw, combination instrument	M5x20	4 Nm (3 lbf ft)	Loctite®243™
Screw, combination switch, left	M5	1.5 Nm (1.11 lbf ft)	
Screw, combination switch, right	M5	5 Nm (3.7 lbf ft)	
Screw, engine sprocket cover	M5x17	5 Nm (3.7 lbf ft)	
Screw, fender on fork protector	M5x12	3 Nm (2.2 lbf ft)	
Screw, foot brake lever stub	M5	10 Nm (7.4 lbf ft)	Loctite®243™
Screw, fuel level sensor	M5	3 Nm (2.2 lbf ft)	
Screw, fuel tank filler cap	M5	3 Nm (2.2 lbf ft)	
Screw, fuel tank insert	M5	3 Nm (2.2 lbf ft)	
Screw, heat guard	M5	5 Nm (3.7 lbf ft)	Loctite®243™
Screw, license plate holder	M5	5 Nm (3.7 lbf ft)	Loctite®243™
Screw, lower rear panel	M5x10	3 Nm (2.2 lbf ft)	Loctite®243™
Screw, mask support cover	M5x17	3.5 Nm (2.58 lbf ft)	
Screw, side stand sensor	M5	2 Nm (1.5 lbf ft)	
Screw, splash protector, link fork	M5x20	10 Nm (7.4 lbf ft)	Loctite®243™
Screw, splash protector, shock absorber	M5x17	2.8 Nm (2.07 lbf ft)	
Screw, tank guard on tank guard rack	M5x12	3 Nm (2.2 lbf ft)	
Screw, trim	M5	3 Nm (2.2 lbf ft)	
Screw, windshield	M5x14	5 Nm (3.7 lbf ft)	
Special screw, headlight adjustment on mask support	M5x14	5 Nm (3.7 lbf ft)	
Special screw, top instrument support	M5x12	5 Nm (3.7 lbf ft)	

Special screw, trim	M5	3 Nm (2.2 lbf ft)
Spoke nipple	M5	6 Nm (4.4 lbf ft)
Adapter piece frame screws for mask support pipe	M6x16	10 Nm (7.4 lbf ft)
Brake cylinder screw on the rear brake system	M6	10 Nm (7.4 lbf ft) Loctite®243™
Nut, hand brake lever	M6	Attach torque to nut. 10 Nm (7.4 lbf ft)
Nut, push rod, foot brake lever	M6	6 Nm (4.4 lbf ft)
Nut, shift rod	M6LH	6 Nm (4.4 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
Screw, 6-D sensor	M6	5 Nm (3.7 lbf ft)
Screw, ABS module on holder	M6	8 Nm (5.9 lbf ft)
Screw, ABS module retaining bracket on frame	M6x18	10 Nm (7.4 lbf ft) Loctite®243™
Screw, activated carbon filter on retaining bracket	M6	8 Nm (5.9 lbf ft) Loctite®243™
Screw, ball joint of push rod on foot brake cylinder	M6	6 Nm (4.4 lbf ft) Loctite®243™
Screw, battery holding bracket	M6	4.5 Nm (3.32 lbf ft)
Screw, battery terminal	M6	4.5 Nm (3.32 lbf ft)
Screw, brace for mask support	M6x16	10 Nm (7.4 lbf ft) Loctite®243™
Screw, brake assembly	M6	5 Nm (3.7 lbf ft)
Screw, cable on starter motor	M6	5 Nm (3.7 lbf ft)
Screw, cable on starter relay	M6	4.5 Nm (3.32 lbf ft)
Screw, chain guide	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, clutch assembly	M6	5 Nm (3.7 lbf ft)
Screw, cross brace in rear	M6x12	6 Nm (4.4 lbf ft) Loctite®243™
Screw, cross member on lower rear panel	M6x12	6 Nm (4.4 lbf ft) Loctite®243™
Screw, engine guard	M6x8	8 Nm (5.9 lbf ft)
Screw, engine guard	M6x10	10 Nm (7.4 lbf ft) Loctite®243™
Screw, footrest bracket, rear	M6	9 Nm (6.6 lbf ft) Loctite®243™
Screw, front brake disc	M6	14 Nm (10.3 lbf ft) Loctite®243™
Screw, front wheel speed sensor	M6	6 Nm (4.4 lbf ft)
Screw, fuel pump	M6	6 Nm (4.4 lbf ft)
Screw, fuel tank clamp	M6	3 Nm (2.2 lbf ft)
Screw, ground wire on frame	M6	6 Nm (4.4 lbf ft)
Screw, ground wire on starter motor	M6	10 Nm (7.4 lbf ft)
Screw, headlight	M6x18	10 Nm (7.4 lbf ft)

23 TECHNICAL SPECIFICATIONS

Screw, headlight adapter on headlight	M6x16	5 Nm (3.7 lbf ft) Loctite®243™
Screw, ignition lock (tamper-proof screw)	M6	Tighten until the screw cap tears off. Loctite®243™
Screw, license plate holder on lower rear panel	M6x18	10 Nm (7.4 lbf ft) Loctite®243™
Screw, license plate holder on subframe	M6x16	10 Nm (7.4 lbf ft) Loctite®243™
Screw, magnetic holder on side stand	M6	2 Nm (1.5 lbf ft) Loctite®243™
Screw, mask support on steering head	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, plate adapter, chain guide	M6x12	10 Nm (7.4 lbf ft) Loctite®243™
Screw, radiator bracket, bottom	M6	5 Nm (3.7 lbf ft)
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft) Loctite®243™
Screw, rear wheel speed sensor	M6	6 Nm (4.4 lbf ft)
Screw, seat lock	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift rod	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift shaft deflector on shift shaft	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, side bag rack	M6	10 Nm (7.4 lbf ft)
Screw, sliding seat for side cover	M6x20	10 Nm (7.4 lbf ft) Loctite®243™
Screw, subframe on air filter box	M6x12	10 Nm (7.4 lbf ft) Loctite®243™
Screw, tail light	M6x16	5 Nm (3.7 lbf ft) Loctite®243™
Screw, tank guard on engine guard, bottom	M6x18	10 Nm (7.4 lbf ft)
Screw, tank guard on engine guard, front	M6x25	10 Nm (7.4 lbf ft)
Screw, tank guard rack on tank holding rubber	M6x15	10 Nm (7.4 lbf ft) Loctite®243™
Screw, voltage regulator	M6	6 Nm (4.4 lbf ft) Loctite®243™
Screw, fuel cock	M6x12	6 Nm (4.4 lbf ft)
Foot brake lever, fitting	M8	25 Nm (18.4 lbf ft) Loctite®243™
Front brake caliper clamp screw	M8x35	25 Nm (18.4 lbf ft)
Nut, manifold on cylinder head	M8	Tighten the nuts evenly. Do not bend the metal. 20 Nm (14.8 lbf ft)

Nut, rear sprocket screw	M8	Attach torque to nut. 35 Nm (25.8 lbf ft) Loctite®2701™
Pin, rear brake caliper	M8	22 Nm (16.2 lbf ft) Loctite®243™
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)
Screw, activated carbon filter holder fastening	M8x16	25 Nm (18.4 lbf ft) Loctite®243™
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
Screw, case holder	M8x20	25 Nm (18.4 lbf ft) Loctite®243™
Screw, cross member in rear	M8x35	25 Nm (18.4 lbf ft) Loctite®243™
Screw, engine fixing arm linkage bracket	M8	25 Nm (18.4 lbf ft) Loctite®243™
Screw, engine guard frame	M8	25 Nm (18.4 lbf ft) Loctite®243™
Screw, exhaust system clamp	M8	12 Nm (8.9 lbf ft) Copper paste
Screw, foot brake lever spring	M8	12 Nm (8.9 lbf ft) Loctite®2701™
Screw, fork stub	M8	15 Nm (11.1 lbf ft)
Screw, grab handle	M8	25 Nm (18.4 lbf ft) Loctite®243™
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
Screw, main silencer fastening	M8	15 Nm (11.1 lbf ft)
Screw, presilencer on frame	M8	15 Nm (11.1 lbf ft) Loctite®243™
Screw, rear footrest bracket	M8	25 Nm (18.4 lbf ft) Loctite®243™
Screw, seat bracket	M8	25 Nm (18.4 lbf ft) Loctite®243™
Screw, shift lever	M8	25 Nm (18.4 lbf ft) Loctite®243™
Screw, side bag rack	M8x20	25 Nm (18.4 lbf ft)
Screw, spring holder plate on side stand bracket	M8	15 Nm (11.1 lbf ft) Loctite®2701™
Screw, steering damper on holder	M8	8 Nm (5.9 lbf ft) Loctite®243™
Screw, steering damper on triple clamp	M8	8 Nm (5.9 lbf ft) Loctite®243™
Screw, steering stem	M8	20 Nm (14.8 lbf ft) Loctite®243™
Screw, top triple clamp	M8	15 Nm (11.1 lbf ft)
Securing bolt for brake linings	M8	10 Nm (7.4 lbf ft)
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)

23 TECHNICAL SPECIFICATIONS

Screw, engine bracket	M10	45 Nm (33.2 lbf ft) Loctite®243™
Screw, front footrest bracket	M10x30	45 Nm (33.2 lbf ft) Loctite®243™
Screw, front footrest bracket	M10x40	45 Nm (33.2 lbf ft) Loctite®243™
Screw, front footrest bracket	M10x65	45 Nm (33.2 lbf ft) Loctite®243™
Screw, handlebar support	M10	45 Nm (33.2 lbf ft) Loctite®243™
Screw, side stand	M10	40 Nm (29.5 lbf ft) Loctite®243™
Screw, subframe	M10	50 Nm (36.9 lbf ft) Loctite®243™
Banjo bolt, brake line	M10x1	25 Nm (18.4 lbf ft)
Nut, turn signal	M10x1.25	4 Nm (3 lbf ft)
Screw, front brake caliper	M10x1.25	45 Nm (33.2 lbf ft) Loctite®243™
Screw, bottom shock absorber	M12	80 Nm (59 lbf ft) Loctite®2701™
Screw, swingarm pivot	M12	100 Nm (73.8 lbf ft)
Screw, top shock absorber	M12	80 Nm (59 lbf ft) Loctite®2701™
Lambda sensor	M18x1.5	50 Nm (36.9 lbf ft)
Bushing, shock absorber support	M20LHx1.5	10 Nm (7.4 lbf ft) Thread and fitting greased
Screw, steering head	M20x1.5	18 Nm (13.3 lbf ft)
Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft) Thread and contact area of wheel spindle greased
Screw, front wheel spindle	M25x1.5	45 Nm (33.2 lbf ft) Thread greased

24.1 Declarations of conformity

**Info**

The functional and equipment scope is model-dependent and may not include all wireless systems and application areas referred to.

KTM AG hereby declares that the **Immo641** wireless system conforms with the relevant guidelines. The full text of the Declaration of Conformity is available at the following Internet address.

Certification website: <http://www.husqvarna-motorcycles.com/immo641>

Polaris hereby declares that the **Connectivity Control Unit "CCU-2"** wireless system conforms with the relevant guidelines. The full text of the Declaration of Conformity is available at the following Internet address.

Certification website: <http://www.husqvarna-motorcycles.com/ccu-2>

LDL Technology hereby declares that the **Tyre Pressure Monitoring System** wireless system conforms with the relevant guidelines. The full text of the Declaration of Conformity is available at the following Internet address.

Certification website: <http://www.husqvarna-motorcycles.com/tpms>

Schrader Electronics Ltd hereby declares that the **Tyre Pressure Monitoring System** wireless system conforms with the relevant guidelines. The full text of the Declaration of Conformity is available at the following Internet address.

Certification website: <http://www.husqvarna-motorcycles.com/tpms>

24.2 Country-specific declarations of conformity

Immo641		 MCMC CIDF18000141		 EUTRAC		 CNC COMISIÓN NACIONAL DE COMUNICACIONES H-21170	
Complies with IMDA Standards N2035-18		ictQATAR Type Approval reg. No.: CRA/SA/2018/R-7050		RTIKTM18-0315, KTM, Minda Immo641 La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.			
 R-R-KTM-MindaImmo641		Company Name: KTM AG Equipment Name: Immobilizer System Model Name: Minda Immo641 Manufactured Date: Manufacturer / Country: Minda Corporation Limited / India		 UA.TR.109			
Israel 51-65016 מוצר זה פטור מרישיון הפעלה אלקטרוני. המוצר אסור לשימוש למתן שירות לצד ג'. אסור להתחילף אנטנת המכשיר המקוריית. אסור לעשות במכשיר כל שינוי טכני.		This product contains radio equipment (125 kHz transmitter) which is conform with the regulations for communications equipment (extremely low-power radio station) specified in article 6, paragraph 1 of the Radio Law Enforcement Regulations.		 ANATEL Agência Nacional de Telecomunicações 03469-18-11400			
This product does not need an Israeli wireless operation license. It is forbidden to use this product for service to third party. It is forbidden to replace the original antenna It is forbidden to make any technical change in this product.		AGREE PAR L'ANRT MAROC Numéro d'agrément: MR 16565 ANRT 2018 Date d'agrément: 15/05/2018		"Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário."			

F03629-01

Brake fluid DOT 4 / DOT 5.1**Standard/classification**

- DOT

Guideline

- Use only brake fluid that complies with the specified standard (see specifications on the container) and that exhibits the corresponding properties.

Recommended supplier**Castrol**

- REACT PERFORMANCE DOT 4

MOTOREX®

- Brake Fluid DOT 5.1

Coolant**Guideline**

- Only use high-grade, silicate-free coolant with corrosion inhibitor additive for aluminum motors. Low grade and unsuitable antifreeze causes corrosion, deposits and frothing.
- Do not use pure water as only coolant is able to meet the requirements needed in terms of corrosion protection and lubrication properties.
- Only use coolant that complies with the requirements stated (see specifications on the container) and that has the relevant properties.

Antifreeze protection to at least	-25 °C (-13 °F)
-----------------------------------	-----------------

The mixture ratio must be adjusted to the necessary antifreeze protection. Use distilled water if the coolant needs to be diluted.

The use of premixed coolant is recommended.

Observe the coolant manufacturer specifications for antifreeze protection, dilution and miscibility (compatibility) with other coolants.

Recommended supplier**MOTOREX®**

- COOLANT M3.0

Engine oil (SAE 10W/50)**Standard/classification**

- JASO T903 MA2 (📖 p. 184)
- SAE (📖 p. 184) (SAE 10W/50)

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Fully synthetic engine oil

Recommended supplier**MOTOREX®**

- Power Synt 4T

Fork oil (SAE 5)

Standard/classification

- SAE (📖 p. 184) (SAE 5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Recommended supplier

MOTOREX®

- Racing Fork Oil

Fork oil (SAE 4) (48601166S1)

Standard/classification

- SAE (📖 p. 184) (SAE 4)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Shock absorber fluid (SAE 2.5) (50180751S1)

Standard/classification

- SAE (📖 p. 184) (SAE 2.5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Super unleaded (ROZ 95)

Standard/classification

- DIN EN 228 (ROZ 95)

Guideline

- Only use super unleaded fuel that matches or is equivalent to the specified standard.
- Fuel with an ethanol content of up to 10% (E10 fuel) is safe to use.

**Info**

Do **not** use fuel containing methanol (e.g., M15, M85, M100) or more than 10% ethanol (e.g., E15, E25, E85, E100).

Chain cleaner

Recommended supplier

MOTOREX®

- Chain Clean

Fuel additive

Recommended supplier

MOTOREX®

- Fuel Stabilizer

Long-life grease

Recommended supplier

MOTOREX®

- Bike Grease 2000

Motorcycle cleaner

Recommended supplier

MOTOREX®

- Moto Clean

Preserving materials for paints, metal and rubber

Recommended supplier

MOTOREX®

- Moto Protect

Shine spray for paint, plastic and chromium

Recommended supplier

MOTOREX®

- Moto Shine

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces

Recommended supplier

MOTOREX®

- Quick Cleaner

Street chain spray

Guideline

Recommended supplier

MOTOREX®

- Chainlube Road Strong

Universal oil spray

Recommended supplier

MOTOREX®

- Joker 440 Synthetic

JASO T903 MA2

Different technical development directions required a separate specification for motorcycles – the **JASO T903 MA2** standard.

Earlier, engine oils from the automobile industry were used for motorcycles because there was no separate motorcycle specification.

Whereas long service intervals are demanded for automobile engines, the focus for motorcycle engines is on high performance at high engine speeds.

In most motorcycle engines, the transmission and clutch are lubricated with the same oil.

The **JASO T903 MA2** standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

ABS	Anti-lock braking system	Safety system that prevents locking of the wheels when driving straight ahead without the influence of lateral forces
-	Easy Shift	Engine electronics function for shifting up and down without clutch actuation
ETTC	Engine traction torque control	Auxiliary function of the engine control, which prevents rear wheel locking with excessive engine braking effect, by lightly opening the throttle valve
MTC	Motorcycle Traction Control	Auxiliary function of the motor control that reduces engine torque with spinning rear wheel
OBD	On-board diagnosis	Vehicle system, which monitors the specified parameters of the vehicle electronics
-	Ride Husqvarna	System for wireless communication with appropriate cellphones and headsets for telephony and audio

29 LIST OF ABBREVIATIONS

Art. no.	Article number
ca.	circa
cf.	compare
e.g.	for example
etc.	et cetera
i.a.	inter alia
no.	number
poss.	possibly

30.1 Red symbols

Red symbols indicate an error condition that requires immediate intervention.

	The oil pressure warning lamp lights up red – The oil pressure is too low. Stop immediately, taking care not to endanger yourself or other road users in the process, and switch off the engine.
---	--

30.2 Yellow and orange symbols

Yellow and orange symbols indicate an error condition that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	The general warning lamp lights up yellow – A note/warning note on operating safety has been detected. This is also shown in the display.
	The malfunction indicator lamp lights up yellow – The OBD has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized Husqvarna Motorcycles workshop.
	The cruise control system indicator lamp lights up yellow – The cruise control system function is switched on, but cruise control is not activated.
	Ice warning is active in the display – The warning lamp lights up when there is increased risk of icy roads.
	TC indicator lamp lights up/flashs yellow – MTC (p. 153) is not enabled or is currently intervening. The TC indicator lamp also lights up if a malfunction is detected. Contact an authorized Husqvarna Motorcycles workshop. The TC indicator lamp flashes if MTC or MSR actively engage.
	ABS warning lamp lights up yellow – Status or error messages relating to ABS.

30.3 Green and blue symbols

Green and blue symbols reflect information.

	The idle indicator lamp lights up green – The transmission is in neutral.
	The high beam indicator lamp lights up blue – The high beam is switched on.
	The cruise control system indicator lamp lights up green – The cruise control system function is switched on and cruise control is activated.
	The turn signal indicator lamp flashes green simultaneously with the turn signal – The turn signal is switched on.

1		
12-V battery		
charging	141	
installing	139	
removing	138	
A		
ABS	120	
ABS fuses		
changing	143	
ACC1		
front	148	
rear	148	
ACC2		
front	148	
rear	148	
Anti-lock braking system	120	
Auxiliary substances	15	
B		
Battery cover		
installing	108	
removing	107	
Brake discs		
checking	121	
Brake fluid		
adding front brake	122	
rear brake, adding	125	
Brake fluid level		
of front brake, checking	122	
of rear brake, checking	125	
Brake lining retainers		
of front brake, checking	123	
of rear brake, checking	126	
Brake linings		
of front brake, checking	123	
of rear brake, checking	126	
Brake system	120-127	
Brakes	78	
Braking	78	
Breakdown		
towing	81	
C		
Capacity		
coolant	168	
engine oil	155, 168	
fuel	82, 169	
Center stand	32	
Chain		
checking	98	
checking for dirt	95	
cleaning	96	
Chain tension		
adjusting	97	
checking	96	
Clutch lever	20	
basic position, adjusting	66	
Combination instrument	33-64	
ABS display	40	
ABS Mode	44	
activation and test	33	
ambient air temperature indicator	39	
Audio (optional)	54	
Bike Info	48	
Bluetooth (optional)	56	
Call display	42	
Clock & Date	60	
Clock Format	60	
Consumption	62	
coolant temperature indicator	40	
cruise control indicator	39	
Date Format	61	
display	36	
Distance	61	
Easy Shift	45	
explorer display (optional)	37	
Extra Functions	63	
Favorites	51, 55	
Favorites display	42	
Favorites-Anzeige 1-4	55	
fuel level display	41	
Headset Type (optional)	58	
heated grip (optional)	41	
Heating (optional)	46	
Heating Grips (optional)	46	
Heating Rider Seat (optional)	46	
ice warning	34	
indicator lamps	35	
Interface	47	
Language	62	
Last search	50	
menu	43	
Motorcycle	43	
MTC + MSR	45	
MTC display	40	
navigation	50	
Navigation display	42	
overview	33	
Phone Pairing (optional)	57	

Pressure	62	Engine guard	
Quick Selector Down	56	installation	118
Quick Selector Up	55	removing	116
Ride Husqvarna (optional)	56	Engine number	19
Ride Mode	43	Engine oil	
Ride-Mode display	40	adding	156
Riders Headset (optional)	58	changing	154
seat heating (optional)	42	Engine oil level	
Settings	55	checking	154
shift warning light	38	Engine sprocket	
Shift Light RPM1	59	checking	98
Shift Light RPM2	60	Engine traction torque control	78
Shift Light State	59	Environment	13
Skip Waypoint	52	F	
slip adjustment (optional)	153	Figures	15
Slip Adjuster (optional)	47	Foot brake lever	31
Speed	38	basic position, adjusting	67
speedometer	39	free travel, checking	124
Stop Navigation	53	Foot brake lever stub	
Temperature	61	adjusting	67
Throttle (optional)	47, 153	Fork	85
time	39	compression damping, adjusting	85
Trip 1	49	rebound, adjusting	86
Trip 2	49	spring preload, adjusting	87
Trip Info	48	Fork legs	
Units	61	dust boots, cleaning	113
Volume	52	Fork part number	19
warnings	34	Free travel of clutch lever	
Combination switch	20	adjusting	157
overview	20	checking	157
Coolant level		Front fender	
checking in the compensating tank	150	installing	112
correcting in the compensating tank	151	removing	112
Cooling system	150	Front rider's seat	
Cornering MTC	153	adjusting	65
Cruise control system		Front rider's seat	
operation	21	mounting	95
Customer service	15	removing	95
D		Front wheel	
Declarations of conformity	179-180	installing	129
country-specific	179	removing	128
country-specific (CCU-2)	180	Fuel cocks	27
Diagnostics connector	148	Fuel tank cover, left	
E		installing	115
Easy Shift	75	removing	114
Emergency OFF switch	23	Fuel tank filler cap	
Engine		closing	26
running in	71		

opening	26	rear from the lifting gear, removing	92
Fuel tank spoiler, center		taking off front lifting gear	93
installing	109	Motorcycle traction control	153
removing	108	MSR	78
Fuel tank spoiler, left		O	
installing	110	Oil filter	
removing	109	changing	154
Fuel, oils, etc.	15	Oil screens	
Fuse		cleaning	154
of the individual electrical power consumers, changing	144	Owner's Manual	14
G		P	
Grab handles	30	Parking	80
H		Passenger foot pegs	31
Hand brake lever	20	Passenger seat	
basic position, adjusting	67	mounting	94
Handlebar position	65	removing	94
adjusting	65	Preparing for use	
Hazard warning flasher	24	advice on preparing for first use	70
Hazard warning flasher switch	24	after storage	162
Headlight		checks and maintenance measures when preparing for use	73
headlight range, adjusting	146	Protective clothing	13
setting, checking	146	R	
Horn button	23	Rear hub damping rubber pieces	
I		checking	133
Ice warning	34	Rear sprocket	
Ignition lock	24	checking	98
Implied warranty	15	Rear wheel	
Indicator lamps	35	installing	132
Intended use	7	removing	131
K		Refueling	
Key number	18	fuel	82
L		Riding	75
Light switch	21	starting off	74
Loading the vehicle	71	Right fuel tank cover	
Luggage	71	installing	116
Luggage rack	30	removing	115
M		Right fuel tank spoiler	
Main fuse		installing	111
changing	142	removing	111
Manufacturer warranty	15	Right side cover	
Misuse	7	installing	107
Motorcycle		removing	106
cleaning	158	S	
lifting gear at rear, raising with	92	Safe operation	12
lifting with front lifting gear	92	Seat lock	30
		Service	15

Service schedule	83-84
Shift lever	31
basic position, adjusting	69
basic position, checking	68
Shifting	75
Shock absorber	85
compression damping	88
high-speed compression damping, adjusting	89
low-speed compression damping, adjusting	88
rebound damping, adjusting	89
spring preload, adjusting	90
Shock absorber article number	19
Side bag rack	
installing	101
removing	100
Side bags	
installing	104
removal	103
Side cover, left	
installing	106
removing	105
Side stand	32
Socket for electrical accessories	25
Spare parts	15
Spoke tension	
checking	136
Start button	23
Starting	73
Steering	
locking	24
unlocking	25
Steering damper article number	19
Steering lock	24
Stopping	80
Storage	161
Storage compartment on the left	
closing	28
opening	27
Storage compartment on the right	
closing	29
opening	28
Supplementary headlight	
headlight range, adjusting	147
setting, checking	147
Supplementary headlight switch	25
Switch	
on the left side of the handlebar	20
on the right side of the handlebar	23

T	
Technical accessories	15
Technical specifications	
capacities	168
chassis	169
chassis tightening torques	173
electrical system	170
engine	165-178
engine tightening torques	166
fork	171
shock absorber	172
tires	171
Throttle grip	20
Time	
adjusting	63
Tire condition	
checking	134
Tire pressure	
checking	135
Tire repair spray	
using	137
Tool set	30
Towing	81
Transporting	81
Troubleshooting	163-164
Tubeless tire system	137
Turn signal switch	23
Type label	18
U	
USB socket	25
Use definition	7
V	
Vehicle	
raising with the center stand	93
removing from the center stand	94
Vehicle identification number	18
View of vehicle	
front left	16
rear right	17
W	
Windshield	
installing	114
removing	113
Winter operation	
checks and maintenance steps	159
Work rules	13



3402762en

26.04.2024



Husqvarna Motorcycles GmbH
Stallhofnerstraße 3 | 5230 Mattighofen | Austria
www.husqvarna-motorcycles.com



Photo: Mitterbauer/KISKA,
Husqvarna Motorcycles GmbH