

990 DUKE R

ITEM NO.: 3240301EN



KTM

Congratulations on your decision to purchase a KTM motorcycle. You are now the owner of a state-of-the-art sports vehicle which, with proper care, will bring you pleasure for a long time to come.

We hope you enjoy your bike and have a safe journey at all times!

You can enter the serial numbers of your vehicle below to find the serial numbers more quickly if required:

Vehicle identification number  (p. 17)	Stamp of the contractual partner
Engine number  (p. 17)	

The owner's manual contained the latest information for this model series at the time of publication. However, minor differences due to further developments in design cannot be ruled out completely.

All specifications are non-binding. KTM Sportmotorcycle GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, differences from illustrations and descriptions, misprints, and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

© 2026 KTM Sportmotorcycle GmbH, Mattighofen Austria

All rights reserved. Figures: Mitterbauer / Visus Studios / KISKA / KTM

Written permission from the copyright owner is required before any duplication or reproduction.

ISO 9001

KTM applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.



12 100 6061

Issuing institution:

TÜV SÜD Management Service GmbH

KTM Sportmotorcycle GmbH
Stallhofnerstraße 3
5230 Mattighofen, Austria

This document is valid for:
990 DUKE R EU (F9803ZE)
990 DUKE R JP (F9886ZE)



3240301en

24/02/2026

Table of contents

1	Means of representation	9	6.10	Turn signal switch	23
1.1	Conventions.....	9	6.11	Horn button	23
1.1.1	Icons	9	6.12	Hazard warning flasher switch	24
1.1.2	Formatting	9	6.13	Mode switch	24
1.1.3	Abbreviations	9	6.14	Start button/kill switch	24
2	Safety	10	6.15	Ignition and steering lock	25
2.1	Safety instructions	10	6.16	Opening the fuel tank cap	25
2.2	Ban on tampering	10	6.17	Closing the fuel tank cap	26
2.3	Safe use	11	6.18	USB socket	26
2.4	Protective clothing	11	6.19	Seat lock	26
2.5	Work rules	11	6.20	Passenger strap (optional)	27
2.6	Environment	12	6.21	Passenger footpegs (optional)	27
2.7	Owner's manual	12	6.22	Gear shift lever	27
2.8	Roadside Assistance	12	6.23	Brake pedal	28
2.9	Use definition – intended use	12	6.24	Side stand	28
2.10	Improper use	13	7	Dashboard	29
3	Important notes	14	7.1	dashboard	29
3.1	Manufacturer's warranty, implied warranty	14	7.2	Touchscreen	29
3.2	Auxiliary material, operating material	14	7.3	demo mode	30
3.3	Spare parts, accessories	14	7.4	activation and testing	31
3.4	Service	14	7.4.1	Activation	31
3.5	Figures	14	7.4.2	Test.....	31
3.6	Customer service	14	7.5	warnings	31
4	View of the vehicle	15	7.6	ice warning	32
4.1	View of vehicle, front left (example)	15	7.7	indicator lamps	33
4.2	View of vehicle, rear right (example)	16	7.8	Display	34
5	Serial number	17	7.9	Reduced display	35
5.1	Vehicle identification number	17	7.10	Ride mode Track (optional)	36
5.2	Type approval label	17	7.11	Display ride mode Track reduced (optional)	37
5.3	Key number	17	7.12	Gear display	38
5.4	Engine number	17	7.13	speed	39
5.5	Fork part number	18	7.14	shift light	39
5.6	Shock absorber part number	18	7.15	Speed	40
5.7	Steering damper article number	18	7.16	cruise control indicator (optional)	40
6	Controls	19	7.17	Ride mode display	40
6.1	Clutch lever	19	7.18	fuel level display	41
6.2	Handbrake lever	19	7.19	time	41
6.3	Throttle grip	19	7.20	ambient air temperature indicator	42
6.4	Combination switch	19	7.21	heated grip (optional)	42
6.5	Light switch	20	7.22	coolant temperature indicator	42
6.6	Cruise control switches (optional)	20	7.23	Splitscreen display	43
6.7	+RES/-SET button	22	7.24	display Favourites	44
6.8	UP/DOWN button	22	7.25	Navigation display (optional)	45
6.9	Menu buttons	22	7.26	Audio display (optional)	45
			7.27	display Telemetry (optional)	45
			7.28	display Lap Timer (optional)	46
			7.29	Call display	46
			8	Menu	47
			8.1	Menu	47
			8.2	Open menu	47

8.3	Ride	47	9.6	Adjusting the basic position of the brake pedal 	99
8.3.1	Ride mode	48	9.7	Checking the basic position of the gear shift lever	100
8.3.2	Configure ride mode	49	9.8	Adjusting the basic position of the gear shift lever 	100
8.4	info	57	10	Preparing for use	101
8.4.1	Trip info	58	10.1	Notes on preparing for first use	101
8.4.2	info	60	10.2	Running in the engine	102
8.4.3	Lap timer	61	10.3	Loading the vehicle	102
8.4.4	E-SIM	63	11	Riding instructions	104
8.4.5	Mobile	64	11.1	Checks and maintenance measures when preparing for use	104
8.4.6	Communication system	64	11.2	Starting the vehicle	104
8.4.7	warnings	65	11.3	Starting off	105
8.4.8	Extra functions	65	11.4	Launch-Control (optional)	105
8.4.9	Demo mode	66	11.5	Starting off with launch control (optional)	106
8.5	Heating	66	11.6	Quickshifter+ (optional)	106
8.5.1	heated grip (optional)	67	11.7	Shifting, riding	107
8.6	navigation	67	11.8	Engine traction torque control	109
8.6.1	Search	68	11.9	Braking	110
8.6.2	Choose on Map	68	11.10	Stop, park	111
8.6.3	Stop navigation	69	11.11	Transportation	112
8.6.4	Overview of routes	69	11.12	Towing in the event of a breakdown	112
8.6.5	Settings	70	11.13	Refueling	113
8.7	Apps	73	12	Service schedule	114
8.7.1	Calls	73	12.1	Service schedule	114
8.7.2	Music	74	13	Tuning the chassis	116
8.8	Settings	74	13.1	Fork/shock absorber	116
8.8.1	favorites	75	13.2	Adjusting the compression damping of the fork	116
8.8.2	Paddle buttons	76	13.3	Adjusting the rebound damping of the fork	116
8.8.3	Connectivity	76	13.4	Adjusting the low-speed compression damping of the shock absorber	117
8.8.4	Tire pressure monitoring system warnings (optional)	84	13.5	Adjusting the high-speed compression damping of the shock absorber	118
8.8.5	Shift Light	85	13.6	Adjusting the rebound damping of the shock absorber	118
8.8.6	Coming Home light	87	13.7	Adjusting the spring preload of the shock absorber 	119
8.8.7	Light system warnings	87			
8.8.8	Daytime Running Light	88			
8.8.9	Button Illumination	88			
8.8.10	Setting the time and date	89			
8.8.11	Units	91			
8.8.12	Language	94			
8.8.13	Heating setup	95			
8.8.14	Touchscreen	96			
8.8.15	Factory setting	96			
9	Ergonomics	97			
9.1	Handlebar position	97			
9.2	Adjusting the handlebar position 	97			
9.3	Adjusting the basic position of the clutch lever	98			
9.4	Adjusting the response of the hand brake lever	98			
9.5	Adjusting the basic position of the hand brake lever	98			

14	Service work on the chassis	120	16	Wheels, tires	143
14.1	Raising the motorcycle with rear lifting gear	120	16.1	Removing the front wheel 	143
14.2	Removing the rear of the motorcycle from the lifting gear	120	16.2	Installing the front wheel 	144
14.3	Lifting the motorcycle with the front lifting gear	120	16.3	Removing the rear wheel 	146
14.4	Taking the motorcycle off the front lifting gear	121	16.4	Installing the rear wheel 	147
14.5	Cleaning the dust boots of the fork legs 	121	16.5	Checking the rear hub damping rubber pieces 	149
14.6	Removing the passenger seat (optional)	122	16.6	Checking the tire condition	150
14.7	Mounting the passenger seat (optional)	123	16.7	Checking the tire pressure	151
14.8	Removing passenger seat cover	123	16.8	Using tire repair spray	151
14.9	Mounting the passenger seat cover	124	17	Electrics	153
14.10	Remove the front rider's seat	124	17.1	daytime running light	153
14.11	Mounting the front rider's seat	125	17.2	Low beam	153
14.12	Checking the chain for dirt	125	17.3	high beam	153
14.13	Cleaning the chain	126	17.4	Removing the 12 V battery 	154
14.14	Checking the chain tension	126	17.5	Installing the 12 V battery 	155
14.15	Adjusting the chain tension	127	17.6	Charging the 12 V battery 	156
14.16	Checking the chain, rear sprocket, front sprocket, and chain guide	128	17.7	Changing the main fuse	158
14.17	Removing the right tank spoiler	130	17.8	Changing the ABS fuses	160
14.18	Installing the right tank spoiler	131	17.9	Changing the fuses of individual electrical power consumers	161
14.19	Removing the left tank spoiler	132	17.10	Remove the mask support cover with headlight.	162
14.20	Installing the left tank spoiler	133	17.11	Mounting the mask support cover with headlight	162
15	Brake system	135	17.12	Checking the headlight setting	163
15.1	Anti-lock braking system	135	17.13	Adjusting the headlight range	164
15.2	Checking the brake discs	136	17.14	Diagnostic connector	164
15.3	Checking the brake fluid level for the front brake	137	17.15	Front ACC1 and ACC2	165
15.4	Adding brake fluid for the front brake 	137	17.16	Rear ACC1 and ACC2	165
15.5	Checking that the brake pads of the front brake are secured	139	17.17	Setting the time and date	165
15.6	Checking the free travel of the brake pedal	139	18	Cooling system	167
15.7	Checking the brake fluid level for the rear brake	140	18.1	Cooling system	167
15.8	Adding brake fluid for the rear brake 	140	18.2	Checking the frost protection and coolant level	167
15.9	Checking that the brake pads of the rear brake are secured	141	18.3	Checking the coolant level in the compensating tank	169
15.10	Removing the brake manifold of the front brake	142	18.4	Draining the coolant 	170
15.11	Mounting the brake manifold of the front brake	142	18.5	Filling/bleeding the cooling system 	171
			18.6	Changing the coolant	172
			19	Tuning the engine	175
			19.1	Ride Mode	175
			19.2	Motorcycle traction control	176
			19.3	slip adjustment (optional)	176
			19.4	Throttle Response (optional)	177

20	Service work on the engine	178	25	Declarations of conformity	206
20.1	Checking the engine oil level	178	25.1	Declarations of conformity	206
20.2	Changing the engine oil and oil filter, cleaning the oil screens 	178	25.2	Country-specific declarations of conformity (CCU 3)	206
20.3	Adding engine oil	180	25.3	Country-specific declarations of conformity (Tire Pressure Monitoring System)	206
20.4	Checking the free travel of the clutch lever	181	26	Recycling	207
20.5	Adjusting the free travel of the clutch lever 	181	26.1	Recycling	207
21	Cleaning, care	182	Notes	209	
21.1	Cleaning the motorcycle	182	A	Technical terms	209
21.2	Checks and maintenance steps for winter operation	183	B	Fuels.....	210
22	Storage	185	C	Operating supplies.....	211
22.1	Storage	185	D	Electrics.....	213
22.2	Preparing for use after storage	186	E	Cleaning agents.....	216
23	Troubleshooting	187	F	Icons.....	217
23.1	troubleshooting	187	F.1	Symbol colors	217
24	Technical specifications	189	F.1.1	Red symbols.....	217
24.1	Engine	189	F.1.2	Yellow and orange symbols	217
24.1.1	Technical data - engine	189	F.1.3	Green and blue symbols	217
24.1.2	Capacities - engine	190	Index	218	
24.2	Chassis	190			
24.2.1	Technical data - chassis	190			
24.2.2	Technical data - tires	191			
24.2.3	Fuel	192			
24.2.4	Vehicle capacity	192			
24.3	Electrics	192			
24.3.1	Battery	192			
24.3.2	Fuses	192			
24.3.3	Lamps	192			
24.4	Fork	193			
24.4.1	Technical data - fork	193			
24.4.2	Fork oil capacity	193			
24.5	Shock absorber	193			
24.5.1	Technical data - shock absorber	193			
24.5.2	Shock absorber capacity	194			
24.6	Tightening torque	194			
24.6.1	engine tightening torques	194			
24.6.2	Chassis tightening torques	198			

1.1 Conventions

1.1.1 Icons



Indicates a desired result (e.g. of a work step or a function).



Indicates an undesired result (e.g. of a work step or a function).



All work marked with this symbol requires specialist knowledge and technical understanding. Ensure that this work is carried out or supervised by trained personnel from an authorized contractual partner, and that any special tools required are used.



Indicates a page reference.



Indicates information with more details.



Indicates a tip, e.g. to simplify work.



Indicates the result from a test step.



Indicates the end of an activity, including any rework.

1.1.2 Formatting

Proprietary name	Indicates a proprietary name.
Name[®]	Indicates a protected name.
Brand[™]	Indicates a brand available on the open market.
<u>Underlined terms</u>	Refer to technical details of the vehicle or indicate technical terms that are explained in the glossary.

1.1.3 Abbreviations

2–pc.	two-part
Part no.	Part number
or	respectively
approx.	circa
etc.	et cetera
poss.	possibly/possible
if necessary	if necessary
cmpl.	complete
min.	at least
no.	number
no fig.	no figure
s.	see
among others	among others/not limited to
and the like	and the like
etc.	et cetera
cf.	compare
e.g.	for example

2.1 Safety instructions

Function of the safety instruction

Safety instruction brings attention to dangers when handling the product. Hazards are classified, named, described, and supplemented with information on how to avoid them.

- If there is a safety instruction before a list of instructions, the danger exists throughout the entire activity.
- If there is a safety instruction immediately before an instruction, the next step presents a danger.

Safety instruction layout

All safety instructions are identified by a signal word and a warning symbol. The combination of signal word and warning symbol determines the degree of danger.



DANGER

Indicates an imminent danger that leads to serious injury or death.



WARNING

Indicates a potentially imminent danger that could lead to serious injury or death.



CAUTION

Indicates a potentially imminent danger that can lead to minor or slight injuries.



NOTE

Indicates a situation that can lead to damage to the product or the product environment.



NOTE

Indicates a situation that can lead to environmental damage.

2.2 Ban on tampering

No changes may be made to the noise control equipment and components.

Tampering that is prohibited

- Removing or disabling any devices or components used for noise control before the new vehicle is sold or delivered to the end customer.
- Removing or disabling any device or component used for noise control for purposes other than service, repair, or replacement during the service life of the vehicle.
- Use of the vehicle after a device or component used for noise control has been removed, disabled, or inadequately maintained.

Examples of prohibited tampering

- Removing or drilling through rear mufflers, baffle plates, manifolds, or other components that conduct exhaust gases.
- Removing or puncturing parts of the intake system.
- Replacing moving parts of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

2.3 Safe use



DANGER

Danger of accidents A rider who is not fit to ride poses a danger to themselves and to others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs, or medication.
- Do not operate the vehicle if you are physically or mentally incapable of doing so.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.



WARNING

Danger of burns Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Allow the vehicle parts to cool down before performing any work on the vehicle.

The vehicle should only be used when it is in perfect technical condition, for its intended purpose, and in a safe and environmentally-friendly manner.

An appropriate driver's license is needed to drive the vehicle on public roads.

Have any faults that impair safety immediately remedied by an authorized contractual partner.

Adhere to the information and warning labels on the vehicle.

2.4 Protective clothing



WARNING

Risk of injury Missing or inadequate protective clothing increases the risk of injury.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as pants and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.

2.5 Work rules

Unless specified otherwise, the ignition must be switched off during all work (models with ignition lock, models with transponder key) or the engine must be at a standstill (models without ignition lock or transponder key).

Special tools are required for some work. The tools are not part of the vehicle, but can be ordered using the number in parentheses. Example: bearing puller (15112017000)

Unless otherwise noted, normal conditions apply to all tasks and descriptions.

Ambient temperature	20 °C (68.0 °F)
Ambient air pressure	1,013 mbar (14.69 psi)
Relative air humidity	60 ±5 %

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, expansion screws, seals, sealing rings, O-rings, pins, and lock washers).

A thread lock (e.g. **Loctite**®) is required for some screw connections. Observe the manufacturer's specific instructions for use.

If thread lock (e.g. **Precote**®) has already been applied to a new part, do not apply any additional thread lock.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Replace damaged or worn parts.

After completing a repair or service, check the operating safety of the vehicle.

2.6 Environment

Handling the vehicle responsibly reduces the risk of conflict with other road users and the surrounding area. The future of motorcycling also depends on using motorcycles legally, being environmentally conscious and respecting the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, the laws and regulations of the respective country must be observed.

As motorcycles are not subject to the EU regulations governing the disposal of end-of-life vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. More information is available from the authorized contractual partner.

2.7 Owner's manual

Read this owner's manual carefully and in full before riding off for the first time. The owner's manual contains information and tips on how to operate, handle, and service your vehicle, as well as advice on optimum tuning and how to avoid injuries.



Tip

Save this owner's manual on your smartphone, for example, so that you can access it at any time.

An authorized contractual partner will be happy to assist you if you are unsure.

The owner's manual is an important component of the vehicle. If the vehicle is sold, the owner's manual must be downloaded again by the new owner.

The owner's manual can be downloaded multiple times using the QR code or the link on the delivery certificate.

The owner's manual is also available for download from your authorized contractual partner and on the KTM website.

International KTM Website: <https://www.ktm.com>

A printed copy can be ordered from the following address.

Website for printed copy: <https://print.ktm.com>

2.8 Roadside Assistance

For peace of mind when traveling with your vehicle in Europe, we offer Roadside Assistance free of charge in selected countries (handled in cooperation with a contracting partner).

Each service at your authorized contractual partner extends your free Roadside Assistance until the next service or for a maximum of 12 months.

In the event of a breakdown, call the KTM Assistance Center hotline or contact them directly via the KTMconnect app.

The applicable conditions and benefits can be found on the KTM website:

International KTM Website: <https://www.ktm.com>

2.9 Use definition – intended use

The vehicle is designed and constructed to withstand the usual demands of regular traffic and use on race courses.

This vehicle is not suitable for offroad use.



Note

This vehicle is only authorized for operation on public roads in its homologated version.

2.10 Improper use

The vehicle may only be used as intended.

Improper use can result in danger to people, property and the environment.

Any use of the vehicle beyond the intended and defined use constitutes misuse.

Improper use includes the use of operating and auxiliary materials that do not meet the required specifications for the respective use.

3 Important notes

3.1 Manufacturer's warranty, implied warranty

The work prescribed in the service schedule must only be carried out by an authorized contractual partner and then confirmed in the electronic proof of service, as otherwise all warranty claims will be void. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the manufacturer's warranty.

3.2 Auxiliary material, operating material

Use operating materials and auxiliary materials in accordance with the operating instructions and specifications.

3.3 Spare parts, accessories

For safety reasons, only spare parts and accessories approved by KTM may be used. They may only be installed by an authorized contractual partner. KTM accepts no liability for other products and any resulting damage or loss. Certain spare parts and accessory products are specified in parentheses in the descriptions. Authorized contractual partners will be happy to help.

The current **KTM PowerParts** are listed for each vehicle on the KTM website.

International KTM Website: <https://www.ktm.com>

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work is properly carried out as described in the owner's manual. An incorrect suspension setting can lead to damage and breakage of chassis components.

Use of the vehicle under difficult conditions, such as dusty environments, heavy rain, high heat or with a heavy load, can lead to increased wear of components such as the air filter, powertrain, brake systems, or suspension components. For this reason, it may be necessary to inspect or replace components before the next scheduled service interval.

The prescribed running-in times and service intervals must be observed, otherwise the long-term durability of the vehicle will be severely impaired.

The relevant mileage or time interval is whichever occurs first.

3.5 Figures

Some of the figures in this document contain optional extras.

For clarity, some components may be shown disassembled or may not be shown at all. Disassembly is not always absolutely necessary in order to carry out the activities described. The textual information takes precedence.


3.6 Customer service

Authorized contractual partners will be happy to answer questions about the vehicle and KTM.

A list of authorized contractual partners can be found on the KTM website.

International KTM Website: <https://www.ktm.com>

4.1 View of vehicle, front left (example)




A02686-10

- | | |
|--|------------------------------|
| ❶ dashboard 📖 (p. 29) | ❺ Side stand 📖 (p. 28) |
| ❷ Ignition and steering lock 📖 (p. 25) | ❻ Gear shift lever 📖 (p. 27) |
| ❸ Clutch lever 📖 (p. 19) | ❼ Engine number 📖 (p. 17) |
| ❹ Seat lock 📖 (p. 26) | |

4 View of the vehicle


4.2 View of vehicle, rear right (example)



A02687-10


- | | |
|--|--|
| ① Fuel tank cap | ④ Handbrake lever  (p. 19) |
| ② Combination switch  (p. 19) | ⑤ Level viewer, engine oil |
| ③ Start button/kill switch  (p. 24) | ⑥ Brake pedal  (p. 28) |

5.1 Vehicle identification number




The vehicle identification number ❶ is stamped on the right-hand side of the steering head.
The vehicle identification number is also shown on the type label.

5.2 Type approval label



The type approval label ❶ is located on the steering head on the left.

5.3 Key number




The key number ❶ for the lock system can be found on the key card.



Note


The key number is required to order a spare key and should therefore be kept in a safe place.

5.4 Engine number




The engine number ❶ is stamped on the right side of the engine.

5.5 Fork part number




Fork part number ❶ is stamped on the inside of the fork shoe.

5.6 Shock absorber part number




The shock absorber part number ❶ is stamped on the top of the shock absorber.

5.7 Steering damper article number




Steering damper article number ❶ is embossed on the underside of the steering damper.

6.1 Clutch lever




Clutch lever **1** is fitted on the left side of the handlebar.

6.2 Handbrake lever



Hand brake lever **1** is fitted on the right side of the handlebar. The front brake is engaged using the hand brake lever.

6.3 Throttle grip




The throttle twist grip **1** is fitted on the right side of the handlebar.

6.4 Combination switch


The combination switch is fitted on the left side of the handlebar.

Overview of the left combination switch



- 1** Light switch (p. 20)
- 2** Cruise control switches (optional) (p. 20)
- 3** Menu buttons (p. 22)
- 4** Turn signal switch (p. 23)
- 5** Horn button (p. 23)
- 6** UP/DOWN button (p. 22)


6.5 Light switch



The light switch 1 is fitted on the combination switch on the left.

Condition		Meaning
	Light switch in position A.	In this position, the low beam and the tail light are switched on.
	Light switch in position B.	In this position, the high beam and the tail light are switched on.
	Light switch in position C.	The headlight flasher is operated in this position.

6.6 Cruise control switches (optional)



Cruise control buttons 1, 2 and 3 are located on the left side of the combination switch.

Condition	Meaning
Cruise control tip switch 1 pressed briefly.	Cruise control function is switched on or off. The operating mode is displayed on the combination instrument.
Button +RES 2 pressed briefly.	The cruise control function is activated and the current speed is maintained. The last saved speed is reapplied. Every subsequent brief pressing increases the target speed by 1 km/h or 1 mph.
Button +RES 2 pressed and held.	The target speed is rounded to the next 5 km/h or 5 mph increment. The target speed then increases in increments of 5 km/h or 5 mph.

Condition	Meaning
Button –SET  pressed briefly.	The cruise control function is activated and the current speed is maintained. The last saved speed is reapplied. Every subsequent brief press reduces the target speed by 1 km/h or 1 mph.
Button –SET  pressed and held.	The target speed is rounded to the previous 5 km/h or 5 mph increment. The target speed then decreases in increments of 5 km/h or 5 mph.

**WARNING**

Danger of accidents The cruise control system function is not suitable for all riding situations. The selected cruise speed will not be reached if the engine power is not sufficient for a gradient. The selected cruise speed will be exceeded if the engine braking effect and the brake power are not sufficient on an incline.

- Do not use the cruise control systems function on winding roads.
- Do not use the cruise control systems on slippery road surfaces (e.g. rain, ice or snow), where there is poor visibility or on unpaved surfaces (e.g. sand, stones or gravel).
- Do not use the cruise control systems function if the traffic does not permit a constant speed.

Functions of cruise control:

- After activating the cruise control function, the throttle grip can be turned back to the basic position. The selected speed will be maintained.
- If no cruise speed has been saved yet, this can be saved using the **–SET** or **+RES** button.
- If the cruise speed is exceeded for less than 30 seconds by turning the throttle grip, the cruise control remains activated.
- If the cruise speed differs from the current speed by more than 10 km/h or 10 mph, e.g. when overtaking, the current speed is stored as the cruise speed by pressing the **–SET** button briefly.
- If there is a sharp incline and the engine braking effect is not sufficient to maintain the set cruise speed, the system brakes actively.
- If the set target speed is significantly below the current speed, the system brakes actively in order to reach the target speed.
- The speed is reduced as the lean angle increases.

The cruise control function is deactivated when one of the following events occurs (switch-off conditions):


- Operating the handbrake lever.
- Operating the rear brake lever.
- Operating the clutch lever for more than 2.5 seconds.
- Closing the throttle beyond the basic position.
- Slip at the rear wheel or the front wheel lifting and thus associated regulation of the motorcycle traction control (**MTC**) for longer than 1 second.
- Control of ABS for more than 1 second.
- A malfunction occurring, which impairs the cruise control system function.
- Exceeding the target speed for more than 30 seconds when overtaking.
- Steep lean angles above 41°.
- Engine speed below 1,500 rpm.
- First gear engaged or transmission in neutral position.
- Motorcycle traction control (**MTC**) is switched off.
- **ABS** mode **Supermoto** is activated.

The cruise control can only be activated if the following conditions are met (switching conditions):

- Motorcycle traction control (**MTC**) is activated.
- No strong acceleration.
- No lean angles above 41°.
- 2nd, 3rd, 4th, 5th or 6th gear is engaged.

- Vehicle speed between 30 and 200 km/h or between 20 and 125 mph.
- **ABS** mode **Road** is active.

6.7 +RES/-SET button




The **+RES** button ① is fitted on the top left of the handlebar.
The **-SET** button ② is located on the rear of the **+RES** button ①.

i Note

The **+RES** and **-SET** buttons are used to control the cruise control when the cruise control function is activated.

6.8 UP/DOWN button



The **UP** button ① is fitted on the front left of the handlebar.
The **DOWN** button ② is fitted on the rear left of the handlebar.


i Note

Buttons **UP** and **DOWN** can be used to set **Slip Adjuster** and **Engine Brake**.

6.9 Menu buttons


The menu buttons are fitted in the middle of the left combination switch.

Overview of menu buttons



- ① **UP** button
- ② **RIGHT** button
- ③ **DOWN** button
- ④ **LEFT** button
- ⑤ **SET** button
- ⑥ **BACK** button

6.10Turn signal switch



Turn signal switch 1 is fitted on the left side of the handlebar.

Condition		Meaning
	Turn signal switch pressed to the left.	Left turn signal on.
	Turn signal switch pressed to the right.	Right turn signal on.

To switch off the turn signal, press turn signal switch 1 towards the switch case.



Note

An automatic turn signal switch-off function (**ATIR**) is available as a software feature.


The **ATIR** function uses a time and distance counter.

If the turn signal has been on for at least 10 seconds and 150 meters of riding distance, the turn signal is switched off.

If the vehicle is stationary, both counters are stopped.

If the turn signal switch is reactivated, both counters are reset.


6.11Horn button



Horn button 1 is fitted on the left side of the handlebar.

Condition		Meaning
Horn buttons  in the basic position		No function
Horn buttons  pressed		The horn is operated in this position.

6.12 Hazard warning flasher switch



The hazard warning flasher switch ❶ is fitted on the right side of the combination switch.

The hazard warning flasher is used to indicate emergency situations.


Condition	Meaning
Hazard warning flasher switch  not activated.	The hazard blinker is off.
Hazard warning flasher switch  pressed	All four turn signals and the green turn signal indicator lights in the combination instrument flash.

i Note

The hazard warning flasher can be activated or deactivated while the ignition is switched on or up to 60 seconds after the ignition is switched off.

Only keep the hazard warning flasher activated as long as necessary as it depletes the 12-V battery.

6.13 Mode switch



Mode switch ❶ is fitted on the right side of the combination switch.

i Note

The mode switch enables quick access to various ride modes.

The individual ride modes are configured in menu **RIDE**.

6.14 Start button/kill switch



The start button/emergency OFF switch ❶ is fitted on the right side of the combination switch.

Condition		Meaning
	Start button/kill switch off (upper position)	In this position, the ignition circuit is interrupted, a running engine stops, and cannot be started. A message appears on the display.
	Start button/kill switch on (middle position)	This position is required for operation; the ignition circuit is closed.
	Starter motor on (lower position)	In this position, the starter motor is actuated.

6.15 Ignition and steering lock



The ignition and steering lock is located in front of the upper triple clamp.

Condition		Meaning
	Ignition off	In this position, the ignition circuit is interrupted, a running engine stops, and an engine at a standstill will not start. The ignition key can be removed.
	Ignition on	In this position, the ignition circuit is closed, and the engine can be started.
	Steering locked	In this position, the ignition circuit is interrupted and the steering locked. The ignition key can be removed.

6.16 Opening the fuel tank cap



DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.



WARNING

Danger of poisoning Fuel is harmful to health.


- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.



NOTE

Environmental hazard Improper handling of fuel is dangerous to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Lift cover **1** of the fuel tank filler cap and insert the ignition key into the lock.




NOTE

Danger of damage The ignition key may break if overloaded.

- Push down on the fuel tank filler cap to take pressure off the ignition key.
-
- Turn the ignition key 90° clockwise.
 - Lift the fuel tank filler cap.

6.17 Closing the fuel tank cap



- Fold down the fuel tank filler cap.
- Turn the ignition key 90° clockwise.
- Push down the fuel tank filler cap and turn the ignition key counterclockwise until the lock closes.




WARNING

Fire hazard Fuel is highly flammable and a health hazard.

- Check that the fuel tank filler cap is locked correctly after closing.
- If fuel spills on to your clothing, change the clothing.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.

- Remove the ignition key and close the cover.


6.18 USB socket



The USB-C socket **1** for the power supply to external devices is fitted on the left-hand side of the mask support.
The USB-C socket is switched on with the ignition.

USB-C socket	
Voltage	5 V
Maximum current consumption	2.1 A


6.19 Seat lock



Seat lock **1** is located on the left side of the vehicle.
The seat lock can be locked with the ignition key.

6.20

Passenger strap (optional)



 **Note**

Observe the fitting instructions for **KTM PowerParts**.

The passenger strap **1** is located under the passenger seat and is used for maneuvering the motorcycle.


If you carry a passenger, the passenger can hold onto the grab handles during the trip.

If the passenger strap is not needed, it can be stowed underneath the passenger seat.

- Passenger strap kit (00010000463)

6.21

Passenger footpegs (optional)



 **Note**

Observe the fitting instructions for **KTM PowerParts**.


The passenger foot pegs can be folded up and down.

Condition	Meaning
Passenger foot pegs folded up	For operation without a passenger (solo).
Passenger foot pegs folded down	For operation with a passenger.


- Passenger footpeg bracket left (00010000461)
- Passenger footpeg bracket kit right (00010000462)

6.22

Gear shift lever




Gear shift lever **1** is mounted on the left of the engine.



The gear positions can be seen in the figure.


The neutral or idle position is between the first and second gears.

6.23 Brake pedal



Brake pedal ❶ is located in front of the right footpeg.
The rear brake is operated with the brake pedal.

6.24 Side stand




The side stand ❶ is located on the left of the vehicle.
The side stand is used for parking the motorcycle.

Condition	Meaning
Side stand folded out	The vehicle can be supported on the side stand. The safety starting system is active.
Side stand folded in	This position is mandatory when riding the motorcycle. The safety starting system is inactive.

i Note
The side stand must be folded up during motorcycle use.
The side stand is coupled with the safety starting system.
See the instructions in the section on “Stopping, parking”.

7.1 dashboard



I01850-01

The combination instrument is attached in front of the handlebar.

The combination instrument is divided into two function areas.

① indicator lamps  (p. 33)

Display ②

**CAUTION**

Danger of burns Parts of the combination instrument become hot in certain situations.

The display in particular can heat up considerably at ambient temperatures above 55 °C (131 °F) during long periods of inactivity, e.g. at traffic lights, or in direct sunlight.

- Do not touch the combination instrument with bare hands in the situations referred to.
- Where appropriate protective clothing.
- In the event of burns, rinse the area affected immediately with lukewarm water.

7.2 Touchscreen



I01851-01


The dashboard can be navigated using the controls or the **Touchscreen**.

Note
Operating the **Touchscreen** can lead to distraction and accidents.

The thicker the glove, the worse the **Touchscreen** works.
The **Touchscreen** works in the rain.
The focus of the **Touchscreen** is on active functions.

Note
To avoid scratches, remove dust from the **Touchscreen** and clean it with a microfiber cloth.

7.3 demo mode



Demo mode is activated in the factory and allows you to test optional software functions.
Once a distance has been covered, demo mode is automatically deactivated as soon as the ignition is turned off.

Distance until demo mode is deactivated	1,500 km (932.1 mi)
---	------------------------

Note
Notifications about the remaining distance until the demo mode is deactivated are displayed at regular intervals.
All optional software functions will be deactivated and no longer displayed when demo mode ends. The optional software features are available from authorized dealers.

- Functions included in demo mode**
- Riding mode **Track**
 - **QUICKSHIFTER+**
 - **ETTC**
 - Engine Brake Control
 - Additional ride modes **Custom**

7.4 activation and testing

7.4.1 Activation



I01852-01

The dashboard is switched on with the ignition.

Note

The brightness of the displays is controlled by an ambient light sensor in the combination instrument.

7.4.2 Test

The welcome text appears on the display and the indicator lights are briefly activated for a function check.

Note

The failure indicator light  will always light up as long as the engine is not running. If the engine is running and the failure indicator light  lights up, stop (taking care not to endanger yourself or other road users in the process) and contact an authorized dealer.

The oil pressure warning light  will always light up as long as the engine is not running. If the engine is running and the oil pressure warning light  lights up, stop immediately (taking care not to endanger yourself or other road users in the process) and switch off the engine.

The ABS warning light  and the TC indicator light  light up until a speed of approx. 6 km/h (approx. 4 mph) or faster has been reached.


7.5 warnings



I01853-01

Warnings appear in the left-hand part of the display; these are shown in yellow or red depending on their relevance.


Yellow warnings indicate malfunctions or information which require prompt intervention or an adjustment to the riding style.



Red warnings indicate malfunctions or information which require immediate intervention.

Note
Warnings can be hidden by pressing any button.
All the existing warnings are displayed in the **Warnings** menu until they are no longer active.

7.6 ice warning



The **ice warning**  goes on when there is an increased risk of ice on the roads.
The **ice warning**  appears in the upper area of the display and is highlighted in yellow.
The **ice warning**  appears on the display when the ambient temperature has fallen to or below the specified value.


Temperature	$\leq 4\text{ }^{\circ}\text{C}$ ($\leq 39.2\text{ }^{\circ}\text{F}$)
-------------	---

The **ice warning**  disappears from the display when the ambient temperature has risen to or above the specified value again.

Temperature	$\geq 6\text{ }^{\circ}\text{C}$ ($\geq 42.8\text{ }^{\circ}\text{F}$)
-------------	---

Note
When the **ice warning**  lights up, warning **Ice Warning** also appears.

7.7 indicator lamps



I01856-01

The indicator lamps offer additional information about the operating state of the motorcycle.
When the ignition is switched on, all indicator lamps light up briefly.

Note

The failure indicator light  will always light up as long as the engine is not running. If the engine is running and the failure indicator light  lights up, stop (taking care not to endanger yourself or other road users in the process) and contact an authorized dealer.

The oil pressure warning light  will always light up as long as the engine is not running. If the engine is running and the oil pressure warning light  lights up, stop immediately (taking care not to endanger yourself or other road users in the process) and switch off the engine.

The ABS warning light  and the TC indicator light  light up until a speed of approx. 6 km/h (approx. 4 mph) or faster has been reached.

Condition		Meaning
	The left turn signal indicator light flashes green with a steady rhythm.	The left turn signal is switched on.
	The oil pressure warning light lights up red.	The oil pressure is too low. Stop immediately, taking care not to endanger yourself or other road users in the process, and switch off the engine.
	The general warning light lights up yellow.	A note/warning note on operating safety has been detected. This is also shown in the display.
	The failure indicator light lights up yellow.	The OBD has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized dealer.


Condition		Meaning
	TC indicator light lights up/ flashes yellow.	The MTC is not active or is currently intervening. The TC indicator lamp also lights up if a malfunction is detected. Contact an authorized contractual partner. The TC indicator lamp flashes, if TC actively engages.
	The cruise control system indicator light lights up yellow.	The cruise control function is switched on in CC Only mode, but cruise control is not activated.
	The cruise control system indicator light lights up green.	The cruise control function is switched on in CC Only mode and cruise control is activated.
	The ABS warning light lights up yellow.	Status or error messages relating to ABS .
	The ABS rear warning light lights up yellow	ABS is deactivated on the rear wheel.
	Ice warning is active on the display.	The warning lamp lights up when there is increased risk of icy roads.
	The high beam indicator light lights up blue.	The high beam is switched on.
	The right turn signal indicator light flashes green with a steady rhythm.	The right turn signal is switched on.
	Neutral position indicator is active on the display.	The transmission is in the neutral position.

7.8 Display



Note

The figure shows the start screen of the combination instrument. If the menu is open, the speed and the selected gear are still displayed.




I01857-01

- | | |
|---|--|
| 1 Menu button | 6 Speed (p. 40) |
| 2 speed (p. 39) | 7 Ride mode display (p. 40) |
| 2 shift light (p. 39) | 8 fuel level display (p. 41) |
| The shift light is integrated in the rpm gauge display. | 9 Fuel range display |
| 3 Unit for the engine speed display | 10 time (p. 41) |
| 4 Gear display (p. 38) | 11 ambient air temperature indicator (p. 42) |
| 5 Unit of speed | 12 Splitscreen display (p. 43) |

7.9 Reduced display

Note

The figure shows the start screen of the combination instrument. If the menu is open, the speed and the selected gear are still displayed.



I01902-01


- | | |
|---|--------------------------------|
| 1 Menu button | 5 Speed (p. 40) |
| 2 time (p. 41) | 6 Unit of speed |
| 3 ambient air temperature indicator (p. 42) | 7 Ride mode display (p. 40) |
| 4 speed (p. 39) | 8 fuel level display (p. 41) |
| 4 shift light (p. 39) | 9 Fuel range display |
| The shift light is integrated in the rpm gauge display. | 10 Gear display (p. 38) |
| | 11 Splitscreen display (p. 43) |

7.10 Ride mode Track (optional)



Note

The figure shows the start screen of the combination instrument in active riding mode **Track**. If the menu is open, the speed and the selected gear are still displayed.




I01858-01

- | | |
|---|--------------------------------------|
| ① Menu button | ⑧ coolant temperature display |
| ② time (p. 41) | ⑨ Unit of speed |
| ③ ambient air temperature indicator (p. 42) | ⑩ Ride mode display (p. 40) |
| ④ speed (p. 39) | ⑪ Engine brake control display |
| ④ shift light (p. 39) | ⑫ Launch control |
| The shift light is integrated in the rpm gauge display. | ⑬ Anti Wheelie Mode |
| ⑤ Gear display (p. 38) | ⑭ fuel level display (p. 41) |
| ⑥ Unit for the engine speed display | ⑮ Fuel range display |
| ⑦ Speed (p. 40) | ⑯ Slip Adjuster indicator |
| | ⑰ Splitscreen display (p. 43) |

7.11 Display ride mode Track reduced (optional)


Note

The figure shows the start screen of the combination instrument in active riding mode **Track**. If the menu is open, the speed and the selected gear are still displayed.




- 1 Menu button
- 2 time (p. 41)
- 3 ambient air temperature indicator (p. 42)
- 4 speed (p. 39)
- 4 shift light (p. 39)
The shift light is integrated in the rpm gauge display.
- 5 Gear display (p. 38)
- 6 Speed (p. 40)
- 7 Unit of speed
- 8 Ride mode display (p. 40)
- 9 fuel level display (p. 41)
- 10 Fuel range display
- 11 Slip Adjuster indicator
- 12 Splitscreen display (p. 43)

7.12 Gear display




The gear is shown in area 1 of the display.

7.13speed




The engine speed is shown in area ❶ of the display.
The engine speed is displayed in revolutions per minute.

7.14shift light



The shift light is integrated in the rpm gauge display.




The speed for the shift light can be set in the **Shift Light** menu. The shift warning light is always active during the running-in phase (up to 1,000 km / 621 mi). The shift warning light can only be deactivated, and the values for **RPM1** and **RPM2** can only be adjusted after this. At **RPM1**, the engine speed display flashes red and at **RPM2**, the entire display flashes red.

Note
After the first service, the shift warning light is deactivated when the engine is warm and in sixth-gear.

Coolant temperature	≤ 35 °C (≤ 95.0 °F)
ODO	< 1,000 km (< 621.4 mi)
The shift warning light always lights up at	5,000 rpm (83.33 Hz)

Coolant temperature	> 35 °C (> 95.0 °F)
ODO	> 1,000 km (> 621.4 mi)
RPM1 Engine speed display	flashes red
RPM2 entire display	flashes red

7.15 Speed




The speed is shown in area ❶ of the display.
The unit of speed can be configured in the **Units** menu.
Speed is shown in kilometers per hour **km/h** or in miles per hour **mph**.

7.16 cruise control indicator (optional)



The operating state of the active cruise control (optional) is shown in the area ❶ of the display.
Cruise control is operated using the [cruise control buttons](#).

7.17 Ride mode display



The **Ride Mode** setting is shown in area ❶ of the display.
The riding mode can be configured in the menu **Ride Mode**.


Ways to change Ride Mode:

1. Select **Ride Mode** by pressing the **Ride Mode** button and confirm by holding it.
2. Press the **Ride Mode** button, select **Ride Mode** using the **UP** or **DOWN** button, and confirm with the **SET** button.
3. Via **Touchscreen**.
4. Via the menu.

**Note**

If a function of the **Ride Mode** is locked, is displayed for that function.

If a function of **Ride Mode** cannot be changed, is displayed for that function and the message “Note: Not all settings have been changed” appears.

7.18 fuel level display

The fuel tank capacity is shown in area ① of the display.

The fuel level indicator consists of bars. The more bars are lit, the more fuel is in the fuel tank.

The range is displayed in increments of 5 km or 5 m.

**Note**

If the fuel level is getting low, the last bar flashes, the fuel symbol turns red and the **Fuel reserve** warning also appears.

The fuel level is displayed with a slight delay to prevent the indicator from constantly moving while riding.

If the combination instrument does not receive a signal from the fuel level sensor, all fuel level display bars will flash.

The fuel range display adjusts over time to reflect average fuel consumption.

To ensure that the fuel gauge works correctly, only refuel when the tank is half empty.

7.19 time

The time is shown in area ① of the display.

The time can be displayed in 24-hour format or 12-hour format in all languages.

The format of the time can be configured in sub-menu **Clock Format**.



Note

The time must be reset if the 12 V battery was disconnected from the vehicle or the fuse was removed.

7.20 ambient air temperature indicator



The ambient temperature is shown in area ❶ of the display.

The ambient air temperature is displayed in °C or °F.

The unit of the ambient air temperature can be configured in the **Temperature** submenu.

7.21 heated grip (optional)



The status of the heated grip is shown in area ❶ of the display.

The grip heater can be configured in menu **Heating** or via the **Touchscreen**.

The button is only available when the grip heater is activated in **Settings**.

If the grip heater is not activated, the menu **Heating** is not displayed.

7.22 coolant temperature indicator



The coolant temperature is displayed by a symbol . The color of symbol changes depending on the temperature. Symbol disappears when the engine has reached operating temperature.

**NOTE**

Engine failure Overheating damages the engine.

- If the coolant temperature warning is displayed, stop immediately and take care not to endanger yourself or other traffic participants in the process.
- Allow the engine and cooling system to cool down.
- Check and, if necessary, correct the coolant level on the cooling system while it is in a cooled state.



**Note**

If the coolant temperature gauge lights up red, a warning is displayed.

If the cooling system overheats, the maximum engine speed is limited.

Condition		Meaning
	Coolant temperature gauge lights up blue.	The engine is cold.
	Coolant temperature gauge does not light up.	The engine is at operating temperature.
	Coolant temperature gauge lights up red.	Engine is hot.

7.23 Splitscreen display



I01883-01

The **Splitscreen** display can be opened with the **DOWN**, **RIGHT**, or **UP** button or via **Touchscreen**.

In the **Splitscreen** display, you can use the **DOWN** or **UP** button to switch between the **Favourites** display, the audio display, the navigation display, the **Lap Timer** display (optional), and the telemetry display (optional).

The **Splitscreen** display can be shown in four different sizes.

In the full size (4/4) of the **Splitscreen** of the favorites, 8 favorites are displayed.

At 3/4 size of the **Splitscreen**, 6 favorites are displayed.

At 2/4 size of the **Splitscreen**, 4 favorites are displayed.

At 1/4 size of the **Splitscreen**, 2 favorites are displayed.

In the full size (4/4) of the **Splitscreen** of the navigation, the map, the route, the speed control, the compass north button, the **Zoom in** button, and the **Zoom out** button are displayed.

At 3/4 size of the **Splitscreen**, the map, the route, the compass north button, the **Zoom in** button, and the **Zoom out** button are displayed.

At 2/4 size of the **Splitscreen**, the map, the route, and the speed control are displayed.

At 1/4 size of the **Splitscreen**, the map, the route, and the speed control are displayed.

In the full size (4/4) of the **Splitscreen** of the music, current song information (album cover, track, and artist), volume, the button to increase volume, the button to decrease volume, and the start/pause button are displayed.

At 3/4 size of the **Splitscreen**, current song information (album cover, track, and artist), volume, the button to increase volume, the button to decrease volume, and the start/pause button are displayed.

At 2/4 size of the **Splitscreen**, current song information (album cover, track, and artist), volume, and the start/pause button are displayed.

At 2/4 size of the **Splitscreen**, current song information (album cover, track, and artist), volume, and the start/pause button are displayed.

In the full size (4/4) of the **Splitscreen** of telemetry (optional), the maximum lean angle, the current lean angle, the current throttle position, the MTC engagement, the current acceleration, and the current deceleration are displayed.

At 3/4 size of the **Splitscreen**, the maximum lean angle, the current lean angle, the current throttle position, the MTC engagement, the current acceleration, and the current deceleration are displayed.

At 2/4 size of the **Splitscreen**, the maximum lean angle, the current lean angle, the current throttle position, the MTC engagement are displayed.

At 1/4 size of the **Splitscreen**, the maximum lean angle and the current lean angle are displayed.


At full size (4/4) of the **Splitscreen** of the **Lap Timer** (optional), the best lap, the last lap, the difference from the target lap, the current lap time, the number of laps and the start/stop button are displayed.

At 3/4 size of the **Splitscreen**, the best lap, the difference from the target lap, the current lap time, the number of laps and the start/stop button are displayed.

At 2/4 size of the **Splitscreen**, the difference from the target lap, the current lap time, the number of laps and the start/stop button are displayed.


At 1/4 size of the **Splitscreen**, the difference from the target lap, the current lap time and the start/stop button are displayed.

7.24 display Favourites



Up to eight items of information are shown in the **Favourites** display.
The **Favourites** indicator can be freely configured in the **Favourites** menu.


7.25 Navigation display (optional)



The **Navigation** indicator appears when the navigation function is activated.

The **Navigation** indicator shows the direction arrow, the distance to the next waypoint, the road name, the arrival time as well as the distance to the destination.

7.26 Audio display (optional)



The music display is available on the **Splitscreen**.

The current track is displayed.




Note

With some cell phones, the cell phone audio player needs to be started before playback is possible.


You can change tracks and adjust the volume using the **RIGHT** and **LEFT** buttons. Confirm the selection using the **SET** button or via **Touchscreen**.

7.27 display Telemetry (optional)



The **Telemetry** display shows, for example, the lean angle, acceleration, and throttle position.


7.28 display Lap Timer (optional)



The **Lap Timer** display shows, for example, the best lap, the last lap, the difference from the target lap, the current lap time and the number of laps.

A new lap is started by pressing the light switch.

7.29 Call display



WARNING

Danger of accidents Headphone volume which is too high distracts attention from traffic activity.
– Always select headphone volume which is low enough for you to still clearly hear acoustic signals.

The **Call** indicator appears for incoming or active calls.

Press the **RIGHT** or **LEFT** button and confirm with the **SET** button to accept or reject an incoming call or via the **Touchscreen**.

If a call is rejected, the rejection screen remains visible for a moment and then switches back to the previously open view.

When the call is answered, the display switches to the active call view. Use the **RIGHT** or **LEFT** button to navigate between volume up, volume down, mute, and hang up. Press the **SET** button to confirm your selection or use the **Touchscreen**.


The active call view can be minimized using the **BACK** button. Pressing the **BACK** button again returns you to the active call view.



Note

It is not possible to change the audio volume using the combination switch with every cell phone. The call duration and contact are displayed. Depending on the cell phone settings, the contact is displayed with the name.
You cannot navigate in the menu during an active phone conversation.

8.1 Menu



i Note


Press the **SET** button **5** in the start screen to open the menu.

Use the **UP** button **1**, the **RIGHT** button **2**, the **DOWN** button **3** and the **LEFT** button **4** to navigate in the menu. Press the **BACK** button **6** to close the current menu or the menu overview.

The menu can also be opened via the **Touchscreen**.

You can also navigate the menu using the **Touchscreen**.

8.2 Open menu




- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

8.3 Ride



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

In **RIDE**, for example, the ride mode, the ABS mode, the traction control of the vehicle and the engine braking (optional) can be configured.

8.3.1 Ride mode



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.



WARNING


Danger of accidents An incorrectly selected ride mode makes it more difficult to control the vehicle. The riding modes are each only suitable for certain conditions.

- Always select a riding mode that suits the surface on which you are riding, the weather and the riding situation.

- Press the **RIGHT** or **LEFT** button until **RIDE MODE** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to select the ride mode, which changes coordinated settings for the engine and motorcycle traction control, or this can be done via the **Touchscreen**.
- Press the **SET** button to confirm the selection or use the **Touchscreen**.
 - ✓ **Street** - Homologated performance with balanced response; the Motorcycle Traction Control allows normal slip on the rear wheel.
 - ✓ **Rain** - Reduced homologated performance for better ridability; the Motorcycle Traction Control allows less slip on the rear wheel.
 - ✓ **Sport** - Homologated performance with very direct response; the Motorcycle Traction Control allows greater slip on the rear wheel.
 - ✓ **Track** (optional) - Response and Motorcycle Traction Control can be adjusted individually.
 - ✓ **Custom 1** - Response and Motorcycle Traction Control can be adjusted individually.
 - ✓ **Custom 2** (optional) - Response and Motorcycle Traction Control can be adjusted individually.
 - ✓ **Custom 2** (optional) - Response and Motorcycle Traction Control can be adjusted individually.

The ride mode can be configured in submenu **Ride Mode Settings**.

8.3.2 Configure ride mode



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.3.2.1 ABS



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **ABS** is highlighted or use the **Touchscreen**.



WARNING

Danger of accidents An incorrectly selected ABS mode makes it more difficult to control the vehicle. The ABS modes are each only suitable for certain conditions.

- Always select an ABS mode that suits the ground and the riding situation.

- Press the **UP** or **DOWN** button to select the desired ABS mode. Press the **SET** button to confirm the selection or use the **Touchscreen**.

Do not open the throttle during the selection.

**Note**

The ABS mode can be switched during the journey.
The ABS mode cannot be changed in **Ride Mode Rain**.

**Note**

When the ABS mode **Road** is active, ABS controls both wheels.
The curve-dependent control is active.

**Note**

When ABS mode **Sport** is active, the ABS allows for an increased incline of the rear wheel when braking and reduced engagement in the inclined position.
More brake pressure is allowed on the front wheel.
The curve-dependent control is active.


**Note**

When the **Supermoto** ABS mode is active, ABS only controls the front wheel. The rear wheel is no longer controlled by ABS and may lock during braking maneuvers. The indicator lamp **ABS REAR** lights up.
More slip is allowed on the front wheel to enable a sporty riding style.
The curve-dependent control is not active.

**Note**

When the ABS mode **Supermoto+** is active, ABS controls both wheels. The ABS enables the bike to slide into bends by operating the rear brake.
More slip is allowed on the front wheel to enable a sporty riding style.
The curve-dependent control is not active.

8.3.2.2 MTC



Condition: Cruise control function (optional) is deactivated

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **MTC** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to switch **MTC** on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.


Do not open the throttle when switching on or off.

Press the **UP** or **DOWN** button briefly when activating the Motorcycle Traction Control and the motor slip regulation and confirm with the **SET** button.

Press and hold the **UP** or **DOWN** button when switching off the Motorcycle Traction Control and motor slip regulation and confirm with the **SET** button.

Note
The settings are saved automatically and remain active even after the ignition is switched off and on again.

8.3.2.3 MTC+MSR (optional)



Condition: Model with **MTC+MSR**, Cruise control function (optional) is deactivated

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **MTC+MSR** is highlighted or use the **Touchscreen**.
- Use the **UP** or **DOWN** button to switch the **MTC+MSR** on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.


Do not open the throttle when switching on or off.

Press the **UP** or **DOWN** button briefly when activating the Motorcycle Traction Control and the motor slip regulation and confirm with the **SET** button.

Press and hold the **UP** or **DOWN** button when switching off the Motorcycle Traction Control and motor slip regulation and confirm with the **SET** button.

Note
When ABS mode **Supermoto** is active, the **MSR** is not active.
The settings are saved automatically and remain active even after the ignition is switched off and on again.

8.3.2.4 Slip Adjuster (optional)



- Press the **SET** button when the menu is closed or use the **Touchscreen**.

i Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SLIP ADJUSTER** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the maximum permitted slip of the motorcycle traction control. Press the **SET** button to confirm the selection or use the **Touchscreen**.

Do not open the throttle during the selection.

The spin adjuster is a motorcycle traction control function.

The slip adjustment allows the motorcycle traction control to be tuned through nine levels to the desired characteristic map.

Level 0 allows maximum slip on the rear wheel, and level 9 allows the minimum.


If the cruise control function (optional) is deactivated, the **Paddle Buttons** or the **+RES** and **-SET** buttons can be used in the main display or in submenu **SLIP ADJUSTER** to set **Slip Adjuster**. When using the **UP** and **DOWN** buttons, the setting must be confirmed with the **SET** button.

i Note

Menu **SLIP ADJUSTER** is only available in ride mode **Track** (optional) or in ride mode **Custom**, which is a copy of ride mode **Track**.

The spin adjuster is only available when motorcycle traction control is activated.

8.3.2.5 Wheelie Control (optional)



Condition: Ride mode **Track** (optional) or **Custom** (optional) is activated

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.



WARNING

Danger of accidents When Anti Wheelie Mode is disabled, the motorcycle traction control no longer counteracts the raising of the front wheel.

- Only switch off the Anti Wheelie Mode if you have the appropriate experience.

- Press the **RIGHT** or **LEFT** button until **WHEELIE CONTROL** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to adjust **Wheelie Control** or use **Touchscreen**.




WARNING

Danger of accidents Electronic driving aids can only influence the vehicle within the limits of its physical capabilities.

- Even when using electronic driving aids, always adapt your riding style to the road conditions, the traffic situation and your own ability.

- The **Wheelie Control** (optional) is a partial function of the traction control, which counteracts the lifting of the front wheel. The intervention time can be set in stages in the sub-menu. At a higher level with later intervention, the front wheel is more likely to lift.

8.3.2.6 Engine Brake Control (Optional)



Condition: **Akrapovic Evolution Line** installed, Software active, Function enabled in the diagnostic tester

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note


If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **ENGINE BRAKE** is highlighted or use the **Touchscreen**.
- Press the **UP-** or **DOWN** button to adjust the **Engine Brake**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

Do not open the throttle when adjusting the throttle response.

The engine brake control adjusts the effect of the engine braking when closing the throttle twist grip.

8.3.2.7 Throttle Response (optional)



Condition: Ride mode **Track** (optional) or **Custom** (optional) is activated

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **THROTTLE RESPONSE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

**Note**


Menu **THROTTLE RESPONSE** is only available in ride mode **Track** (optional) or in ride mode **Custom**, which is a copy of ride mode **Track**.

- Press the **UP** or **DOWN** button to set the value for **Throttle Response**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

Do not open the throttle when adjusting the throttle response.

- ✓ Street – balanced response.
- ✓ Sport – very direct responsiveness.
- ✓ Track – extremely direct responsiveness.

8.3.2.8 Launch Control (optional)



- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**


If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LAUNCH CONTROL** is highlighted or use the **Touchscreen**.
- Switch **Launch Control** on or off using the **UP** or **DOWN** button or by using **Touchscreen**.

**Note**

The **Launch Control** (optional) can only be switched on after the first 1000 km.

8.3.2.9 QUICKSHIFTER+ (optional)



Condition: Model with QUICKSHIFTER+


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **QUICKSHIFTER+** is highlighted or use the **Touchscreen**.
- Use the **UP** or **DOWN** button to switch **QUICKSHIFTER+** on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.3.2.10 Display Mode




- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **DISPLAY MODE** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the value for **Display Mode** or use the **Touchscreen**.
- Press the **SET** button or use **Touchscreen** to switch between the following speedometer views: reduced and normal.

8.3.2.11 Reset ride mode



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **RIDE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDE MODE SET.** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired ride mode is highlighted. Open the settings for the desired ride mode by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RESET RIDE MODE** is highlighted. Press the **SET** button or use **Touchscreen** to reset the ride mode to factory settings.

To delete **Custom Ride Mode**, a **Factory Reset** must be performed.

8.4 info



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

In **INFO**, for example, general information, trip and warnings that may be present can be called up.

8.4.1 Trip info



- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TRIP INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

General information on the distance traveled, trip time, average fuel consumption, and average speed can be accessed in menu **TRIP INFO**.

Up to 8 trip counters can be displayed.

8.4.1.1 trip




- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TRIP INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TRIP** is highlighted or use the **Touchscreen**.

8.4.1.2 Add trip



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.


- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TRIP INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **ADD TRIP** is highlighted. Press the **SET** button to add a new **Trip** or use **Touchscreen**.



Note

Up to 8 separate trip counters are possible.

8.4.1.3 Reset trip



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.


- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TRIP INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **DOWN** or **UP** button until **RESET** is highlighted. Press the **SET** button or use **Touchscreen** to reset the selected **Trip**.



Note

Each trip counter can be reset separately.

8.4.1.4 Delete trip




- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TRIP INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **DOWN** or **UP** button until **DELETE** is highlighted. Press the **SET** button to delete **Trip** or use **Touchscreen**.

Note
Trip 3 to **Trip 8** can be deleted.

8.4.2 info



- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the desired information is highlighted, or use **Touchscreen**.

TPMS FR (optional) shows the current tire air pressure of the front tire.

TPMS RE (optional) shows the current tire air pressure of the rear tire.

Note
The tire pressure monitoring system display mode can be set in menu **TPMS WARNINGS**.

COOLANT TEMP. displays the coolant temperature.

RANGE indicates the possible fuel range you can cover with the fuel reserve.

BATTERY VOLTAGE displays the battery voltage.

ODOMETER displays the total mileage.


WARNINGS displays warnings that have occurred until they are no longer active.

VERSION displays the version of the dashboard.

NEXT SERVICE IN displays when the next service is due.

NEXT SERVICE ON displays when the next service is due.

8.4.3 Lap timer



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LAP TIMER** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.4.3.1 Lap timer setting



Condition: Ride mode **Track** (optional) is activated

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note


If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LAP TIMER** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LAP TIMER SETTING** is highlighted.
- Press the **UP** or **DOWN** button to switch **Lap Timer** on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.

**Note**

If the **Lap Timer** is switched off, the **Splitscreen Lap Timer** is deactivated.

8.4.3.2 Set reference round



Condition: Ride mode **Track** (optional) is activated

- Press the **SET** button when the menu is closed or use the **Touchscreen**.


**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LAP TIMER** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SET REFERENCE ROUND** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **UP**- or **DOWN** button to adjust the **Set Reference Round**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

Select from best lap, last lap and target lap.

8.4.3.3 Set target round



Condition: Ride mode **Track** (optional) is activated, **Target round** is set with **Set Reference Round**


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LAP TIMER** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SET TARGET ROUND** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.4.3.4 Session



Condition: Ride mode **Track** (optional) is activated

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **Info** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LAP TIMER** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SESSION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

7 **Sessions** with 20 laps in each case can be generated.

If more than 7 **Sessions** have been generated, the first **Session** is overwritten.


New **Sessions** are generated for each ignition cycle, if at least one lap has been ridden.

A new **Session** is started after 20 laps.

Individual **Sessions** or all **Sessions** can be deleted.

The date, time, average temperature, number of laps, and for each lap the lap time, the delta from the target lap, the maximum lean angle, the maximum speed and the maximum deceleration are stored.

8.4.4 E-SIM



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **E-SIM** is highlighted or use the **Touchscreen**.

E-SIM shows the status of the **E-SIM**.

8.4.5 Mobile



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
 - Press the **RIGHT** or **LEFT** button until **PHONE** is highlighted or use the **Touchscreen**.
- PHONE** shows the status of the cell phone.

8.4.6 Communication system



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
 - Press the **RIGHT** or **LEFT** button until **HEADSET** is highlighted or use the **Touchscreen**.
- HEADSET** shows the status of the **Headset**.

8.4.7 warnings



Condition: Message or warning is present

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **WARNINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.




Note

If warnings are available, the general warning light  lights up.

The warnings that have occurred are saved in the display until they are no longer active.

8.4.8 Extra functions



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **EXTRA FUNCTIONS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.




Note

The optional extra functions are listed.

The current **KTM PowerParts** and available software are listed on the KTM website.

For the first 1500 km, this is menu item **DEMO MODE**.

8.4.9 Demo mode



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **INFO** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **DEMO MODE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.



Note

The activated demo mode functions (p. 30) are listed.

After the demo mode expires, the optional software functions are available from authorized partners.
After the first 1500 km, this is menu item **EXTRA FUNCTIONS**.

8.5 Heating



Condition: **Heated Grips** is set to available in menu **SETTINGS**

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **HEATING** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.5.1 heated grip (optional)



Condition: The grip heater is set to available in menu **SETTINGS**

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **HEATING** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **DOWN** or **UP** button to adjust **Heated Grips**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.6 navigation



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.6.1 Search



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SEARCH** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.6.2 Choose on Map



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **PICK ON MAP** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.6.3 Stop navigation



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **STOP NAVIGATION** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.6.4 Overview of routes



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **ROUTE OVERVIEW** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.6.5 Settings




Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.6.5.1 Offline maps



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **OFFLINE MAPS** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

Various maps can be downloaded from menu **OFFLINE MAPS**.

8.6.5.2 Map Style




Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **MAP STYLE** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- The **Map Style** can be configured by pressing the **UP** or **DOWN** button. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.6.5.3 Notifications




Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **NOTIFICATIONS** is highlighted or use **Touchscreen**.
- Press the **UP** or **DOWN** button to configure the **Notifications**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.6.5.4 Display speed control



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SHOW SPEED LIMIT** is highlighted or use the **Touchscreen**.
- **Show Speed Limit** can be configured by pressing the **UP** or **DOWN** button. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.6.5.5 Threshold value of speed control



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **MAP NAVIGATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SPEED LIMIT THRESHOLD** is highlighted or use the **Touchscreen**.
- **Speed Limit Threshold** can be configured by pressing the **UP** or **DOWN** button. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.7 Apps



- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **APPS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.7.1 Calls



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **APPS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CALL** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.7.2 Music



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **APPS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **MUSIC** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.8 Settings



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

In menu **SETTINGS**, favorites, quick selections, **Connectivity** (optional), and the shift light can be configured. Settings can be made for units or various values. Several functions can be enabled or disabled.

8.8.1 favorites



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **FAVORITES** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

Up to eight items of information can be selected in the **FAVORITES** menu.

8.8.1.1 Favorites display 1–8



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **FAVORITES** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button to select **Favorite 1**, **Favorite 2**, **Favorite 3**, **Favorite 4**, **Favorite 5**, **Favorite 6**, **Favorite 7** or **Favorite 8**, or use **Touchscreen**.
- Press the **UP** or **DOWN** button to select the desired information. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.8.2 Paddle buttons



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **PADDLE BUTTONS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **UP** or **DOWN** button to configure the **Paddle Buttons**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.8.3 Connectivity



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

The standard **Bluetooth® 4.0** must be supported.

In sub-menu **Connectivity**, a suitable cell phone or suitable communication system can be connected via **Bluetooth®** to the dashboard, allowing the audio and navigation functions to be configured.

**Note**

Not every cell phone and communication system is suitable for pairing with the dashboard. For details, contact an authorized dealer.

8.8.3.1 Bluetooth & WiFi



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.8.3.2 Updates



Condition: Motorcycle is stationary, **WIFI** is connected

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **UPDATES** is highlighted. Press the **SET** button to check for updates or use the **Touchscreen**.

8.8.3.3 WIFI settings



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

8.8.3.4 WiFi



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **WIFI** is highlighted or use the **Touchscreen**.
- Use the **DOWN** or **UP** button to select the menu item and turn **WIFI** on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.8.3.5 Adding network



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **ADD NETWORK** is highlighted. Press the **SET** button to open the submenu or use **Touchscreen**.
- The dashboard starts searching for a suitable **WIFI**. If the search is successful, the name of the **WIFI** will be displayed in the Add network submenu. Press the **SET** button to initiate the pairing or use **Touchscreen**.

Note
Public networks are not supported.

8.8.3.6 Bluetooth settings



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.


- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

- Press the **RIGHT** or **LEFT** button until **Bluetooth** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

Note

Not every cell phone and communication system is suitable for pairing with the dashboard.

8.8.3.7 Bluetooth



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note

If the **Splitscreen** is open, press and hold the **SET** button.


- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH** is highlighted or use the **Touchscreen**.
- Use the **UP** or **DOWN** button to select a menu item to switch the **Bluetooth®** function on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.

Function **Bluetooth®** must be activated in order to pair a suitable cell phone or communication system with the vehicle.

Note

Not every cell phone and communication system is suitable for pairing with the dashboard.

8.8.3.8 Phone pairing



Condition: Motorcycle is stationary, Function **Bluetooth** activated, Function **Bluetooth®** also activated on the device that is to be paired

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **PHONE PAIRING** is marked. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

Note
Only one cellphone can be paired with the combination instrument.

- The dashboard starts the search for a suitable cell phone. If the search is successful, the name of the cell phone is displayed in submenu **PHONE PAIRING**. Press the **SET** button to initiate the pairing or use **Touchscreen**.

The cell phone must be visible via **Bluetooth®** in order for the cell phone to be found by the dashboard.


- A message appears on the combination instrument indicating that this is now ready for pairing. The pairing is successfully completed by confirming the **Passkey** on the cell phone and on the dashboard.

Note
Once the pairing is completed, the name of the paired cell phone is displayed in submenu **Phone**. Press the **RIGHT** or **LEFT** button until the paired device is marked. The paired device can be deleted by pressing the **SET** button.
Not every cell phone is suitable for pairing with the dashboard.

- Move the previously paired device into the range of the combination instrument while the **Bluetooth®** function is active.
 - ✓ The device is automatically paired with the combination instrument.
 - ✗ If the device is not automatically paired with the combination instrument after approx. 30 seconds:
 - Restart combination instrument or **Pairing** repeat procedure.

In submenu **Phone**, a suitable cell phone can be paired with the dashboard.

8.8.3.9 Rider communication system pairing



Condition: Motorcycle is stationary, Function **Bluetooth®** activated, Function **Bluetooth®** also activated on the device that is to be paired

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RIDERS HEADSET PAIRING** is marked. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- The vehicle starts searching for a suitable communication system. If the search was successful, the name of the rider's audio device is displayed in the **New Pairing** submenu. Press the **SET** button to initiate the pairing or use **Touchscreen**.

The communication system must be in pairing mode for the communication system to be found by the vehicle. Follow the instructions in the communication system owner's manual.

Note


Press the **RIGHT** or **LEFT** button until **Delete Pairing** is highlighted. The paired device can be deleted by pressing the **SET** button.

Not every communication system is suitable for pairing with the vehicle.

- Move the previously paired device into the range of the vehicle while the **Bluetooth®** function is active.
 - ✓ The device is automatically connected with the vehicle.
 - ✗ If the device is not automatically connected with the vehicle after approx. 30 seconds:
 - Switch on the vehicle again or repeat the **New Pairing** procedure.

In the **Riders Headset** submenu, a suitable rider communication system can be paired with the vehicle.

8.8.3.10 Passenger communication system pairing



Condition: Motorcycle is stationary, Function **Bluetooth®** activated, Function **Bluetooth®** also activated on the device that is to be paired

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONNECTIVITY** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH & WIFI** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BLUETOOTH** is highlighted. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **PILLION HEADSET PAIRING** is marked. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- The vehicle starts searching for a suitable communication system. If the search was successful, the name of the passenger's headset is displayed in the **New Pairing** submenu. Press the **SET** button to initiate the pairing or use **Touchscreen**.

The communication system must be in pairing mode for the communication system to be found by the vehicle. Follow the instructions in the communication system owner's manual.



Note


Press the **RIGHT** or **LEFT** button until **Delete Pairing** is highlighted. The paired device can be deleted by pressing the **SET** button.

Not every communication system is suitable for pairing with the vehicle.

- Move the previously paired device into the range of the vehicle while the **Bluetooth®** function is active.
 - ✓ The device is automatically connected with the vehicle.
 - ✗ If the device is not automatically connected with the vehicle after approx. 30 seconds:
 - Switch on the vehicle again or repeat the **New Pairing** procedure.

In the passenger communication system pairing submenu, a suitable communication system for the rider can be paired with the vehicle.

8.8.4 Tire pressure monitoring system warnings (optional)



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

i Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TPMS WARNINGS** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the value for **TPMS WARNINGS**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

Two different **TPMS** modes can be selected in menu **TPMS WARNINGS**.

The **Default** mode corresponds to the preset basic setting of the tire air pressure monitor recommended by KTM.

i Note

It may take some time for the **TPMS** sensors to send a value and for the new reference value to be saved.

The reference value can be between 1 bar and 5 bar (between 14.5 psi and 72.5 psi).

The stored reference value is displayed in the **Bike Info** menu.

If the value currently measured by the tire air pressure sensors is more than 50% above or 20% below the stored guide value, a warning appears on the dashboard display.


In **Warnings Off** mode, the warnings from the tire air pressure monitor are deactivated. The tire air pressure is still measured by the tire air pressure sensors, but warnings no longer appear on the dashboard display.

i Note

KTM recommends **Default** mode.

A second wheel set can be programmed via the KTM diagnostics tool. An authorized dealer will be happy to help.

8.8.5 Shift Light



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.


Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SHIFT LIGHT** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

The shift warning light can be configured in the **Shift Light** submenu.

Note
The rev limiter is dependent on the coolant temperature.

8.8.5.1 RPM1



Condition: Motorcycle is stationary, **ODO** > 1,000 km (621 miles)

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SHIFT LIGHT** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RPM1** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the value for **RPM1**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

RPM1 must not be larger than **RPM2**.




Note

RPM1 can be set in intervals of 500 between 5,500 and 10,000 rpm.

The shift light can also be turned off.

If the engine speed reaches the set value **RPM1**, the engine speed display flashes as a shift warning light.

8.8.5.2 RPM2



Condition: Motorcycle is stationary, **ODO** > 1,000 km (621 miles)

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SHIFT LIGHT** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **RPM2** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the value for **RPM2**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

RPM2 must not be smaller than **RPM1**.




Note

RPM2 can be set in intervals of 500 between 7,000 and 10,000 rpm.

The shift light can also be turned off.

If the engine speed reaches the set value **RPM2**, the screen flashes as a shift warning light.

8.8.6 Coming Home light



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **COMING HOME LIGHT** is highlighted or use the **Touchscreen**.
- Press the **DOWN** or **UP** button to turn **Coming Home Light** on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.

The **Coming Home** light can be set to short (15 seconds) or long (30 seconds) and can be switched off.

8.8.7 Light system warnings



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LIGHT SYS. WARNING** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the value for **Light System Warnings**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

If "No warnings" is selected, no light warnings will be displayed on the dashboard.

8.8.8 Daytime Running Light



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **DAYTIME RUNNING LIGHT** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **DOWN** or **UP** button to turn **Daytime Running Light** on or off. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.8.9 Button Illumination



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **BUTTON ILLUMINATION** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the value for **Button Illumination**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.8.10 Setting the time and date




Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
 - Press the **RIGHT** or **LEFT** button until **CLOCK & DATE** is highlighted or use the **Touchscreen**.
 - The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- The time, date and format can be adjusted in menu **CLOCK & DATE**.

8.8.10.1 Setting the clock




Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

Note
If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CLOCK & DATE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SET CLOCK** is highlighted or use the **Touchscreen**.
- The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the hours or minutes are highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the hours or minutes. Press the **SET** button to confirm the selection or use the **Touchscreen**.
- Press the **BACK** button to close the sub-menu or use the **Touchscreen**.

8.8.10.2 Setting the date



Condition: Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CLOCK & DATE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **SET DATE** is highlighted or use the **Touchscreen**.
- The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until the day, month or year is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to set the day, month or year. Press the **SET** button to confirm the selection or use the **Touchscreen**.
- Press the **BACK** button to close the sub-menu or use the **Touchscreen**.

8.8.10.3 Clock format



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.


**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CLOCK & DATE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CLOCK FORMAT** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to select the time format. Press the **SET** button to confirm the selection or use the **Touchscreen**.

**Note**

The possible settings are 24h and 12h.

8.8.10.4 Date format

Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.


**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CLOCK & DATE** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **DATE FORMAT** is highlighted or use the **Touchscreen**.
- Press the **UP** or **DOWN** button to select the date format. Press the **SET** button to confirm the selection or use the **Touchscreen**.

**Note**

The possible settings are DD.MM.YYYY, MM/DD/YYYY and YYYY-MM-DD.

8.8.11 Units

Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **UNITS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

The **UNITS** submenu allows settings to be made for units or various values.

8.8.11.1 Distance



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **UNITS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **DISTANCE** is highlighted or use the **Touchscreen**.
- Use the **UP** or **DOWN** button to navigate to the menu item and select the desired unit. Press the **SET** button to confirm the selection or use the **Touchscreen**.



Note

Kilometers or miles can be set.

8.8.11.2 Temperature



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **UNITS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **TEMPERATURE** is highlighted or use the **Touchscreen**.
- Use the **UP** or **DOWN** button to navigate to the menu item and select the desired unit. Press the **SET** button to confirm the selection or use the **Touchscreen**.

**Note**

Celsius or Fahrenheit can be set.

8.8.11.3 Pressure (optional)



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **UNITS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **PRESSURE** is highlighted or use the **Touchscreen**.
- Use the **UP** or **DOWN** button to navigate to the menu item and select the desired unit. Press the **SET** button to confirm the selection or use the **Touchscreen**.

**Note**

You can set it to bar or PSI.

8.8.11.4 Utilization



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **UNITS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **CONSUMPTION** is highlighted or use the **Touchscreen**.


- Use the **UP** or **DOWN** button to navigate to the menu item and select the desired unit. Press the **SET** button to confirm the selection or use the **Touchscreen**.



Note

You can set it to l/100 km, km/l, USG/100 mi, mi/USG, mi/l, l/100 mi, UKG/100 mi or mi/UKG.

8.8.11.5 Acceleration



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.


- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **UNITS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **ACCELERATION** is highlighted or use the **Touchscreen**.
- Use the **UP** or **DOWN** button to navigate to the menu item and select the desired unit. Press the **SET** button to confirm the selection or use the **Touchscreen**.



Note

You can set it to m/s² or ft/s².

8.8.12 Language



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.


- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **LANGUAGE** is highlighted or use the **Touchscreen**.

- Use the **UP** or **DOWN** button to set the desired language. Press the **SET** button to confirm the selection or use the **Touchscreen**.

**Note**

The menu languages are US English, UK English, German, Italian, French, and Spanish.

8.8.13 Heating setup



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.


**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **HEATING** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

The grip heater (optional) can be configured in **Heating**.

8.8.13.1 heated grip (optional)



Condition: Model with grip heater, Motorcycle is stationary


- Press the **SET** button when the menu is closed or use the **Touchscreen**.

**Note**

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **HEATING** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **GRIPS** is marked. The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Use the **UP** or **DOWN** button to set whether the grip heater is available or unavailable. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.8.14 Touchscreen



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.




Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **Touchscreen** is highlighted or use the **TOUCHSCREEN**.
- Press the **UP** or **DOWN** button to set the function for **Touchscreen**. Press the **SET** button to confirm the selection or use the **Touchscreen**.

8.8.15 Factory setting



Condition: Motorcycle is stationary

- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.

- Press the **RIGHT** or **LEFT** button until **SETTINGS** is highlighted. The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button until **FACTORY SETTING** is highlighted or use the **Touchscreen**.
- Press the **SET** button or use **Touchscreen** to execute **Factory Reset**.


All settings are reset to the factory setting. For example, all **Trips**, all maps, all connections, and **Custom Ride Modes** will be deleted, and all ride modes will be reset.



Note

After **Factory Reset** there may be deviations in the **Range** display. After a trip time of approx. 30 minutes, the **Range** is displayed correctly again.

9.1 Handlebar position



On the upper triple clamp there are two holes at a distance of **A** apart.

Hole distance A	15 mm (0.59 in)
------------------------	--------------------

The handlebar can be mounted in two different positions. This allows the handlebar to be mounted in the most comfortable position for the rider.



Note

KTM recommends the front handlebar position when using the vehicle on a race track.

9.2 Adjusting the handlebar position




WARNING

Danger of accidents A repaired handlebar poses a safety risk.

If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

- Change the handlebar if the handlebar is damaged or bent.



- Remove screws **1**. Take off the handlebar clamps **2**. Position the handlebar so that screws **3** are accessible.

Protect the components against damage by covering them.

Do not kink the cables or lines.

- Remove screws **3**. Take off handlebar supports **4**.
- Move the handlebar supports into the desired position **A** or **B**. Mount and tighten screws **3**.

Mount the left and right handlebar supports in the same position.

Screw, handlebar mount


M10	45 Nm (33.2 ft·lb _r) Loctite® 243
-----	--

- Position the handlebar.
- Make sure the cables and wiring are routed correctly.
- Position the handlebar clamps. Mount screws **1** and tighten evenly.

Handlebar clamp screw

M8	20 Nm (14.8 ft·lb _r)
----	-------------------------------------

9.3 Adjusting the basic position of the clutch lever



- Push clutch lever forward.
- Adjust the basic position of the clutch lever to your hand size by turning adjusting screw ①.

Only turn the adjusting screw by hand, and do not use force.

Do not make any adjustments while riding.




Note

When the adjusting screw is turned clockwise, the clutch lever moves away from the handlebar.

When the adjusting screw is turned counterclockwise, the clutch lever moves closer to the handlebar.

The range of adjustment is limited.

9.4 Adjusting the response of the hand brake lever



- Adjust the response of the hand brake lever with adjusting screw ①.

Only turn the adjusting screw by hand, and do not use force.

Do not make any adjustments while riding.


- ✓ 19 - Setting with large hand brake lever transmission ratio (soft response, more lever travel, less lever force).
- ✓ 20 - Setting with balanced hand brake lever response.
- ✓ 21 - Setting with small hand brake lever transmission ratio (hard response, less lever travel, more lever force).



Note

The transmission ratio and, therefore, the response of the hand brake lever can be changed.

9.5 Adjusting the basic position of the hand brake lever



- Push hand brake lever forward.
- Adjust the basic position of the hand brake lever to your hand size by turning adjusting screw ①.

Only turn the adjusting screw by hand, and do not use force.

Do not make any adjustments while riding.



Note

Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.

Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.


The range of adjustment is limited.

9.6 Adjusting the basic position of the brake pedal



WARNING

Danger of accidents The brake system fails in the event of overheating.
If there is no free travel on the brake lever, pressure builds up in the brake system.
– Set the free travel on the brake lever as specified.



- Detach spring ①.
- Loosen nut ②.



Tip

Press the foot brake lever downwards to make this easier.


- Turn the push rod ③ to set the basic position of the foot brake lever.

The screw must be screwed in by at least five full turns.



Note

The range of adjustment is limited.
Screwing the push rod into the ball joint adjusts the foot brake lever downwards.
Screwing the push rod out of the ball joint adjusts the brake lever upwards.



- Loosen nut ④ and turn screw ⑤ correspondingly until the free travel A is present. If necessary, adjust the basic position of the brake pedal.

Free travel of brake pedal	3 mm ... 5 mm (0.12 in ... 0.20 in)
----------------------------	--

- Hold screw ⑤ and tighten nut ④.

Remaining nuts on chassis	
M6	10 Nm (7.4 ft·lb _f)

- Tighten nut ②.


Nut, push rod, brake pedal	
M6	10 Nm (7.4 ft·lb _f)



Tip


Press the foot brake lever downwards to make this easier.

- Attach spring ①.




9.7 Checking the basic position of the gear shift lever

Note
When driving, the gear shift lever must not touch the rider's boot when in the basic position.
If the shift lever is permanently touching the boot, the transmission will be subject to excessive load; this can cause a malfunction of the quickshifter + (optional).



- Sit on the vehicle in the riding position and measure the distance **A** between the upper edge of your boot and the shift lever.
- | | |
|--|--|
| Distance between the gear shift lever and upper edge of boot | 10 mm ... 20 mm
(0.39 in ... 0.79 in) |
|--|--|
- » If the distance does not meet the specifications:
 - Adjust the basic position of the gear shift lever. 
-  (p. 100)

9.8 Adjusting the basic position of the gear shift lever



- Loosen nut **1** while holding stud **2**.
- Loosen nut **3** while holding stud **2**.

Note
Nut **3** has an LH thread.

- Turn stud **2** to adjust the shift lever.

The gear shift lever must not come into contact with any other vehicle components during the shift procedure.

Note
The range of adjustment is limited.

- Tighten nut **3** while holding stud **2**.

Nut, shift rod	
M6LH	6 Nm (4.4 ft·lb _f)

- Tighten nut **1** while holding stud **2**.

Nut, shift rod	
M6	6 Nm (4.4 ft·lb _f)

10.1 Notes on preparing for first use



DANGER

Danger of accidents A rider who is not fit to ride poses a danger to themselves and to others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs, or medication.
- Do not operate the vehicle if you are physically or mentally incapable of doing so.



WARNING

Danger of accidents The brake system fails in the event of overheating.

If the brake pedal is not released, the brake pads grind continuously.

- Take your foot off the brake pedal when you are not braking.



WARNING

Danger of accidents Non-approved or non-recommended tyres and wheels impact the handling characteristic.

- Only use tires and wheels approved and recommended by the vehicle manufacturer with the corresponding speed rating.



WARNING

Danger of accidents New tires have reduced road grip.

The contact surface on new tires is not yet roughened.

- Run in new tires with moderate riding and only gradually increase the lean angle.

Run-in distance	200 km (124.3 mi)
-----------------	----------------------



WARNING

Danger of accidents Different tire profiles on the front and rear wheels can make it more difficult to control the vehicle.

- Make sure that only tires of the same tread type are mounted to the front and rear wheel.



WARNING

Risk of injury Missing or inadequate protective clothing increases the risk of injury.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as pants and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.



Note

When using the vehicle, remember that others may feel disturbed by excessive noise.

- Ensure that the pre-delivery inspection has been carried out by an authorized contractual partner.
 - ✓ The delivery certificate is transferred upon vehicle handover.
- Read the entire owner's manual before riding for the first time.
- Get to know the controls.
- Adjust the basic position of the clutch lever. 📖 (p. 98)
- Adjust the basic position of the hand brake lever. 📖 (p. 98)
- Adjust the basic position of the brake pedal. 🦶 📖 (p. 99)
- Get used to the handling characteristics of the motorcycle on suitable terrain before undertaking a more challenging ride. Also, ride as slowly as possible to get a better feeling for the motorcycle.
- Hold the handlebar firmly with both hands and keep your feet on the footpegs when riding.
- Run in the engine. 📖 (p. 102)



10.2 Running in the engine

- During the running-in time, do not exceed the specified engine speed.

Maximum engine speed	
During the first: 1,000 km (621.4 mi)	6,500 rpm (108.33 Hz)
After the first: 1,000 km (621.4 mi)	9,800 rpm (163.33 Hz)
Avoid fully opening the throttle.	

10.3 Loading the vehicle



WARNING

Fire hazard The hot exhaust system may burn luggage.

- Fasten your luggage in such a way that it cannot be burned or singed by the hot exhaust system.



WARNING

Danger of accidents A high payload alters the handling characteristic and increases the stopping distance.

- Adapt your speed to your payload.



WARNING

Danger of accidents Carrying luggage alters handling characteristics.

- Adapt your speed to your payload.
- Ride more slowly if your vehicle is loaded with cases or other luggage.

Maximum speed with luggage	130 km/h (80.8 mph)
----------------------------	------------------------



WARNING

Danger of accidents Items of luggage that have slipped or are incorrectly fastened can obscure the lighting system.

- Check that your luggage is fixed properly at regular intervals.
- Make sure that the lighting system is not covered by luggage.



WARNING

Danger of accidents Total weight and axle loads influence the handling characteristic.

The total weight consists of: operational vehicle with a full tank, rider and, if applicable, a passenger with protective clothing and helmet, and, if applicable, mounted luggage.

- Do not exceed the maximum permissible total weight or the axle loads.



WARNING

Danger of accidents Improper mounting of cases, tank rucksacks or other luggage impairs the handling characteristics.

Luggage mounted incorrectly can slip while the vehicle is in motion.

- Mount and secure all luggage according to the manufacturer's instructions.
- Check that your luggage is fixed properly at regular intervals.

**WARNING**

Danger of accidents The luggage system will be damaged if it is overloaded.

- Read the manufacturer information on maximum payload when mounting cases.

- If luggage is carried, ensure it is fixed firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.
- The maximum permissible total weight and the maximum permissible axle loads must not be exceeded.


Maximum permissible total weight	390 kg (859.8 lb)
Maximum permissible front axle load	165 kg (363.8 lb)
Maximum permissible rear axle load	270 kg (595.2 lb)



11.1 Checks and maintenance measures when preparing for use

Note

Before every trip, check the condition of the vehicle and ensure that it is roadworthy.
The vehicle must be in perfect technical condition when it is being operated.



- Check the engine oil level.  (p. 178)
- Check the brake fluid level for the front brake.  (p. 137)
- Check the brake fluid level for the rear brake.  (p. 140)
- Check that the brake pads of the front brake are secured.  (p. 139)
- Check that the brake pads of the rear brake are secured.  (p. 141)
- Check that the brake system is functioning properly.
- Check the coolant level in the compensating tank.  (p. 169)
- Check the chain for dirt.  (p. 125)
- Check the chain tension.  (p. 126)
- Check the tire condition.  (p. 150)
- Check the tire pressure.  (p. 151)
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check that the electrical equipment is functioning properly.
- Check that luggage is properly secured.
- Sit on the motorcycle and check the rear mirror setting.
- Check the fuel level.

11.2 Starting the vehicle



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.



WARNING

Danger of accidents Electronic components and safety devices will be damaged if the 12-V battery is discharged or missing.

If the 12-V battery is discharged or defective, malfunctions in the vehicle electronics can occur, especially when starting.


- Never operate the vehicle with a discharged 12-V battery or without a 12-V battery.



NOTE

Engine failure Running a cold engine at high engine speeds negatively impacts the service life of the engine.

- Always warm up the engine at low engine speeds.



- Take the motorcycle off the side stand and sit on the motorcycle.
- Make sure that the start button/kill switch is in the middle position (○).
- Switch on the ignition by turning the ignition key to position (○).

To avoid malfunctions in the control unit communication, do not switch the ignition off and on in rapid succession.

- ✓ After you switch on the ignition, you can hear the fuel pump working for about two seconds. The function check of the combination instrument is run at the same time.
- ✓ The ABS warning light lights up and goes out again after starting off.
- Shift the transmission into the neutral position.
- ✓ The green idle indicator lamp **N** lights up.
- Briefly press the start button/kill switch into lower position (Ⓝ).

Only press the start button/emergency OFF switch into the lower position (Ⓝ) when the combination instrument function check has been completed.

Do not open the throttle to start.

If the starting attempt is unsuccessful, wait for 15 seconds before making another attempt at starting.

After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other malfunctions instead.



Note

This motorcycle is equipped with a safety starting system. You can only start the engine if the transmission is in neutral or if the clutch lever is pulled when a gear is engaged. If the side stand is folded out and you shift into gear releasing the clutch lever, the engine stops.




11.3 Starting off

- Pull the clutch lever, shift into first gear, release the clutch lever slowly and at the same time carefully open the throttle.



11.4 Launch-Control (optional)



Launch Control is a vehicle electronics function.

Launch control adjusts the engine speed in order to achieve the best possible acceleration.

Launch control can be used for starting off for a maximum of three times in succession. Launch control is temporarily deactivated after the third starting off in order to protect the engine, transmission and cooling system from overloading.

Launch control is also deactivated if all conditions for activation are no longer met.

Launch control is enabled again in the following cases: the engine runs for at least three minutes, the engine is switched off for 20 minutes or a distance of 1.5 km (0.93 mi) has been covered.

11.5 Starting off with launch control (optional)




WARNING

Danger of accidents Launch Control enables powerful acceleration which may overwhelm a novice rider. Public roads are neither a safe place nor a necessary environment for the use of Launch Control.

- Only use the launch control if you have the necessary experience.
- Do not use launch control on public roads.


Condition: Ride mode **TRACK** (optional) is activated, The vehicle is in first gear, TC indicator lamp does not light up, Coolant temperature: > 60 °C (> 140.0 °F), Total riding distance covered: > 1,000 km (> 621.4 mi)



- Activate launch control in the combination instrument.
 - ✓ The number of available starts is indicated on the start screen.
- Apply full throttle with the clutch lever pulled.
 - ✓ The engine speed is adjusted.

9,000 rpm
(150.00 Hz)
 - ✓ The TC indicator lamp flashes quickly.
- Release clutch lever quickly but in a controlled manner.

11.6 Quickshifter+ (optional)



If the **QUICKSHIFTER+** is activated, you can shift up and down without actuating the clutch.

Because there is no need to close the throttle grip, uninterrupted gear shifts are possible.

The **QUICKSHIFTER+** uses the shift shaft position to check whether or not a shift should be initiated, and sends a corresponding signal to the engine control unit.

If the **QUICKSHIFTER+** is disabled in the combination instrument, the clutch needs to be actuated in the normal way for each shift.

11.7 Shifting, riding



WARNING

Risk of injury The passenger may fall from the vehicle if they act incorrectly.

- Ensure that the passenger sits correctly on the passenger seat, places his or her feet on the passenger foot pegs and holds on to the rider or the grab handles.



WARNING

Danger of accidents Not adapting the riding style constitutes a major risk.

- Comply with traffic regulations and ride defensively and with foresight to detect sources of danger as early as possible.



WARNING

Danger of accidents Total weight and axle loads influence the handling characteristic.

The total weight consists of: operational vehicle with a full tank, rider and, if applicable, a passenger with protective clothing and helmet, and, if applicable, mounted luggage.

- Do not exceed the maximum permissible total weight or the axle loads.



WARNING

Danger of accidents Improper mounting of cases, tank rucksacks or other luggage impairs the handling characteristics.

Luggage mounted incorrectly can slip while the vehicle is in motion.

- Mount and secure all luggage according to the manufacturer's instructions.
- Check that your luggage is fixed properly at regular intervals.



WARNING

Danger of accidents Adjustments to the vehicle distract attention from traffic activity.

- Make all adjustments when the vehicle is at a standstill.



WARNING

Danger of accidents Abrupt load alterations can cause the vehicle to become out of control.

- Avoid abrupt load alterations and sudden braking actions unless a hazardous situation arises.



WARNING

Danger of accidents Cold tires have reduced road grip.

- Ride the first miles carefully on every journey at moderate speed until the tires reach operating temperature.



WARNING

Danger of accidents New tires have reduced road grip.

The contact surface on new tires is not yet roughened.

- Run in new tires with moderate riding and only gradually increase the lean angle.

Run-in distance	200 km (124.3 mi)
-----------------	----------------------



WARNING

Danger of accidents A fall can damage the vehicle more seriously than it may first appear.

- Check the vehicle after a fall as you do when preparing for use.



WARNING

Danger of accidents An incorrect ignition key position causes malfunctions.

- Do not change the ignition key position while riding.



WARNING

Danger of accidents If you downshift at high engine speed, the rear wheel blocks and the engine races.

- Do not downshift to a lower gear at high engine speeds.



NOTE

Engine failure Overheating damages the engine.

- If the coolant temperature warning is displayed, stop immediately and take care not to endanger yourself or other traffic participants in the process.
- Allow the engine and cooling system to cool down.
- Check and, if necessary, correct the coolant level on the cooling system while it is in a cooled state.



NOTE

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

Dust and dirt can enter the engine if there is no air filter or if the air filter is mounted incorrectly.

- Only operate the vehicle if an air filter is correctly fitted.



NOTE

Transmission damage Incorrect use of the QUICKSHIFTER+ will damage the transmission.

The QUICKSHIFTER+ can only be used if the function is enabled in the combination instrument.


The QUICKSHIFTER+ is not active if you pull the clutch lever.

- Only use the QUICKSHIFTER+ in the permitted speed range shown.



Note

If you hear unusual noises while riding, stop immediately in a safe manner, switch off the engine, and contact an authorized contractual partner.



- Shift into a higher gear when conditions allow (incline, road situation, etc.).
- Release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever, and open the throttle.



Note

You can see the positions of the 6 forward gears in the figure. The neutral or idle position is between the first and second gears. First gear is used for starting off or for steep inclines.

The operating temperature is reached when 5 bars of the temperature indicator light up.

- After reaching maximum speed by fully opening the throttle twist grip, turn the throttle back so that it is $\frac{3}{4}$ open. This will reduce the speed slightly, but the fuel consumption will be considerably lower.
- Accelerate only up to a speed suitable for the road surface and weather conditions. In particular, you should not change gear on bends and should only accelerate very cautiously.
- Brake if necessary and close the throttle at the same time in order to shift down.
- Pull clutch lever and shift into a lower gear, release the clutch lever slowly, and open the throttle or shift again.

- If the engine stalls (e.g., at a crossroads), just pull clutch lever and press the start button/emergency OFF switch into the lower position (⚡). The transmission must not be shifted into neutral.
- Switch off the engine if you are likely to be running at idle speed or stationary for a long time.
- If the oil pressure warning lamp  lights up during a trip, stop immediately and switch off the engine. Contact an authorized contractual partner.
- If malfunction indicator  lamp lights up during a trip, please contact an authorized contractual partner as soon as possible.
- If the general warning lamp  lights up during a trip, the display shows a message.



Note

Very important messages are stored in the **Warnings** menu.



- If the ice warning appears in the combination instrument, the roads may be icy. Adjust your speed to the road conditions.
- If the **QUICKSHIFTER+** (optional) is activated in the combination instrument, you can shift up in the engine speed range indicated without pulling the clutch lever.



Note

The minimum engine speed in rpm before shifting up is shown in the figure.

Pull the shift lever to the stop quickly without changing the throttle twist grip position.



- If the **QUICKSHIFTER+** (optional) is activated in the dashboard, you can shift down in the rev range indicated without pulling the clutch lever.




Note

The maximum engine speed in rpm before shifting down is shown in the figure.

Press the shift lever to the stop quickly without changing the throttle twist grip position.

11.8 Engine traction torque control



The **MSR** is a function of the engine control.

If the engine braking effect is too great, the **MSR** prevents the rear wheel from locking or sliding away on a sloping position.

To avoid slip of the rear wheel, the **MSR** only opens the throttle valve as far as absolutely necessary.

The **MSR** is applied on surfaces, where the friction coefficient is too low to open the slipper clutch.

To further increase ride safety, the **MSR** is slope dependent.



Note

When the **ABS** or active ABS mode **Supermoto** is switched off, the **MSR** is not active.

11.9 Braking



WARNING

Danger of accidents A spongy pressure point on the front or rear brake reduces the brake action.

- Do not drive the vehicle if the brake system has a spongy pressure point.



WARNING

Danger of accidents The brake system fails in the event of overheating. If the brake pedal is not released, the brake pads grind continuously.

- Take your foot off the brake pedal when you are not braking.



WARNING

Danger of accidents Braking with excessive force locks the wheels. The ABS effectiveness is only ensured if it is switched on.

- Leave the ABS switched on in order to benefit from the protective effect.



WARNING

Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake pads and the brake discs.



WARNING

Danger of accidents The rear wheel can lock due to the engine braking effect.

- Pull the clutch when performing emergency braking or braking on slippery surfaces.



WARNING

Danger of accidents Salt on the roads impairs the brake system.

- Brake carefully several times to remove salt from the brake linings and the brake discs.



WARNING

Danger of accidents ABS may increase the stopping distance in certain situations.

- Adapt your braking to the riding situation and the road conditions.



WARNING

Danger of accidents Higher total weight increases the stopping distance.

- Take the longer stopping distance into account when carrying a passenger or luggage with you.

- When braking, release the throttle and apply the front and rear brakes at the same time.



Note

When the **ABS** is enabled, maximum braking power can be applied even on surfaces with low road grip such as sandy, wet, or slippery terrain without the danger of the wheels locking.


WARNING

Danger of accidents The rear wheel can lock due to the engine braking effect.

- Pull the clutch when performing emergency braking or braking on slippery surfaces.


WARNING

Danger of accidents Banked or laterally sloping ground reduces the maximum possible delay.

- If possible finish braking before going into a bend.

- Always finish braking before you go into a bend. Shift into a lower gear that suits the speed.
- Use the brake action of the engine on long downhill stretches. To do so, shift back one or two gears, but do not overrev the engine. This means that significantly less braking is required and means the brake system does not overheat.



11.10 Stop, park


WARNING

Risk of injury People who act without authorization endanger themselves and others.

- Never leave the vehicle unattended while the engine is running.
- Lock the steering and remove the ignition key if you leave the vehicle unattended.


WARNING

Danger of burns Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Allow the vehicle parts to cool down before performing any work on the vehicle.


NOTE

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.


NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.

- Brake the motorcycle.
- Shift the transmission into the neutral position.
- Switch off the ignition by turning the ignition key to position .


Note

If the engine is switched off with the kill switch and the ignition remains switched on at the ignition lock, power continues to flow to most electrical loads. This discharges the 12-V battery. You should therefore always switch off the engine with the ignition lock – the kill switch is intended for emergencies only.

- Park the motorcycle on a firm surface.
- Swing side stand forward with your foot as far as it will go and lean the vehicle on it.
- Lock the steering by turning the handlebar fully to the left, pressing down the ignition key to position  and turning it to position . To make the steering lock engage more easily, move the handlebar a little to the left and right. Remove the ignition key.

11.11 Transportation



NOTE

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.




NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.



- Switch off the engine.
- Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.


11.12 Towing in the event of a breakdown



NOTE

Danger of damage Damage to the powertrain and transmission can occur when towing with a towing vehicle.

- Do not use towing equipment where the wheels of the broken down vehicle remain on the road and rotate as it is towed.
- Always transport a broken down vehicle on a trailer or on the loading area of a transport vehicle.



- Ensure that the broken down vehicle is properly secured on the trailer or transport vehicle.
- Observe local regulations for the recovery of broken down vehicles.

11.13 Refueling



DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.



WARNING

Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.



NOTE

Material damage Inadequate fuel quality can lead to losses in performance and consequential damage.


- Refuel only with clean fuel that meets the specified standards.



NOTE

Environmental hazard Improper handling of fuel is dangerous to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Switch off the engine.
- Open the fuel tank cap. (p. 25)
- Fill the fuel tank with fuel up to the lower edge **A** of the filler neck.

Fuel tank capacity, approx.	
Super unleaded (ROZ 95) (p. 210)	14.8 l (3.91 liq. gal _{US})

- Close the fuel tank cap. (p. 26)



W00620-10

12.1 Service schedule

Any further work that results from the service work must be ordered separately and invoiced separately.

Different service intervals may apply in your country, depending on the local operating conditions.

Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule is available for authorized contractual partners for the electronic proof of service. Your authorized contractual partner will be happy to advise you.

	Every 48 months					
	Every 24 months					
	Every 12 months					
	Every 30,000 km (18,641.1 mi)					
	Every 15,000 km (9,320.6 mi)					
	After 1,000 km (621.4 mi)					
Read out the fault memory using the diagnostics tool. 	○	●	●	●	●	●
Program the shift shaft sensor. 	○	●	●	●	●	●
Check that the electrical equipment is functioning properly. 	○	●	●	●	●	●
Check that the brake pads of the front brake are secured.  (p. 139)	○	●	●	●	●	●
Check that the brake pads of the rear brake are secured.  (p. 141)	○	●	●	●	●	●
Check the brake discs.  (p. 136)	○	●	●	●	●	●
Check the brake lines for damage and tightness. 	○	●	●	●	●	●
Check the brake fluid level for the front brake.  (p. 137)	○	●	●	●		
Change the brake fluid for the front brake. 					●	●
Check the brake fluid level for the rear brake.  (p. 140)	○	●	●	●		
Change the brake fluid for the rear brake. 					●	●
Check the free travel of the clutch lever.  (p. 181)	○	●	●	●	●	●
Check the free travel of the brake pedal.  (p. 139)	○	●	●	●	●	●
Change the engine oil and the oil filter, clean the oil screens.   (p. 178)	○	●	●	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and boots for cracking, leaks, and correct routing. 		●	●	●	●	●
Empty the drainage hoses. 	○	●	●	●	●	●
Check the cables for damage and that there are no kinks in the routing. 		●	●	●	●	●
Check the frame. 			●			
Check the swingarm. 			●			
Check the swingarm bearing for play. 		●	●			
Check the steering head bearing play. 	○	●	●			
Check the wheel bearing for play. 		●	●			
Check the shock absorber and fork for leaks. Perform a fork service and shock absorber service as needed, when possible and depending on how the vehicle is used. 	○	●	●	●	●	●
Check the tire condition.  (p. 150)	○	●	●	●	●	●
Check the tire pressure.  (p. 151)	○	●	●	●	●	●
Check the chain, rear sprocket, engine sprocket, and chain guide.  (p. 128)		●	●	●	●	●

	Every 48 months					
	Every 24 months					
	Every 12 months					
	Every 30,000 km (18,641.1 mi)					
	Every 15,000 km (9,320.6 mi)					
	After 1,000 km (621.4 mi)					
Check the chain tension.  (p. 126)	○	●	●	●	●	●
Grease all moving parts (e.g. side stand, hand lever, chain, etc.) and check for smooth operation. 	○	●	●	●	●	●
Change the spark plugs. 			●			
Check the valve clearance. 			●			
Change the air filter, clean the air filter box. 		●	●			
Check the fuel pressure and dampers of the fuel tank rollers. 		●	●	●	●	●
Check the headlight setting.  (p. 163)	○	●	●			
Check the tightness of the safety-relevant screws and nuts which are easily accessible. 	○	●	●	●	●	●
Clean the dust boots of the fork legs.   (p. 121)		●	●			
Check the frost protection and coolant level.  (p. 167)	○	●	●	●	●	
Change the coolant. 						●
Check that the radiator fan is functioning properly. 	○	●	●	●	●	●
Final check: Check the vehicle is roadworthy and take a test ride. 	○	●	●	●	●	●
Read out the fault memory after the test ride using the diagnostics tool. 	○	●	●	●	●	●
Set the service interval display. 	○	●	●	●	●	●
Make a service entry in the contractual partner portal. 	○	●	●	●	●	●

- One-time interval
- Periodic interval

13.1 Fork/shock absorber



The fork and the shock absorber offer many options for adapting the chassis to the riding style and the payload.

i Note
The recommendations for the suspension setting are shown in table 1. The table is located under the rider's seat.

These adjustments should be understood as guide values and should always be the basis for one's personal suspension setting. Do not change the adjustments at random, as otherwise the riding characteristics could deteriorate, particularly at high speeds.

13.2 Adjusting the compression damping of the fork

i Note
The hydraulic compression damping determines the fork suspension behavior.



- Turn white adjuster 1 clockwise as far as it will go.

i Note
The adjuster 1 **COMP** (white adjuster) is located at the upper end of the left fork leg.
The rebound damping **REB** (red adjuster) is located in the right fork leg.


- Turn counterclockwise by the number of clicks corresponding to the fork type.

Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	12 clicks
Full payload	15 clicks

i Note
Turning clockwise increases damping; turning counterclockwise reduces damping during compression.

13.3 Adjusting the rebound damping of the fork

i Note
The hydraulic rebound damping determines the fork suspension behavior.



- Turn red adjuster **1** clockwise as far as it will go.



Note

The adjuster **1** **REB** (red adjuster) is located at the upper end of the right fork leg.

The compression damping **COMP** (white adjuster) is located in the left fork leg.

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Rebound damping	
Comfort	14 clicks
Standard	12 clicks
Sport	10 clicks
Full payload	12 clicks



Note

Turning clockwise increases damping; turning anticlockwise reduces damping on rebound.



13.4 Adjusting the low-speed compression damping of the shock absorber



CAUTION


Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided.



Note

The effect of the low-speed compression adjustment can be seen in slow to normal compression of the shock absorber.



- Turn adjusting screw **1** clockwise with a screwdriver as far as the last perceptible click.

Do not loosen fitting **2**!

- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Low-speed compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	6 clicks



Note

Turn clockwise to increase damping; turn counterclockwise to reduce damping during slow to normal compression.



13.5 Adjusting the high-speed compression damping of the shock absorber



CAUTION


Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided.



Note

The effect of the high-speed compression adjustment can be seen in the fast compression of the shock absorber.



- Using an open end wrench, turn adjusting screw ① clockwise all the way.
- Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Do not loosen fitting ②!

High-speed compression damping	
Comfort	2 turns (720°)
Standard	2 turns (720°)
Sport	1.5 turns (540°)
Full payload	1 turn (360°)



Note

Turn clockwise to increase damping; turn counterclockwise to reduce damping during fast compression.


13.6 Adjusting the rebound damping of the shock absorber



CAUTION

Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided.



- Turn adjusting screw ① clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Rebound damping	
Comfort	16 clicks
Standard	12 clicks
Sport	6 clicks
Full payload	6 clicks



Note

Turning clockwise increases damping; turning anticlockwise reduces damping on rebound.



13.7 Adjusting the spring preload of the shock absorber



WARNING

Danger of accidents Modifications to the suspension settings that are not properly coordinated can impair the handling and overload components.

- Only make adjustments within the recommended range.
- Ride slowly to start with after making adjustments to get the feel of the new handling characteristics.



Note

The spring preload defines the initial status of the spring operation on the shock absorber.

The best spring preload setting is achieved when it is set for the weight of the rider and that of any luggage and a passenger, thus ensuring an ideal compromise between handling and stability.



- Adjust the spring preload by turning at adjusting device **1** using the hexagon socket wrench from the tool set.

Preload adjuster	
Comfort	3 turns (1,080°)
Standard	3 turns (1,080°)
Sport	3 turns (1,080°)
Full payload	7 turns (2,520°)




14.1 Raising the motorcycle with rear lifting gear



NOTE

Material damage The vehicle may be damaged if parked incorrectly. Damage can occur if the vehicle rolls away or falls over. The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.



- Mount the supports of the wheel stand.
- Insert the adapter in the rear wheel stand.

Retaining adapter (63529955000)
Rear wheel work stand (69329955000)

- Stand the motorcycle upright, align the wheel stand with the swingarm and the adapters, and raise the motorcycle.


14.2 Removing the rear of the motorcycle from the lifting gear



NOTE

Material damage The vehicle may be damaged if parked incorrectly. Damage can occur if the vehicle rolls away or falls over. The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.



- Secure the motorcycle against falling over.
- Remove the rear lifting gear and lean the vehicle on side stand 1.
- Remove the retaining adapter from the link fork.

14.3 Lifting the motorcycle with the front lifting gear



NOTE

Material damage The vehicle may be damaged if parked incorrectly. Damage can occur if the vehicle rolls away or falls over. The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.

Preparatory work

- Raise the motorcycle with the rear lifting gear.  (p. 120)
- Remove the brake manifold of the front brake.  (p. 142)


Main work

- Move the handlebar to the straight-ahead position. Position wheel stand at the front.

Always raise the motorcycle at the rear first.

Front wheel work stand, small (61129965100)

- Lift the motorcycle at the front.



14.4 Taking the motorcycle off the front lifting gear



NOTE

Material damage The vehicle may be damaged if parked incorrectly.


Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Make sure that nobody sits on the vehicle when it is parked on a stand.

Main work

- Secure the motorcycle against falling over.
- Remove the front lifting gear.




Reworking

- Mount the brake manifold of the front brake.  (p. 142)

14.5 Cleaning the dust boots of the fork legs

Preparatory work

- Raise the motorcycle with the rear lifting gear.  (p. 120)
- Remove the brake manifold of the front brake.  (p. 142)
- Lift the motorcycle with the front lifting gear.  (p. 120)



Main work

- Push dust boot **1** downward on both fork legs.

i Note

The dust boots should remove dust and coarse dirt particles from the inner fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.

- Clean and oil the dust boots and the inner fork tube of both fork legs.

Universal oil spray  (p. 211)

- Press the dust boots back into their installation position.
- Remove excess oil.

Reworking

- Take the motorcycle off the front lifting gear.  (p. 121)
- Mount the brake manifold of the front brake.  (p. 142)
- Remove the rear of the motorcycle from the lifting gear.  (p. 120)


14.6 Removing the passenger seat (optional)



Note

Observe the fitting instructions for **KTM PowerParts**.

The passenger seat can be fitted in the same way as the passenger seat cover.



- Insert the ignition key in seat lock **1** and turn it clockwise.
- Raise the front of the passenger seat, push it toward the fuel tank, and remove it upward.

Passenger seat (A60707047000C1B)

- Remove the ignition key from the seat lock.

14.7 Mounting the passenger seat (optional)



Note

Observe the fitting instructions for **KTM PowerParts**.

The passenger seat can be fitted in the same way as the passenger seat cover.



- Hook the holding lugs **1** of the passenger seat onto the storage compartment, lower the front and push backward.

Passenger seat (A60707047000C1B)


- Press the passenger seat downward until it clicks into place.



WARNING

Danger of accidents The seat can come loose from the anchoring if it is not mounted correctly.


- After assembly, check whether the seat is correctly locked and cannot be pulled up.



- Check that the passenger seat is mounted correctly.




14.8 Removing passenger seat cover



- Insert the ignition key in seat lock **1** and turn it clockwise.
- Raise the front of the passenger seat cover, push it toward the fuel tank, and remove it upward.
- Remove the ignition key from the seat lock.



14.9 Mounting the passenger seat cover



- Hook the holding lugs **1** of the passenger seat cover onto the storage compartment, lower the front and push backward.
- Press the passenger seat cover downward until it clicks into place.
- Check that the passenger seat cover is mounted correctly.


14.10 Remove the front rider's seat

Preparatory work

- Remove passenger seat cover.  (p. 123)
- Remove the passenger seat (optional).  (p. 122)

Main work




- Remove screws **1**.
- Lift the rear of the front rider's seat and carefully release it from the quick-release fastener, pull it back and remove it upward.



14.11 Mounting the front rider's seat

Main work

- Push the front rider's seat forward and lower at the rear.
 - ✓ The holding lugs ① engage in the loops A on the rear frame.
 - ✓ Holding lug ② engages in quick-release coupling B of the cross member.



- Mount and tighten screws ③.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _r)


- Check that the front rider's seat is mounted correctly.

Reworking

- Mount the passenger seat cover. (p. 124)
- Mount the passenger seat (optional). (p. 123)



14.12 Checking the chain for dirt



- Check the chain for coarse dirt accumulation.
 - » If the chain is very dirty:
 - Clean the chain. (p. 126)



14.13 Cleaning the chain

**WARNING**
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.

**WARNING**
Danger of accidents Lubricants on the tires reduces the road grip.


- Remove lubricants from the tires using a suitable cleaning agent.

**NOTE**
Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

**Note**
The service life of the chain depends largely on its maintenance.

- Preparatory work**
- Raise the motorcycle with the rear lifting gear.  (p. 120)



- Main work**
- Rinse off the loose dirt with a gentle jet of water.
 - Remove old grease residues with a chain cleaner.

Chain cleaner  (p. 216)
 - After drying, apply chain spray.

Street chain spray  (p. 211)

- Reworking**
- Remove the rear of the motorcycle from the lifting gear.  (p. 120)

14.14 Checking the chain tension

**WARNING**
Danger of accidents Incorrect chain tension can damage components and result in an accident.
If the chain tension is too high, the chain, front sprocket, rear sprocket, transmission, and rear wheel bearings wear more quickly. Some components may break if overloaded.
If the chain is too loose, the chain may fall off the front sprocket or the rear sprocket. This can damage the rear wheel or the engine.


- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with the rear lifting gear.  (p. 120)

Main work

- Shift the transmission into the neutral position.
- Push the chain behind the chain sliding piece up and determine the chain tension **A** between the link fork and the upper edge of the chain.



Distance B from the chain sliding piece	2.5 cm (0.98 in)
Measure the distance from the flat part of the link fork directly above the chain, not from the edge of the link fork.	
Chain tension	2 mm ... 5 mm (0.08 in ... 0.20 in)
The top part of chain C must be taut.	
Chain wear is not always even, so repeat this measurement at different positions on the chain.	

- » If the chain tension does not meet the specification:
 - Adjust the chain tension.  (p. 127)

Reworking

- Remove the rear of the motorcycle from the lifting gear.  (p. 120)



14.15 Adjusting the chain tension



WARNING

Danger of accidents Incorrect chain tension can damage components and result in an accident.


If the chain tension is too high, the chain, front sprocket, rear sprocket, transmission, and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the front sprocket or the rear sprocket. This can damage the rear wheel or the engine.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with the rear lifting gear.  (p. 120)
- Check the chain tension.  (p. 126)



Main work

- Loosen nut 1.
- Loosen nuts 2.
- Adjust the chain tension by turning adjusting screws 3 on the left and right.

Chain tension	2 mm ... 5 mm (0.08 in ... 0.20 in)
In order for the rear wheel to be correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to reference markings A.	
The upper part of the chain must be taut.	
Chain wear is not always even. Repeat this measurement at different chain positions.	

- Tighten nuts 2.
- Make sure that chain tension adjusters 4 are fitted correctly on adjusting screws 3.
- Tighten nut 1.

Nut, wheel spindle, rear	
M25×1.5	90 Nm (66.4 ft·lb _f) Long-life grease

Note
Chain tension adjusters 4 can be turned.

Reworking

- Check the chain tension. (p. 126)
- Remove the rear of the motorcycle from the lifting gear. (p. 120)

14.16 Checking the chain, rear sprocket, front sprocket, and chain guide


Preparatory work


- Raise the motorcycle with the rear lifting gear. (p. 120)

Main work

- Check the rear sprocket and the front sprocket for wear.
 - » If the rear sprocket and engine sprocket are worn:
 - Change the drivetrain kit.

Always replace the front sprocket, rear sprocket, and chain together.





- Shift the transmission into the neutral position.
- Pull on the lower chain section with specified weight **A**.

Weight, chain wear measurement	15 kg (33.1 lb)
--------------------------------	--------------------

- Measure distance **B** of chain rollers in the lower chain section.

Chain wear is not always even, so repeat this measurement at different positions on the chain.

Maximum distance B of chain rollers at the longest chain section	272 mm (10.71 in)
---	----------------------


- » If distance **B** is greater than the specified measurement:
 - Change the drivetrain kit.

When installing a new chain, also replace the rear sprocket and front sprocket.

Note


New chains wear out faster on old, worn sprockets.

For safety reasons, the chain has no chain joint.




- Check the engine sprocket cover **1** for tightness.
 - » If the engine sprocket cover is loose:
 - Tighten the screws on the engine sprocket cover.


Screw, front sprocket cover	
M5	5 Nm (3.7 ft·lb _f) Loctite® 243



- Check chain sliding piece **2** for wear.
 - » If the chain sliding piece is highly worn in the marked area **C**:
 - Change the chain slider.
- Check that chain sliding piece **2** is firmly seated.
 - » If the chain slider is loose:
 - Tighten the screws on the chain slider.

Remaining screws on chassis	
M8	25 Nm (18.4 ft·lb _f)





- Check the chain slider at the top for wear.
 - » If continuous signs of wear to the chain are visible on the chain slider in the areas **D** marked:
 - Change the chain slider. 🔧
 - » If the chain slider is highly worn in the marked area **E**:
 - Change the chain slider. 🔧
- Check that the chain slider is firmly seated.
 - » If the chain slider is loose:
 - Tighten the screws of the chain slider.

Remaining screws on chassis	
M5	5 Nm (3.7 ft·lb _r)

Reworking

- Remove the rear of the motorcycle from the lifting gear. 📖 (p. 120)

14.17 Removing the right tank spoiler


Preparatory work

- Remove passenger seat cover. 📖 (p. 123)
- Remove the passenger seat (optional). 📖 (p. 122)
- Remove the front rider's seat. 📖 (p. 124)

Main work

- Remove screws **1**.





- Remove screw ② and screw ③.
- Remove screws ④ and screw ⑤.
- Detach the fuel tank spoiler in the areas A and carefully remove it.


14.18 Installing the right tank spoiler

Main work

- Attach the fuel tank spoiler in the areas A and engage it.
- Mount and tighten screw ① and screw ②.
- Mount and tighten screw ③ and screws ④.

Screw, trim	
M5	3.5 Nm (2.58 ft·lb _r)

Screw, trim	
M5	3.5 Nm (2.58 ft·lb _r)





- Mount and tighten screws 5.

Screw, trim	
M5	3.5 Nm (2.58 ft·lb _f)

Reworking

- Mount the front rider's seat. (p. 125)
- Mount the passenger seat cover. (p. 124)
- Mount the passenger seat (optional). (p. 123)


14.19 Removing the left tank spoiler


Preparatory work

- Remove passenger seat cover. (p. 123)
- Remove the passenger seat (optional). (p. 122)
- Remove the front rider's seat. (p. 124)

Main work

- Remove screws 1.






- Remove screw 2 and screw 3.
- Remove screws 4 and screw 5.
- Detach fuel tank spoiler in the areas A and carefully remove it.

14.20

Installing the left tank spoiler




Main work

- Attach the fuel tank spoiler in the areas A and engage it.
- Mount and tighten screw 1 and screw 2.
- Mount and tighten screw 3 and screws 4.

Screw, trim	
M5	3.5 Nm (2.58 ft·lb _r)

Screw, trim	
M5	3.5 Nm (2.58 ft·lb _r)



- Mount and tighten screws 5.

Screw, trim	
M5	3.5 Nm (2.58 ft·lb _f)

Reworking

- Mount the front rider's seat. (p. 125)
- Mount the passenger seat cover. (p. 124)
- Mount the passenger seat (optional). (p. 123)



15.1 Anti-lock braking system



WARNING

Danger of accidents Changes to the vehicle impair the function of the ABS.

- Do not make any changes to the suspension travel.
- Only use spare parts on the brake system which have been approved and recommended by the vehicle manufacturer.
- Only use tires and wheels approved and recommended by the vehicle manufacturer with the corresponding speed rating.
- Maintain the specified tire pressure.
- Ensure that service work and repairs are performed professionally.




WARNING

Danger of accidents Driving aids can reduce the probability of a fall only within physical limits.

It is not always possible to compensate for certain riding situations, for example with luggage loaded with a high center of gravity, varying road surfaces, steep descents or full braking without disengaging the gear.

- Adapt your riding style to the road conditions and your driving ability.



The **ABS** module **1**, which consists of a hydraulic unit, ABS control unit, and return pump, is installed under the fuel tank. One wheel speed sensor **2** is located in each case on the front and the rear wheel.



WARNING

Danger of accidents An incorrectly selected ABS mode makes it more difficult to control the vehicle. The ABS modes are each only suitable for certain conditions.

- Always select an ABS mode that suits the ground and the riding situation.

The **ABS** is a safety system that prevents the wheels locking when driving straight ahead or when cornering (within the limits of physics).

The ABS control is dependent on the riding mode. ABS has two operating modes: the **Road** and **Supermoto** ABS modes.

In ABS mode **Road**, ABS controls both wheels.

In ABS mode **Sport**, the ABS controls both wheels and allows more brake pressure on the front wheel.

In ABS mode **Supermoto**, there is no ABS control on the rear wheel, allowing for more slip on the front wheel.

In ABS mode **Supermoto+**, the ABS controls both wheels and allows more slip on the front and rear wheels.

Note
The curve-dependent control is only active in ABS mode **Road** and **Sport**.

The ABS operates with two independent brake circuits (front and rear brakes). When the ABS control unit detects a locking tendency in a wheel, ABS begins regulating the brake pressure. The control function causes a slight pulsing of the hand and foot brake levers.


The ABS warning light **3** must light up after the ignition is switched on and go out after starting off. If it does not go out after starting off or if it is lit while riding, this indicates a fault in the ABS. In this case, the ABS is no longer enabled and the wheels may lock during braking. The brake system itself stays functional; only ABS control is not available.

The ABS warning lamp may also light up if the rotating speeds of the front and rear wheels differ greatly under extreme riding conditions, for example when making "wheelies" or if the rear wheel spins. This causes the ABS to switch off.

To reactivate the ABS, stop the vehicle and switch off the ignition. The ABS is reactivated when the vehicle is switched on again. The ABS warning light goes out after starting off.

15.2 Checking the brake discs

WARNING
Danger of accidents Worn-out brake discs reduce the braking action.
– Make sure that worn-out brake discs are replaced immediately.



- Check the brake disc thickness of the front and rear brake disc at several places on the disc to see if they conform to measurement **A**.

Brake disc wear limit	
front	4.5 mm (0.177 in)
rear	4.5 mm (0.177 in)

Note
Wear will reduce the thickness of the brake disc at contact surface **1** of the brake linings.

- » If the brake disc thickness is less than the specified value.
 - Change the front brake discs. 🛠️
 - Change the brake discs on the rear brake. 🛠️

- Check the front and rear brake discs for damage, cracks, and deformation.
 - » If the brake disc shows signs of damage, cracks, or deformation:
 - Change the front brake discs. 🔧
 - Change the brake discs on the rear brake. 🔧



15.3 Checking the brake fluid level for the front brake



WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.




WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



- Move the brake reservoir mounted on the handlebar to a horizontal position.
- Check brake fluid level in brake fluid reservoir ①.
 - » If the brake fluid level has dropped below **MIN** marking ②:
 - Add brake fluid for the front brake. 🔧 📖 (p. 137)



15.4 Adding brake fluid for the front brake 🔧



WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.



WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



WARNING

Health hazard Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
- Consult a doctor immediately if brake fluid has been ingested.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



NOTE

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note


Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work

- Check that the brake pads of the front brake are secured.
 (p. 139)


Main work

- Move the brake reservoir mounted on the handlebar to a horizontal position.
- Remove screws **1**.
- Take off cover **2** with diaphragm **3**.
- Add brake fluid up to the **MAX** marking **A**.
- Position cover **2** with diaphragm **3**.



Brake fluid DOT 5.1  (p. 212)

- Mount and tighten screws **1**.



Brake fluid reservoir cover, front


M4

1 Nm
(0.7 ft·lb_f)

Immediately clean up any brake fluid that has overflowed or spilled with water.

15.5Checking that the brake pads of the front brake are secured

- WARNING**
Danger of accidents Worn brake pads reduce the brake action.
– Make sure that worn brake pads are replaced immediately.
- WARNING**
Danger of accidents Damaged brake discs reduce the braking action.
If the brake linings are not changed in time, the brake lining carriers grind against the brake disc. As a consequence, the brake action is greatly reduced and the brake discs are destroyed.
– Check the brake linings regularly.




- Check all brake pads on both brake calipers for their lining thickness **A**.

Minimum pad thickness A	≥ 1 mm (≥ 0.04 in)
--------------------------------	-----------------------

 - » If it is less than the minimum thickness:
 - Change the front brake pads.
- Check the brake pads for damage and cracking:
 - » If there is damage or cracking:
 - Change the front brake pads.
- Check that the brake pads are secured.
 - » If the brake pads are not secured correctly:
 - Secure brake pads, replace with new parts if necessary.

15.6Checking the free travel of the brake pedal

- WARNING**
Danger of accidents The brake system fails in the event of overheating.
If there is no free travel on the brake lever, pressure builds up in the brake system.
– Set the free travel on the brake lever as specified.



- Detach spring **1**.
- Move the brake pedal back and forth between the end stop and the brake pedal cylinder piston actuation and check free travel **A**.

Free travel of brake pedal	3 mm ... 5 mm (0.12 in ... 0.20 in)
----------------------------	--

 - » If the free travel does not meet the specifications:
 - Adjust the basic position of the brake pedal.
 - (p. 99)
- Attach spring **1**.

15.7 Checking the brake fluid level for the rear brake



WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.




WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



- Stand the vehicle upright.
- Check the brake fluid level in the brake fluid reservoir.
 - » If the fluid level reaches the **MIN** marking ①:
 - Add brake fluid for the rear brake. 🛠️ 📖 (p. 140)

15.8 Adding brake fluid for the rear brake 🛠️



WARNING

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
- Make sure that only clean, approved brake fluid from a tightly sealed container is used.



WARNING

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.

- Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



WARNING

Health hazard Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
- Consult a doctor immediately if brake fluid has been ingested.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



NOTE

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work

- Check that the brake pads of the rear brake are secured.
 (p. 141)

Main work

- Stand the vehicle upright.
- Loosen the brake fluid reservoir screw.
- Guide the brake fluid reservoir to the front.
- Remove screw cover **1** with insert and membrane **2**.
- Add brake fluid up to the **MAX** marking **A**.

Brake fluid DOT 5.1  (p. 212)

- Mount and tighten screw cover with insert and membrane.

Immediately clean up any brake fluid that has overflowed or spilled using water.


- Guide the brake fluid reservoir to the bracket and mount it with the screw.

Remaining screws on chassis

M5

5 Nm
(3.7 ft·lb_f)

Do not kink the brake fluid hose.



15.9 Checking that the brake pads of the rear brake are secured



WARNING

Danger of accidents Worn brake pads reduce the brake action.

- Make sure that worn brake pads are replaced immediately.




WARNING

Danger of accidents Damaged brake discs reduce the braking action.

If the brake linings are not changed in time, the brake lining carriers grind against the brake disc. As a consequence, the brake action is greatly reduced and the brake discs are destroyed.

- Check the brake linings regularly.




- Check all brake pads on both brake calipers for their lining thickness **A**.

Minimum pad thickness A	≥ 1 mm (≥ 0.04 in)
--------------------------------	-----------------------


 - » If it is less than the minimum thickness:
 - Change the rear brake pads. 
- Check the brake pads for damage and cracking.
 - » If there is damage or cracking:
 - Change the rear brake pads. 
- Check that the brake pads are secured.
 - » If the brake pads are not secured correctly:
 - Secure brake pads, replace with new parts if necessary.

15.10 Removing the brake manifold of the front brake



- Remove the screw **1**.
- Push the brake manifold **2** carefully to the side.

15.11 Mounting the brake manifold of the front brake



- Position the brake manifold **1**.
- Mount and tighten screw **2**.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _f)

16.1 Removing the front wheel

Preparatory work

- Raise the motorcycle with the rear lifting gear. (p. 120)
- Remove the brake manifold of the front brake. (p. 142)
- Lift the motorcycle with the front lifting gear. (p. 120)



Main work

- Remove screw ① and pull wheel speed sensor ② out of the hole.
- Remove screws ③.
- Press back the brake linings by slightly tilting the left brake caliper laterally on the brake disc.
- Pull the left brake caliper carefully back from the brake disc and hang to the side.


Do not operate the hand brake lever if the brake caliper has been removed.

- Remove screws ④.
- Press back the brake linings by slightly tilting the right brake caliper laterally on the brake disc.
- Pull the right brake caliper carefully back from the brake disc and hang to the side.

Do not operate the hand brake lever if the brake caliper has been removed.



A02702-10



A02703-10

- Loosen screw ⑤ by four turns.
- Loosen screws ⑥.
- Press on screw ⑤ to push the wheel spindle out of the fork shoe.
- Remove screw ⑤.




WARNING

Danger of accidents Damaged brake discs reduce the braking action.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Hold front wheel and remove wheel spindle. Take the front wheel out of the fork.




- Remove spacers 7.

16.2 Installing the front wheel

WARNING


Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the front wheel bearing.
- Clean and grease radial shaft seal 1 and contact surfaces A on the spacers.

Long-life grease (p. 211)




- Insert wide spacer 2 on the left in the direction of travel.
- Insert narrow spacer 3 on the right in the direction of travel.

Note

Arrow B indicates the direction of travel of the front wheel.


The wheel speed sensor wheel is on the left viewed in the direction of travel.



- Clean screw 4 and the wheel spindle.
- Grease wheel spindle lightly.
- Jack up the front wheel into the fork, position it, and insert the wheel spindle.
- Mount and tighten screw 4.

Long-life grease (p. 211)	
Screw, wheel spindle, front	
M25×1.5	45 Nm (33.2 ft·lb _f)

 **Tip**
Temporarily tighten one of the axle clamp screws so that the axle does not rotate with it.
Loosen the axle clamp screw again before compression to allow the fork legs to align.



- Position both brake calipers.
✓ The brake linings are correctly positioned.
- Mount screws 5 on both sides but do not tighten yet.
- Operate the hand brake lever repeatedly until the brake pads are in contact with the brake disc and a pressure point is reached. Secure the hand brake lever in the activated position.
✓ The brake calipers straighten.
- Tighten screws 5 on both sides.


Screw, front brake caliper	
M10×1.25	45 Nm (33.2 ft·lb _f) Loctite® 243

Screw, front brake caliper	
M10×1.25	45 Nm (33.2 ft·lb _f) Loctite® 243

- Position wheel speed sensor 6 in the hole.
- Mount and tighten screw 7.

Screw, wheel speed sensor	
M6	6 Nm (4.4 ft·lb _f)

- Remove the locking piece of the hand brake lever.
- Take the motorcycle off the front lifting gear. (p. 121)
- Remove the rear of the motorcycle from the lifting gear. (p. 120)



- Operate the front brake and compress the fork a few times firmly.
✓ The fork legs straighten.
- Tighten screws **8**.

Screw, fork shoe	
M8	15 Nm (11.1 ft·lb _f)




16.3 Removing the rear wheel

Preparatory work

- Raise the motorcycle with the rear lifting gear.  (p. 120)

Main work

- Manually press the brake caliper toward the brake disc to push back the brake pistons.
- Remove screw **1** and pull wheel speed sensor **2** out of the hole.
- Remove nut **3**. Remove chain tension adjuster **4**.
- Pull out wheel spindle **5** far enough to allow the rear wheel to be pushed forward.



- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.

Protect the components against damage by covering them.

- Hold the rear wheel and remove wheel spindle.
- Pull the rear wheel back until the brake caliper bracket is suspended freely between the brake disc and rim.

**WARNING**
Danger of accidents Damaged brake discs reduce the braking action.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Take the rear wheel out of the swingarm.

Do not actuate the brake pedal when the rear wheel is removed.



16.4 Installing the rear wheel



WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.



WARNING

Danger of accidents There is no braking effect to start with at the rear brake after installing the rear wheel.

- Actuate the foot brake several times before going on a ride until you can feel a firm pressure point.

Main work

- Check the rear hub damping rubber pieces.   (p. 149)
- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the rear wheel bearing. 
- Remove spacer.
- Clean and grease shaft seal ring **1** and contact surface **A** of the spacer.

Long-life grease  (p. 211)


- Insert a spacer.
- Clean and grease the thread of the wheel spindle and nut.


Long-life grease  (p. 211)

- Clean and lightly grease the wheel spindle.


Long-life grease  (p. 211)

- Clean the contact areas on the brake caliper bracket and link fork.





- Lift the rear wheel into the link fork, position it, and insert wheel spindle ②.
- ✓ The brake pads are positioned correctly.
- Place the chain on the sprocket.



- Position chain tension adjuster ③. Mount nut ④ but do not tighten yet.

Mount the left and right chain adjusters in the same position.

- Make sure that chain adjusters ③ are fitted correctly on the adjusting screws. Tighten nut ④.

In order for the rear wheel to be correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to reference markings B.

Nut, wheel spindle, rear	
M25×1.5	90 Nm (66.4 ft·lb _f) Long-life grease

- Position wheel speed sensor ⑤ in the hole.
- Mount and tighten screw ⑥.

Screw, wheel speed sensor	
M6	6 Nm (4.4 ft·lb _f)

- Actuate the brake pedal repeatedly until the brake pads are in contact with the brake disc and a pressure point is achieved.

Reworking

- Check the chain tension. 📖 (p. 126)
- Remove the rear of the motorcycle from the lifting gear. 📖 (p. 120)

16.5 Checking the rear hub damping rubber pieces


Note
The engine power is transmitted from the rear sprocket to the rear wheel via the 6 damping rubber pieces. They eventually wear out during operation. If the damping rubber pieces are not changed in time, the rear sprocket carrier and the rear hub will be damaged.

Preparatory work


- Raise the motorcycle with the rear lifting gear.  (p. 120)
- Remove the rear wheel.   (p. 146)

Main work

- Check bearing **1**.
 - » If the bearing is damaged or worn:
 - Change the bearing of the rear sprocket carrier. 
- Check damping rubber pieces **2** of the rear hub for damage and wear.
 - » If the damping rubber pieces of the rear hub are damaged or worn:
 - Change all the damping rubber pieces of the rear hub.



- Lay the rear wheel on a workbench with the rear sprocket facing upwards and insert the wheel spindle in the hub.
- To check play **A**, hold the rear wheel tight and try to turn the rear sprocket with your hand.



Play of damping rubber pieces on rear wheel	$\leq 5\text{ mm}$ ($\leq 0.20\text{ in}$)
---	---

Note
Measure the play on the outside of the rear sprocket.

- » If clearance **A** is larger than the specified value:
 - Change all the damping rubber pieces of the rear hub. 

Reworking

- Install the rear wheel.   (p. 147)
- Check the chain tension.  (p. 126)
- Remove the rear of the motorcycle from the lifting gear.  (p. 120)

16.6 Checking the tire condition

**WARNING**
Danger of accidents If a tire bursts while riding, the vehicle becomes uncontrollable.
– Ensure that damaged or worn tires are replaced immediately.

**WARNING**
Danger of accidents Non-approved or non-recommended tyres and wheels impact the handling characteristic.
– Only use tires and wheels approved and recommended by the vehicle manufacturer with the corresponding speed rating.

**WARNING**
Danger of accidents New tires have reduced road grip.
The contact surface on new tires is not yet roughened.
– Run in new tires with moderate riding and only gradually increase the lean angle.

Run-in distance	200 km (124.3 mi)
-----------------	----------------------

**WARNING**
Danger of accidents Different tire profiles on the front and rear wheels can make it more difficult to control the vehicle.
– Make sure that only tires of the same tread type are mounted to the front and rear wheel.

**Note**


The type, condition, and pressure of the tires all have a major impact on the braking and handling of the motorcycle.

Worn tires have a negative effect on handling characteristics, especially on wet surfaces.

Tires must not be moved or loaded while they are cold.

Tires must not be stored or fitted when too cold.

Observe the tire manufacturer's specifications and recommendations.




- Check the front and rear tires for cuts, embedded objects, and other damage.
 - » If the tires have cuts, run-in objects, or other damage:
 - Change the tires. 
- Check the tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)
---------------------	-----------------------

**Note**

Observe the minimum tread depth required by national law.

- » If the tread depth is less than the minimum tread depth:
 - Change the tires. 



- Check the tire age.



Note

The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.

KTM recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

- » If the tires are older than five years:
 - Change the tires.




16.7 Checking the tire pressure



Note

Low tire pressure leads to abnormal wear and the tire overheating.

Correct tire pressure ensures optimal riding comfort and maximum tire service life.



- Remove the protection cap.
- Check the tire pressure when the tires are cold.

Tire pressure when solo	
front	2.3 bar (33.4 psi)
rear	2.5 bar (36.3 psi)

Tire pressure with passenger / full payload	
front	2.3 bar (33.4 psi)
rear	2.6 bar (37.7 psi)

- » If the tire pressure does not meet specifications:
 - Correct tire pressure.
- Mount the protection cap.



16.8 Using tire repair spray



WARNING

Danger of accidents Incorrect use of tire repair spray will result in the repaired tire losing pressure. Tire repair spray cannot be used for all types of damage.


- Observe the instructions and specifications of the manufacturer of the tire repair spray.
- After repairing a tire with tire repair spray, ride slowly and carefully.
- Ride no further than the nearest authorized dealer and have the tire replaced.



NOTE

Material damage Tire repair spray damages the tire pressure sensor.

- Note that after using tire repair spray, the tire pressure sensor may need to be replaced.
-



Tire repair spray should only be used in an emergency.
Transporting the broken-down vehicle to the nearest authorized dealer is recommended instead of repairing it.


17.1 daytime running light



WARNING

Danger of accidents When visibility is poor, the daytime running light is not a substitute for the low beam. Automatic switching between the daytime running light and low beam may only be partially available when visibility is impaired due to fog, snow or rain.

- Ensure that the appropriate type of lighting is always selected.
- If necessary switch off the daytime running lights using the menu before going on a ride or when stopped so that the low beam is switched on permanently.
- Make sure that the daytime running light is deactivated with the diagnostic tool when the menu item is not available, but the low beam is required.
- Note the legal regulations regarding the daytime running light.



The daytime running light ① (DRL) is integrated in the main headlight.

The daytime running light ① (DRL) must only be switched on when visibility conditions are good.


The daytime running light ① (DRL) is activated on the dashboard. This is controlled by the ambient light sensor in the combination instrument. When visibility conditions are good, the low beam is switched off and the daytime running light is switched on.



Note

The daytime running light ① lights up with all types of lighting.

17.2 Low beam



The low beam ① is integrated into the main headlight.

The low beam ① is activated when the ignition is switched on.

To save power in the 12-V battery, the low beam ① is deactivated again after 5 seconds if the engine is not started.

If the ignition is inadvertently switched off during the trip, the low beam ① stays on.

17.3 high beam



The high beam ① is integrated in the main headlight.

17.4 Removing the 12 V battery



WARNING

Danger of accidents Electronic components and safety devices will be damaged if the 12-V battery is discharged or missing.

If the 12-V battery is discharged or defective, malfunctions in the vehicle electronics can occur, especially when starting.

- Never operate the vehicle with a discharged 12-V battery or without a 12-V battery.



WARNING

Risk of injury Battery acid and battery gases cause chemical burns.



- Keep 12-V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.

Preparatory work


- Remove passenger seat cover. (p. 123)
- Remove the passenger seat (optional). (p. 122)
- Remove the front rider's seat. (p. 124)

Main work


- Remove positive terminal cover **1**.



- Disconnect negative cable **2** from the 12 V battery.
- Disconnect positive cable **3** from the 12-V battery.



- Remove screws ④ with the seat lock and secure to the front.
- Remove screws ⑤.
- Remove screws ⑥ and remove the retaining cable.
- Remove cross member ⑦.



- Remove screws ⑧ and remove battery support ⑨.
- Take the battery ⑩ out of the battery compartment.

17.5 Installing the 12 V battery

Main work

- Position 12-V battery ① in the battery compartment.


12 V battery (HTZ12A-BS) (p. 213)

✓ The battery terminals face opposite the direction of travel.

- Position battery support bracket ②.
- Mount and tighten screws ③.

Screw, battery holding bracket

M5	3.5 Nm (2.58 ft·lb _f)
----	--------------------------------------



- Position cross member ④.
- Mount screws ⑤ with the retaining cable but do not tighten yet.

Remaining screws on chassis


M6	10 Nm (7.4 ft·lb _f)
----	------------------------------------



- Mount and tighten screws ⑥.

Remaining screws on chassis

M6	10 Nm (7.4 ft·lb _f)
----	------------------------------------

- Tighten screws ⑤.





Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _f)

- Position the seat lock and mount and tighten screws 7.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb _f)

- Connect positive cable 8 to the 12 V battery.

Screw, battery terminal	
M6×12	4.5 Nm (3.32 ft·lb _f)

- Connect negative cable 9 to the 12 V battery.

Screw, battery terminal	
M6×12	4.5 Nm (3.32 ft·lb _f)

- Mount positive terminal cover 10.

Reworking

- Mount the front rider's seat. (p. 125)
- Mount the passenger seat cover. (p. 124)
- Mount the passenger seat (optional). (p. 123)
- Set the time and date. (p. 165)

17.6 Charging the 12 V battery

WARNING

Risk of injury Battery acid and battery gases cause chemical burns.

- Keep 12-V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.



NOTE

Environmental hazard 12-V batteries contain environmentally-hazardous materials.

- Do not dispose of 12-V batteries as household waste.
- Dispose of 12-V batteries at a collection point for used batteries.



NOTE

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note

Even when there is no load on the 12 V battery, it discharges steadily each day.

The state of charge and the method of charging are very important for the service life of the 12 V battery.

Rapid recharging with a high charging current shortens the service life of the battery.

If the charging current, charging voltage, or charging time is exceeded, electrolyte escapes through the safety valves. This reduces the capacity of the 12-V battery.

If the 12-V battery is left in a discharged state for an extended period, it will become over-discharged and will be irreparably damaged.


The 12 V battery is maintenance-free.

Preparatory work

- Remove passenger seat cover. (p. 123)
- Remove the passenger seat (optional). (p. 122)
- Remove the front rider's seat. (p. 124)

Main work

- Disconnect negative cable **1** from the 12 V battery to avoid damaging the onboard electronics.
- Remove positive terminal cover **2**.



- Connect a charger to the 12 V battery. Connect the battery charger to the mains connection.

EU battery charger TecMATE Optimate PRO (A61029974044)

Work material (Alternative 1 / 2)
--

USA/CA battery charger TecMATE Optimate PRO (A61029974144)
--

Work material (Alternative 2 / 2)
--

Battery charger TecMATE Optimate PRO UK (A61029974244)
--


- 

Note
After charging, the battery charger can remain on the vehicle, ensuring that the battery voltage is maintained during the maintenance charging cycle.
- 

Note
It is impossible to overcharge the 12-V battery using this battery charger.

- Disconnect the battery charger from the mains connection and the 12-V battery after charging.

The charging current, charging voltage, and charging time must not be exceeded.	
If the 12 V battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.	
Recharge the 12 V battery regularly when the motorcycle is not being used.	3 months



- Mount positive terminal cover **2**.
- Connect negative cable **1** to the 12 V battery.

Screw, battery terminal	
M6×12	4.5 Nm (3.32 ft·lb _r)

- Reworking**
- Mount the front rider's seat.  (p. 125)
 - Mount the passenger seat cover.  (p. 124)
 - Mount the passenger seat (optional).  (p. 123)
 - Set the time and date.  (p. 165)

17.7 Changing the main fuse



WARNING
Fire hazard Incorrect fuses overload the electrical system.

- Use only fuses with the prescribed amperage.
- Do not bypass or repair fuses.

- 


Note
The main fuse protects all electrical power loads of the vehicle. The main fuse is under the front rider's seat.

Preparatory work

- Remove passenger seat cover.  (p. 123)
- Remove the passenger seat (optional).  (p. 122)
- Remove the front rider's seat.  (p. 124)

Main work

- Remove protection cap **1**.



- Remove faulty main fuse **2**.




Note

A faulty fuse has a burned-out fuse wire **A**.
A spare fuse **3** is located in the starter relay.

- Insert the main fuse.


Fuse (58011109130)  (p. 214)



Tip

Insert a new spare fuse into the starter relay to have it available when needed.

- Mount protection cap **1**.



Reworking

- Mount the front rider's seat.  (p. 125)
- Mount the passenger seat cover.  (p. 124)
- Mount the passenger seat (optional).  (p. 123)
- Set the time and date.  (p. 165)

17.8 Changing the ABS fuses



WARNING

Fire hazard Incorrect fuses overload the electrical system.

- Use only fuses with the prescribed amperage.
- Do not bypass or repair fuses.



Note

Two fuses for the ABS are located under the rider's seat. These fuses protect the return pump and the hydraulic unit of the ABS. The third fuse, which protects the ABS control unit, is located in the fuse box.

Preparatory work

- Remove passenger seat cover. (p. 123)
- Remove the passenger seat (optional). (p. 122)
- Remove the front rider's seat. (p. 124)

Main work

- Select one of the following alternatives.

Changing the fuse of the ABS hydraulic unit

- Remove the protection cap and fuse ❶.



Note

A faulty fuse has a burned-out fuse wire **A**.

- Insert the spare fuse with the correct rating.

Fuse (75011088010) (p. 214)



Tip

Insert spare fuse ❷ in the fuse box so that it is available if needed.

- Mount the protection cap.

Changing the fuse of the ABS return pump

- Remove the protection cap and fuse ❸.



Note

A faulty fuse has a burned-out fuse wire **A**.

- Insert the spare fuse with the correct rating.



Fuse (75011088025) (p. 214)



Tip

Insert spare fuse ❹ in the fuse box so that it is available if needed.

- Mount the protection cap.



Reworking

- Mount the front rider's seat.  (p. 125)
- Mount the passenger seat cover.  (p. 124)
- Mount the passenger seat (optional).  (p. 123)



17.9 Changing the fuses of individual electrical power consumers



WARNING

Fire hazard Incorrect fuses overload the electrical system.

- Use only fuses with the prescribed amperage.
- Do not bypass or repair fuses.



Note


The fuse box containing the fuses of individual electrical power consumers is located under the rider's seat.

Preparatory work

- Remove passenger seat cover.  (p. 123)
- Remove the passenger seat (optional).  (p. 122)
- Remove the front rider's seat.  (p. 124)

Main work

- Open fuse box cover **1**.



- Remove the faulty fuse.

Fuse 1 - 5 A - ignition, vehicle system control unit, alarm system

Fuse 2 - 10 A - ACC1

Fuse 3 - 10 A - power supply power relay

Fuse 4 - 15 A - ACC2, USB charging port, HCU (optional)
--

Fuse SPARE - 5 A/10 A/15 A - spare fuses



Note

A faulty fuse has a burned-out fuse wire **A**.

- Insert the spare fuse with the correct rating.

Fuse (75011088005)  (p. 214)

Fuse (75011088010)  (p. 214)

Fuse (75011088015)  (p. 214)



Tip
Put a spare fuse in the fuse box so that it is available if needed.


- Check the function of the electrical power consumer.
- Close the fuse box cover.

Reworking


- Mount the front rider's seat. (p. 125)
- Mount the passenger seat cover. (p. 124)
- Mount the passenger seat (optional). (p. 123)

17.10 Remove the mask support cover with headlight.

i Note
The mask support cover with headlight must be removed in order to gain access to the ACC1 and ACC2 power supply.




- Remove screws **1**.



- Remove screws **2**, **3** and **4**.
- Take off the mask support cover together with the headlight and place them on a soft cloth.


17.11 Mounting the mask support cover with headlight



- Position the headlights in the mask support.
- Mount screw **1** and bushing and tighten.

Screw, lower mask support	
M6	6 Nm (4.4 ft·lb _r)

- Mount and tighten screws **2**.



Screw, mask support	
M5	3.5 Nm (2.58 ft·lb _f)

- Mount and tighten screws ③.


Screw, mask support	
M5	3.5 Nm (2.58 ft·lb _f)

- Mount and tighten screws ④.

Remaining screws on chassis	
M5	5 Nm (3.7 ft·lb _f)



17.12 Checking the headlight setting



- Park the vehicle on a horizontal surface in front of a light-colored wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance ② under the first marking.

Distance ②	5 cm (2.0 in)
------------	------------------

- Position the vehicle upright at distance ① from the wall and switch on the low beam.

Distance ①	5 m (16 ft – 5 in)
------------	-----------------------

- Get on the motorcycle, together with any luggage or passenger.
- Check the headlight adjustment.

The light-dark boundary must lie exactly on the lower marking when the motorcycle is ready to operate with the rider mounted along with any luggage and a passenger if applicable.

- » If the boundary between light and dark does not meet specifications:
 - Adjust headlight range. 📖 (p. 164)



17.13 Adjusting the headlight range

Preparatory work



- Check the headlight setting.  (p. 163)

Main work

- Turn adjusting screw **1** to adjust the headlight range.

Screw **1** also secures the headlight. Ensure the screw is always screwed in far enough.

i Note
Turn clockwise to increase the headlight range; turn counterclockwise to reduce the headlight range.
If you have a load, you may have to correct the headlight range.



- Park the vehicle on a horizontal surface in front of a light-colored wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance **B** under the first marking.

Distance B	5 cm (2.0 in)
-------------------	------------------


- Position the vehicle upright at distance **A** from the wall and switch on the low beam.

Distance A	5 m (16 ft – 5 in)
-------------------	-----------------------

- Get on the motorcycle, together with any luggage or passenger.
- Check the headlight adjustment.


The light-dark boundary must lie exactly on the lower marking when the motorcycle is ready to operate with the rider mounted along with any luggage and a passenger if applicable.

17.14 Diagnostic connector



Diagnostics connector **1** is located under the passenger seat.


17.15 Front ACC1 and ACC2



Installation location

- The front power supplies ACC1 ① and ACC2 ② are located behind the headlight brackets.

17.16 Rear ACC1 and ACC2




Installation location

- The rear power supplies ACC1 ① and ACC2 ② are located under the passenger seat next to the battery compartment.

17.17 Setting the time and date

Condition: Motorcycle is stationary



- Press the **SET** button when the menu is closed or use the **Touchscreen**.



Note

If the **Splitscreen** is open, press and hold the **SET** button.


- Press the **UP** or **DOWN** button until **SETTINGS** appears or use the **Touchscreen**.
- The menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **UP** or **DOWN** button until **CLOCK & DATE** is highlighted or use the **Touchscreen**.
- The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.

Setting the clock




- Press the **UP** or **DOWN** button until **SET CLOCK** is highlighted or use the **Touchscreen**.
- The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **UP** or **DOWN** button until the hours or minutes are highlighted or use the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button to set the hours or minutes. Press the **SET** button to confirm the selection or use the **Touchscreen**.
- Press the **BACK** button to close the sub-menu or use the **Touchscreen**.

Setting the date




- Press the **UP** or **DOWN** button until **SET DATE** is highlighted or use the **Touchscreen**.
- The sub-menu can be opened by pressing the **SET** button or by using the **Touchscreen**.
- Press the **UP** or **DOWN** button until the day, month or year is highlighted or use the **Touchscreen**.
- Press the **RIGHT** or **LEFT** button to set the day, month or year. Press the **SET** button to confirm the selection or use the **Touchscreen**.
- Press the **BACK** button to close the sub-menu or use the **Touchscreen**.

18.1 Cooling system



Water pump **1** in the engine circulates the coolant. The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap **2**. Heat expansion causes excess coolant to flow into compensating tank **3**. When the temperature falls, this surplus coolant is sucked back into the cooling system. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

115 °C
(239.0 °F)



The coolant is cooled by the air stream and a radiator fan **4**, which is activated at high temperature. The lower the vehicle speed, the lower the cooling effect. Dirty cooling fins also reduce the cooling effect.

18.2 Checking the frost protection and coolant level



WARNING

Health hazard Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.



WARNING

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.

Condition: The engine is cold

Preparatory work

- Remove passenger seat cover. (p. 123)
- Remove the passenger seat (optional). (p. 122)
- Remove the front rider's seat. (p. 124)



- Remove the right tank spoiler. 📖 (p. 130)
- Stand the motorcycle upright on a level surface.

Main work

- Remove radiator cap ❶ and cap ❷ of the compensating tank.
- Check the frost protection in the coolant.

Antifreeze	-45 °C ... -25 °C (-49.0 °F ... -13.0 °F)
------------	---

- » If the frost protection in the coolant does not match the specified value:
 - Correct the frost protection in the coolant.



- Check the coolant level in the compensating tank.

The coolant level must be between **MIN** and **MAX**.

- » If the coolant level in the reservoir is not correct, but the reservoir is not yet empty:
 - Replenish coolant up to a level between **MIN** and **MAX**.

coolant	
Coolant 📖 (p. 212) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.9 l (0.50 liq. gal _{US})

- » If there is no coolant in the compensating tank:
 - Check the transmission and cooling system for leaks.



Do not start the motorcycle.

- Fill/bleed the cooling system. 🛠️ 📖 (p. 171)
- Mount cap ❷ on the compensating tank.
- Check the coolant level in the radiator.

The radiator must be filled completely.

- » If the coolant level does not meet the specifications:
 - Check the coolant level and the reason for the loss.
- » If you had to add more coolant than the specified amount:
 - > 0.50 l
(> 0.132 liq. gal_{US})
 - Fill/bleed the cooling system. 🛠️ 📖 (p. 171)
- Mount radiator cap ❶.

Reworking

- Install the right tank spoiler.  (p. 131)
- Mount the front rider's seat.  (p. 125)
- Mount the passenger seat cover.  (p. 124)
- Mount the passenger seat (optional).  (p. 123)

**18.3 Checking the coolant level in the compensating tank****WARNING****Health hazard** Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.


**WARNING****Danger of scalding** The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.

Condition: The engine is cold, Radiator is completely full

Preparatory work

- Stand the motorcycle upright on a level surface.



Main work

- Check the coolant level in the compensating tank.

The coolant level must be between **MIN** and **MAX**.

- » If the coolant level in the reservoir is not correct, but the reservoir is not yet empty:
 - Remove cap **1** of the compensating tank.
 - Replenish coolant up to a level between **MIN** and **MAX**.

coolant	
Coolant  (p. 212)	1.9 l
Antifreeze protection to at least: -25 °C (-13.0 °F)	(0.50 liq. gal _{US})

- Mount the cap of the compensating tank.
- » If there is no coolant in the compensating tank:
 - Check the transmission and cooling system for leaks.

 Do not start the motorcycle.

- Fill/bleed the cooling system.   (p. 171)

18.4 Draining the coolant



WARNING

Health hazard Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.




WARNING

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.

Condition: The engine is cold



- Stand the motorcycle upright.
- Position an appropriate container under the engine.
- Remove screw ❶ with the sealing ring.
- Remove the radiator cap.
- Completely drain the coolant.
- Mount screw ❶ with the new sealing ring and tighten.

Screw plug, water pump drain hole	
EJOT Altracs® Plus – 60×14	8 Nm (5.9 ft·lb _f) Loctite® 243

- Mount the radiator cap.



18.5 Filling/bleeding the cooling system



WARNING

Health hazard Coolant is harmful to health.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.


Preparatory work

- Remove passenger seat cover.  (p. 123)
- Remove the passenger seat (optional).  (p. 122)
- Remove the front rider's seat.  (p. 124)
- Remove the right tank spoiler.  (p. 130)
- Remove the left tank spoiler.  (p. 132)

Main work

- Remove radiator cap ❶.





- Remove bleeder screw ❷.
- Tilt the vehicle slightly to the right.
- Pour in coolant until it emerges without bubbles at the vent hole, and then mount and tighten bleeder screw ❷ immediately.

coolant	
Coolant  (p. 212)	1.9 l
Antifreeze protection to at least: -25 °C (-13.0 °F)	(0.50 liq. gal _{US})

- Completely fill the radiator with coolant. Mount radiator cap ❶.
- Rest the vehicle on the side stand.
- Check the coolant level in the compensating tank.  (p. 169)



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and run it until the 5th bar of the temperature indicator lights up.
- Stop the engine and allow it to cool down.
- When the engine is cool, check the coolant level in the radiator and, if necessary, add coolant.
- Check the coolant level in the compensating tank.  (p. 169)

- Reworking**
- Install the right tank spoiler.  (p. 131)
 - Install the left tank spoiler.  (p. 133)
 - Mount the front rider's seat.  (p. 125)
 - Mount the passenger seat cover.  (p. 124)
 - Mount the passenger seat (optional).  (p. 123)

18.6 Changing the coolant



WARNING

Health hazard Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

**WARNING**

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Condition: The engine is cold

Preparatory work

- Remove passenger seat cover. 📖 (p. 123)
- Remove the passenger seat (optional). 📖 (p. 122)
- Remove the front rider's seat. 📖 (p. 124)
- Remove the right tank spoiler. 📖 (p. 130)
- Remove the left tank spoiler. 📖 (p. 132)


Main work

- Stand the motorcycle upright.
- Position an appropriate container under the engine.
- Remove screw ❶ with the sealing ring.



- Remove radiator cap ❷.
- Completely drain the coolant.
- Mount screw ❶ with the new sealing ring and tighten.

Screw plug, water pump drain hole	
EJOT Altracs® Plus – 60×14	8 Nm (5.9 ft·lb _f) Loctite® 243



- Remove bleeder screw ❸.
- Tilt the vehicle slightly to the right.
- Pour in coolant until it emerges without bubbles at the vent hole, and then mount and tighten bleeder screw ❸ immediately.

coolant	
Coolant 📖 (p. 212) Antifreeze protection to at least: –25 °C (–13.0 °F)	1.9 l (0.50 liq. gal _{US})

- Completely fill the radiator with coolant. Mount radiator cap ❷.
- Rest the vehicle on the side stand.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and run it until the 5th bar of the temperature indicator lights up.
- Stop the engine and allow it to cool down.
- After the engine has cooled down, check the coolant level in the radiator and in the compensating tank again and add more coolant if necessary.

Reworking

- Install the right tank spoiler.  (p. 131)
- Install the left tank spoiler.  (p. 133)
- Mount the front rider's seat.  (p. 125)
- Mount the passenger seat cover.  (p. 124)
- Mount the passenger seat (optional).  (p. 123)



19.1 Ride Mode



WARNING

Danger of accidents An incorrectly selected ride mode makes it more difficult to control the vehicle. The riding modes are each only suitable for certain conditions.

- Always select a riding mode that suits the surface on which you are riding, the weather and the riding situation.


Vehicle tunings **Street**, **Rain**, **Sport**, **Track** (optional), **Custom 1**, **Custom 2** (optional) and **Custom 3** (optional) can be selected in the dashboard in submenu **Ride Mode**.

The most recently selected ride mode appears on the display.

The riding mode can also be changed while riding with the throttle grip closed.

Condition	Meaning
STREET	Homologated performance with balanced response; the motorcycle traction control allows normal slip on the rear wheel.
SPORT	Homologated performance with very direct response; the motorcycle traction control allows greater slip on the rear wheel.
RAIN	Reduced homologated performance for better rideability; the motorcycle traction control allows less slip on the rear wheel.
Track (optional)	Throttle response and motorcycle traction control can be adjusted individually.
CUSTOM 1	Throttle response and motorcycle traction control can be adjusted individually.
CUSTOM 2 (optional)	Throttle response and motorcycle traction control can be adjusted individually.
CUSTOM 3 (optional)	Throttle response and motorcycle traction control can be adjusted individually.

19.2 Motorcycle traction control




The motorcycle traction control (**MTC**) lowers the engine torque in case of loss of traction in the rear wheel. Depending on the riding mode  (p. 175), different amounts of slip are allowed when traction control is activated.

i Note
When motorcycle traction control is switched off, the rear wheel may spin during strong acceleration and on surfaces with low grip, resulting in a risk of falling.
After the ignition is switched on, motorcycle traction control is enabled again.

In the combination instrument, the motorcycle traction control can be switched on or off via the **MTC** submenu.

i Note
When the motorcycle traction control is active, the TC indicator lamp  flashes.
When motorcycle traction control is switched off, the TC indicator lamp  lights up.

19.3 slip adjustment (optional)




The spin adjuster is a motorcycle traction control function.
The slip adjustment allows the motorcycle traction control to be tuned through nine levels to the desired characteristic map.
Level 1 allows the maximum slip on the rear wheel, and level 9 the minimum.
The slip adjuster can be set while riding using the **+RES** or **–SET** button when the menu is closed, or using the **RIGHT** or **LEFT** button when the menu is open.

i Note
The slip adjustment is only available in **Track** riding mode (optional).

19.4

Throttle Response (optional)



In the combination instrument the characteristics of the throttle response can be adjusted via the **Throttle Response** submenu.

The **Throttle Response** can also be set while riding with a closed throttle grip.

 **Note**

Throttle Response is only available in riding mode **TRACK** (optional).


Condition	Meaning
TRACK	Extremely direct response
SPORT	Very direct response
STREET	Balanced response

20.1 Checking the engine oil level

i Note

Oil consumption depends on the riding style and the operating conditions.

Condition: The engine is at operating temperature



- Stand the motorcycle upright on a level surface.
- Check the engine oil level.

After switching off the engine, wait one minute before checking the level.

The engine oil must be between marking **A** and marking **B** of the oil level viewer.

- » If the engine oil level is below the marking **B**:
 - Add engine oil.  (p. 180)
- » If the engine oil level is above the marking **A**:
 - Correct engine oil level.

20.2 Changing the engine oil and oil filter, cleaning the oil screens



WARNING

Danger of scalding Engine and gear oil heat up when the motorcycle is operated.

- Wear suitable protective clothing and safety gloves.
- In the event of scalding, rinse the area affected immediately with lukewarm water.




NOTE

Environmental hazard Hazardous substances cause environmental damage.


- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Condition: The engine is at operating temperature




Main work

- Rest the motorcycle on its side stand on a horizontal surface.
- Position an appropriate container under the engine.
- Remove oil filler plug **1** with the O-ring from the clutch cover.




- Remove oil drain plugs **2** along with the magnets, the O-rings, and the oil screens.



- Remove screws **3**.
- Take off oil filter cover **4** with the O-ring.
- Pull oil filter **5** out of the oil filter housing.

Lock ring plier (51012011000)

- Allow the engine oil to drain completely.
- Thoroughly clean the parts and the sealing surfaces.



- Insert new oil filter **5**.



Only insert the oil filter by hand.

- Oil the O-ring of the oil filter cover.
- Position oil filter cover **4**.
- Mount and tighten screws **3**.

Screw, oil filter cover

M6	10 Nm (7.4 ft·lb _f)
----	------------------------------------

- Thoroughly clean magnets **A** and oil screens **B** of the oil drain plugs.



- Mount the oil drain plugs **2** with magnets and new seal rings, and tighten.


Plug, oil screen

M20×1.5	20 Nm (14.8 ft·lb _f)
---------	-------------------------------------

- Fill up with engine oil at the clutch cover.

engine oil

engine oil (SAE 10W/50) (p. 211) fully synthetic	2.6 l (0.69 liq. gal _{US})
--	---



- Mount and tighten oil plug **1** with O-ring.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and check it for leaks.

Reworking


- Check the engine oil level. 📖 (p. 178)

20.3 Adding engine oil



Note

Too little engine oil or poor-quality engine oil will result in premature wear of the engine.



Main work

- Remove filler plug **1** with the O-ring, and fill up with engine oil.
- Fill engine oil to the middle of the level viewer.

engine oil (SAE 10W/50) 📖 (p. 211)
fully synthetic



Note

In order to achieve optimal engine oil performance, it is not advisable to mix different engine oils.

KTM recommends changing the engine oil if necessary.

- Mount and tighten oil plug **1** with O-ring.



DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and check it for leaks.

Reworking

- Check the engine oil level. 📖 (p. 178)


20.4 Checking the free travel of the clutch lever



NOTE

Clutch damage If there is no free travel by the clutch lever, the clutch will slip.

- Check the free travel of the clutch lever each time before using the vehicle.
- Adjust the free travel of the clutch lever when necessary in accordance with the specification.



- Check the clutch lever for smooth operation.
- Move the handlebar to the straight-ahead position.
- Pull the clutch lever until resistance is perceptible, and determine the free travel **A**.

Free travel of clutch lever A	5 mm (0.20 in)
--------------------------------------	-------------------

- » If the free travel of the clutch lever does not meet specifications:

- Set the free travel of the clutch lever. (p. 181)


- Move the handlebar back and forth over the entire steering range.

The free travel of the clutch lever must not change.

- » If the free travel of the clutch lever changes:
 - Check the routing of the clutch cable.




20.5 Adjusting the free travel of the clutch lever



- Move the handlebar to the straight-ahead position.
- Loosen lock nut **1**.
- Adjust the free travel **A** by turning adjusting screw **2**.

Free travel of clutch lever A	5 mm (0.20 in)
--------------------------------------	-------------------

- Tighten lock nut **1**.



21.1 Cleaning the motorcycle



NOTE
Material damage Components can be damaged or destroyed if a high-pressure cleaner is used incorrectly. The high pressure forces water into the electrical components, socket connectors, clutch cables, and bearings, etc.
Too high a pressure can cause malfunctions and destroy components.

- Do not direct the water jet directly on to electrical components, socket connectors, clutch cables, or bearings.
- Maintain a minimum distance between the nozzle of the high-pressure cleaner and the component.

Minimum distance	60 cm (23.6 in)
------------------	--------------------




NOTE
Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.



Note
Clean the motorcycle regularly to maintain its value and appearance over a long period.
Avoid direct sunshine when cleaning the motorcycle.



- Seal the exhaust system to prevent water from entering into it.
- Remove loose dirt first with a soft jet of water.
- Spray the heavily soiled parts with a standard commercial motorcycle cleaner and clean using a brush.

Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

Environmentally neutral universal cleaning agent
 (p. 216)



Note
Use warm water containing standard motorcycle cleaner and a soft sponge.
If the vehicle was driven in road salt, clean it with cold water. Warm water would enhance the corrosive effects of salt.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Remove the cover from the exhaust system.



WARNING
Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake pads and the brake discs.

- After cleaning, ride the vehicle a short distance until the engine warms up.



Note

The heat produced causes water to evaporate at inaccessible locations in the engine and on the brake system.

- After the motorcycle has cooled off, lubricate all moving parts and pivot points.
- Clean the chain. (p. 126)



WARNING

Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.

- Treat bare metal (except for brake discs and the exhaust system) with an anticorrosive.

Preserving materials (p. 216)

- Treat all painted parts with a mild paint care product.

Do not polish parts that were matte when delivered as this would strongly impair the material quality.

Shine spray with beading effect (p. 216)

- Treat the plastic parts and powder-coated parts with a mild cleaning agent and care product.

Cleaning agents for plastics, glass, lacquers, metals, windshields and visors (p. 216)

- Oil the ignition and steering lock, tank lock, and seat lock.

Universal oil spray (p. 211)



21.2 Checks and maintenance steps for winter operation



WARNING

Danger of accidents Salt on the roads impairs the brake system.

- Brake carefully several times to remove salt from the brake linings and the brake discs.



WARNING


Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.

- Always keep the brake discs free of oil, fat and wax.
- Clean the brake discs with brake cleaner when necessary.



Note

If you use the motorcycle in winter, salt can be expected on the roads. You should therefore take precautions against aggressive road salt.



- Clean the motorcycle. 📖 (p. 182)
- Clean brake system.

After every trip on salted roads, thoroughly wash the brake calipers and brake pads with cold water and dry carefully. This should be done after the parts are cooled down and while they are installed.

After riding on salted roads, thoroughly clean the vehicle with cold water and dry it well.



Note

Warm water enhances the corrosive effects of salt.

- Treat the engine, swingarm, and all other bare or zinc-plated parts (except the brake discs) with a wax-based anticorrosive.


Corrosion inhibitor must not come in contact with the brake discs as this would greatly reduce the braking force.

- Clean the chain. 📖 (p. 126)

22.1 Storage

**Note**

If the vehicle will not be ridden for an extended period, additional steps are recommended. Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less overload of the authorized partner). This allows you to avoid long waiting periods when the next season starts.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.

Fuel additive (p. 210)

- Refuel. (p. 113)

**Tip**

Fill the fuel tank completely as specified, using fuel with the lowest possible ethanol content.

- Clean the motorcycle. (p. 182)
- Change the engine oil and the oil filter, clean the oil screens. (p. 178)
- Check the frost protection and coolant level. (p. 167)
- Check the tire pressure. (p. 151)
- Remove the 12 V battery. (p. 154)
- Charge the 12 V battery. (p. 156)

Storage temperature of the 12 V battery without direct sunlight	0 °C ... 35 °C (32.0 °F ... 95.0 °F)
---	---

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature. Various vehicle components such as the 12 V battery, tires, etc. must not be stored at temperatures that are too low. Observe the tire manufacturer's specifications and recommendations.

**Note**

KTM recommends jacking up the motorcycle.

- Raise the motorcycle with the rear lifting gear. (p. 120)
- Lift the motorcycle with the front lifting gear. (p. 120)


Cover the motorcycle with a tarp or cover that is permeable to air.

Do not use non-porous materials because they prevent humidity from escaping and thus cause corrosion.

**Note**

Avoid running the engine of a motorcycle in storage for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and the exhaust system to rust.

22.2 Preparing for use after storage



- Take the motorcycle off the front lifting gear. (p. 121)
- Remove the rear of the motorcycle from the lifting gear. (p. 120)
- Charge the 12 V battery. (p. 156)
- Install the 12 V battery. (p. 155)
- Set the time and date. (p. 165)
- Perform checks and maintenance measures when preparing for use. (p. 104)
- Take a test ride.

23.1 troubleshooting

Cause	Finding	Remedy
The dashboard shows nothing on the display	Fuse 1 blown Main fuse blown 12 V battery discharged	– Change the fuses of individual electrical power consumers.  (p. 161) – Set the time and date.  (p. 165) – Change the main fuse.  (p. 158) – Charge the 12 V battery.   (p. 156) – Check the open-circuit current. 
Engine does not rotate if the start button/emergency OFF switch is pressed into the lower position	Operating error 12 V battery discharged Faulty safety starting system Electronic fault	– Carry out the starting procedure.  (p. 104) – Charge the 12 V battery.   (p. 156) – Check the open-circuit current.  – Read out the fault memory using the diagnostics tool.  – Read out the fault memory using the diagnostics tool. 
The engine only turns over if the clutch lever is pulled	The vehicle is in gear Faulty safety starting system	– Shift the transmission into the neutral position. – Read out the fault memory using the diagnostics tool. 
The engine turns over although a gear is engaged	Faulty safety starting system	– Read out the fault memory using the diagnostics tool. 
The engine turns but does not start	Quick-lock coupling not joined Malfunction in the electronic fuel injection The fuel quality is insufficient	– Join quick-lock couplings. – Read out the fault memory using the diagnostics tool.  – Add suitable fuel.
The engine dies during the trip	Lack of fuel Malfunction in the electronic fuel injection	– Refuel.  (p. 113) – Read out the fault memory using the diagnostics tool. 
Malfunction indicator lamp lights up or flashes	Malfunction in the electronic fuel injection	– Read out the fault memory using the diagnostics tool. 
The ABS warning light lights up	ABS fuse blown Large difference in wheel speeds of the front and rear wheels Malfunction in ABS	– Change the ABS fuses.  (p. 160) – Stop the vehicle, switch off the ignition, and start it again. – Read out the ABS fault memory using the diagnostic tool. 
High oil consumption	The engine oil level is too high The engine oil is too thin (low viscosity)	– Check the engine oil level.  (p. 178) – Change the engine oil and the oil filter, clean the oil screens.   (p. 178)
12 V battery discharged	The hazard warning flasher is switched on The 12-V battery is not being charged by the alternator Ignition was not switched off when vehicle was parked	– Switch off the hazard warning flasher. – Charge the 12 V battery.   (p. 156) – Check the charging voltage.  – Check the open-circuit current. 

Cause	Finding	Remedy
		– Charge the 12 V battery.   (p. 156)

24.1 Engine

24.1.1 Technical data - engine

Design	2-cylinder 4-stroke in-line engine, water-cooled
Displacement	950 cm ³ (57.97 in ³)
Stroke	70.4 mm (2.772 in)
Bore	92.5 mm (3.642 in)
Compression ratio	13.5:1
Control	DOHC, 4 valves per cylinder controlled via cam lever, chain drive
Valve diameter, intake	37 mm (1.46 in)
Valve diameter, exhaust	30 mm (1.18 in)
Valve clearance, cold	
Intake at: 20 °C (68.0 °F)	0.10 mm ... 0.15 mm (0.0039 in ... 0.0059 in)
Exhaust at: 20 °C (68.0 °F)	0.15 mm ... 0.20 mm (0.0059 in ... 0.0079 in)
Crankshaft bearing	Plain bearing
big (bottom) end bearing	Plain bearing
Piston	Forged light alloy
Piston rings	1 compression ring, 1 lower compression ring, 1 oil ring with spring expander
Engine lubrication	Pressure circulation lubrication with 2 trochoidal pumps
Primary transmission	42:76
Clutch	Multi-disc clutch in oil bath/mechanically operated
Transmission	6 speed transmission, claw shift
Gear ratios	
1st gear	13:37
2nd gear	17:34
3rd gear	20:31
4th gear	22:28
5th gear	24:26
6th gear	23:22
Mixture formation	Electronic fuel injection
Ignition system	Contactless controlled fully electronic ignition with digital ignition adjustment
Alternator	14 V 400 W (0.536 hp)
Spark plug	NGK LMAR9AI-10

Plug gap of spark plug	1.0 mm (0.039 in)
Cooling	Liquid cooling, permanent circulation of coolant by water pump
idle speed	1,550 rpm ... 1,650 rpm (25.83 Hz ... 27.50 Hz)
Starting aid	Starter motor

24.1.2 Capacities - engine

engine oil	
engine oil (SAE 10W/50)  (p. 211) fully synthetic	2.6 l (0.69 liq. gal _{US})
coolant	
Coolant  (p. 212) Antifreeze protection to at least: -25 °C (-13.0 °F)	1.9 l (0.50 liq. gal _{US})

24.2 Chassis

24.2.1 Technical data - chassis


Frame	Lattice frame made of chrome molybdenum steel tubing, powder-coated
Fork	WP Suspension APEX
Shock absorber	WP Suspension APEX
Suspension travel:	
front	143 mm (5.63 in)
rear	140 mm (5.51 in)
Brake system	
front	Double disc brake with radially mounted four-piston brake calipers, floating brake discs
rear	Disc brake with single-piston brake caliper, floating
Brake discs - diameter	
front	320 mm (12.60 in)
rear	240 mm (9.45 in)
Brake disc wear limit	
front	4.5 mm (0.177 in)
rear	4.5 mm (0.177 in)
Tire pressure when solo	
front	2.3 bar (33.4 psi)

rear	2.5 bar (36.3 psi)
Tire pressure with passenger / full payload	
front	2.3 bar (33.4 psi)
rear	2.6 bar (37.7 psi)
Final drive	16:43
	Note Modifications to the transmission ratio are not permitted and can lead to malfunctions.
Chain	5/8 x 1/4" (520) X-ring
Steering head angle	65.9° (1.150 rad)
Wheelbase	1,481 mm (58.31 in)
Seat Height unloaded	840 mm (33.07 in)
Ground clearance unloaded	214 mm (8.43 in)
Roadworthy weight	188 kg (414.5 lb)
Maximum permissible front axle load	165 kg (363.8 lb)
Maximum permissible rear axle load	270 kg (595.2 lb)
Maximum permissible total weight	390 kg (859.8 lb)

24.2.2 Technical data - tires

Tire front	Rear tire
120/70 ZR 17 M/C 58W TL Michelin Power Cup 2	180/55 ZR 17 M/C 73W TL Michelin Power Cup 2
The tires specified represent one of the possible series production tires. For alternative manufacturers, if any, contact an authorized manufacturer or qualified tire dealership. If local road approval regulations apply, these and the respective technical specifications must be observed.	

24.2.3 Fuel



Please observe the labels on EU fuel pumps.

24.2.4 Vehicle capacity

Fuel tank capacity, approx.	
Super unleaded (ROZ 95)  (p. 210)	14.8 l (3.91 liq. gal _{US})

24.3 Electrics

24.3.1 Battery

12 V battery	HTZ12A-BS	Battery voltage: 12 V Nominal capacity: 10 Ah Maintenance-free
--------------	-----------	--

24.3.2 Fuses

Fuse	75011088075	7.5 A
Fuse	75011088010	10 A
Fuse	75011088015	15 A
Fuse	75011088025	25 A
Fuse	58011109130	30 A

24.3.3 Lamps

Low beam/high beam	LED
Daytime running light/position light	LED
Dashboard illumination and indicator lights	LED
Turn signal	LED
Tail light	LED
Brake light	LED
License plate lighting	LED

24.4 Fork

24.4.1 Technical data - fork

Fork part number	A679C149Y401000
Fork	WP Suspension APEX
Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	12 clicks
Full payload	15 clicks
Rebound damping	
Comfort	14 clicks
Standard	12 clicks
Sport	10 clicks
Full payload	12 clicks
Spring rate	
Medium (standard)	7.5 N/mm (42.83 lb _f /in)
Spring length with preload spacer(s)	325 mm (12.80 in)
Fork length	781 mm (30.75 in)

24.4.2 Fork oil capacity

Fork oil per fork leg	
Fork oil (48601166S1) (SAE 4)  (p. 211)	600 ±5 ml (20.29 ±0.17 fl. oz _{US})

24.5 Shock absorber

24.5.1 Technical data - shock absorber

Shock absorber part number	A679C449Y313000
Shock absorber	WP Suspension APEX
Low-speed compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	6 clicks
High-speed compression damping	
Comfort	2 turns (720°)
Standard	2 turns (720°)

Sport	1.5 turns (540°)
Full payload	1 turn (360°)
Rebound damping	
Comfort	16 clicks
Standard	12 clicks
Sport	6 clicks
Full payload	6 clicks
Preload	
Comfort	10 turns (3,600°)
Standard	10 turns (3,600°)
Sport	10 turns (3,600°)
Full payload	14 turns (5,040°)
Spring rate	
Medium (standard)	75 N/mm (428.3 lb _f /in)
Spring length	184 mm (7.24 in)
Gas assisted	10 bar (145 psi)
Installation position	356 mm (14.02 in)

24.5.2 Shock absorber capacity

Shock absorber oil	
Shock absorber oil (50180751S1) (SAE 2.5)  (p. 211)	Fill to the maximum mark

24.6 Tightening torque

24.6.1 engine tightening torques

Hose clip, intake flange	M4	2.5 Nm (1.84 ft·lb _f)
Remaining screws for engine	M5	6 Nm (4.4 ft·lb _f)
Screw, gear position sensor	M5	6 Nm (4.4 ft·lb _f) Loctite® 243
Oil spray tube, crank chamber evacuation	M5	2 Nm (1.5 ft·lb _f)

Oil spray tube, camshaft lubrication	M5	2 Nm (1.5 ft·lb _r)
Screw, cam lever axial lock	M5	6 Nm (4.4 ft·lb _r) Loctite® 243
Screw, crankshaft position sensor	M5	6 Nm (4.4 ft·lb _r) Loctite® 243
Screw, thermostat case	M5	6 Nm (4.4 ft·lb _r) Loctite® 243
Screw, shift shaft sensor	M5	6 Nm (4.4 ft·lb _r) Loctite® 243
Securing screw, balancer shaft	M5	5 Nm (3.7 ft·lb _r) Loctite® 243
Pressure sensor, throttle valve body	M5×14	5 Nm (3.7 ft·lb _r) Loctite® 243
Screw, fuel rail	M5×30	3 Nm (2.2 ft·lb _r) Loctite® 243
Screw, water flange	M5	6 Nm (4.4 ft·lb _r) Loctite® 243
Remaining screws for engine	M6	10 Nm (7.4 ft·lb _r)
Screw, oil filter cover	M6	10 Nm (7.4 ft·lb _r)
Screw, suction pump cover	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, pressure pump cover	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Detent arm screw	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, upper guide rail	M6	8 Nm (5.9 ft·lb _r) Loctite® 243
Screw, clutch cover	M6	10 Nm (7.4 ft·lb _r)
Screw, engine case	M6×35	12 Nm (8.9 ft·lb _r)
Screw, engine case	M6×60	12 Nm (8.9 ft·lb _r)

Bell crank	M6	14 Nm (10.3 ft·lb _f) Loctite® 243
Screw, starter motor	M6	10 Nm (7.4 ft·lb _f)
Stator screw	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, valve cover	M6	10 Nm (7.4 ft·lb _f)
Screw, water pump cover	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, water pump impeller	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, cylinder head	M6	10 Nm (7.4 ft·lb _f)
Screw, ignition cover	M6×30	10 Nm (7.4 ft·lb _f)
Screw, camshaft bearing bridge	M6	10 Nm (7.4 ft·lb _f)
Screw, timing chain shaft	M6	10 Nm (7.4 ft·lb _f)
Screw, shift shaft retaining bracket	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, main shaft bearing support	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, oil pump unit	M6	10 Nm (7.4 ft·lb _f)
Screw, oil pan	M6×30	10 Nm (7.4 ft·lb _f)
Screw, oil pan	M6×40	10 Nm (7.4 ft·lb _f)
Screw, oil pan	M6×70	10 Nm (7.4 ft·lb _f)
Screw, oil pan	M6×80	10 Nm (7.4 ft·lb _f)
Screw, oil/water heat exchanger	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, ignition coil	M6	8 Nm (5.9 ft·lb _f)
Screw, clutch release lever	M6	10 Nm (7.4 ft·lb _f) Loctite® 243

Screw, clutch cable retaining bracket	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Nut, starter motor cable	M6	5 Nm (3.7 ft·lb _f)
Screw, bleeder flange	M6	8 Nm (5.9 ft·lb _f) Loctite® 243
Clutch cover, damping plate	M6	8 Nm (5.9 ft·lb _f)
Shift mechanism support	M6	10 Nm (7.4 ft·lb _f)
Clutch pressure cap	M6	8 Nm (5.9 ft·lb _f)
Screw, bearing flange	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, timing chain shaft, cylinder head	M6	10 Nm (7.4 ft·lb _f)
Remaining screws for engine	M8	20 Nm (14.8 ft·lb _f)
Screw, engine case	M8×65	27 Nm (19.9 ft·lb _f)
Screw, engine case	M8×90	27 Nm (19.9 ft·lb _f)
Slide rail screw	M8×25	15 Nm (11.1 ft·lb _f) Loctite® 243
Stud, exhaust flange	M8	15 Nm (11.1 ft·lb _f) Loctite® 243
Exhaust flange nut	M8	15 Nm (11.1 ft·lb _f)
Screw plug, locking screw	M8	15 Nm (11.1 ft·lb _f)
Knock sensor screw	M8	20 Nm (14.8 ft·lb _f)
Oil hole screw plug	M8	8 Nm (5.9 ft·lb _f) Loctite® 243
Screw, reduction jet, clutch lubrication	M8	5 Nm (3.7 ft·lb _f) Loctite® 243
Screw, conrod bearing M9×1 engine oil	1.	5 Nm (3.7 ft·lb _f)
	2.	15 Nm (11.1 ft·lb _f)

Screw, conrod bearing M9×1 engine oil	3.	90° (1.57 rad)
Screw, release for timing chain tensioner M10×1		8 Nm (5.9 ft·lb _f)
Oil pressure sensor M10×1		10 Nm (7.4 ft·lb _f)
Spark plug M10		11 Nm (8.1 ft·lb _f)
Coolant temperature sensor M10×1.25		10 Nm (7.4 ft·lb _f)
Screw plug, cam lever shaft M10×1		8 Nm (5.9 ft·lb _f)
Screw, cylinder head M11×115 engine oil	1.	5 Nm (3.7 ft·lb _f)
	2.	23 Nm (17.0 ft·lb _f)
	3.	90° (1.57 rad)
	4.	90° (1.57 rad)
Screw, rotor M12×1.5		90 Nm (66.4 ft·lb _f) Long-life grease
Nut, engine sprocket M20×1.5		120 Nm (88.5 ft·lb _f) Loctite® 243
Nut, inner clutch hub M20×1.5		135 Nm (99.6 ft·lb _f)
Plug, oil screen M20×1.5		20 Nm (14.8 ft·lb _f)
Screw plug, timing chain tensioner M24×1.5		25 Nm (18.4 ft·lb _f)
Screw plug, alternator cover M24×1.5		8 Nm (5.9 ft·lb _f)
Screw plug, water pump drain hole EJOT ALtracs® Plus – 60×14		8 Nm (5.9 ft·lb _f) Loctite® 243

24.6.2 Chassis tightening torques

Throttle valve body hose clamp	2.8 Nm (2.07 ft·lb _f)
Radiator hose hose clamp	2.2 Nm (1.62 ft·lb _f)
Remaining nuts on chassis M4	3 Nm (2.2 ft·lb _f)

Remaining screws on chassis	M4	3 Nm (2.2 ft·lb _r)
Screw, fixed grip, left	M4	3 Nm (2.2 ft·lb _r)
Brake fluid reservoir cover, front	M4	1 Nm (0.7 ft·lb _r)
Screw, combination switch, right	M5	3.5 Nm (2.58 ft·lb _r)
Screw, heat guard	M5	7 Nm (5.2 ft·lb _r)
Remaining screws on chassis	M5	5 Nm (3.7 ft·lb _r)
Screw, air filter box	M5	3 Nm (2.2 ft·lb _r)
Screw, brake fluid reservoir for rear brake	M5	5 Nm (3.7 ft·lb _r)
Screw, mask support	M5	3.5 Nm (2.58 ft·lb _r)
Screw, throttle twist grip	M5	3.5 Nm (2.58 ft·lb _r)
Screw, combination switch, left	M5	3.5 Nm (2.58 ft·lb _r)
Remaining nuts on chassis	M5	5 Nm (3.7 ft·lb _r)
Screw, trim	M5	3.5 Nm (2.58 ft·lb _r)
Screw, support roller	M5	4 Nm (3.0 ft·lb _r) Loctite® 243
Screw, front sprocket cover	M5	5 Nm (3.7 ft·lb _r) Loctite® 243
Screw, front rider's seat	M5×12	3 Nm (2.2 ft·lb _r)
Screw, fuel level sensor	M5	3 Nm (2.2 ft·lb _r)
Screw, battery holding bracket	M5	3.5 Nm (2.58 ft·lb _r)
Fuel tank cover screw	M5	3.5 Nm (2.58 ft·lb _r)
Screw, lower rear panel	M5	3 Nm (2.2 ft·lb _r)
Screw, dashboard trim	M5	3.5 Nm (2.58 ft·lb _r)
Screw, mask support cable protection	M5	3.5 Nm (2.58 ft·lb _r)
Screw, turn signal	M5	3 Nm (2.2 ft·lb _r)

Screw, heat protection electrics	M5	3.5 Nm (2.58 ft·lb _f)
Screw, ride-by-wire throttle clamping screw	M5	3.5 Nm (2.58 ft·lb _f)
Screw, combination switch clamping screw	M5	4.5 Nm (3.32 ft·lb _f)
Screw connection, evaporative canister bracket in frame	M5	3.5 Nm (2.58 ft·lb _f)
Screw, air deflector radiator on ABS carrier	M5	3.5 Nm (2.58 ft·lb _f)
Screw, control unit reservoir	M5	3.5 Nm (2.58 ft·lb _f)
Nut, push rod, brake pedal	M6	10 Nm (7.4 ft·lb _f)
Screw, combination instrument	M6	8 Nm (5.9 ft·lb _f)
Screw, side stand sensor	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, battery terminal	M6×12	4.5 Nm (3.32 ft·lb _f)
Screw, battery terminal	M6×20	4.5 Nm (3.32 ft·lb _f)
Screw, foot brake lever stub	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, seat lock	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Nut, cable on starter motor	M6	5 Nm (3.7 ft·lb _f)
Screw, ground wire to starter motor	M6	6 Nm (4.4 ft·lb _f)
Screw, ground wire on frame	M6	6 Nm (4.4 ft·lb _f)
Remaining nuts on chassis	M6	10 Nm (7.4 ft·lb _f)
Remaining screws on chassis	M6	10 Nm (7.4 ft·lb _f)
Screw, fuel tank spoiler	M6	3 Nm (2.2 ft·lb _f)
Screw, brake cylinder on the rear brake system	M6	10 Nm (7.4 ft·lb _f) Loctite® 243
Screw, license plate holder	M6	6 Nm (4.4 ft·lb _f)

Screw, push rod ball joint on the rear brake cylinder	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, radiator bracket, bottom	M6	5 Nm (3.7 ft·lb _r)
Screw, magnetic holder on side stand	M6	2 Nm (1.5 ft·lb _r) Loctite® 243
Nut, shift rod	M6	6 Nm (4.4 ft·lb _r)
Nut, shift rod	M6LH	6 Nm (4.4 ft·lb _r)
Screw, ignition lock (tamper-proof screw)	M6	Tighten until the head breaks off Loctite® 243
Screw, shift lever stub	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, shift rod	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, front brake assembly	M6	8 Nm (5.9 ft·lb _r)
Screw, angle sensor	M6	6 Nm (4.4 ft·lb _r)
Screw, wheel speed sensor	M6	6 Nm (4.4 ft·lb _r)
Screw, clutch lever assembly	M6	8 Nm (5.9 ft·lb _r)
Screw, shift shaft deflector on shift shaft	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, fuel tank rollers	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, subframe brace	M6	10 Nm (7.4 ft·lb _r) Loctite® 243
Screw, lower mask support	M6	6 Nm (4.4 ft·lb _r)
Screw, activated carbon filter holder	M6	6 Nm (4.4 ft·lb _r)
License plate holder support screw	M6	6 Nm (4.4 ft·lb _r)
Nut, hand brake lever	M6	5.5 Nm (4.06 ft·lb _r)
Screw, dashboard clamp	M6	1.5 Nm (1.11 ft·lb _r)

Screw, horn on cooler retaining bracket	M6	6 Nm (4.4 ft·lb _f)
Screw, control unit	M6	6 Nm (4.4 ft·lb _f)
Screw, voltage regulator	M6	6 Nm (4.4 ft·lb _f)
Screw, starter relay clamping screw	M6	3.5 Nm (2.58 ft·lb _f)
Screw connection, purge valve	M6	7 Nm (5.2 ft·lb _f)
Screw, reservoir to heat protection	M6	6 Nm (4.4 ft·lb _f)
Screw, ABS modulator bracket	M6	6 Nm (4.4 ft·lb _f)
Screw, ABS modulator	M6	8 Nm (5.9 ft·lb _f)
Screw, wheel speed sensor	M6	6 Nm (4.4 ft·lb _f)
Screw, main silencer clamp	M8	15 Nm (11.1 ft·lb _f)
Screw, manifold clamp	M8	15 Nm (11.1 ft·lb _f)
Nut, manifold on cylinder head	M8	Tighten the nuts evenly. Do not bend the metal. 13 Nm (9.6 ft·lb _f)
Remaining nuts on chassis	M8	25 Nm (18.4 ft·lb _f)
Remaining screws on chassis	M8	25 Nm (18.4 ft·lb _f)
Screw, rear brake disc	M8	28 Nm (20.7 ft·lb _f) Loctite® 2701
Screw, front brake disc	M8	28 Nm (20.7 ft·lb _f) Loctite® 2701
Screw, main silencer fastening	M8	15 Nm (11.1 ft·lb _f)
Screw, spring holder plate on the side stand bracket	M8	15 Nm (11.1 ft·lb _f)
Screw, footrest bracket, rear	M8×30	25 Nm (18.4 ft·lb _f) Loctite® 243
Screw, top triple clamp	M8	15 Nm (11.1 ft·lb _f)
Screw, bottom triple clamp	M8	12 Nm (8.9 ft·lb _f)
Screw, fork shoe	M8	15 Nm (11.1 ft·lb _f)

Screw, steering stem	M8	20 Nm (14.8 ft·lb _r) Loctite® 243
Screw, grab handle	M8×20	25 Nm (18.4 ft·lb _r) Loctite® 243
Handlebar clamp screw	M8	20 Nm (14.8 ft·lb _r)
Screw, steering damper on triple clamp	M8	8 Nm (5.9 ft·lb _r) Loctite® 243
Screw, steering damper on frame	M8	8 Nm (5.9 ft·lb _r) Loctite® 243
Screw, engine fixing arm linkage bracket	M8	25 Nm (18.4 ft·lb _r) Loctite® 243
Screw, foot brake lever	M8	25 Nm (18.4 ft·lb _r) Loctite® 2701
Screw, shift lever	M8	25 Nm (18.4 ft·lb _r) Loctite® 2701
Screw, presilencer on frame	M8	15 Nm (11.1 ft·lb _r) Loctite® 243
Screw, cross member	M8×20	25 Nm (18.4 ft·lb _r) Loctite® 243
Screw, cross member in rear	M8×35	25 Nm (18.4 ft·lb _r) Loctite® 243
Screw, passenger seat bracket	M8	25 Nm (18.4 ft·lb _r) Loctite® 243
Nut, rear sprocket screw	M8	35 Nm (25.8 ft·lb _r) Loctite® 2701
Screw, main silencer clamp	M8	15 Nm (11.1 ft·lb _r)
Screw, main silencer holder	M8×40	25 Nm (18.4 ft·lb _r) Loctite® 243
Screw, main silencer holder	M8×45	25 Nm (18.4 ft·lb _r) Loctite® 243

24 Technical specifications


Screw, main silencer holder	M8×60	25 Nm (18.4 ft·lb _f) Loctite® 243
Pin, brake linings	M8	8 Nm (5.9 ft·lb _f)
Screw, chain slider	M8	25 Nm (18.4 ft·lb _f)
Screw, resonator retaining bracket	M8	15 Nm (11.1 ft·lb _f)
Screw, front footrest bracket	M10×24	45 Nm (33.2 ft·lb _f) Loctite® 243
Screw, front brake caliper	M10×1.25	45 Nm (33.2 ft·lb _f) Loctite® 243
Subframe screw	M10	50 Nm (36.9 ft·lb _f) Loctite® 243
Engine mounting bolt	M10	45 Nm (33.2 ft·lb _f) Loctite® 243
Banjo bolt, brake line	M10×1	25 Nm (18.4 ft·lb _f)
Remaining nuts on chassis	M10	45 Nm (33.2 ft·lb _f)
Remaining screws on chassis	M10	45 Nm (33.2 ft·lb _f)
Screw, handlebar mount	M10	45 Nm (33.2 ft·lb _f) Loctite® 243
Screw, side stand	M10	35 Nm (25.8 ft·lb _f) Loctite® 243
Screw, side stand bracket	M10	45 Nm (33.2 ft·lb _f) Loctite® 243
Screw, main silencer holder	M10×24	30 Nm (22.1 ft·lb _f) Loctite® 243
Screw, resonator retaining bracket to engine	M10×24	45 Nm (33.2 ft·lb _f)
Screw, headlight support at bottom	M10	3 Nm (2.2 ft·lb _f)
Brake light switch screw	M10	23 Nm (17.0 ft·lb _f)
Top shock absorber screw	M12	80 Nm (59.0 ft·lb _f) Loctite® 243

Bottom shock absorber screw	M12	80 Nm (59.0 ft·lb _f) Loctite® 243
Screw, swingarm pivot	M12	100 Nm (73.8 ft·lb _f)
Screw, coupling rod to frame	M12×80	80 Nm (59.0 ft·lb _f)
Screw, triangle cantilever to swingarm	M12	80 Nm (59.0 ft·lb _f)
Oxygen sensor	M18×1.5	50 Nm (36.9 ft·lb _f)
Screw, steering head	M20×1.5	18 Nm (13.3 ft·lb _f)
Bushing, shock absorber support	M20LH×1.5	10 Nm (7.4 ft·lb _f) Long-life grease
Screw, adjusting ring	M24×1.5	10 Nm (7.4 ft·lb _f)
Screw, wheel spindle, front	M25×1.5	45 Nm (33.2 ft·lb _f)
Nut, wheel spindle, rear	M25×1.5	90 Nm (66.4 ft·lb _f) Long-life grease
Remaining screws on chassis	EJOT PT® – K45×12	1 Nm (0.7 ft·lb _f)
Screw, headlight	EJOT PT® – K50×14	4 Nm (3.0 ft·lb _f)
Remaining screws on chassis	EJOT PT® – K50×12	1 Nm (0.7 ft·lb _f)
Remaining screws on chassis	EJOT PT® – K50×14	1 Nm (0.7 ft·lb _f)
Remaining screws on chassis	EJOT PT® – K50×16	2 Nm (1.5 ft·lb _f)
Remaining screws on chassis	EJOT PT® – K50×18	2 Nm (1.5 ft·lb _f)

25.1 Declarations of conformity

i Note
The functional and equipment scope is model-dependent and may not include all wireless systems and application areas referred to.

25.2 Country-specific declarations of conformity (CCU 3)



Continental hereby declares that the **Connectivity Control Unit "CCU-3"** wireless system conforms with the relevant guidelines. The full text of the Declaration of Conformity is available at the following Internet address.
Certification website: <https://www.ktm.com/ccu3>

25.3 Country-specific declarations of conformity (Tire Pressure Monitoring System)

LDL Technology hereby declares that the **Tyre Pressure Monitoring System** wireless system conforms with the relevant guidelines. The full text of the Declaration of Conformity is available at the following Internet address.
Certification website: <https://www.ktm.com/tpms>

26.1 Recycling



I02045-10

Further information is available at the following website.

Recycling information website: <https://www.quefairedemesdechets.fr>

A Technical terms

ABS	Anti-lock braking system	Safety system that prevents locking of the wheels when riding straight ahead without the influence of lateral forces.
ATIR	Automatic Turn Indicator Reset	Software, which automatically switches the turn signal off according to a time or travel distance counter.
DRL	Daytime Running Light	Light that increases the visibility of the vehicle during the day, but unlike the low beam is not focused and does not illuminate the road ahead.
	KTMconnect	System for remote communication with suitable cell phones and communication systems for telephony and audio
MTC	Motorcycle Traction Control	Additional engine management function, where the engine torque is reduced in the event of rear wheel slip.
OBD	On-board diagnosis	Vehicle system that monitors the specified parameters of the vehicle electronics.
	QUICKSHIFTER+	Engine electronics function for shifting up and down without clutch actuation

B Fuels

Super unleaded

Standards

- ROZ 95 → DIN EN 228

Fuel additive

Recommended supplier

MOTOREX®

- **FUEL STABILIZER**

C Operating supplies

Street chain spray

Recommended supplier

MOTOREX®

- CHAINLUBE ROAD STRONG

Fork oil

Order details

- 48601166S1

Standards

- SAE 4 → SAE

Universal oil spray

Recommended supplier

MOTOREX®

- JOKER 440 SYNTHETIC

Long-life grease

Recommended supplier

MOTOREX®

- Bike Grease 2000

engine oil

Recommended supplier

MOTOREX®

- POWER SYNT 4T

Standards

→ JASO T903 MA2

- SAE 10W/50 → SAE

Properties

- fully synthetic

Shock absorber oil

Order details

- 50180751S1

Standards

- SAE 2.5 → SAE

Brake fluid DOT 5.1

Recommended supplier
MOTOREX®
• BRAKE FLUID DOT 5.1
Standards
→ DOT

Coolant

Recommended supplier	
MOTOREX®	
• COOLANT M3.0	
Properties	
• Antifreeze protection to at least	-25 °C (-13.0 °F)

D Electrics**Low beam/high beam (LED)****Product code**

- LED

12 V battery (HTZ12A-BS)**Product code**

- HTZ12A-BS

Properties

- | | |
|--------------------|-------|
| • Battery voltage | 12 V |
| • Nominal capacity | 10 Ah |
| • Maintenance-free | |

Turn signal (LED)**Product code**

- LED

Brake light (LED)**Product code**

- LED

License plate lighting (LED)**Product code**

- LED

Dashboard illumination and indicator lights (LED)**Product code**

- LED

Tail light (LED)**Product code**

- LED

Fuse (75011088010)

Product code

- 75011088010

Properties

- 10 A

Fuse (75011088015)

Product code

- 75011088015

Properties

- 15 A

Fuse (75011088025)

Product code

- 75011088025

Properties

- 25 A

Fuse (58011109130)

Product code

- 58011109130

Properties

- 30 A

Fuse (75011088005)

Product code

- 75011088005

Properties

- 5 A

Fuse (75011088075)

Product code

- 75011088075

Properties

- 7.5 A

Daytime running light/position light (LED)

Product code

- LED

E Cleaning agents

Shine spray with beading effect

Recommended supplier

MOTOREX®

- MOTO SHINE MS1

Chain cleaner

Recommended supplier

MOTOREX®

- CHAIN CLEAN

Preserving materials

Recommended supplier

MOTOREX®

- MOTO PROTECT

Cleaning agents for plastics, glass, lacquers, metals, windshields and visors

Recommended supplier

MOTOREX®

- QUICK CLEANER

Environmentally neutral universal cleaning agent

Recommended supplier

MOTOREX®

- MOTO CLEAN UNIVERSAL

F Icons

F.1 Symbol colors

F.1.1 Red symbols

Red symbols indicate a fault status that requires immediate intervention.

	The oil pressure warning light lights up red.
---	---

F.1.2 Yellow and orange symbols

Yellow and orange symbols indicate a malfunction status that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	TC indicator lamp lights up/flashes yellow
	Ice warning is active on the display.
	The ABS warning light lights up yellow.
	The ABS rear warning light lights up yellow
	The failure indicator light lights up yellow.
	TC indicator light lights up/flashes yellow.
	The cruise control system indicator light lights up yellow.
	The general warning light lights up yellow.

F.1.3 Green and blue symbols

Green and blue symbols convey information.

	The left turn signal indicator light flashes green with a steady rhythm.
	The right turn signal indicator light flashes green with a steady rhythm.
	The high beam indicator light lights up blue.
	The cruise control system indicator light lights up green.
	Neutral position indicator is active on the display.

1

12 V battery	
charging	156
installation	155
removing	154

A

ABS	135
ABS fuses	
changing	160
ACC1	
front	165
rear	165
ACC2	
front	165
rear	165
Accessories	14
Anti-lock braking system	135
Auxiliary substances	14

B

Brake discs	
checking	136
Brake fluid	
adding front brake	137
adding to rear brake	140
Brake fluid level	
checking on front brake	137
checking on rear brake	140
Brake lining retainers	
checking on front brake	139
checking on rear brake	141
of front brake, mounting	142
of front brake, removing	142
Brake manifold	
of front brake, mounting	142
of front brake, removing	142
Brake pad	
checking on front brake	139
Brake pads	
checking on rear brake	141
Brake pedal	28
adjusting the basic position	99
checking the free travel	139
Brakes	110
Braking	110
Breakdown	
towing	112

C

Chain	
checking	128
cleaning	126
dirt, checking for	125
Chain tension	
adjusting	127
checking	126
Changing gear	107
Clothing	11
Clutch lever	19
adjusting the basic position	98
Combination switch	19
Coolant	
draining	170
Coolant level	
checking	167
checking in the compensating tank	169
Cooling system	167
filling/bleeding	171
Cornering MTC	176
Customer service	14

D

Dashboard	
ABS	49
Acceleration	94
Adding network	79
ambient air temperature indicator	42
Bluetooth	80
Bluetooth & WiFi	77
Bluetooth settings	79
Calls	73
Choose on Map	68
Clock format	90
Date format	91
demo mode	30
Display speed control	72
Distance	92
Engine Brake Control (Optional)	54
Favorites display 1–8	75
heated grip (optional)	95
Launch Control (optional)	55
Map Style	71
MTC	50
MTC+MSR (optional)	51
Music	74
Notifications	71
Offline maps	70
overview	29

Overview of routes	69	Fork legs	
Passenger communication system pairing	83	cleaning the dust boots	121
Phone pairing	81	Free travel of clutch lever	
Pressure (optional)	93	adjusting	181
QUICKSHIFTER+ (optional)	56	checking	181
Ride Mode	175	Front sprocket	
Rider communication system pairing	82	checking	128
Search	68	Front wheel	
setting the clock	89	installing	144
Setting the date	90	removing	143
Settings	70	Frost protection	
slip adjustment (optional)	176	checking	167
Slip Adjuster (optional)	52	Fuel tank cap	
Stop navigation	69	closing	26
Temperature	92	opening	25
Threshold value of speed control	72	Fuse	
Throttle Response (optional)	54, 177	of the individual electrical power consumers,	
time	41	changing	161
Updates	77	G	
Utilization	93	Gear shift lever	27
Wheelie Control (optional)	53	adjusting the basic position	100
WiFi	78	checking the basic position	100
WIFI settings	78	H	
Date		Hand brake lever	19
adjusting	165	adjusting the response	98
Declarations of conformity	206	Handbrake lever	
country-specific (CCU 3)	206	adjusting the basic position	98
country-specific (Tire Pressure Monitoring System)	206	Handlebar position	97
Defined use	12	adjusting	97
Diagnostic connector	164	Hazard lights	24
Difficult operating conditions	14	Hazard warning flasher switch	24
E		Headlight	
Electric starter	24	adjusting headlight range	164
Engine		daytime running light	153
running in	102	setting, checking	163
Engine oil		Horn button	23
adding	180	I	
changing	178	Ignition lock	25
Engine oil level		Implied warranty	14
checking	178	Improper use	13
Engine traction torque control	109	Intended use	12
Environment	12	K	
ETTC	109	Key number	17
F		Kill switch	24
Figures	14	L	
Fork		Launch Control (optional)	105
compression damping, adjusting	116		
rebound, adjusting	116		

Left tank spoiler	
installation	133
removing	132
Loading the vehicle	102
Luggage	102
M	
Main fuse	
changing	158
Manufacturer's warranty	14
Mask support cover with headlight	
mounting	162
removing	162
Motorcycle	
cleaning	182
lifting gear at rear, raising with	120
raising the front with lifting gear	120
removing from the front lifting gear	121
removing the rear from the lifting gear	120
Motorcycle traction control	176
O	
Oil filter	
changing	178
Oil screens	
cleaning	178
Operating conditions	
use in difficult conditions	14
Owner's manual	12
P	
Parking	111
Passenger footpegs (optional)	27
Passenger seat (optional)	
mounting	123
removing	122
Passenger seat cover	
mounting	124
removing	123
Passenger strap (optional)	27
Preparing for use	
after storage	186
checks and maintenance measures when preparing for use	104
notes on preparing for first use	101
Protective clothing	11
Q	
Quickshifter+ (optional)	106

R	
Rear hub damping rubbers	
checking	149
Rear sprocket	
checking	128
Rear wheel	
installation	147
removing	146
Recycling	207
Refueling	
fuel	113
Resources	14
Rider seat	
mounting	125
removing	124
Riding	107
Starting off	105
Starting off with launch control (option- al)	106
Right tank spoiler	
installation	131
removing	130
Roadside Assistance	12
S	
Safe use	11
Seat lock	26
Serial number	
lock system	17
Service	14
Shock absorber	
adjusting the high-speed compression damping	118
adjusting the low-speed compression damp- ing	117
adjusting the rebound damping	118
adjusting the spring preload	119
Side stand	28
Spare parts	14
Starting	104
Steering lock	25
Stopping	111
Storage	185
Storage compartment	
USB socket	26
T	
Tampering	10
Throttle twist grip	19

Time	
adjusting	165
Tire condition	
checking	150
Tire pressure	
checking	151
Tire repair spray	
use	151
towing	112
Transportation	112
Turn signal switch	23
U	
UP/DOWN button	22
USB socket	26
V	
Vehicle identification number	17
VIN	17
W	
Winter operation	
checks and maintenance steps	183
Work rules	11



3240301en

24/02/2026

