OWNER'S MANUAL **2015**

FC 250 EU
FC 250 US

Art. no. 3402019en



THE PIONEERS OF MOTOCROSS

Husqvarna®
MOTORCYCLES

DEAR HUSQVARNA CUSTOMER

Congratulations on your decision to purchase a Husqvarna motorcycle. You are now the owner of a state-of-the-art sports motorcycle that will give you enormous pleasure if you service and maintain it accordingly.

We wish you a lot of enjoyment in riding this vehicle.

Enter the serial numbers of your vehicle below.

Chassis number (☛ p. 10)	Dealer's stamp
Engine number (☛ p. 10)	

The Owner's Manual contained the latest information for this model series at the time of going to print. Slight deviations resulting from continuing development and design can, however, not be completely excluded.

All specifications are non-binding. Husqvarna Motorcycles GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. Husqvarna accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2014 Husqvarna Motorcycles GmbH, Mattighofen Austria
All rights reserved
Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.

ISO 9001(12 100 6061)
Husqvarna applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.
Issued by: TÜV Management Service

REG.NO. 12 100 6061

Husqvarna Motorcycles GmbH
5230 Mattighofen, Austria

TABLE OF CONTENTS

1 MEANS OF REPRESENTATION 4
1.1 Symbols used 4
1.2 Formats used 4
2 SAFETY ADVICE 5
2.1 Use definition - intended use 5
2.2 Safety advice 5
2.3 Degrees of risk and symbols 5
2.4 Tampering warning 5
2.5 Safe operation 5
2.6 Protective clothing 6
2.7 Work rules 6
2.8 Environment 6
2.9 Owner's Manual 6
3 IMPORTANT NOTES 7
3.1 Manufacturer and implied warranty 7
3.2 Operating and auxiliary substances 7
3.3 Spare parts, accessories 7
3.4 Service 7
3.5 Figures 7
3.6 Customer service 7
4 VIEW OF VEHICLE 8
4.1 View of vehicle, front left side (example) 8
4.2 View of vehicle, rear right side (example) 9
5 SERIAL NUMBERS 10
5.1 Chassis number 10
5.2 Type label 10
5.3 Engine number 10
5.4 Fork part number 10
5.5 Shock absorber part number 10
6 CONTROLS 11
6.1 Clutch lever 11
6.2 Hand brake lever 11
6.3 Throttle grip 11
6.4 Kill switch 11
6.5 Electric starter button 11
6.6 Map-Select switch for the basic setting 12
6.7 Map-Select switch for vehicle operation 12
6.8 Overview of indicator lamps 12
6.9 Opening the filler cap 12
6.10 Closing the filler cap 13
6.11 Cold start button 13
6.12 Idle speed adjusting screw 14
6.13 Shift lever 14
6.14 Foot brake lever 14
6.15 Plug-in stand 15
7 PREPARING FOR USE 16
7.1 Advice on first use 16
7.2 Running in the engine 17
7.3 Preparing the vehicle for difficult operating conditions 17
7.4 Preparing for rides on dry sand 17
7.5 Preparing for rides on wet sand 18
7.6 Preparing for rides on wet and muddy surfaces 18
7.7 Preparing for rides at high temperatures and low speeds 19
7.8 Preparing for rides at low temperatures or in snow 19
8 RIDING INSTRUCTIONS 20
8.1 Checks and maintenance before putting into operation 20
8.2 Starting 20
8.3 Starting off 21
8.4 Shifting, riding 21
8.5 Applying the brakes 21
8.6 Stopping, parking 21
8.7 Transport 22
8.8 Refueling 22
9 SERVICE SCHEDULE 24
9.1 Service schedule 24
9.2 Service work (as additional order) 25
10 TUNING THE CHASSIS 26
10.1 Checking the basic chassis setting with the rider's weight 26
10.2 Compression damping of the shock absorber 26
10.3 Adjusting the low-speed compression damping of the shock absorber 26
10.4 Adjusting the high-speed compression damping of the shock absorber 27
10.5 Adjusting the rebound damping of the shock absorber 27
10.6 Measuring rear wheel sag unloaded 28
10.7 Checking the static sag of the shock absorber 28
10.8 Checking the riding sag of the shock absorber 28
10.9 Adjusting the spring preload of the shock absorber 🔧 29
10.10 Adjusting the riding sag 🔧 29
10.11 Checking the basic setting of the fork 30
10.12 Adjusting the compression damping of the fork 30
10.13 Adjusting the rebound damping of the fork 31
10.14 Handlebar position 31
10.15 Adjusting the handlebar position 🔧 31
11 SERVICE WORK ON THE CHASSIS 33
11.1 Raising the motorcycle with the lift stand 33
11.2 Removing the motorcycle from the lift stand 33
11.3 Bleeding the fork legs 33
11.4 Cleaning the dust boots of the fork legs 34
11.5 Removing the fork protector 34
11.6 Installing the fork protector 34
11.7 Removing the fork legs 🔧 35
11.8 Installing the fork legs 🔧 35
11.9 Removing the lower triple clamp 🔧 36
11.10 Installing the lower triple clamp 🔧 36
11.11 Checking the steering head bearing play 38
11.12 Adjusting the play of the steering head bearing 🔧 38
11.13 Greasing the steering head bearing 🔧 39
11.14 Removing the start number plate 39
11.15 Installing the start number plate 39
11.16 Removing the front fender 39
11.17 Installing the front fender 40
11.18 Removing the shock absorber 🔧 40
11.19 Installing the shock absorber 🔧 41
11.20 Removing the seat 42
11.21 Mounting the seat 43
11.22 Removing the air filter box lid 43
11.23 Installing the air filter box lid 43
11.24 Removing the air filter 🔧 43

TABLE OF CONTENTS

11.25 Installing the air filter 🔧 ... 44
11.26 Cleaning the air filter and air filter box 🔧 ... 44
11.27 Sealing the air filter box 🔧 ... 45
11.28 Removing the main silencer ... 45
11.29 Installing the main silencer ... 45
11.30 Changing the glass fiber yarn filling of the main silencer 🔧 ... 45
11.31 Removing the right side cover ... 46
11.32 Installing the right side cover ... 46
11.33 Removing the fuel tank 🔧 ... 47
11.34 Installing the fuel tank 🔧 ... 48
11.35 Checking for chain dirt accumulation ... 49
11.36 Cleaning the chain ... 49
11.37 Checking the chain tension ... 49
11.38 Adjusting the chain tension ... 50
11.39 Checking the chain, rear sprocket, engine sprocket and chain guide ... 51
11.40 Checking the frame 🔧 ... 53
11.41 Checking the swingarm 🔧 ... 53
11.42 Checking the throttle cable routing ... 53
11.43 Checking the rubber grip ... 54
11.44 Additionally securing the rubber grip ... 54
11.45 Adjusting the basic position of the clutch lever ... 54
11.46 Checking/rectifying the fluid level of the hydraulic clutch ... 54
11.47 Changing the hydraulic clutch fluid 🔧 ... 55
12 BRAKE SYSTEM ... 56
12.1 Checking the free travel of the hand brake lever ... 56
12.2 Adjusting the basic position of the hand brake lever ... 56
12.3 Checking the brake discs ... 56
12.4 Checking the front brake fluid level ... 57
12.5 Adding front brake fluid 🔧 ... 57
12.6 Checking the front brake linings ... 58
12.7 Changing the front brake linings 🔧 ... 58
12.8 Checking the free travel of foot brake lever ... 60
12.9 Adjusting the basic position of the foot brake lever 🔧 ... 60
12.10 Checking the rear brake fluid level ... 61
12.11 Adding rear brake fluid 🔧 ... 61
12.12 Checking the rear brake linings ... 62
12.13 Changing the rear brake linings 🔧 ... 63
13 WHEELS, TIRES ... 65
13.1 Removing the front wheel 🔧 ... 65
13.2 Installing the front wheel 🔧 ... 65
13.3 Removing the rear wheel 🔧 ... 66
13.4 Installing the rear wheel 🔧 ... 67
13.5 Checking the tire condition ... 68
13.6 Checking the tire air pressure ... 69
13.7 Checking the spoke tension ... 69
14 ELECTRICAL SYSTEM ... 70
14.1 Removing the battery 🔧 ... 70
14.2 Installing the battery 🔧 ... 70
14.3 Recharging the battery 🔧 ... 71
14.4 Changing the main fuse ... 72
15 COOLING SYSTEM ... 73
15.1 Cooling system ... 73
15.2 Checking the antifreeze and coolant level ... 73
15.3 Checking the coolant level ... 74
15.4 Draining the coolant 🔧 ... 74
15.5 Refilling coolant 🔧 ... 75
16 TUNING THE ENGINE ... 76
16.1 Checking the play in the throttle cable ... 76
16.2 Adjusting the play in the throttle cable 🔧 ... 76
16.3 Adjusting the idle speed 🔧 ... 77
16.4 Checking the basic position of the shift lever ... 77
16.5 Adjusting the basic position of the shift lever 🔧 ... 77
17 SERVICE WORK ON THE ENGINE ... 78
17.1 Changing the fuel screen 🔧 ... 78
17.2 Checking the engine oil level ... 78
17.3 Changing the engine oil and oil filter, cleaning the oil screen 🔧 ... 79
17.4 Adding engine oil ... 80
18 CLEANING, CARE ... 82
18.1 Cleaning the motorcycle ... 82
19 STORAGE ... 83
19.1 Storage ... 83
19.2 Putting into operation after storage ... 83
20 TROUBLESHOOTING ... 84
21 BLINK CODE ... 86
22 TECHNICAL DATA ... 87
22.1 Engine ... 87
22.2 Engine tightening torques ... 87
22.3 Capacities ... 89
22.3.1 Engine oil ... 89
22.3.2 Coolant ... 89
22.3.3 Fuel ... 89
22.4 Chassis ... 89
22.5 Electrical system ... 90
22.6 Tires ... 90
22.7 Fork ... 90
22.8 Shock absorber ... 90
22.9 Chassis tightening torques ... 91
23 SUBSTANCES ... 93
24 AUXILIARY SUBSTANCES ... 95
25 STANDARDS ... 96
INDEX ... 97

1 MEANS OF REPRESENTATION

1.1 Symbols used

The symbols used are explained in the following.



Identifies an expected reaction (e.g. to a work step or a function).



Identifies an unexpected reaction (e.g. to a work step or a function).



All work marked with this symbol requires specialist knowledge and technical understanding. In the interest of your own safety, have these jobs performed by an authorized Husqvarna workshop. There, your motorcycle will be optimally cared for by specially trained experts using the special tools required.



Identifies a page reference (more information is provided on the specified page).

1.2 Formats used

The following typographical formats are used.

Specific name	Identifies a proprietary name.
Name®	Identifies a protected name.
Brand™	Identifies a brand available on the open market.

2 SAFETY ADVICE

2.1 Use definition - intended use

Husqvarna sport motorcycles are designed and built to withstand the normal stresses and strains of competitive use. The motorcycles comply with currently valid regulations and categories of the top international motorsport organizations.

Info
The motorcycle may only be used in closed off areas remote from public road traffic.

2.2 Safety advice

A number of safety instructions need to be followed to operate the vehicle safely. Therefore, read this manual carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.

Info
The vehicle has various information and warning labels at prominent locations. Do not remove information/warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.3 Degrees of risk and symbols

Danger
Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.

Warning
Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.

Caution
Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note
Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.

Warning
Identifies a danger that will lead to environmental damage if the appropriate measures are not taken.

2.4 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

1 The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

1 Removal or puncturing of the main silencer, baffles, header pipes or any other components which conduct exhaust gases.
2 Removal or puncturing of parts of the intake system.
3 Lack of proper maintenance.
4 Replacing moving part of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

2.5 Safe operation

Danger
Danger of accidents Danger arising from the rider's judgement being impaired.

– Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.

Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

– When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

– Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.
The vehicle should only be used by trained persons.
Have malfunctions that impair safety promptly eliminated by an authorized Husqvarna workshop.
Adhere to the information and warning labels on the vehicle.

2.6 Protective clothing

Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

– Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.

In the interest of your own safety, Husqvarna recommends that you only operate the vehicle while wearing protective clothing.

2.7 Work rules

Special tools are necessary for certain tasks. The tools are not contained in the vehicle but can be ordered under the number in parentheses. E.g.: bearing puller (15112017000)
During assembly, non-reusable parts (e.g. self-locking screws and nuts, seals and seal rings, O-rings, pins, lock washers) must be replaced by new parts.
In some instances, a thread locker (e.g. **Loctite®**) is required. The manufacturer instructions for use must be followed.
After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.
After you complete the repair or service work, check the operating safety of the vehicle.

2.8 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.
When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and regulations of the respective country.
Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized Husqvarna dealer will be glad to advise you.

2.9 Owner's Manual

It is important that you read this Owner's Manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and maintain your motorcycle. Only then will you find out how to customize the vehicle ideally for your own use and how you can protect yourself from injury.
Keep the Owner's Manual in an accessible place to enable you to refer to it as needed.
If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized Husqvarna dealer.
The Owner's Manual is an important component of the vehicle and should be handed over to the new owner if the vehicle is sold.

3 IMPORTANT NOTES

3.1 Manufacturer and implied warranty

The work prescribed in the service schedule must be carried out by an authorized Husqvarna workshop only and confirmed in the customer's service & warranty booklet and in the **Husqvarna dealer.net**; otherwise, all warranty claims will be void. No warranty claims can be considered for damage resulting from manipulations and/or alterations to the vehicle.
Additional information on the manufacturer or implied warranty and the procedures involved can be found in the service & warranty booklet.

3.2 Operating and auxiliary substances



Warning
Environmental hazard Improper handling of fuel is a danger to the environment.

– Do not allow fuel to get into the ground water, the ground, or the sewage system.

Use operating and auxiliary substances (such as fuel and lubricants) as specified in the Owner's Manual.

3.3 Spare parts, accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by Husqvarna and have them installed by an authorized Husqvarna workshop. Husqvarna accepts no liability for other products and any resulting damage or loss.
Certain spare parts and accessory products are specified in parentheses in the descriptions. Your authorized Husqvarna dealer will be glad to advise you.

The current **Husky Power** parts for your vehicle can be found on the Husqvarna website.
International Husqvarna website: www.husqvarna-motorcycles.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. Incorrect adjustment and tuning of the engine and chassis can lead to damage and breakage of components.
Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.
It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

3.5 Figures

The figures contained in the manual may depict special equipment.
In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.


3.6 Customer service

Your authorized Husqvarna dealer will be happy to answer any questions you may have on your vehicle and Husqvarna.

A list of authorized Husqvarna dealers can be found on the Husqvarna website.
International Husqvarna website: www.husqvarna-motorcycles.com

4 VIEW OF VEHICLE

4.1 View of vehicle, front left side (example)



1	Hand brake lever (☛ p. 11)
2	Fork compression adjustment
3	Clutch lever (☛ p. 11)
4	Filler cap
5	Cold start button (☛ p. 13)
6	Shift lever (☛ p. 14)
7	Engine number (☛ p. 10)
8	Air filter box lid
9	Plug-in stand (☛ p. 15)


4.2 View of vehicle, rear right side (example)



1	Kill switch (☛ p. 11)
2	Electric starter button (☛ p. 11)
3	Throttle grip (☛ p. 11)
4	Fork rebound adjustment
5	Shock absorber rebound adjustment
6	Shock absorber compression adjustment
7	Level viewer, engine oil
8	Foot brake lever (☛ p. 14)
9	Fork part number (☛ p. 10)


5 SERIAL NUMBERS

5.1 Chassis number




The chassis number ❶ is stamped on the right side of the steering head.

5.2 Type label




The type label ❶ is fixed to the front of the steering head.

5.3 Engine number




The engine number ❶ is stamped on the left side of the engine under the engine sprocket.

5.4 Fork part number



The fork part number ❶ is stamped on the inner side of the axle clamp.


5.5 Shock absorber part number



The shock absorber part number ❶ is stamped on the top of the shock absorber above the adjusting ring on the engine side.


6 CONTROLS

6.1 Clutch lever




The clutch lever ❶ is fitted on the left side of the handlebar.
The clutch is hydraulically operated and self-adjusting.

6.2 Hand brake lever




Hand brake lever ❶ is located on the right side of the handlebar.
The hand brake lever is used to activate the front brake.

6.3 Throttle grip



The throttle grip ❶ is fitted on the right side of the handlebar.

6.4 Kill switch




Kill switch ❶ is fitted on the left side of the handlebar.

Possible states

- Kill switch ⊠ in the basic position – In this position, the ignition circuit is closed and the engine can be started.
- Kill switch ⊠ pressed – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

6.5 Electric starter button




The electric starter button ❶ is fitted on the right side of the handlebar.

Possible states

- Electric starter button ⓢ in basic position
- Electric starter button ⓢ pressed – In this position, the electric starter is actuated.

6.6 Map-Select switch for the basic setting




The **Map-Select** switch for the basic setting ❶ is fitted under the seat.

Possible states

1	Soft – The mapping with reduced peak performance for better rideability is activated.
2	ADVANCED – The mapping for performance with a very direct response is activated.
3 - **9**, **0**	Standard – The mapping for performance with a balanced response is activated.

The **Map-Select** switch for the basic setting is used to preselect the engine characteristic.

6.7 Map-Select switch for vehicle operation




The **Map-Select** switch for vehicle operation ❶ is fitted on the right side of the handlebar.

Possible states

I	Standard – In this position, STANDARD Mapping is always activated.
II	SOFT or ADVANCED – In this position, the mapping that is set on the **Map-Select** switch for the basic setting is activated.

The engine characteristic can be changed on the handlebar using the **Map-Select** switch for vehicle operation. This change is activated while the engine is idling or on restarting.

6.8 Overview of indicator lamps



Possible states

FI	**FI** warning lamp (**MIL**) lights up/flashes orange – The OBD (onboard diagnosis) has identified an emissions- or safety-critical fault.

6.9 Opening the filler cap

Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.

Warning


Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



– Turn filler cap ❶ counterclockwise and lift it off.


6.10 Closing the filler cap



– Mount filler cap ❶ and turn it clockwise until the fuel tank is tightly closed.

Info
Run the fuel tank breather hose ❷ without kinks.

6.11 Cold start button




The cold start button ❶ is fitted on the left on the throttle valve body.
The injection system extends the injection time if the engine is cold and the outside temperature is low. To help the engine burn the increased amount of fuel, it must be supplied with additional oxygen by pulling the cold start button.

Possible states


- The cold start button is activated – The cold start button is pulled out all the way.
- The cold start button is deactivated – The cold start button is pushed in all the way.

6.12 Idle speed adjusting screw




The idle setting of the throttle valve body has a big influence on the vehicle's starting behavior, on stable idling, and on vehicle response when the throttle is opened. This means that an engine with a correctly set idle speed is easier to start than if the idle is set wrongly.
The idle speed is adjusted with the idle speed adjusting screw ❶.
Increase the idle speed by turning the idle speed adjusting screw clockwise.
Decrease the idle speed by turning the idle speed adjusting screw counterclockwise.

6.13 Shift lever




Shift lever ❶ is mounted on the left side of the engine.




The gear positions can be seen in the photograph.
The neutral or idle position is between the first and second gears.

6.14 Foot brake lever



Foot brake lever ❶ is located in front of the right footrest.
The foot brake lever is used to activate the rear brake.

6.15 Plug-in stand



The holder for the plug-in stand ❶ is the left side of the wheel spindle.
The plug-in stand is used to park the motorcycle.

Info
Remove the plug-in stand before starting on a trip.

7 PREPARING FOR USE

7.1 Advice on first use

Danger

Danger of accidents Danger arising from the rider's judgement being impaired.

– Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.

Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

– Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.

Warning

Danger of crashing Poor vehicle handling due to different tire tread patterns on front and rear wheels.

– The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.

Warning

Danger of accidents Critical riding behavior due to inappropriate riding.

– Adapt your riding speed to the road conditions and your riding ability.

Warning

Danger of accidents Accident risk caused by presence of a passenger.

– Your vehicle is not designed to carry passengers. Do not ride with a passenger.

Warning

Danger of accidents Failure of brake system.

– If the foot brake lever is not released, the brake linings drag continuously. The rear brake may fail due to overheating. Take your foot off the foot brake lever when you are not braking.

Warning

Danger of accidents Unstable riding behavior.

– Do not exceed the maximum permissible weight and axle loads.

Warning

Risk of misappropriation Usage by unauthorized persons.

– Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.

Info

When using your motorcycle, remember that others may feel disturbed by excessive noise.

– Make sure that the pre-delivery inspection work has been carried out by an authorized Husqvarna workshop.
  ✓ You receive a delivery certificate and the service record at vehicle handover.
– Before your first trip, read the entire operating instructions carefully.
– Familiarize yourself with the controls.
– Adjust the basic position of the clutch lever. (☛ p. 54)
– Adjust the basic position of the hand brake lever. (☛ p. 56)
– Adjust the basic position of the foot brake lever. 🔧 (☛ p. 60)
– Adjust the basic position of the shift lever. 🔧 (☛ p. 77)
– Get used to handling the motorcycle on a suitable piece of land before making a longer trip.

Info

Your motorcycle is not authorized for riding on public roads.
Offroad, you should be accompanied by another person on another machine so that you can help each other.

– Try also to ride as slowly as possible and in a standing position to get a better feeling for the vehicle.
– Do not make any offroad trips that over-stress your ability and experience.
– Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
– Do not take luggage along.

– Do not exceed the overall maximum permitted weight and the axle loads.

Guideline

Maximum permissible overall weight	335 kg (739 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)

– Run in the engine. (☛ p. 17)

7.2 Running in the engine

– During the running-in phase, do not exceed the specified engine speed and engine performance.

Guideline

Maximum engine speed	
During the first operating hour	7,000 rpm
Maximum engine performance	
During the first 3 operating hours	≤ 75 %

– Avoid fully opening the throttle!

7.3 Preparing the vehicle for difficult operating conditions

Info

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

– Seal the air filter box. 🔧 (☛ p. 45)
– Clean the air filter and air filter box. 🔧 (☛ p. 44)

Info

Check the air filter approx. every 30 minutes.

– Additionally secure the rubber grip. (☛ p. 54)
– Check the electrical connector for humidity and corrosion and to ensure it is firmly seated.
  » If humidity, corrosion or damage is found:
    – Clean and dry the connector, or change it if necessary.

Difficult operating conditions are:

– Rides on dry sand. (☛ p. 17)
– Rides on wet sand. (☛ p. 18)
– Rides on wet and muddy surfaces. (☛ p. 18)
– Rides at high temperatures and low speeds. (☛ p. 19)
– Rides at low temperatures or in snow. (☛ p. 19)

7.4 Preparing for rides on dry sand



B00435-01

– Fit a dust protection device on the air filter.

Dust protection device for air filter (77206920100)

Info

Observe the **Husky Power** fitting instructions.



B00436-01

– Fit a sand protection device on the air filter.

Sand protection device for air filter (59006922000)

Info
Observe the **Husky Power** fitting instructions.


600868-01

– Clean the chain.
– Fit the steel sprocket.

Tip
Do not grease the chain.

– Clean the radiator fins.
– Straighten bent radiator fins carefully.
– If used in sand regularly, replace the piston every 20 operating hours.

7.5 Preparing for rides on wet sand



B00437-01

– Fit a waterproofing device on the air filter.

Waterproofing device for air filter (77206921100)

Info
Observe the **Husky Power** fitting instructions.


600868-01

– Clean the chain.
– Fit the steel sprocket.

Tip
Do not grease the chain.

– Clean the radiator fins.
– Straighten bent radiator fins carefully.
– If used in sand regularly, replace the piston every 20 operating hours.

7.6 Preparing for rides on wet and muddy surfaces



B00437-01

– Fit a waterproofing device on the air filter.

Waterproofing device for air filter (77206921100)

Info
Observe the **Husky Power** fitting instructions.


600868-01

– Fit the steel sprocket.
– Clean the motorcycle. (☛ p. 82)
– Straighten bent radiator fins carefully.

7.7 Preparing for rides at high temperatures and low speeds


600868-01

– Adjust the secondary drive to the road conditions.

Info
The engine oil heats up quickly when the clutch is operated frequently due to an excessively high secondary drive.

– Clean the chain.
– Clean the radiator fins.
– Straighten bent radiator fins carefully.
– Check the coolant level. (☛ p. 74)

7.8 Preparing for rides at low temperatures or in snow



B00437-01

– Fit a waterproofing device on the air filter.

Waterproofing device for air filter (77206921100)

Info
Observe the **Husky Power** fitting instructions.

8 RIDING INSTRUCTIONS

8.1 Checks and maintenance before putting into operation

Info
Before every trip, check the condition of the vehicle and ensure that it is safe to operate.
The vehicle must be in perfect technical condition when used.

- Check the engine oil level. (☛ p. 78)
- Check the front brake fluid level. (☛ p. 57)
- Check the rear brake fluid level. (☛ p. 61)
- Check the front brake linings. (☛ p. 58)
- Check the rear brake linings. (☛ p. 62)
- Check that the brake system is functioning properly.
- Check the coolant level. (☛ p. 74)
- Check for chain dirt accumulation. (☛ p. 49)
- Check the chain, rear sprocket, engine sprocket and chain guide. (☛ p. 51)
- Check the chain tension. (☛ p. 49)
- Check the tire condition. (☛ p. 68)
- Check the tire air pressure. (☛ p. 69)
- Check the spoke tension. (☛ p. 69)
- Clean the dust boots of the fork legs. (☛ p. 34)
- Bleed the fork legs. (☛ p. 33)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts and hose clamps regularly for tightness.
- Check the fuel reserves.


8.2 Starting

Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

Note
Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.



- Remove the plug-in stand.
- Shift gear to neutral.

Condition
Ambient temperature: < 20 °C (< 68 °F)

- Pull the cold start button out all the way.
- Press the electric starter button Ⓢ.

Info
Press the electric starter button for at most 5 seconds. Wait for a least 5 seconds before trying again.
FI warning lamp lights up briefly as a functional control when starting.

8.3 Starting off

– Pull the clutch lever, engage 1st gear, release the clutch lever slowly and simultaneously open the throttle carefully.

8.4 Shifting, riding

Warning
Danger of accidents If you change down at high engine speed, the rear wheel can lock up.

– Do not change into a low gear at high engine speed. The engine races and the rear wheel can lock up.

Info
If you hear unusual noises while riding, stop immediately, switch off the engine and contact an authorized Husqvarna workshop. First gear is used for starting off or for steep inclines.

– When conditions allow (incline, road situation, etc.), you can shift into a higher gear. To do so, release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the throttle.
– If the cold start button was pulled out during starting, push the cold start button all the way in after the engine warms up.
– After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is ¾ open. This will barely reduce the speed but fuel consumption will be considerably lower.
– Always open the throttle only as much as the engine can handle – opening the throttle abruptly increases fuel consumption.
– To shift down, brake and close the throttle at the same time.
– Pull the clutch lever and shift into a lower gear, release the clutch lever slowly and open the throttle or shift again.
– Switch off the engine if you expect to be standing for a long time.

Guideline

≥ 1 min

– Avoid frequent and longer slipping of the clutch. This heats the engine oil, the engine and the cooling system.
– Ride with a lower engine speed instead of with a high engine speed and a slipping clutch.

8.5 Applying the brakes

Warning
Danger of accidents If you brake too hard, the wheels can lock.

– Adapt your braking to the traffic situation and the road conditions.

Warning
Danger of accidents Reduced braking efficiency caused by spongy pressure point of front or rear brake.

– Check the brake system and do not continue riding. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

– Clean or dry a dirty or wet brake system by riding and braking gently.

– On sandy, wet or slippery surfaces, use the rear brake.
– Braking should always be completed before you go into a bend. Change down to a lower gear appropriate to your road speed.
– On long downhill stretches, use the braking effect of the engine. Change down one or two gears, but do not overstress the engine. In this way, you have to apply the brakes far less frequently and the brake system does not overheat.

8.6 Stopping, parking

Warning
Risk of misappropriation Usage by unauthorized persons.

– Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.

Warning
Danger of burns Some vehicle components become very hot when the vehicle is operated.

– Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Note
Danger of damage The parked vehicle may roll away or fall over.

– Always place the vehicle on a firm and even surface.

Note
Fire hazard Some vehicle components become very hot when the vehicle is operated.

– Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.

– Brake the motorcycle.
– Shift gear to neutral.
– Press and hold the kill switch ⊠ while the engine is idling until the engine stops.
– Park the motorcycle on firm ground.


8.7 Transport

Note
Danger of damage The parked vehicle may roll away or fall over.

– Always place the vehicle on a firm and even surface.

Note
Fire hazard Some vehicle components become very hot when the vehicle is operated.

– Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.


401475-01

– Switch off the engine.
– Use tension belts or other suitable devices to secure the motorcycle against accidents or falling over.

8.8 Refueling

Danger
Fire hazard Fuel is highly flammable.

– Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
– The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

Warning
Danger of poisoning Fuel is poisonous and a health hazard.


– Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.

Note
Material damage Premature clogging of the fuel filter.

– In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system. (Your authorized Husqvarna workshop will be glad to help.)
– Only refuel with clean fuel that meets the specified standards.

Warning
Environmental hazard Improper handling of fuel is a danger to the environment.

– Do not allow fuel to get into the ground water, the ground, or the sewage system.



– Switch off the engine.
– Open the filler cap. (☛ p. 12)
– Fill the fuel tank with fuel up to measurement Ⓐ.

Guideline

Measurement of Ⓐ	35 mm (1.38 in)

Total fuel tank capacity, approx.	7.5 l (1.98 US gal)	Super unleaded (ROZ 95/RON 95/PON 91) (☛ p. 94)

– Close the filler cap. (☛ p. 13)

9 SERVICE SCHEDULE

9.1 Service schedule

	Once after 1 operating hour - corresponds to about 7 liters of fuel (1.8 US gal)	Every 10 operating hours - corresponds to about 70 liters of fuel (18.5 US gal) / after every race	Every 20 operating hours - corresponds to about 140 liters of fuel (37 US gal)	Every 30 operating hours - corresponds to about 210 liters of fuel (55.5 US gal)
Read out the fault memory using the Husqvarna diagnostics tool. 🔧	○	●	●	●
Check and charge the battery. 🔧		●	●	●
Check the front brake linings. (☛ p. 58)		●	●	●
Check the rear brake linings. (☛ p. 62)		●	●	●
Check the brake discs. (☛ p. 56)		●	●	●
Check the brake lines for damage and leakage.		●	●	●
Check the rear brake fluid level. (☛ p. 61)		●	●	●
Check the free travel of the foot brake lever. (☛ p. 60)		●	●	●
Check the frame and swingarm. 🔧		●	●	●
Check the swingarm bearing. 🔧			●	
Check the heim joints at the top of the shock absorber. 🔧		●	●	●
Check the shock absorber linkage. 🔧		●	●	●
Check the tire condition. (☛ p. 68)	○	●	●	●
Check the tire air pressure. (☛ p. 69)	○	●	●	●
Check the wheel bearing for play. 🔧		●	●	●
Check the wheel hubs. 🔧		●	●	●
Check the rim run-out. 🔧	○	●	●	●
Check the spoke tension. (☛ p. 69)	○	●	●	●
Check the chain, rear sprocket, engine sprocket and chain guide. (☛ p. 51)		●	●	●
Check the chain tension. (☛ p. 49)	○	●	●	●
Grease all moving parts (e.g., hand lever, chain, ...) and check for smooth operation. 🔧		●	●	●
Check/rectify the fluid level of the hydraulic clutch. (☛ p. 54)		●	●	●
Check the front brake fluid level. (☛ p. 57)		●	●	●
Check the free travel of the hand brake lever. (☛ p. 56)		●	●	●
Check the steering head bearing play. (☛ p. 38)	○	●	●	●
Check the valve clearance. 🔧	○			●
Check the clutch. 🔧			●	
Change the shaft seal rings of the water pump. 🔧				●
Change the engine oil and oil filter, clean the oil screen. 🔧 (☛ p. 79)	○	●	●	●
Check all hoses (e. g. fuel, cooling, bleeding, drainage) and sleeves for tearing, leaks and incorrect routing. 🔧	○	●	●	●
Check the antifreeze and coolant level. (☛ p. 73)	○	●	●	●
Check the cables for damage and routing without sharp bends. 🔧		●	●	●
Check that the throttle cables are undamaged, routed without sharp bends and set correctly.	○	●	●	●
Clean the air filter and air filter box. 🔧 (☛ p. 44)		●	●	●
Change the glass fiber yarn filling of the main silencer. 🔧 (☛ p. 45)			●	
Check the screws and nuts for tightness. 🔧	○	●	●	●
Change the fuel screen. 🔧 (☛ p. 78)	○	●	●	●
Check the fuel pressure. 🔧		●	●	●
Check the idle. 🔧	○	●	●	●
Final check: Check the vehicle for operating safety and take a test ride.	○	●	●	●
Read out the fault memory using after the test ride the Husqvarna diagnostics tool. 🔧	○	●	●	●
Make the service entry in **Husqvarna Dealer.net** and in the service booklet. 🔧	○	●	●	●

○ One-time interval

● Periodic interval

9.2 Service work (as additional order)


	Once after 10 operating hours	Once after 20 operating hours	Every 40 operating hours - corresponds to about 280 liters of fuel (74 US gal)	Every 50 operating hours - corresponds to about 350 liters of fuel (92.5 US gal)	Every 100 operating hours - corresponds to about 700 liters of fuel (185 US gal)	Annually
Change the front brake fluid. 🔧						●
Change the rear brake fluid. 🔧						●
Change the hydraulic clutch fluid. 🔧 (☛ p. 55)						●
Grease the steering head bearing. 🔧 (☛ p. 39)						●
Perform a fork service. 🔧	○		●			
Service the shock absorber. 🔧		○	●			
Change the spark plug and spark plug connector. 🔧					●	
Change the piston. 🔧				●	●	
Check/measure the cylinder. 🔧				●	●	
Check the cylinder head. 🔧				●	●	
Change the valves, valve springs and valve spring seats. 🔧					●	
Check the camshaft and cam lever. 🔧				●	●	
Change the connecting rod, conrod bearing, and crank pin. 🔧					●	
Check the transmission and shift mechanism. 🔧					●	
Check the oil pressure regulator valve. 🔧				●	●	
Change the suction pump. 🔧					●	
Check the force pump and lubrication system. 🔧					●	
Change the timing chain. 🔧					●	
Check the timing assembly. 🔧				●	●	
Change all engine bearings. 🔧					●	

○ One-time interval

● Periodic interval

10.1 Checking the basic chassis setting with the rider's weight

Info
When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, swingarm and frame, the basic settings of the suspension components must match the rider's weight.
- As delivered, Husqvarna motorcycles are adjusted for an average rider's weight (with full protective clothing).

  Guideline

Standard rider weight	75… 85 kg (165… 187 lb.)

- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
- Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.

10.2 Compression damping of the shock absorber


The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed.
High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.
The high-speed setting, for example, has an effect on the landing after a jump: the rear wheel suspension compresses more quickly.
The low-speed setting, for example, has an effect when riding over long ground swells: the rear wheel suspension compresses more slowly.
These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

10.3 Adjusting the low-speed compression damping of the shock absorber

Caution
Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna workshop will be glad to help.)

Info
The low-speed setting can be seen during the slow to normal compression of the shock absorber.



- Turn adjusting screw ❶ clockwise with a screwdriver up to the last perceptible click.

  Info
  Do not loosen fitting ❷.

- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

  Guideline

Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks


Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.4 Adjusting the high-speed compression damping of the shock absorber

Caution
Danger of accidents Disassembly of pressurized parts can lead to injury.

– The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna workshop will be glad to help.)

Info
The high-speed setting can be seen during the fast compression of the shock absorber.



– Turn adjusting screw ❶ all the way clockwise with a socket wrench.

Info
Do not loosen fitting ❷.

– Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline


Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.5 Adjusting the rebound damping of the shock absorber

Caution
Danger of accidents Disassembly of pressurized parts can lead to injury.

– The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna workshop will be glad to help.)




– Turn adjusting screw ❶ clockwise up to the last perceptible click.
– Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.6 Measuring rear wheel sag unloaded



Preparatory work

– Raise the motorcycle with the lift stand. (☛ p. 33)

Main work


– Measure the distance – as vertical as possible – between the rear axle and a fixed point, for example, a mark on the side cover.

– Note down the value as dimension Ⓐ.

Finishing work

– Remove the motorcycle from the lift stand. (☛ p. 33)

10.7 Checking the static sag of the shock absorber



– Measure distance Ⓐ of rear wheel unloaded. (☛ p. 28)

– Hold the motorcycle upright with the aid of an assistant.

– Measure the distance between the rear axle and the fixed point again.

– Note down the value as dimension Ⓑ.

Info

The static sag is the difference between measurements Ⓐ and Ⓑ.


– Check the static sag.

Static sag	30 mm (1.18 in)

» If the static sag is less or more than the specified value:

– Adjust the spring preload of the shock absorber. 🔧 (☛ p. 29)

10.8 Checking the riding sag of the shock absorber



– Measure distance Ⓐ of rear wheel unloaded. (☛ p. 28)

– With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.

✓ The rear wheel suspension levels out.

– Another person now measures the distance between the rear axle and the fixed point.

– Note down the value as dimension Ⓒ.

Info

The riding sag is the difference between measurements Ⓐ and Ⓒ.

– Check the riding sag.

Riding sag	100 mm (3.94 in)

» If the riding sag differs from the specified measurement:

– Adjust the riding sag. 🔧 (☛ p. 29)

10.9 Adjusting the spring preload of the shock absorber


Caution

Danger of accidents Disassembly of pressurized parts can lead to injury.

– The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized Husqvarna workshop will be glad to help.)

Info

Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.



Preparatory work

– Raise the motorcycle with the lift stand. (☛ p. 33)
– Remove the seat. (☛ p. 42)
– Remove the right side cover. (☛ p. 46)
– Remove the main silencer. (☛ p. 45)
– Remove the shock absorber. (☛ p. 40)
– After removing the shock absorber, clean it thoroughly.

Main work

– Loosen screw ❶.
– Turn adjusting ring ❷ until the spring is no longer under tension.

Hook wrench (T106S)

– Measure the overall spring length while the spring is not under tension.
– Tighten the spring by turning adjusting ring ❷ to measurement Ⓐ.

Guideline

Spring preload	8 mm (0.31 in)

Info

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

– Tighten screw ❶.

Guideline

Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)


Finishing work

– Install the shock absorber. (☛ p. 41)
– Install the main silencer. (☛ p. 45)
– Install the right side cover. (☛ p. 46)
– Mount the seat. (☛ p. 43)
– Remove the motorcycle from the lift stand. (☛ p. 33)

10.10 Adjusting the riding sag

Preparatory work

– Raise the motorcycle with the lift stand. (☛ p. 33)
– Remove the seat. (☛ p. 42)
– Remove the right side cover. (☛ p. 46)
– Remove the main silencer. (☛ p. 45)
– Remove the shock absorber. (☛ p. 40)
– After removing the shock absorber, clean it thoroughly.


B00292-10

Main work

– Choose and mount a suitable spring.

Guideline

Spring rate	
Weight of rider: 65… 75 kg (143… 165 lb.)	51 N/mm (291 lb/in)
Weight of rider: 75… 85 kg (165… 187 lb.)	54 N/mm (308 lb/in)
Weight of rider: 85… 95 kg (187… 209 lb.)	57 N/mm (325 lb/in)


Info
The spring rate is shown on the outside of the spring.

Finishing work

– Install the shock absorber. (☛ p. 41)
– Install the main silencer. (☛ p. 45)
– Install the right side cover. (☛ p. 46)
– Mount the seat. (☛ p. 43)
– Check the static sag of the shock absorber. (☛ p. 28)
– Check the riding sag of the shock absorber. (☛ p. 28)
– Adjust the rebound damping of the shock absorber. (☛ p. 27)
– Remove the motorcycle from the lift stand. (☛ p. 33)

10.11 Checking the basic setting of the fork

Info
For various reasons, no exact riding sag can be determined for the forks.


401000-01

– As with the shock absorber, smaller differences in the rider's weight can be compensated by the spring preload.
– However, if the fork is often overloaded (hard end stop on compression), harder springs must be fit to avoid damage to the fork and frame.

10.12 Adjusting the compression damping of the fork

Info
The hydraulic compression damping determines the fork suspension behavior.



M00244-10

– Turn the white adjusting screw ❶ all the way clockwise.

Info
Adjusting screw ❶ is located at the upper end of the left fork leg.
The compression damping is located in the left fork leg (white adjusting screw). The rebound damping is located in the right fork leg (red adjusting screw).

– Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.13 Adjusting the rebound damping of the fork

Info
The hydraulic rebound damping determines the fork suspension behavior.



– Turn the red adjusting screw ❶ all the way clockwise.

Info
Adjusting screw ❶ is located at the upper end of the right fork leg.
The rebound damping is located in the right fork leg (red adjusting screw).
The compression damping is located in the left fork leg (white adjusting screw).


– Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.14 Handlebar position



On the upper triple clamp, there are two holes at a distance of Ⓐ to each other.


Hole distance A	15 mm (0.59 in)

The holes on the handlebar support are placed at a distance of Ⓑ from the center.

Hole distance B	3.5 mm (0.138 in)

The handlebar can be mounted in four different positions. In this way, the handlebar can be mounted in the position that is most comfortable for the rider.

10.15 Adjusting the handlebar position



– Remove screws ❶. Take off the handlebar clamps. Take off the handlebar and lay it to one side.

Info
Protect the components against damage by covering them.
Do not bend the cables and lines.

– Remove screws ❷. Remove the handlebar support.
– Place the handlebar support in the required position. Mount and tighten screws ❷.

Guideline

Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	**Loctite® 243™**

Info
Position the left and right handlebar supports evenly.

– Position the handlebar.

Info
Make sure the cables and wiring are positioned correctly.

– Position the handlebar clamps. Mount and tighten screws ❶ evenly.

Guideline

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)


11 SERVICE WORK ON THE CHASSIS

11.1 Raising the motorcycle with the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

– Always place the vehicle on a firm and even surface.


401942-01

– Raise the motorcycle at the frame underneath the engine.
  ✓ The wheels must no longer touch the ground.
– Secure the motorcycle against falling over.


Lift stand (81329955000)

11.2 Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

– Always place the vehicle on a firm and even surface.




402001-10

– Remove the motorcycle from the lift stand.
– Remove the lift stand.
– To park the motorcycle, insert plug-in stand ❶ into the left side of the wheel spindle.

Info
Remove the plug-in stand before starting on a trip.

11.3 Bleeding the fork legs

Preparatory work
– Raise the motorcycle with the lift stand. (☛ p. 33)




M00245-10

Main work
– Release bleeder screws ❶.
  ✓ Any excess pressure escapes from the interior of the fork.
– Tighten the bleeder screws.

Finishing work
– Remove the motorcycle from the lift stand. (☛ p. 33)

11.4 Cleaning the dust boots of the fork legs



Preparatory work

– Raise the motorcycle with the lift stand. (☛ p. 33)
– Remove the fork protector. (☛ p. 34)

Main work

– Push dust boot ❶ downward of both fork legs.

Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can penetrate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.

Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

– Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

– Clean and oil the dust boots and inside fork tube of both fork legs.


Universal oil spray (☛ p. 95)

– Press the dust boots back into their normal position.
– Remove excess oil.

Finishing work


– Install the fork protector. (☛ p. 34)
– Remove the motorcycle from the lift stand. (☛ p. 33)

11.5 Removing the fork protector



– Remove screws ❶ on the left fork leg and take off the clamp.
– Remove screws ❷ on the left fork leg and take off the left fork protector.
– Remove screws ❸ on the right fork leg and take off the right fork protector.

11.6 Installing the fork protector



– Position the left fork protector. Mount and tighten screws ❶.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)


– Position the brake line and clamp. Mount and tighten screws ❷.
– Position the right fork protector. Mount and tighten screws ❸.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)


11.7 Removing the fork legs

Preparatory work
- Raise the motorcycle with the lift stand. (p. 33)
- Remove the front wheel. (p. 65)




Main work
- Remove screws 1 and take off the clamp.
- Remove screws 2 and take off the brake caliper.
- Allow the brake caliper and brake line to hang tension-free to the side.

Info
Do not pull the hand brake lever when the front wheel is removed.




- Loosen screws 3. Take out the left fork leg.
- Unscrew screws 4. Take out the right fork leg.

11.8 Installing the fork legs



Main work
- Position the fork legs.
  - ✓ Bleeder screws 1 face forward.

Info
The rebound damping is located in the right fork leg (red adjusting screw). The compression damping is located in the left fork leg (white adjusting screw).
Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.



- Tighten screws 2.


  Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)

- Tighten screws 3.

  Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)



- Position the brake caliper. Mount and tighten screws 4.

  Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	**Loctite® 243™**


- Position the brake line and clamp. Mount and tighten screws 5.

Finishing work
- Install the front wheel. (p. 65)

11.9 Removing the lower triple clamp

Preparatory work

- Raise the motorcycle with the lift stand. (☛ p. 33)
- Remove the front wheel. (☛ p. 65)
- Remove the fork legs. (☛ p. 35)
- Remove the start number plate. (☛ p. 39)
- Remove the front fender. (☛ p. 39)
- Remove the handlebar cushion.




M00250-10

Main work

- Take off cable holder ❶ in front of the left radiator.
- Remove screw ❷.
- Remove screw ❸.
- Take off the upper triple clamp with the handlebar and set it aside.


Info
Protect the components against damage by covering them.
Do not bend the cables and lines.



B01865-10

- Remove O-ring ❹. Remove protective ring ❺.
- Take off the lower triple clamp with the steering stem.
- Remove the upper steering head bearing.

11.10 Installing the lower triple clamp




401540-10

Main work

- Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease (☛ p. 95)

- Insert the lower triple clamp with the steering stem. Mount the upper steering head bearing.
- Check whether the upper steering head seal ❶ is correctly positioned.
- Slide on protective ring ❷ and O-ring ❸.



M00251-10

- Position the upper triple clamp with the steering.
- Mount screw ❹ but do not tighten yet.




– Position the fork legs.

✓ Bleeder screws ❺ face forward.

Info

The rebound damping is located in the right fork leg (red adjusting screw). The compression damping is located in the left fork leg (white adjusting screw).


Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.



– Fully tighten screws ❻.

Guideline


Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)



– Tighten screw ❹.

Guideline


Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)



– Mount and tighten screw ❼.

Guideline

Screw, top steering stem	M8	17 Nm (12.5 lbf ft)	**Loctite® 243™**




– Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.

– Tighten screws ❽.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)

– Secure the wiring harness with cable holder ❾.



– Position the brake caliper. Mount and tighten screws ❿.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	**Loctite® 243™**

– Position the brake line and clamp. Mount and tighten screws ⓫.

Finishing work


– Install the front fender. (☛ p. 40)

– Install the start number plate. (☛ p. 39)
– Install the front wheel. 🔧 (☛ p. 65)
– Check that the wiring harness, cables, and brake and clutch lines can move freely and are routed correctly.
– Check the steering head bearing play. (☛ p. 38)
– Remove the motorcycle from the lift stand. (☛ p. 33)
– Mount the handlebar cushion.

11.11 Checking the steering head bearing play

Warning
Danger of accidents Unstable vehicle handling from incorrect steering head bearing play.
– Adjust the steering head bearing play without delay. (Your authorized Husqvarna workshop will be glad to help.)

Info
If the bike is ridden with play in the steering head bearing, the bearing and the bearing seats in the frame can become damaged over time.


400738-11

Preparatory work
– Raise the motorcycle with the lift stand. (☛ p. 33)

Main work
– Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

No play should be noticeable in the steering head bearing.


» If there is noticeable play present:
– Adjust the play of the steering head bearing. 🔧 (☛ p. 38)
– Move the handlebar to and fro over the entire steering range.

The handlebar must be able to move easily over the entire steering range. No resting locations should be noticeable.

» If click positions are noticeable:
– Adjust the play of the steering head bearing. 🔧 (☛ p. 38)
– Check the steering head bearing and change if necessary.

Finishing work
– Remove the motorcycle from the lift stand. (☛ p. 33)

11.12 Adjusting the play of the steering head bearing 🔧



M00257-10

Preparatory work
– Raise the motorcycle with the lift stand. (☛ p. 33)
– Remove the handlebar cushion.

Main work
– Loosen screws ❶. Remove screw ❷.
– Loosen and retighten screw ❸.
Guideline

Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)

– Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
– Tighten screws ❶.
Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)


– Mount and tighten screw ❷.
Guideline

Screw, top steering stem	M8	17 Nm (12.5 lbf ft)	**Loctite® 243™**

Finishing work
– Check the steering head bearing play. (☛ p. 38)


– Remove the motorcycle from the lift stand. (☛ p. 33)
– Mount the handlebar cushion.

11.13 Greasing the steering head bearing




– Remove the lower triple clamp. (☛ p. 36)
– Install the lower triple clamp. (☛ p. 36)

11.14 Removing the start number plate



– Take brake line ❶ out of the brake line guide.
– Remove screw ❷. Take off the start number plate.

11.15 Installing the start number plate




– Position the start number plate. Mount and tighten screw ❶.
Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

✓ The holding lugs engage.
– Position brake line ❷ in the brake line guide.

11.16 Removing the front fender


Preparatory work
– Remove the start number plate. (☛ p. 39)



Main work

– Remove screws ❶ and ❷. Remove the front fender.

11.17 Installing the front fender



Main work

– Position the front fender. Mount and tighten screws ❶ and ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)


Finishing work

– Install the start number plate. (☛ p. 39)

11.18 Removing the shock absorber


Preparatory work

– Raise the motorcycle with the lift stand. (☛ p. 33)
– Remove the seat. (☛ p. 42)
– Remove the right side cover. (☛ p. 46)
– Remove the main silencer. (☛ p. 45)




Main work

– Remove screw ❶.
– Remove screw cap ❷.




– Press angle lever ❸ toward the rear.
– Press linkage lever ❹ downward.




– Detach springs ❺.

Spring hooks (50305017000)

– Remove screw ❻ and take off the manifold.




– Remove screws ❼ on both sides.
– Loosen screws ❽ on both sides.



– Remove screw ❾.
– Raise the rear frame slightly and remove the shock absorber toward the top.

11.19 Installing the shock absorber




Main work

– Raise the rear frame slightly and insert the shock absorber from above.
– Position the shock absorber.
– Mount and tighten screw ❶.

Guideline

Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)	**Loctite® 2701™**



– Position the rear frame.
– Mount and tighten screws ❷ on both sides.


Guideline

Screw, subframe	M8	30 Nm (22.1 lbf ft)	**Loctite® 2701™**

– Remove screws ❸ on both sides.
– Mount and tighten screws ❸ on both sides.

Guideline

Screw, subframe	M8	30 Nm (22.1 lbf ft)	**Loctite® 2701™**




– Position the manifold.
– Attach springs ❹.

Spring hooks (50305017000)

– Mount and tighten screw ❺.

Guideline

Screw, manifold holder	M8	15 Nm (11.1 lbf ft)



– Position the angle lever and linkage lever.
– Mount and tighten screw cap ❻.

Guideline

Nut, linkage lever to angle lever	M14x1.5	80 Nm (59 lbf ft)

– Mount and tighten screw ❼.


Guideline

Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)	**Loctite® 2701™**

Finishing work


– Install the main silencer. (☛ p. 45)
– Install the right side cover. (☛ p. 46)
– Mount the seat. (☛ p. 43)
– Remove the motorcycle from the lift stand. (☛ p. 33)

11.20 Removing the seat



– Remove screws ❶ in the recessed grips on the left and right.
– Lift up the seat at the rear, pull it back and then remove it from above.

11.21 Mounting the seat




– Hook in the front of the seat at the collar bushing of the fuel tank, lower it at the rear and simultaneously push it forward.
– Make sure that the seat is correctly locked in.
– Mount and tighten the screws for securing the seat.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

11.22 Removing the air filter box lid



– Release catch ❶, pull off the air filter box lid sideways in areas Ⓐ and Ⓑ and remove toward the rear.

11.23 Installing the air filter box lid



– Position the air filter box lid and tab ❶. Engage the air filter box lid in areas Ⓐ and Ⓑ.
– Engage tab ❶.

11.24 Removing the air filter

Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

– Never operate the vehicle without an air filter as dust and dirt will enter the engine and lead to increased wear.


Warning

Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Preparatory work


– Remove the air filter box lid. (☛ p. 43)



Main work

– Push air filter holder ❶ toward the air filter at position Ⓐ and detach it at end Ⓑ. Swing the air filter holder to one side and remove the air filter with the air filter support.
– Remove the air filter from the air filter support.

11.25 Installing the air filter




Main work

– Mount the clean air filter on the air filter support.

– Grease the air filter in area A.

Long-life grease (☛ p. 95)



– Insert both parts together, position them, and fasten them using air filter holder 1 in area B.

✓ The arrow of marking **UP** faces up.

Info

If the air filter is not correctly mounted, dust and dirt can enter the engine and cause damage.

Finishing work

– Install the air filter box lid. (☛ p. 43)

11.26 Cleaning the air filter and air filter box

Warning

Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.

Preparatory work

– Remove the air filter box lid. (☛ p. 43)

– Remove the air filter. (☛ p. 43)



Main work

– Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaning agent (☛ p. 95)

Info

Only press the air filter to dry it, never wring it out.

– Oil the dry air filter with a high quality filter oil.

Oil for foam air filter (☛ p. 95)

– Clean the air filter box.


– Check the intake flange for damage and looseness.

Finishing work

– Install the air filter. (☛ p. 44)

– Install the air filter box lid. (☛ p. 43)

11.27 Sealing the air filter box




Preparatory work
– Remove the air filter box lid. (☛ p. 43)

Main work
– Seal the air filter box in the marked area Ⓐ.

Finishing work
– Install the air filter box lid. (☛ p. 43)

11.28 Removing the main silencer


Warning
Danger of burns The exhaust system gets very hot when the vehicle is driven.
– Allow the exhaust system to cool down. Do not touch hot components.



Preparatory work
– Remove the right side cover. (☛ p. 46)

Main work
– Disconnect spring ❶.
– Remove screws ❷ and take off the main silencer.

11.29 Installing the main silencer



Main work
– Mount the main silencer. Mount screws ❶ but do not tighten yet.
– Reconnect spring ❷.
– Tighten screws ❶.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

Finishing work
– Install the right side cover. (☛ p. 46)

11.30 Changing the glass fiber yarn filling of the main silencer

Warning
Danger of burns The exhaust system gets very hot when the vehicle is driven.
– Allow the exhaust system to cool down. Do not touch hot components.

Info
Over time, the fibers of the glass fiber yarn escape and the damper "burns" out.
Not only is the noise level higher, the performance characteristic changes.




Preparatory work
- Remove the right side cover. (☛ p. 46)
- Remove the main silencer. (☛ p. 45)

Main work
- Remove all screws from the main silencer.
- Take off silencer cap ❶ and O-ring ❷.
- Take off outer tube ❸ and O-ring ❹.
- Pull the glass fiber yarn filling ❺ from inner tube ❻.
- Clean the parts that are to be reinstalled.
- Mount the new glass fiber yarn filling ❺ on the inner tube.
- Slide O-ring ❹ and outer tube ❸ over the glass fiber yarn filling.
- Insert O-ring ❷ and silencer cap ❶ into the outer tube.
- Mount and tighten all screws.


Finishing work
- Install the main silencer. (☛ p. 45)
- Install the right side cover. (☛ p. 46)

11.31 Removing the right side cover



- Remove screw ❶.
- Pull off the side cover in area Ⓐ sideways and remove it toward the rear.

11.32 Installing the right side cover



- Position the side cover and engage in area Ⓐ.
- Mount and tighten screw ❶.

  Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

11.33 Removing the fuel tank

Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

Warning

Danger of poisoning Fuel is poisonous and a health hazard.


- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.

Preparatory work

- Remove the seat. (☛ p. 42)

Main work

- Unplug connector ❶ of the fuel pump.
- Thoroughly clean plug-in connection ❷ of the fuel line using compressed air.




Info

Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve.

- Disconnect the plug-in connection of the fuel line.
- Mount wash cap set Ⓐ.


Wash cap set (81212016100)




- Remove the tube from the fuel tank breather.
- Remove screws ❸ with the collar bushing.



- Remove screw ❹ with the rubber bushing.





– Pull both spoilers off of the sides of the radiator bracket and lift off the fuel tank.

11.34 Installing the fuel tank

Danger

Fire hazard Fuel is highly flammable.

– Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
– The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

Warning

Danger of poisoning Fuel is poisonous and a health hazard.

– Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.

Main work

– Check the throttle cable routing. (☛ p. 53)
– Position the fuel tank and fit the two spoilers to the sides of the radiator bracket.
– Make sure that no cables are trapped or damaged.
– Mount the fuel tank breather.
– Mount and tighten screw ❶ with the rubber bushing.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)




– Mount and tighten screws ❷ with the collar bushing.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)





– Plug in connector ❸.
– Remove the wash cap set and thoroughly clean the plug-in connection of the fuel line using compressed air.

Info

Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve.

– Lubricate the O-ring and connect plug-in connection ❹ of the fuel line.


Info

Route the cable and fuel line at a safe distance from the exhaust system.

Finishing work

– Mount the seat. (☛ p. 43)

11.35 Checking for chain dirt accumulation



– Check the chain for coarse dirt accumulation.
  » If the chain is very dirty:
    – Clean the chain. (☛ p. 49)

11.36 Cleaning the chain

Warning
Danger of accidents Oil or grease on the tires reduces their grip.

– Remove oil and grease with a suitable cleaning material.


Warning
Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

– Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

Warning
Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info
The service life of the chain depends largely on its maintenance.



Preparatory work
– Raise the motorcycle with the lift stand. (☛ p. 33)

Main work
– Clean the chain regularly and then treat with chain spray.

Offroad chain spray (☛ p. 95)


Finishing work
– Remove the motorcycle from the lift stand. (☛ p. 33)

11.37 Checking the chain tension

Warning
Danger of accidents Danger caused by incorrect chain tension.

– If the chain is too taut, the components of the secondary power transmission (chain, engine sprocket, rear sprocket, bearings in the transmission and in the rear wheel) will be under additional load. In addition to premature wear, this can cause the chain or the countershaft of the transmission to break in extreme cases. If the chain is too loose, however, it may fall off the engine sprocket or rear sprocket and block the rear wheel or damage the engine. Ensure that the chain tension is correct and adjust it if necessary.

Preparatory work
– Raise the motorcycle with the lift stand. (☛ p. 33)



Main work

– Pull the chain at the end of the chain sliding component upwards to measure chain tension Ⓐ.

Info

The lower chain section ❶ must be taut.
Chain wear is not always even, so you should repeat this measurement at different chain positions.

Chain tension	55… 58 mm (2.17… 2.28 in)

» If the chain tension does not meet specifications:

– Adjust the chain tension. (☛ p. 50)

Finishing work

– Remove the motorcycle from the lift stand. (☛ p. 33)

11.38 Adjusting the chain tension


Warning

Danger of accidents Danger caused by incorrect chain tension.

– If the chain is too taut, the components of the secondary power transmission (chain, engine sprocket, rear sprocket, bearings in the transmission and in the rear wheel) will be under additional load. In addition to premature wear, this can cause the chain or the countershaft of the transmission to break in extreme cases. If the chain is too loose, however, it may fall off the engine sprocket or rear sprocket and block the rear wheel or damage the engine. Ensure that the chain tension is correct and adjust it if necessary.

Preparatory work

– Raise the motorcycle with the lift stand. (☛ p. 33)
– Check the chain tension. (☛ p. 49)



Main work
(FC 250 EU)

– Loosen nut ❶.
– Loosen nuts ❷.
– Adjust the chain tension by turning adjusting screws ❸ left and right.

Guideline

Chain tension	55… 58 mm (2.17… 2.28 in)
Turn adjusting screws ❸ on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks Ⓐ. The rear wheel is then correctly aligned.	


– Tighten nuts ❷.
– Make sure that chain adjusters ❹ are fitted correctly on adjusting screws ❸.
– Tighten nut ❶.

Guideline

Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)

Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.
Chain adjusters ❹ can be turned by 180°.



(FC 250 US)

- Loosen nut ❶.
- Loosen nuts ❷.
- Adjust the chain tension by turning adjusting screws ❸ left and right.

  Guideline

Chain tension	55… 58 mm (2.17… 2.28 in)
Turn adjusting screws ❸ on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks Ⓐ. The rear wheel is then correctly aligned.	

- Tighten nuts ❷.
- Make sure that chain adjusters ❹ are fitted correctly on adjusting screws ❸.
- Tighten nut ❶.

  Guideline

Nut, rear wheel spindle	M25x1.5	80 Nm (59 lbf ft)

Info
The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.
Chain adjusters ❹ can be turned by 180°.


Finishing work

- Remove the motorcycle from the lift stand. (☛ p. 33)

11.39 Checking the chain, rear sprocket, engine sprocket and chain guide

Preparatory work


- Raise the motorcycle with the lift stand. (☛ p. 33)



Main work

- Shift gear to neutral.
- Check the rear sprocket and engine sprocket for wear.
  - » If the rear sprocket and engine sprocket are worn:
    - Change the power set. 🔧

Info
The engine sprocket, rear sprocket and chain should always be replaced together.



- Pull on the upper part of the chain with the specified weight Ⓐ.

  Guideline

Weight, chain wear measurement	10… 15 kg (22… 33 lb.)


- Measure the distance Ⓑ of 18 chain rollers in the lower chain section.

Info
Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance Ⓑ at the longest chain section	272 mm (10.71 in)

  - » If the distance Ⓑ is greater than the specified measurement:
    - Change the power set. 🔧


Info
When the chain is replaced, the rear sprocket and engine sprocket should also be changed.
New chains wear out faster on old, worn sprockets.


M00273-10

– Check the chain sliding guard for wear.
  » If the bottom edge of the chain pin is in line with or below the chain sliding guard:
    – Change the chain sliding guard.
– Check that the chain sliding guard is firmly seated.
  » If the chain sliding guard is loose:
    – Tighten the chain sliding guard.

  Guideline


Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	**Loctite® 243™**


M00274-10

– Check the chain sliding piece for wear.
  » If the bottom edge of the chain pin is in line with or below the chain sliding piece:
    – Change the chain sliding piece.
– Check that the chain sliding piece is firmly seated.
  » If the chain sliding piece is loose:
    – Tighten the chain sliding piece.

  Guideline


Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)


401760-01

– Check the chain guide for wear.

Info
Wear can be seen on the front of the chain guide.

  » If the light part of the chain guide is worn:
    – Change the chain sliding piece.


B01928-01


– Check that the chain guide is firmly seated.
  » If the chain guide is loose:
    – Tighten the chain guide.

  Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

Finishing work
– Remove the motorcycle from the lift stand. (p. 33)

11.40 Checking the frame


402015-01

– Check the frame for cracking and deformation.
  » If the frame exhibits cracking or deformation due to a mechanical impact:
    – Change the frame.

Info
A frame that has been damaged due to a mechanical impact must always be changed. Repair of the frame is not authorized by Husqvarna.

11.41 Checking the swingarm


500285-01

– Check the swingarm for damage, cracking, and deformation.
  » If the swingarm shows signs of damage, cracking, or deformation:
    – Change the swingarm.

Info
A damaged swingarm must always be changed. Repair of the swingarm is not authorized by Husqvarna.

11.42 Checking the throttle cable routing

Preparatory work
– Remove the seat. (p. 42)
– Remove the fuel tank. (p. 47)


M00276-01


Main work
– Check the throttle cable routing.

Both throttle cables must be routed to the throttle valve body side by side behind the handlebars and above the fuel tank bearing.

  » If the throttle cable is not routed as specified:
    – Correct the throttle cable routing.

Finishing work
– Install the fuel tank. (p. 48)
– Mount the seat. (p. 43)

11.43 Checking the rubber grip




– Check the rubber grips on the handlebar for damage and wear and to ensure they are firmly seated.
  » If a rubber grip is damaged, worn or loose:
    – Change and secure the rubber grip.

Rubber grip adhesive (00062030051) (☛ p. 95)

11.44 Additionally securing the rubber grip

Preparatory work
– Check the rubber grip. (☛ p. 54)




Main work
– Secure the rubber grip at two points using the securing wire.

Securing wire (54812016000)
Wire twister forceps (U6907854)

✓ The twisted wire ends face away from the hands and are bent toward the rubber grip.

11.45 Adjusting the basic position of the clutch lever




– Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ❶.

Info
Turn the adjusting screw counterclockwise to decrease the distance between the clutch lever and the handlebar.
Turn the adjusting screw clockwise to increase the distance between the clutch lever and the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding!

11.46 Checking/rectifying the fluid level of the hydraulic clutch

Info
The fluid level rises with increased wear of the clutch lining discs.



– Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
– Remove screws ❶.
– Remove cover ❷ with membrane ❸.
– Check the fluid level.

Fluid level below container rim	4 mm (0.16 in)

  » If the fluid level does not meet specifications:
    – Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 (☛ p. 93)


– Position the cover with the membrane. Mount and tighten the screws.

Info
Clean up overflowed or spilt brake fluid immediately with water.


11.47 Changing the hydraulic clutch fluid

Warning
Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



– Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
– Remove screws ❶.
– Remove cover ❷ with membrane ❸.




– Fill bleeding syringe ❹ with the appropriate hydraulic fluid.

Bleed syringe (50329050000)
Brake fluid DOT 4 (☛ p. 93)

– Mount bleeding syringe ❹ on bleeder screw ❺ with a suitable hose piece.
– On the clutch slave cylinder, only release bleeder screw ❺ to the point where filling is possible.

Info
Wash off overflowing or spilled brake fluid immediately with water.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.
Use only clean brake fluid from a sealed container.



– Inject the liquid into the system until it escapes from openings ❻ of the master cylinder without bubbles.
– To prevent overflow, drain fluid occasionally from the master cylinder reservoir.
– Tighten the bleeder screw and remove the bleeding syringe with the hose.
– Correct the fluid level of the hydraulic clutch.
Guideline


Fluid level below container rim	4 mm (0.16 in)

– Position the cover with the membrane. Mount and tighten the screws.

12.1 Checking the free travel of the hand brake lever

Warning
Danger of accidents Brake system failure.

– If there is no free travel on the hand brake lever, pressure builds up on the front brake circuit. The front brake can fail due to overheating. Adjust the free travel on hand brake lever according to specifications.




– Push the hand brake lever forward and check free travel A.

Free travel of hand brake lever	≥ 3 mm (≥ 0.12 in)

» If the free travel does not meet specifications:
– Adjust the basic position of the hand brake lever. (☛ p. 56)

12.2 Adjusting the basic position of the hand brake lever

Preparatory work
– Check the free travel of the hand brake lever. (☛ p. 56)




Main work
– Adjust the basic setting of the hand brake lever to your hand size by turning adjusting screw 1.

Info
Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.
Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding!

12.3 Checking the brake discs

Warning
Danger of accidents Reduced braking efficiency due to worn brake disc(s).

– Change the worn brake disc(s) without delay. (Your authorized Husqvarna workshop will be glad to help.)



– Check the thickness of the front and rear brake discs at several places on the disk to see if it conforms to measurement A.

Info
Wear reduces the thickness of the brake disc around the area used by the brake linings.

Brake discs - wear limit	
Front	2.5 mm (0.098 in)
Rear	3.5 mm (0.138 in)

» If the brake disc thickness is less than the specified value:
– Change the brake disc.

– Check the front and rear brake discs for damage, cracking and deformation.
» If the brake disc shows signs of damage, cracking or deformation:
– Change the brake disc.


12.4 Checking the front brake fluid level

Warning
Danger of accidents Brake system failure.

– If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.

– Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna workshop will be glad to help.)



Preparatory work
– Check the front brake linings. (☛ p. 58)

Main work
– Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
– Check the brake fluid level in level viewer ❶.
  » If the brake fluid has dropped below marking Ⓐ:
    – Add front brake fluid. 🔧 (☛ p. 57)

12.5 Adding front brake fluid 🔧

Warning
Danger of accidents Brake system failure.

– If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Skin irritation Brake fluid can cause skin irritation on contact.

– Avoid contact with skin and eyes, and keep out of the reach of children.
– Wear suitable protective clothing and goggles.
– If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.


– Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info
Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.
Use only clean brake fluid from a sealed container.

Preparatory work
– Check the front brake linings. (☛ p. 58)



Main work

– Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
– Remove screws ❶.
– Remove cover ❷ with membrane ❸.
– Add brake fluid to level Ⓐ.

Guideline

Dimension Ⓐ (brake fluid level below top edge of container)	5 mm (0.2 in)

Brake fluid DOT 4 (☛ p. 93)


– Position the cover with the membrane. Mount and tighten the screws.

Info
Clean up overflowed or spilt brake fluid immediately with water.

12.6 Checking the front brake linings

Warning
Danger of accidents Reduced braking efficiency caused by worn brake linings.

– Change worn brake linings immediately. (Your authorized Husqvarna workshop will be glad to help.)



– Check the brake linings for minimum thickness Ⓐ.

Minimum thickness Ⓐ	≥ 1 mm (≥ 0.04 in)

» If the minimum thickness is less than specified:
– Change the front brake linings. 🔧 (☛ p. 58)

– Check the brake linings for damage and cracking.
» If damage or cracking is visible:
– Change the front brake linings. 🔧 (☛ p. 58)

12.7 Changing the front brake linings 🔧

Warning
Danger of accident Brake system failure.

– Maintenance work and repairs must be carried out professionally. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Skin irritation Brake fluid can cause skin irritation on contact.

– Avoid contact with skin and eyes, and keep out of the reach of children.
– Wear suitable protective clothing and goggles.
– If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.


Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.

– Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna workshop will be glad to help.)


Warning
Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info
Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container.




– Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
– Remove screws ❶.
– Remove cover ❷ with membrane ❸.




– Manually press the brake caliper to the brake disc to push back the brake pistons. Ensure that brake fluid does not flow out of the brake fluid reservoir, extracting it by suction if it does.

Info
Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.

– Remove cotter pin ❹, pull out pin ❺, and remove the brake linings.
– Clean the brake caliper and brake caliper support.




– Check that leaf spring ❻ in the brake caliper and sliding plate ❼ in the brake caliper support are seated correctly.



– Insert the new brake linings, insert pin ❺, and mount cotter pins ❹.

Info
Always change the brake linings in pairs.

– Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



– Add brake fluid to level Ⓐ.

Guideline

Dimension Ⓐ (brake fluid level below top edge of container)	5 mm (0.2 in)

Brake fluid DOT 4 (☛ p. 93)


– Position cover ❷ with membrane ❸.
– Mount and tighten screws ❶.

Info
Clean up overflowed or spilt brake fluid immediately with water.

12.8 Checking the free travel of foot brake lever

Warning
Danger of accidents Brake system failure.

– If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



– Disconnect spring ❶.
– Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel Ⓐ.

Guideline


Free travel at foot brake lever	3… 5 mm (0.12… 0.2 in)

» If the free travel does not meet specifications:
  – Adjust the basic position of the foot brake lever. 🔧 (☛ p. 60)
– Reconnect spring ❶.

12.9 Adjusting the basic position of the foot brake lever 🔧

Warning
Danger of accidents Brake system failure.

– If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



– Disconnect spring ❶.
– Loosen nut ❹ and, with push rod ❺, turn it back until you have maximum free travel.
– To adjust the basic position of the foot brake lever individually, loosen nut ❷ and turn screw ❸ accordingly.

Info
The range of adjustment is limited.

– Turn push rod ❺ accordingly until you have free travel Ⓐ. If necessary, adjust the basic position of the foot brake lever.

Guideline

Free travel at foot brake lever	3… 5 mm (0.12… 0.2 in)

– Hold push rod ❺ and tighten nut ❹.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)

– Hold screw ❸ and tighten nut ❷.

Guideline

Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)

– Reconnect spring ❶.


12.10 Checking the rear brake fluid level

Warning
Danger of accidents Brake system failure.

– If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.

– Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna workshop will be glad to help.)



Preparatory work
– Check the rear brake linings. (☛ p. 62)

Main work
– Stand the vehicle upright.
– Check the brake fluid level in level viewer ❶.
  » If the brake fluid has dropped below marking Ⓐ:
    – Add rear brake fluid. 🔧 (☛ p. 61)

12.11 Adding rear brake fluid 🔧

Warning
Danger of accidents Brake system failure.

– If the brake fluid level drops below the specified marking or the specified value, this is an indication that the brake system is leaking or that the brake linings are completely worn down. Check the brake system and do not continue riding. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.


Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info
Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container.



Preparatory work
- Check the rear brake linings. (☛ p. 62)

Main work
- Stand the vehicle upright.
- Remove screw cap ❶ with membrane ❷ and the O-ring.
- Add brake fluid to level Ⓐ.

Brake fluid DOT 4 (☛ p. 93)


- Mount and tighten the screw cap with the membrane and O-ring.

Info
Clean up overflowed or spilt brake fluid immediately with water.

12.12 Checking the rear brake linings

Warning
Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized Husqvarna workshop will be glad to help.)



- Check the brake linings for minimum thickness Ⓐ.

Minimum thickness Ⓐ	≥ 1 mm (≥ 0.04 in)

» If the minimum thickness is less than specified:
  - Change the rear brake linings. 🔧 (☛ p. 63)
- Check the brake linings for damage and cracking.

» If damage or cracking is visible:
  - Change the rear brake linings. 🔧 (☛ p. 63)

12.13 Changing the rear brake linings

Warning
Danger of accident Brake system failure.

– Maintenance work and repairs must be carried out professionally. (Your authorized Husqvarna workshop will be glad to help.)

Warning
Skin irritation Brake fluid can cause skin irritation on contact.

– Avoid contact with skin and eyes, and keep out of the reach of children.
– Wear suitable protective clothing and goggles.
– If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.


Warning
Danger of accidents Reduced braking efficiency due to old brake fluid.

– Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized Husqvarna workshop will be glad to help.)


Warning
Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info
Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container.




– Stand the vehicle upright.
– Remove screw cap ❶ with membrane ❷ and the O-ring.



– Press the brake caliper onto the brake disc by hand in order to push back the brake piston and ensure that brake fluid does not flow out of the brake fluid reservoir, extracting it by suction if it does.


Info
Ensure that the brake caliper is not pressed against the spokes when pushing back the brake piston.


– Remove cotter pins ❸, pull out pin ❹, and remove the brake linings.
– Clean the brake caliper and brake caliper support.



– Check that leaf spring ❺ in the brake caliper and sliding plate ❻ in the brake caliper support are seated properly.

Info
The arrow on the leaf spring points in the rotation direction of the brake disc.





– Insert the new brake linings, insert pin ❹, and mount cotter pins ❸.

Info
Always change the brake linings in pairs.

Info
Make sure that decoupling plate ❼ is mounted on the piston side of the brake lining.

– Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.
– Add brake fluid to level Ⓐ.

Brake fluid DOT 4 (☛ p. 93)


– Mount and tighten screw cap ❶ with membrane ❷ and the O-ring.

Info
Clean up overflowed or spilt brake fluid immediately with water.

13.1 Removing the front wheel

Preparatory work


– Raise the motorcycle with the lift stand. (☛ p. 33)




Main work

– Press the brake caliper onto the brake disc by hand in order to push back the brake pistons.

Info
Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.




– Loosen screw ❶ by several turns.
– Loosen screws ❷.
– Press on screw ❶ to push the wheel spindle out of the axle clamp.
– Remove screw ❶.



– Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.

Info
Do not pull the hand brake lever when the front wheel is removed.
Always lay the wheel down in such a way that the brake disc is not damaged.




– Remove spacers ❸.

13.2 Installing the front wheel

Warning
Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


– Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



– Check the wheel bearing for damage and wear.
  » If the wheel bearing is damaged or worn:
    – Change the wheel bearing.
– Clean and grease the shaft seal rings ❶ and contact surface Ⓐ of the spacers.

Long-life grease (☛ p. 95)

– Insert the spacers.
– Position the front wheel and insert the wheel spindle.
  ✓ The brake linings are correctly positioned.



– Mount and tighten screw ❷.

Guideline

Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)

– Activate the hand brake lever multiple times until the brake linings are in contact with the brake disc.
– Remove the motorcycle from the lift stand. (☛ p. 33)
– Pull the front brake and compress the fork powerfully a few times.
  ✔ The fork legs straighten.
– Tighten screws ❸.


Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)

13.3 Removing the rear wheel

Preparatory work

– Raise the motorcycle with the lift stand. (☛ p. 33)



Main work

(FC 250 EU)

– Press the brake caliper onto the brake disc by hand in order to push back the brake piston.


Info
Ensure that the brake caliper is not pressed against the spokes when pushing back the brake piston.

– Remove nut ❶.
– Remove chain adjuster ❷. Withdraw wheel spindle ❸ only enough to allow the rear wheel to be pushed forward.
– Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.

Info
Protect the components against damage by covering them.

– Holding the rear wheel, withdraw the wheel spindle. Take the rear wheel out of the swingarm.

Info
Do not operate the foot brake when the rear wheel is removed.
Always lay the wheel down in such a way that the brake disc is not damaged.



(FC 250 US)

– Press the brake caliper onto the brake disc by hand in order to push back the brake piston.


Info
Ensure that the brake caliper is not pressed against the spokes when pushing back the brake piston.

– Remove nut ❶.
– Remove chain adjuster ❷. Withdraw wheel spindle ❸ only enough to allow the rear wheel to be pushed forward.
– Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.

Info
Protect the components against damage by covering them.

– Holding the rear wheel, withdraw the wheel spindle. Take the rear wheel out of the swingarm.


Info
Do not operate the foot brake when the rear wheel is removed.
Always lay the wheel down in such a way that the brake disc is not damaged.



– Remove spacers ❹.

13.4 Installing the rear wheel


Warning
Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.
– Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.




Main work
– Check the wheel bearing for damage and wear.
  » If the wheel bearing is damaged or worn:
    – Change the wheel bearing.
– Clean and grease the shaft seal rings ❶ and contact surface Ⓐ of the spacers.

Long-life grease (☛ p. 95)

– Insert the spacers.



(FC 250 EU)
– Position the rear wheel and insert wheel spindle ❷.
  ✓ The brake linings are correctly positioned.
– Put the chain on.




– Position chain adjuster ❸. Mount nut ❹ but do not tighten it yet.
– Make sure that chain adjusters ❸ are fitted correctly on adjusting screws ❺.
– Check the chain tension. (☛ p. 49)
– Tighten nut ❹.

Guideline

Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)


Info
The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.
Chain adjusters ❸ can be turned by 180°.

– Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



(FC 250 US)

– Position the rear wheel and insert wheel spindle ❷.
  ✓ The brake linings are correctly positioned.
– Put the chain on.



– Position chain adjuster ❸. Mount nut ❹ but do not tighten it yet.
– Make sure that chain adjusters ❸ are fitted correctly on adjusting screws ❺.
– Check the chain tension. (☛ p. 49)
– Tighten nut ❹.

  Guideline

Nut, rear wheel spindle	M25x1.5	80 Nm (59 lbf ft)

Info
The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.
Chain adjusters ❸ can be turned by 180°.


– Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

Finishing work

– Remove the motorcycle from the lift stand. (☛ p. 33)

13.5 Checking the tire condition

Info
Only mount tires approved and/or recommended by Husqvarna.
Other tires could have a negative effect on riding behavior.
The type, condition and air pressure of the tires all have an important impact on the riding behavior of the motorcycle.
The tires mounted on the front and rear wheels must have a similar profile.
Worn tires have a negative effect on riding behavior, especially on wet surfaces.



– Examine the front and rear tires for cuts, foreign bodies and other damage.
  » If you find cuts, foreign bodies or other damage on a tire:
    – Change the tire.
– Check the depth of the tread.

Info
Note local national regulations concerning the minimum tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)


  » If the tread depth is less than the minimum allowable depth:
    – Change the tire.
– Check the tire age.

Info
The tire manufacture date is usually included in the tire identification number and comprises the last four digits of the **DOT** code. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.
Husqvarna recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

» If the tire is older than five years:
– Change the tire.

13.6 Checking the tire air pressure

Info
Low tire air pressure leads to abnormal wear and overheating of the tire.
Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



– Remove the protection cap.
– Check the tire air pressure when the tires are cold.


Tire air pressure, offroad	
Front	1.0 bar (15 psi)
Rear	1.0 bar (15 psi)

» If the tire pressure does not meet specifications:
– Correct the tire pressure.
– Mount the protection cap.

13.7 Checking the spoke tension

Warning
Danger of accidents Instable handling due to incorrect spoke tension.
– Ensure that the spoke tension is correct. (Your authorized Husqvarna workshop will be glad to help.)

Info
A loose spoke causes wheel imbalance and rapidly leads to more loose spokes.
If the spokes are too tight, they can break due to local overload.
Check the spoke tension regularly, especially on a new motorcycle.



– Briefly strike each spoke with the tip of a screwdriver.

Info
The tone frequency depends on the length of the spoke and the spoke diameter.
If you hear different tone frequencies from different spokes of equal length and diameter, this is an indication of different spoke tensions.

You should hear a high note.

» If the spoke tension varies:
– Correct the spoke tension.
– Check the spoke torque.

Guideline

Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)

Torque wrench with various accessories in set (58429094000)

14.1 Removing the battery


Warning

Risk of injury Battery acid and battery gases cause serious chemical burns.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep sparks and open flames away from the battery. Only charge in well-ventilated rooms.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.

Preparatory work


- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 42)



Main work

- Pull back the negative terminal cover ❶ and disconnect the negative cable from the battery.
- Pull back the positive terminal cover ❷ and disconnect the positive cable from the battery.
- Detach rubber band ❸ from the bottom.
- Lift the battery out.

14.2 Installing the battery



Main work

- Insert the battery into the battery compartment with the terminals facing to the front.

Battery (YTX5L-BS) (☛ p. 90)

- Reconnect rubber band ❶.

Info

Contact disk Ⓐ must be mounted between screw ❹ and cable socket ❺ with the claws facing down.

- Position the positive cable and mount and tighten the screw.

  Guideline

Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)

- Slide positive terminal cover ❷ over the positive terminal.
- Position the negative cable and mount and tighten the screw.

  Guideline

Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)

- Slide negative terminal cover ❸ over the negative terminal.

Finishing work

- Mount the seat. (☛ p. 43)

14.3 Recharging the battery

Warning

Risk of injury Battery acid and battery gases cause serious chemical burns.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep sparks and open flames away from the battery. Only charge in well-ventilated rooms.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.

Warning

Environmental hazard Battery components and acid are harmful to the environment.

- Do not dispose of batteries with the household waste. Dispose of a defective battery in an environmentally friendly manner. Give it to your Husqvarna dealer or to a disposal center for used batteries.


Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info

Even when there is no load on the battery, it still loses power steadily.
The charge state and the type of charge are very important for the service life of the battery.
Rapid recharging with a high charging current shortens the battery's service life.
If the charging current, charging voltage and charging time are exceeded, electrolyte escapes through the safety valves. This reduces the battery capacity.
If the battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.
If the battery is left in a discharged state for an extended period, it will become over-discharged and sulfate, destroying the battery.
The battery is maintenance-free, i.e., the acid level does not have to be checked.



Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 42)
- Disconnect the negative cable of the battery to avoid damage to the onboard electronics.

Main work

- Connect the battery charger with the battery. Switch on the battery charger.

Battery charger (81229074000)

You can also use the battery charger to test rest potential and start potential of the battery, and to test the alternator. With this device, you cannot overcharge the battery.

Info

Never remove cover ❶.
Charge the battery with a maximum of 10% of the capacity specified on the battery housing ❷.

- Switch off the battery charger after charging. Connect the negative cable with the battery.

Guideline

The charge current, charge voltage and charge time must not be exceeded.	
Charge the battery regularly when the motorcycle is not in use	3 months

Finishing work

- Mount the seat. (☛ p. 43)

14.4 Changing the main fuse


Warning

Fire hazard The electrical system can be overloaded if the wrong fuses are used.

– Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

Info

The main fuse protects all power consumers of the vehicle. It is located in the starter relay housing under the air filter box lid.



Preparatory work

– Switch off all power consumers and switch off the engine.

– Remove the air filter box lid. (☛ p. 43)

Main work

– Take off protection caps ❶.

– Remove the faulty main fuse ❷.

Info

A defective fuse is indicated by a burned-out fuse wire Ⓐ.
A spare fuse ❸ is located in the starter relay.

– Install a new main fuse.

Fuse (58011109110) (☛ p. 90)

– Check that the electrical equipment is functioning.

Tip


Insert the spare fuse so that it is available if needed.

– Mount the protection caps.

Finishing work

– Install the air filter box lid. (☛ p. 43)

15.1 Cooling system



Water pump ❶ in the engine circulates the coolant.
The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ❷. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream.
The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.


15.2 Checking the antifreeze and coolant level

Warning
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

– Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

Warning
Danger of poisoning Coolant is poisonous and a health hazard.

– Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If coolant is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.



Condition
The engine is cold.

– Stand the motorcycle upright on a horizontal surface.
– Remove the radiator cap.
– Check the antifreeze of the coolant.

−25… −45 °C (−13… −49 °F)

» If the antifreeze of the coolant does not meet specifications:
– Correct the antifreeze of the coolant.

– Check the coolant level in the radiator.

Coolant level Ⓐ above radiator fins.	10 mm (0.39 in)

» If the coolant level does not meet specifications:
– Correct the coolant level.

Alternative 1

Coolant (☛ p. 93)

Alternative 2

Coolant (mixed ready to use) (☛ p. 93)

– Mount the radiator cap.


15.3 Checking the coolant level

Warning
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

– Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

Warning
Danger of poisoning Coolant is poisonous and a health hazard.

– Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If coolant is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.



Condition
The engine is cold.

– Stand the motorcycle upright on a horizontal surface.
– Remove the radiator cap.
– Check the coolant level in the radiator.

Coolant level A above radiator fins.	10 mm (0.39 in)

» If the coolant level does not meet specifications:
– Correct the coolant level.

Alternative 1

Coolant (☛ p. 93)

Alternative 2

Coolant (mixed ready to use) (☛ p. 93)

– Mount the radiator cap.


15.4 Draining the coolant

Warning
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

– Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

Warning
Danger of poisoning Coolant is poisonous and a health hazard.

– Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If coolant is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.



Condition
The engine is cold.

– Position the motorcycle upright.
– Place a suitable container under the water pump cover.
– Remove screw 1. Take off radiator cap 2.
– Completely drain the coolant.
– Mount and tighten screw 1 with a new seal ring.
Guideline


Screw, water pump cover	M6	10 Nm (7.4 lbf ft)

15.5 Refilling coolant

Warning

Danger of poisoning Coolant is poisonous and a health hazard.

– Coolant must not come into contact with the skin, eyes, or clothing. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If coolant is swallowed, contact a physician immediately. Change clothing that is contaminated with coolant. Keep coolant out of reach of children.



– Make sure that screw 1 is tightened.
– Position the motorcycle upright.
– Pour coolant in up to measurement A above the radiator fins.

Guideline

Dimension A over the radiator fins	10 mm (0.39 in)

Alternative 1


Coolant (☛ p. 93)

Alternative 2

Coolant (mixed ready to use) (☛ p. 93)

– Mount the radiator cap.
– Take a short test ride.
– Check the coolant level. (☛ p. 74)

16.1 Checking the play in the throttle cable



– Check the throttle grip for smooth operation.
– Move the handlebar to the straight-ahead position. Turn the throttle grip back and forth slightly and determine the play in throttle cable Ⓐ.

Throttle cable play	3… 5 mm (0.12… 0.2 in)

» If the throttle cable play does not meet specifications:
– Adjust the play in the throttle cable. 🔧 (☛ p. 76)

Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.
– When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.


– Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

» If the idle speed changes:
– Adjust the play in the throttle cable. 🔧 (☛ p. 76)

16.2 Adjusting the play in the throttle cable 🔧

Preparatory work
– Remove the seat. (☛ p. 42)
– Remove the fuel tank. 🔧 (☛ p. 47)
– Check the throttle cable routing. (☛ p. 53)



Main work
– Move the handlebar to the straight-ahead position.
– Push back sleeves ❶.
– Loosen nut ❷. Turn adjusting screw ❸ in as far as possible.
– Loosen nut ❹. Turn adjusting screw ❺ so that there is play in the throttle cable at the throttle grip.


Guideline

Throttle cable play	3… 5 mm (0.12… 0.2 in)

– Tighten nut ❹.
– Press and hold the throttle grip in the closed setting. Turn adjusting screw ❸ out until there is no play in the throttle cable ❻.
– Tighten nut ❷.
– Push sleeves ❶ on. Check the throttle grip for smooth operation.

Finishing work
– Check the play in the throttle cable. (☛ p. 76)
– Install the fuel tank. 🔧 (☛ p. 48)
– Mount the seat. (☛ p. 43)

16.3 Adjusting the idle speed



– Run the engine until warm.
– Set the desired idle speed by turning the idle speed adjusting screw ❶.


Guideline

Idle speed	2,250… 2,350 rpm

Tachometer (45129075000)

Info
Turn counterclockwise to decrease the idle speed.
Turn clockwise to increase the idle speed.

16.4 Checking the basic position of the shift lever




– Sit on the vehicle in the riding position and determine the distance Ⓐ between the upper edge of your boot and the shift lever.


Distance between shift lever and upper edge of boot	10… 20 mm (0.39… 0.79 in)

» If the distance does not meet specifications:
– Adjust the basic position of the shift lever. (☛ p. 77)

16.5 Adjusting the basic position of the shift lever



– Remove screw ❶ and take off shift lever ❷.



– Clean gear teeth Ⓐ of the shift lever and shift shaft.
– Mount the shift lever on the shift shaft in the required position and engage the gearing.

Info
The range of adjustment is limited.
The shift lever must not come into contact with any other vehicle components during the shift procedure.

– Mount and tighten the screw.

Guideline

Screw, shift lever	M6	14 Nm (10.3 lbf ft)	**Loctite® 243™**

17.1 Changing the fuel screen

Danger
Fire hazard Fuel is highly flammable.


- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- The fuel in the fuel tank expands when warm and may emerge if overfilled. Follow the instructions on refueling.

Warning
Danger of poisoning Fuel is poisonous and a health hazard.

- Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel.

Warning
Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Clean the plug-in connection ❶ of the fuel line thoroughly with compressed air.

Info
Under no circumstances should dirt enter into the fuel line. Dirt clogs the injection valve.

- Disconnect the plug-in connection of the fuel line.
- Pull fuel screen ❷ out of the connecting piece.
- Insert the new fuel screen all the way into the connecting piece.
- Lubricate the O-ring and connect the plug-in connection of the fuel line.


Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check the response.

17.2 Checking the engine oil level

Info
The engine oil level can be checked when the engine is cold or warm.



Preparatory work
- Stand the motorcycle upright on a horizontal surface.

Condition
The engine is cold.
- Check the engine oil level.

The engine oil level is up to the middle Ⓐ of the level viewer.

» If the engine oil is not up to the middle of the level viewer:
- Add engine oil. (☛ p. 80)

Condition
The engine is at operating temperature.
- Check the engine oil level.

Info
After switching off the engine, wait one minute before checking the level.

The engine oil is at a level between the middle Ⓐ and upper edge Ⓑ of the level viewer.

» If the engine oil is not up to the middle Ⓐ of the level viewer:
  – Add engine oil. (☛ p. 80)

17.3 Changing the engine oil and oil filter, cleaning the oil screen


Warning
Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.
– Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.

Warning
Environmental hazard Hazardous substances cause environmental damage.
– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.


Info
Drain the engine oil only when the engine is warm.

Preparatory work
– Park the motorcycle on a level surface.


Main work
– Place a suitable container under the engine.
– Remove oil drain plug ❶ with the magnet and seal ring.




Info
Do not remove screws ❷ on both sides.



– Remove screw plug ❸ with oil screen ❹.
– Completely drain the engine oil.
– Thoroughly clean the parts and sealing surfaces.



– Position oil screen ❹ with the O-rings on a pin wrench.
– Insert the pin wrench through the drill hole of the screw plug and into the engine case on the opposite side.
– Push the oil screen all the way into the engine case.



– Mount and tighten screw plug ❸ with the O-ring.


Guideline

Screw plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)


– Mount and tighten the oil drain plug ❶ with the magnet and a new seal ring.

Guideline

Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)




– Remove screws 5. Remove the oil filter cover with the O-ring.



– Pull oil filter 6 out of the oil filter housing.

Circlip pliers reverse (51012011000)

– Completely drain the engine oil.
– Thoroughly clean the parts and sealing surfaces.




– Lay the motorcycle on its side and fill the oil filter housing to about ⅓ full with engine oil.
– Fill the oil filter with engine oil and place it in the oil filter housing.
– Oil the O-ring of the oil filter cover and mount it with the oil filter cover 7.
– Mount and tighten the screws.

Guideline

Screw, oil filter cover	M6	10 Nm (7.4 lbf ft)

– Stand the motorcycle upright.



– Remove the oil filler plug 8 with the O-ring from the clutch cover and fill up with engine oil.

Engine oil	1.10 l (1.16 qt.)	Engine oil (SAE 10W/50) (☛ p. 93)

Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.

– Install and tighten the oil filler plug with O-ring.


Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.
– When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

– Start the engine and check that it is oil-tight.

Finishing work
– Check the engine oil level. (☛ p. 78)

17.4 Adding engine oil

Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



– Remove the oil filler plug ❶ with the O-ring from the clutch cover.
– Add the same engine oil that was used when the motor was changed.

Engine oil (SAE 10W/50) (☛ p. 93)

Info

For optimal performance of the engine oil, do not mix different types of engine oil.
If appropriate, change the engine oil.

– Install and tighten the oil filler plug with O-ring.

Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

– When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

– Start the engine and check that it is oil-tight.

18.1 Cleaning the motorcycle

Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

– When cleaning the vehicle with a pressure cleaner, do not point the water jet directly onto electrical components, connectors, cables, bearings, etc. Maintain a minimum distance of 60 cm between the nozzle of the pressure cleaner and the component. Excessive pressure can cause malfunctions or destroy these parts.


Warning

Environmental hazard Hazardous substances cause environmental damage.

– Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Info

If you clean the motorcycle regularly, its value and appearance will be maintained over a long period.
Avoid direct sunshine on the motorcycle during cleaning.


401061-01

– Close off the exhaust system to keep water from entering.
– First remove coarse dirt particles with a gentle spray of water.
– Spray very dirty areas with a normal motorcycle cleaner and then clean with a paint-brush.

Info

Use warm water containing normal motorcycle cleaner and a soft sponge. Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

– After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
– Remove the closure of the exhaust system.

Warning

Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

– Clean or dry a dirty or wet brake system by riding and braking gently.

– After cleaning, ride a short distance until the engine reaches operating temperature.

Info

The heat produced causes water at inaccessible locations in the engine and on the brake system to evaporate.

– Push back the protection caps of the handlebar controls to allow any water that has penetrated to evaporate.
– After the motorcycle has cooled off, lubricate all moving parts and bearings.
– Clean the chain. (☛ p. 49)
– Treat bare metal parts (except for brake discs and the exhaust system) with a corrosion inhibitor.

Preserving materials for paints, metal and rubber (☛ p. 95)

– Treat all plastic parts and powder-coated parts with a mild cleaning and care agent.

19.1 Storage


Warning

Danger of poisoning Fuel is poisonous and a health hazard.

– Fuel must not come into contact with the skin, eyes, or clothing. Do not breathe in the fuel vapors. If contact occurs with the eyes, rinse with water immediately and contact a physician. Immediately clean contaminated areas on the skin with soap and water. If fuel is swallowed, contact a physician immediately. Change clothing that is contaminated with fuel. Store fuel properly in a suitable canister and keep away from children.

Info

If you want to garage the motorcycle for a longer period, take the following steps.
Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.


401058-01

– When refueling for the last time before taking the motorcycle out of service, add fuel additive.
– Refuel. (☛ p. 22)
– Clean the motorcycle. (☛ p. 82)
– Change the engine oil and oil filter, clean the oil screen. 🔧 (☛ p. 79)
– Check the antifreeze and coolant level. (☛ p. 73)
– Drain the fuel from the fuel tanks into a suitable container.
– Check the tire air pressure. (☛ p. 69)
– Remove the battery. 🔧 (☛ p. 70)
– Recharge the battery. 🔧 (☛ p. 71)

Guideline

Storage temperature of battery without direct sunlight	0… 35 °C (32… 95 °F)

– Store the vehicle in a dry location that is not subject to large fluctuations in temperature.

Info


Husqvarna recommends raising the motorcycle.

– Raise the motorcycle with the lift stand. (☛ p. 33)
– Cover the vehicle with a tarp or a cover that is permeable to air.

Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.
Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and exhaust system to rust.

19.2 Putting into operation after storage


401059-01

– Install the battery. 🔧 (☛ p. 70)
– Remove the motorcycle from the lift stand. (☛ p. 33)
– Perform checks and maintenance steps before putting into operation. (☛ p. 20)
– Take a test ride.

Faults	Possible cause	Action
The engine does not turn when the electric starter button is pressed	Operating error	– Carry out the start procedure. (☛ p. 20)
	Battery discharged	– Recharge the battery. 🔧 (☛ p. 71) – Check the charging voltage. 🔧 – Check the open-circuit current. 🔧 – Check the stator winding of the alternator. 🔧
	Main fuse blown	– Change the main fuse. (☛ p. 72)
	Faulty starter relay	– Check the starter relay. 🔧
	Faulty starter motor	– Check the starter motor. 🔧
Engine turns but does not start	Coupling of fuel hose connection not joined together	– Join the fuel hose connection.
	Fuel screen in the fuel hose connection is clogged	– Change the fuel screen. 🔧 (☛ p. 78)
	Idle speed is not set correctly	– Adjust the idle speed. 🔧 (☛ p. 77)
	Spark plug oily or wet	– Clean and dry the spark plug, or change it if necessary.
	Electrode distance (plug gap) of spark plug too wide	– Adjust the plug gap. Guideline Spark plug electrode gap 0.8 mm (0.031 in)
	Short circuit cable in wiring harness frayed, kill switch defective	– Check the wiring harness. (visual check) – Check the electrical system.
	Defect in fuel injection system	– Read out the fault memory using the Husqvarna diagnostics tool. 🔧
Engine does not speed up	Defect in fuel injection system	– Read out the fault memory using the Husqvarna diagnostics tool. 🔧
Engine has too little power	Air filter is very dirty	– Clean the air filter and air filter box. 🔧 (☛ p. 44)
	Fuel filter is very dirty	– Change the fuel filter. 🔧
	Defect in fuel injection system	– Read out the fault memory using the Husqvarna diagnostics tool. 🔧
	Exhaust system leaky, deformed or too little glass fiber yarn filling in main silencer	– Check exhaust system for damage. – Change the glass fiber yarn filling of the main silencer. 🔧 (☛ p. 45)
	Valve clearance too little	– Adjust the valve clearance. 🔧
Engine dies during the trip	Lack of fuel	– Refuel. (☛ p. 22)
Engine overheats	Too little coolant in cooling system	– Check the cooling system for leakage. – Check the coolant level. (☛ p. 74)
	Too little air stream	– Switch off the engine when standing.
	Radiator fins very dirty	– Clean the radiator fins.
	Foam formation in cooling system	– Drain the coolant. 🔧 (☛ p. 74) – Refill the coolant. 🔧 (☛ p. 75)
	Bent radiator hose	– Change the radiator hose. 🔧
FI warning lamp (**MIL**) lights up/flashes	Defect in fuel injection system	– Stop the motorcycle and identify the faulty part using the blink code. – Check the cabling for damage and the electrical plug-in connections for corrosion and damage. – Read out the fault memory using the Husqvarna diagnostics tool. 🔧
High oil consumption	Engine vent hose bent	– Route the vent hose without bends or change it if necessary.
	Engine oil level too high	– Check the engine oil level. (☛ p. 78)
	Engine oil too thin (low viscosity)	– Change the engine oil and oil filter, clean the oil screen. 🔧 (☛ p. 79)
	Piston and cylinder worn	– Piston/cylinder - determine the mounting clearance.

20 TROUBLESHOOTING

Faults	Possible cause	Action
Battery discharged	Battery is not charging	– Check the charging voltage. 🔧 – Check the stator winding of the alternator. 🔧
	Unwanted power consumer	– Check the open-circuit current. 🔧

21 BLINK CODE

Blink code FI warning lamp (MIL)	 02 **FI** warning lamp (**MIL**) flashes 2x short
Error level condition	Crankshaft position sensor - circuit fault

Blink code FI warning lamp (MIL)	 06 **FI** warning lamp (**MIL**) flashes 6x short
Error level condition	Throttle position sensor circuit A - input signal too low
	Throttle position sensor circuit A - input signal too high

Blink code FI warning lamp (MIL)	 09 **FI** warning lamp (**MIL**) flashes 9x short
Error level condition	Manifold absolute pressure sensor cylinder 1 - input signal too low
	Manifold absolute pressure sensor cylinder 1 - input signal too high

Blink code FI warning lamp (MIL)	 12 **FI** warning lamp (**MIL**) flashes 1x long, 2x short
Error level condition	Engine coolant temperature sensor - input signal too low
	Engine coolant temperature sensor - input signal too high

Blink code FI warning lamp (MIL)	 13 **FI** warning lamp (**MIL**) flashes 1x long, 3x short
Error level condition	Intake air temperature sensor - input signal too low
	Intake air temperature sensor - input signal too high

Blink code FI warning lamp (MIL)	 15 **FI** warning lamp (**MIL**) flashes 1x long, 5x short
Error level condition	Rollover sensor (A/D type) - input signal too low
	Rollover sensor (A/D type) - input signal too high

Blink code FI warning lamp (MIL)	 33 **FI** warning lamp (**MIL**) flashes 3x long, 3x short
Error level condition	Injector cylinder 1 - circuit fault

Blink code FI warning lamp (MIL)	 37 **FI** warning lamp (**MIL**) flashes 3x long, 7x short
Error level condition	Ignition coil 1, cylinder 1 - circuit fault

Blink code FI warning lamp (MIL)	 41 **FI** warning lamp (**MIL**) flashes 4x long, 1x short
Error level condition	Fuel pump control - short circuit to ground or open circuit
	Fuel pump control - input signal too low

22 TECHNICAL DATA

22.1 Engine

Design	1-cylinder 4-stroke engine, water-cooled
Displacement	249.91 cm³ (15.2505 cu in)
Stroke	52.3 mm (2.059 in)
Bore	78 mm (3.07 in)
Compression ratio	13.9:1
Idle speed	2,250… 2,350 rpm
Control	DOHC, four valves controlled via cam lever, drive via timing chain
Valve diameter, intake	32.5 mm (1.28 in)
Valve diameter, exhaust	26.5 mm (1.043 in)
Valve clearance	
Intake at: 20 °C (68 °F)	0.10… 0.15 mm (0.0039… 0.0059 in)
Exhaust at: 20 °C (68 °F)	0.13… 0.18 mm (0.0051… 0.0071 in)
Crankshaft bearing	2 cylinder bearings
Conrod bearing	Slide bearing
Piston pin bearing	Bearing bush
Pistons	Forged light alloy
Piston rings	1 compression ring, 1 oil scraper ring
Engine lubrication	Pressure circulation lubrication with two Eaton pumps
Primary transmission	24:73
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	5-gear, claw shifted
Transmission ratio	
1st gear	13:32
2nd gear	16:32
3rd gear	17:28
4th gear	19:26
5th gear	21:25
Alternator	12 V, 66 W
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment
Spark plug	NGK LMAR9AI-8
Spark plug electrode gap	0.8 mm (0.031 in)
Cooling	Water cooling, permanent circulation of coolant by water pump
Starting aid	Electric starter

22.2 Engine tightening torques

Nozzle, crank chamber ventilation	M4	2 Nm (1.5 lbf ft)	**Loctite® 243™**
Oil nozzle for alternator cooling	M4	2 Nm (1.5 lbf ft)	**Loctite® 243™**
Oil nozzle for balancer shaft lubrication	M4	2 Nm (1.5 lbf ft)	**Loctite® 243™**
Oil nozzle for conrod bearing lubrication	M4	2 Nm (1.5 lbf ft)	**Loctite® 243™**
Screw, oil nozzle for piston cooling	M4	2 Nm (1.5 lbf ft)	**Loctite® 243™**
Screw, stator	M4	4 Nm (3 lbf ft)	**Loctite® 2701™**
Locking screw for bearing	M5	6 Nm (4.4 lbf ft)	**Loctite® 243™**
Oil channel screw plug in alternator cover	M5	1.2 Nm (0.89 lbf ft)	**Loctite® 648™**
Oil nozzle for cam lever lubrication	M5	3 Nm (2.2 lbf ft)	**Loctite® 243™**
Oil nozzle for clutch lubrication	M5	6 Nm (4.4 lbf ft)	**Loctite® 243™**
Oil nozzle, piston cooling	M5	2 Nm (1.5 lbf ft)	**Loctite® 243™**
Screw, crankshaft position sensor	M5	6 Nm (4.4 lbf ft)	**Loctite® 243™**
Screw, locking lever	M5	6 Nm (4.4 lbf ft)	**Loctite® 243™**

Screw, oil pump cover	M5	6 Nm (4.4 lbf ft)	**Loctite® 243™**
Nut, cylinder head	M6	10 Nm (7.4 lbf ft)	Lubricated with engine oil
Nut, water-pump wheel	M6	6 Nm (4.4 lbf ft)	**Loctite® 243™**
Screw, alternator cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch slave cylinder	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch spring	M6	10 Nm (7.4 lbf ft)	–
Screw, cover of torque limiter	M6	10 Nm (7.4 lbf ft)	–
Screw, engine case	M6	10 Nm (7.4 lbf ft)	–
Screw, exhaust flange	M6	10 Nm (7.4 lbf ft)	**Loctite® 243™**
Screw, oil filter cover	M6	10 Nm (7.4 lbf ft)	–
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	**Loctite® 243™**
Screw, shift lever	M6	14 Nm (10.3 lbf ft)	**Loctite® 243™**
Screw, starter motor	M6	10 Nm (7.4 lbf ft)	–
Screw, timing chain guide rail	M6	10 Nm (7.4 lbf ft)	**Loctite® 243™**
Screw, timing chain securing guide	M6	10 Nm (7.4 lbf ft)	**Loctite® 243™**
Screw, valve cover	M6	8 Nm (5.9 lbf ft)	–
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	–
Stud, cylinder head	M6	10 Nm (7.4 lbf ft)	–
Screw, autodecompression	M7x1	15 Nm (11.1 lbf ft)	**Loctite® 243™**
Screw, camshaft bearing bridge	M7x1	14 Nm (10.3 lbf ft)	Lubricated with engine oil
Screw plug, crankshaft location	M8	10 Nm (7.4 lbf ft)	–
Screw, timing chain tensioning rail	M8	15 Nm (11.1 lbf ft)	**Loctite® 243™**
Screw, engine sprocket	M10	60 Nm (44.3 lbf ft)	**Loctite® 2701™**
Plug, oil channel	M10x1	15 Nm (11.1 lbf ft)	**Loctite® 243™**
Rotor screw	M10x1	70 Nm (51.6 lbf ft)	Thread, oiled with engine oil/cone degreased
Screw plug, cam lever axis	M10x1	10 Nm (7.4 lbf ft)	–
Screw, unlocking of timing chain tensioner	M10x1	10 Nm (7.4 lbf ft)	–
Spark plug	M10x1	10… 12 Nm (7.4… 8.9 lbf ft)	–
Nut, cylinder head	M10x1.25	Tightening sequence: Tighten diagonally. 1st tightening stage 10 Nm (7.4 lbf ft) 2nd tightening stage 30 Nm (22.1 lbf ft) 3rd tightening stage 50 Nm (36.9 lbf ft)	Thread, oiled with engine oil/cone greased
Stud, cylinder head	M10x1.25	20 Nm (14.8 lbf ft)	**Loctite® 243™**
Engine coolant temperature sensor	M12x1.5	12 Nm (8.9 lbf ft)	–
Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Plug, oil pressure regulator valve	M12x1.5	20 Nm (14.8 lbf ft)	–
Oil drain plug	M14x1.5	15 Nm (11.1 lbf ft)	–
Nut, inner clutch hub	M18x1.5	100 Nm (73.8 lbf ft)	**Loctite® 243™**
Nut, primary gear	M18LHx1.5	100 Nm (73.8 lbf ft)	**Loctite® 243™**
Screw plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)	–
Plug, timing chain tensioner	M24x1.5	25 Nm (18.4 lbf ft)	–
Screw, alternator cover	M24x1.5	18 Nm (13.3 lbf ft)	–

22.3 Capacities

22.3.1 Engine oil

Engine oil	1.10 l (1.16 qt.)	Engine oil (SAE 10W/50) (☛ p. 93)

22.3.2 Coolant

Coolant	0.95 l (1 qt.)	Coolant (mixed ready to use) (☛ p. 93)
		Coolant (☛ p. 93)

22.3.3 Fuel

Total fuel tank capacity, approx.	7.5 l (1.98 US gal)	Super unleaded (ROZ 95/RON 95/PON 91) (☛ p. 94)

22.4 Chassis

Frame	Central tube frame made of chrome molybdenum steel tubing
Fork	**WP Suspension** Up Side Down 4860 MXMA 4CS
Suspension travel	
Front	300 mm (11.81 in)
Rear	317 mm (12.48 in)
Fork offset	22 mm (0.87 in)
Shock absorber	**WP Suspension** 5018 BAVP DCC
Brake system	Disc brakes, brake calipers on floating bearings
Brake discs - diameter	
Front	260 mm (10.24 in)
Rear	220 mm (8.66 in)
Brake discs - wear limit	
Front	2.5 mm (0.098 in)
Rear	3.5 mm (0.138 in)
Tire air pressure, offroad	
Front	1.0 bar (15 psi)
Rear	1.0 bar (15 psi)
Secondary ratio	13:50
Chain	5/8 x 1/4"
Available rear sprockets	48, 50, 52
Steering head angle	63.5°
Wheelbase	1,495±10 mm (58.86±0.39 in)
Seat height, unloaded	992 mm (39.06 in)
Ground clearance, unloaded	375 mm (14.76 in)
Weight without fuel, approx.	103.7 kg (228.6 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)
Maximum permissible overall weight	335 kg (739 lb.)

22.5 Electrical system

Battery	YTX5L-BS	Battery voltage: 12 V Nominal capacity: 4 Ah Maintenance-free
Fuse	58011109110	10 A

FI warning lamp	LED

22.6 Tires

Front tires	**Rear tires**
80/100 - 21 51M TT Dunlop Geomax MX52F	**100/90 - 19 57M TT** Dunlop Geomax MX52
Additional information is available in the Service section under: www.husqvarna-motorcycles.com	

22.7 Fork

Fork part number	24.18.7O.55
Fork	**WP Suspension** Up Side Down 4860 MXMA 4CS
Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring length with preload spacer(s)	480 mm (18.9 in)
Spring rate	
Weight of rider: 65… 75 kg (143… 165 lb.)	4.4 N/mm (25.1 lb/in)
Weight of rider: 75… 85 kg (165… 187 lb.)	4.6 N/mm (26.3 lb/in)
Weight of rider: 85… 95 kg (187… 209 lb.)	4.8 N/mm (27.4 lb/in)
Fork length	940 mm (37.01 in)

Oil capacity per fork leg	665 ml (22.48 fl. oz.)	Fork oil (SAE 4) (48601166S1) (☛ p. 93)

22.8 Shock absorber

Shock absorber part number	18.18.7O.55
Shock absorber	**WP Suspension** 5018 BAVP DCC
Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring preload	8 mm (0.31 in)
Spring rate	

Weight of rider: 65… 75 kg (143… 165 lb.)	51 N/mm (291 lb/in)
Weight of rider: 75… 85 kg (165… 187 lb.)	54 N/mm (308 lb/in)
Weight of rider: 85… 95 kg (187… 209 lb.)	57 N/mm (325 lb/in)
Spring length	260 mm (10.24 in)
Gas pressure	10 bar (145 psi)
Static sag	30 mm (1.18 in)
Riding sag	100 mm (3.94 in)
Fitted length	490 mm (19.29 in)

Shock absorber oil	Shock absorber fluid (SAE 2.5) (50180751S1) (☛ p. 93)

22.9 Chassis tightening torques

Screw, air filter box lid	**EJOT PT®** K60x20-Z	3 Nm (2.2 lbf ft)	–
Screw, pressure regulator	**EJOT PT®** K60x25-Z	3 Nm (2.2 lbf ft)	–
Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)	–
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)	–
Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)	–
Screw, intake air temperature sensor	M5	2 Nm (1.5 lbf ft)	–
Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)	–
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)	–
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)	–
Screw, ball joint of push rod on foot brake cylinder	M6	10 Nm (7.4 lbf ft)	**Loctite® 243™**
Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	**Loctite® 243™**
Screw, electric starter cable connection	M6	4 Nm (3 lbf ft)	–
Screw, front brake disc	M6	14 Nm (10.3 lbf ft)	**Loctite® 243™**
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft)	**Loctite® 243™**
Screw, throttle grip	M6	5 Nm (3.7 lbf ft)	–
Fuel connection on fuel tank	M8	10 Nm (7.4 lbf ft)	–
Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)	–
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft)	**Loctite® 2701™**
Nut, rim lock	M8	12 Nm (8.9 lbf ft)	–
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)	–
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)	–
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)	–
Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)	–
Screw, engine brace	M8	33 Nm (24.3 lbf ft)	**Loctite® 2701™**
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	–
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	**Loctite® 243™**
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	–
Screw, manifold	M8	15 Nm (11.1 lbf ft)	–
Screw, subframe	M8	30 Nm (22.1 lbf ft)	**Loctite® 2701™**
Screw, top steering stem	M8	17 Nm (12.5 lbf ft)	**Loctite® 243™**
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)	–
Engine carrying screw	M10	60 Nm (44.3 lbf ft)	–
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)	–
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)	–
Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)	**Loctite® 2701™**
Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	**Loctite® 243™**
Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)	**Loctite® 2701™**
Nut, fuel pump	M12	15 Nm (11.1 lbf ft)	–
Nut, frame to linkage lever	M14x1.5	80 Nm (59 lbf ft)	–

Nut, linkage lever on swingarm	M14x1.5	80 Nm (59 lbf ft)	–
Nut, linkage lever to angle lever	M14x1.5	80 Nm (59 lbf ft)	–
Nut, swingarm pivot	M16x1.5	100 Nm (73.8 lbf ft)	–
Nut, rear wheel spindle (FC 250 EU)	M20x1.5	80 Nm (59 lbf ft)	–
Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)	–
Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)	–
Screw-in nozzles, cooling system	M20x1.5	12 Nm (8.9 lbf ft)	**Loctite® 243™**
Nut, rear wheel spindle (FC 250 US)	M25x1.5	80 Nm (59 lbf ft)	–

Brake fluid DOT 4

Standard/classification

– DOT

Guideline

– Use only brake fluid that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties.

Recommended supplier
Bel-Ray®

– **Super DOT 4 Brake Fluid**

Coolant

Guideline

– Use only suitable coolant (even in countries with high temperatures). Using inferior antifreeze can result in corrosion and foaming.

Mixture ratio

Antifreeze protection: −25… −45 °C (−13… −49 °F)	50 % anti-corrosion/antifreeze 50 % distilled water

Coolant (mixed ready to use)

Antifreeze protection	−35 °C (−31 °F)

Recommended supplier
Bel-Ray®

– **Moto Chill Racing Coolant**

Engine oil (SAE 10W/50)

Standard/classification

– JASO T903 MA (☛ p. 96)

– SAE (☛ p. 96) (SAE 10W/50)

Guideline

– Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Synthetic engine oil

Recommended supplier
Bel-Ray®

– **Works Thumper Racing Synthetic Ester 4T**

Fork oil (SAE 4) (48601166S1)

Standard/classification

– SAE (☛ p. 96) (SAE 4)

Guideline

– Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Shock absorber fluid (SAE 2.5) (50180751S1)

Standard/classification

– SAE (☛ p. 96) (SAE 2.5)

Guideline

– Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Super unleaded (ROZ 95/RON 95/PON 91)

Standard/classification

– DIN EN 228 (ROZ 95/RON 95/PON 91)

Guideline

– Only use unleaded super fuel that matches or is equivalent to the specified fuel grade.

– Fuel with an ethanol content of up to 10 % (E10 fuel) is safe to use.

Info

Do **not** use fuel containing methanol (e. g. M15, M85, M100) or more than 10 % ethanol (e. g. E15, E25, E85, E100).

Air filter cleaning agent

Recommended supplier
Bel-Ray®
– **Foam Filter Cleaner & Degreaser**

High viscosity grease

Recommended supplier
SKF®
– **LGHB 2**

Long-life grease

Recommended supplier
Bel-Ray®
– **Waterproof Grease**

Offroad chain spray

Guideline

Recommended supplier
Bel-Ray®
– **Blue Tac Chain Lube**

Oil for foam air filter

Recommended supplier
Bel-Ray®
– **Foam Filter Oil**

Preserving materials for paints, metal and rubber

Recommended supplier
Bel-Ray®
– **Silicone Detailer & Protectant Spray**

Rubber grip adhesive (00062030051)

Recommended supplier
KTM-Sportmotorcycle AG
– **GRIP GLUE**

Universal oil spray

Recommended supplier
Bel-Ray®
– **6 in 1**

JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles – the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. In most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

INDEX

A

Accessories 7

Air filter
- cleaning 44
- installing 44
- removing 43

Air filter box
- cleaning 44
- sealing 45

Air filter box lid
- installing 43
- removing 43

Antifreeze
- checking 73

Auxiliary substances 7

B

Basic chassis setting
- checking with rider's weight 26

Battery
- installing 70
- recharging 71
- removing 70

Blink code 86

Brake discs
- checking 56

Brake fluid
- front brake, adding 57
- rear brake, adding 61

Brake fluid level
- front brake, checking 57
- rear brake, checking 61

Brake linings
- front brake, changing 58
- front brake, checking 58
- rear brake, changing 63
- rear brake, checking 62

C

Capacity
- coolant 89
- engine oil 80, 89
- fuel 23, 89

Chain
- checking 51
- cleaning 49

Chain guide
- checking 51

Chain tension
- adjusting 50
- checking 49

Chassis number 10

Clutch
- fluid level, checking/correcting 54
- fluid, changing 55

Clutch lever 11
- basic position, adjusting 54

Cold start button 13

Compression damping
- fork, adjusting 30

Compression damping, high-speed
- shock absorber, adjusting 27

Compression damping, low-speed
- shock absorber, adjusting 26

Coolant
- draining 74
- refilling 75

Coolant level
- checking 73-74

Cooling system 73

Customer service 7

D

Difficult operating conditions 17

Difficult riding conditions
- dry sand 17
- high temperatures 19
- low speeds 19
- low temperatures 19
- muddy surfaces 18
- snow 19
- wet sand 18
- wet surfaces 18

E

Electric starter button 11

Engine
- running in 17

Engine number 10

Engine oil
- adding 80
- changing 79

Engine oil level
- checking 78

Engine sprocket
- checking 51

Environment 6

F

Figures 7

Filler cap
- closing 13
- opening 12

Foot brake lever 14
- basic position, adjusting 60
- free travel, checking 60

Fork legs
- basic setting, checking 30
- bleeding 33
- compression damping, adjusting 30
- dust boots, cleaning 34
- installing 35

rebound damping, adjusting . . . 31
removing . . . 35
Fork protector
installing . . . 34
removing . . . 34
Frame
checking . . . 53
Front fender
installing . . . 40
removing . . . 39
Front wheel
installing . . . 65
removing . . . 65
Fuel screen
changing . . . 78
Fuel tank
installing . . . 48
removing . . . 47
Fuse
main fuse, changing . . . 72

H

Hand brake lever . . . 11
basic position, adjusting . . . 56
free travel, checking . . . 56
Handlebar position . . . 31
adjusting . . . 31

I

Idle speed
adjusting . . . 77
Idle speed adjusting screw . . . 14
Implied warranty . . . 7
Intended use . . . 5

K

Kill switch . . . 11

L

Lower triple clamp
installing . . . 36
removing . . . 36

M

Main fuse
changing . . . 72
Main silencer
glass fiber yarn filling, changing . . . 45
installing . . . 45
removing . . . 45
Map-Select switch
for the basic setting . . . 12
for vehicle operation . . . 12
Motorcycle
cleaning . . . 82
raising with lift stand . . . 33
removing from lift stand . . . 33

O

Oil filter
changing . . . 79
Oil screen
cleaning . . . 79
Operating substances . . . 7
Overview of indicator lamps . . . 12
Owner's Manual . . . 6

P

Plug-in stand . . . 15
Protective clothing . . . 6
Putting into operation
advice on first use . . . 16
after storage . . . 83
checks and maintenance before putting into operation . . . 20

R

Rear sprocket
checking . . . 51
Rear wheel
installing . . . 67
removing . . . 66
Rebound damping
fork, adjusting . . . 31
shock absorber, adjusting . . . 27
Refueling
fuel . . . 22
Riding sag
adjusting . . . 29
Right side cover
installing . . . 46
removing . . . 46
Rubber grip
checking . . . 54
securing . . . 54

S

Safe operation . . . 5
Seat
mounting . . . 43
removing . . . 42
Service . . . 7
Service schedule . . . 24-25
Shift lever
basic position, adjusting . . . 77
basic position, checking . . . 77
Shock absorber
compression damping, general . . . 26
high speed compression damping, setting . . . 27
installing . . . 41
low speed compression damping, setting . . . 26
rebound damping, adjusting . . . 27
removing . . . 40
riding sag, checking . . . 28
spring preload, adjusting . . . 29
static sag, checking . . . 28

Spare parts 7
Spoke tension
checking 69
Start number plate
installing 39
removing 39
Starting 20
Steering head bearing
greasing 39
Steering head bearing play
adjusting 38
checking 38
Storage 83
Swingarm
checking 53

T

Technical data
capacities 89
chassis 89
chassis tightening torques 91
electrical system 90
engine 87
engine tightening torques 87
fork 90
shock absorber 90
tires 90
Throttle cable play
adjusting 76
checking 76
Throttle cable routing
checking 53
Throttle grip 11
Tire air pressure
checking 69
Tire condition
checking 68
Transport 22
Troubleshooting 84-85
Type label 10

U

Use definition 5

V

View of vehicle
front left 8
rear right side 9

W

Warranty 7
Work rules 6

THE PIONEERS OF MOTOCROSS

3402019en

06/2014



Husqvarna®
MOTORCYCLES

Husqvarna Motorcycles GmbH
Stallhofnerstraße 3 | 5230 Mattighofen
Austria

Photo:
Mitterbauer/Husqvarna
Motorcycles GmbH